



New and Changed Information

Table 1 summarizes the new and changed commands for Cisco MDS NX-OS Release 5.0(1a) and tells you where they are documented in the *Cisco MDS 9000 Family Command Reference*.

The *Cisco MDS 9000 Family Command Reference* applies to Cisco NX-OS Release 5.0(1a), but describes all features in Cisco SAN-OS releases. If you are running Cisco SAN-OS 3.x or lower software on an MDS switch, refer to the *Cisco MDS 9000 Family CLI Command Reference* for the release train that applies to the release on your switch.



Note

As of NX-OS Release 4.1(1b), SAN-OS has been changed to NX-OS. References to SAN-OS releases before 4.1(1b) still apply.

Table 1 *New and Changed Commands in the Cisco MDS 9000 Family Command Reference*

Feature	Description	Where Documented
New and Changed Commands for Cisco NX-OS Release 5.0(1a)		
AAA enhancements	radius-server test command	R Commands
	tacacs-server test command	T Commands
	aaa authentication login chap enable command	A Commands
	aaa authentication login command (Added fallback , error , and local keywords to the syntax description)	
	show aaa authentication login chap enable command	Show Commands
AAM	ivr aam register command	I Commands
	ivr aam pre-deregister-check command	
	fc-redirect version2 enable command	F Commands
	fc-redirect ivr-support enable command	
	show ivr aam command	Show Commands
Enhancements for Call Home	transport email mail-server command	T Commands
	show callhome transport command	Show Commands

Send documentation comments to mdsfeedback-doc@cisco.com

Table 1 *New and Changed Commands in the Cisco MDS 9000 Family Command Reference*

Feature	Description	Where Documented
Per-command authorization with TACACS with roles support	enable command	E Commands
	enable user-server-group command	
	feature command (Added privilege keyword to the syntax description)	F Commands
SSH enhancements	username command (Added the keypair and Priv-lvl keyword to the syntax description)	U Commands
	show username command	Show Commands
FICON	ficon-tape-read-accelerator command	F Commands
ISAPI enhancements	ssm enable feature command (Added a node keyword to the syntax description)	S Commands
Cert PKI	show crypto ca remote-certstore command	Show Commands
	show crypto certificatemap command	
	show crypto ssh-auth-map command	
	crypto certificatemap mapname command	C Commands
	crypto cert ssh-authorize command	
	crypto ca lookup command	
	crypto ca remote ldap command	
LDAP	filter command	F Commands
	ldap-server deadtime command	L Commands
	ldap-server port command	
	ldap-server timeout command	
	ldap-server host command	
	ldap serach-map command	
	ldap-serach-map command	
	aaa group server command	A Commands
	server command	S Commands
	show ldap-server command	Show Commands
	show ldap-server groups command	
	show ldap-search-map command	

Send documentation comments to mdsfeedback-doc@cisco.com

Table 1 *New and Changed Commands in the Cisco MDS 9000 Family Command Reference*

Feature	Description	Where Documented
	aaa authorization ssh-certificate command	A Commands
	aaa authorization ssh-publickey command	
	authentication command	
	auth-mechanism plain command	
	debug ldap command	D Commands
	enable cert-DN-match command	E Commands
	enable user-server-group command	
	deadtime (server group configuration mode) command	D Commands
	CRLLookup command	C Commands
	trustedcert command	T Commands
	user-certdn-match command	U Commands
	user-pubkey-match command	
	user-switch-bind command	
	userprofile command	
Deprecated Command	fcc enable command	F Commands
New and Changed Commands for Cisco NX-OS Release 4.2(1)		
Call Home	destination-profile command (Deleted Avanti keyword from the syntax description. Added the Usage guideline)	D Commands
EEM	action event-default command (Added a note)	A Commands
	terminal event-manager bypass command (Added a note)	T Commands
	event command (Added a note)	E Commands
Port Guard	errdisable detect cause bit-errors command	E Commands
	errdisable detect cause credit-loss command	
	errdisable detect cause link-reset command	
	errdisable detect cause signal-loss command	
	errdisable detect cause sync-loss command	
	errdisable detect cause trustsec-violation command	
	feature command (Added ioa keyword to the syntax description)	F Commands

Send documentation comments to mdsfeedback-doc@cisco.com

Table 1 *New and Changed Commands in the Cisco MDS 9000 Family Command Reference*

Feature	Description	Where Documented
AAA Enhancements	show aaa authentication login chap enable command	Show Commands
	show aaa authorization all command	
	clear tacacs-server statistics command	C Commands
	clear radius-server statistics command	
	aaa authentication login mschapv2 enable command	A Commands
	aaa authorization command	
	test aaa authorization command	T Commands
	terminal verify-user command	
FC-redirect with IVR	show ivr aam command	Show Commands
FC-ID Visibility	show fcns database command (Changed the command output)	Show Commands
IOA	ioa site-local command	I Commands
	ioa cluster command	
	interface ioa command	
	load-balancing (Cisco IOA cluster Configuration submode) command	L Commands
	nport command	N Commands
	node (Cisco IOA cluster node configuration submode) command	
	flowgroup command	F Commands
	host command	H Commands
	trustedcert command	
	show ioa internal interface ioa command	Show Commands
	show ioa cluster summary command	
	show interface ioa command	
	show ioa cluster command	
Port Group Monitoring	show port-group-monitor active command	Show Commands
	show port-group-monitor command	
	show port-group-monitor status command	
	port-group-monitor activate command	P Commands
	port-group-monitor name command	
	port-group-monitor enable command	
	port-group-monitor counter command	
	monitor counter command	M Commands

Send documentation comments to mdsfeedback-doc@cisco.com

Table 1 *New and Changed Commands in the Cisco MDS 9000 Family Command Reference*

Feature	Description	Where Documented
Trustsec	show running-config callhome command	Show Commands
	show fcsp interface command	
	fcsp esp sa command	F Commands
	fcsp command	
	ingress-sa command	I Commands
	interface fc command	
	egress-sa command	E Commands
	mode command	M Commands
	key (sa configuration submode) command	K Commands
	salt (sa configuration submode) command	S Commands
New and Changed Commands for Cisco NX-OS Release 4.1(3a)		
AAA enhancements	aaa authentication login ascii-authentication command (enable the password aging command has been changed from aaa authentication login password-aging enable to aaa authentication login ascii-authentication)	A Commands
	show aaa authentication login ascii-authentication command (enable the password aging command has been changed from show aaa authentication login password-aging enable to show aaa authentication login ascii-authentication)	Show Commands
New and Changed Commands for Cisco NX-OS Release 4.1(3)		
Call Home	destination-profile command (Added the HTTPs URL and transport method to the syntax description)	D Commands
Port Guard	errdisable detect cause link-down command	E Commands
Port Owner	switchport owner command	S Commands
F port Trunking	feature command (Added Keywords hhttp-server , fport-channel-trunk , npiv and npv to the syntax description)	F Commands
	switchport command (Added the F and NP port mode)	S Commands
	show flogi database interface command	Show Commands

Send documentation comments to mdsfeedback-doc@cisco.com

Table 1 *New and Changed Commands in the Cisco MDS 9000 Family Command Reference*

Feature	Description	Where Documented
F port Channeling	show port-channel compatibility-parameters command	Show Commands
	show port-channel consistency command	
	show port-channel database command	
	show port-channel internal command	
	show port-channel summary command	
	show port-channel usage command	
	channel-group command (Deleted auto keyword from the syntax description)	C Commands
	port-channel persistent command (Added usage guideline)	P Commands
	clear asic-cnt command	C Commands
	show fens database command (Changed the command output for show fens database detail)	Show Commands
Hardware	show system command (Changed the show system uptime output)	Show Commands
Radius Configuration	radius-server host command (Changed the command output)	R Commands
	show running radius command (Changed the command output)	Show Commands
EEM	event manager applet command	E Commands
	errdisable detect cause bit-errors command	
	event manager policy command	
	event manager environment command	
	description command	D Commands
	show event manager policy command	Show Commands
	show event manager environment command	
	action cli command	A Commands

Send documentation comments to mdsfeedback-doc@cisco.com

Table 1 *New and Changed Commands in the Cisco MDS 9000 Family Command Reference*

Feature	Description	Where Documented
	action counter command	
	action event-default command	
	action exception log command	
	action forceshut command	
	action overbudgetshut command	
	action policy-default command	
	action reload command	
	action snmp-trap command	
	action syslog command	
	Added SME Commands	S Commands
SME	scaling batch enable command	

Send documentation comments to mdsfeedback-doc@cisco.com

Table 1 *New and Changed Commands in the Cisco MDS 9000 Family Command Reference*

Feature	Description	Where Documented
New and Changed Commands for Cisco NX-OS Release 4.1(1b)		
Call Home	switch-priority command (Added usage guidelines)	S Commands
	system delayed-traps timer command	
	system delayed-traps enable mode command	
system health	system health clear-errors command	S Commands
Port-monitor	show port-monitor status command	Show Commands
	show port-monitor active command	
SNMP	show system internal snmp lc command	
SSM	ssm upgrade delay command	S Commands
SANTap	show isapi tech-support santap file command (Added usage guidelines)	Show Commands
	show santap module dvt command	
	show santap module dvtlun command	
	show santap vttbl dvt command	
	show santap vttbl dvt host command	
SDV	show sdv command (Changed the command output)	Show Commands
	attribute failover auto command	
General Configuration	feature command	F Commands
DPVM	clear dpvm merge statistics command	C Commands
	show dpvm merge statistics command	Show Commands
	show dpvm merge status command	
	dpvm overwrite-duplicate-pwwn command	D Commands
Generation 3 Modules	do command (Added the command output for extended receive bbcredit interface) (Added a Note)	D Commands
	show interface command (Added the command output for bbcredit information for a switch port) (Added the command output for interface capabilities on a 48 port line card)	

Send documentation comments to mdsfeedback-doc@cisco.com

Table 1 *New and Changed Commands in the Cisco MDS 9000 Family Command Reference*

Feature	Description	Where Documented
	show module command (Added the command output for a module resource on a 24 port line card with all ports in shared mode) (Added the command output for a module resource on a 24 port line card with few ports in shared mode and few port in dedicated mode) (Added the command output for a module resource on a 12 port line card with all ports in dedicated mode) (Added the command output for a module resource on a 12 port line card with all ports in dedicated mode and extended feature enabled)	Show Commands
Hardware	show hardware fabric-mode command	Show Commands
	show username command (Changed the command output from SAN-OS to NX-OS)	
	show hardware command (Changed the command output from SAN-OS to NX-OS)	
	show copyright command (Changed the command output from SAN-OS to NX-OS)	
Deprecated Commands		
(see the feature command for replacement commands)		
	crypto ike enable command	C Commands
	dpvm enable command	D Commands
	fabric-binding enable command	F Commands
	fcip enable command	
	fcsp enable command	
	ficon enable command	
	ivr enable command	I Commands
	port-security enable command	P Commands
	sdv enable command	S Commands
	tacacs+ enable command	T Commands
	Added DMM Commands	

Send documentation comments to mdsfeedback-doc@cisco.com

Table 1 *New and Changed Commands in the Cisco MDS 9000 Family Command Reference*

Feature	Description	Where Documented
DMM	dmm module job command (Added the set-vi and modify rate keywords)	D Commands
	show dmm module command (Added the syntax description and the command output)	Show Commands
	Added SME Commands	
SME	cluster command (Cluster command is replaced by the feature command)	C Commands
	show tech-support sme command (Added the command output)	Show Commands
	show role command (Added the command output)	
	show sme cluster (Added the syntax description)	
	show sme transport command (Added the syntax description)	
	show debug command (Added the syntax description)	
	delete command (Added the syntax description)	D Commands