

Preface

This preface describes the audience, organization, and conventions of the *Cisco MDS 9000 Family I/O Accelerator Configuration Guide*. The preface also provides information on how to obtain related documentation.

Audience

This guide is for experienced network administrators who are responsible for planning, installing, configuring, and maintaining the Cisco MDS 9000 Family I/O Accelerator (IOA) feature.

Organization

This document	is	organized	as	follows:
---------------	----	-----------	----	----------

Chapter	Title	Description
Chapter 1	Overview	Presents an overview of the Cisco MDS I/O Accelerator feature and the software and hardware requirements.
Chapter 2	Getting Started	Describes the various configurations that need to be completed before configuring IOA.
Chapter 3	Deployment Considerations	Describes the various deployment scenarios and considerations.
Chapter 4	Configuring IOA Using the CLI	Describes how to use IOA CLI commands to configure and monitor Cisco IOA clusters.
Chapter 5	Configuring IOA Using Cisco DCNM-SAN	Describes how to use Cisco DCNM-SAN to configure and monitor Cisco IOA clusters.
Appendix A	SCSI Write Acceleration and Tape Acceleration	Describes the concept of SCSI write acceleration, tape acceleration, and compression.
Appendix B	Cluster Management and Recovery Scenarios	Describes the cluster management guidelines and cluster recovery procedures.

Document Conventions

boldface font	Commands and keywords are in boldface.		
italic font	Arguments for which you supply values are in italics.		
[]	Elements in square brackets are optional.		
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.		

Command descriptions use these conventions:

Screen examples use these conventions:

screen font	Terminal sessions and information the switch displays are in screen font.		
boldface screen font	Information you must enter is in boldface screen font.		
italic screen font	Arguments for which you supply values are in italic screen font.		
< >	Nonprinting characters, such as passwords, are in angle brackets.		
[]	Default responses to system prompts are in square brackets.		
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.		

This document uses the following conventions:



Means reader *take note*. Notes contain helpful suggestions or references to material not covered in the manual.



Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Additional Related Documentation for Cisco MDS 9000

The documentation set for the Cisco MDS 9000 Family includes the following documents. To find a document online, use the Cisco MDS NX-OS Documentation Locator at:

http://www.cisco.com/en/US/docs/storage/san_switches/mds9000/roadmaps/doclocater.htm

Release Notes

- Cisco MDS 9000 Family Release Notes for Cisco MDS NX-OS Releases
- Cisco MDS 9000 Family Release Notes for MDS SAN-OS Releases
- Cisco MDS 9000 Family Release Notes for Cisco MDS 9000 EPLD Images

Regulatory Compliance and Safety Information

• Regulatory Compliance and Safety Information for the Cisco MDS 9000 Family

Compatibility Information

- Cisco Data Center Interoperability Support Matrix
- Cisco MDS 9000 NX-OS Hardware and Software Compatibility Information and Feature Lists
- Cisco MDS 9000 Family Switch-to-Switch Interoperability Configuration Guide

Hardware Installation

- Cisco MDS 9500 Series Hardware Installation Guide
- Cisco MDS 9200 Series Hardware Installation Guide
- Cisco MDS 9100 Series Hardware Installation Guide
- Cisco MDS 9124 and Cisco MDS 9134 Multilayer Fabric Switch Quick Start Guide

Software Installation and Upgrade

• Cisco MDS 9000 NX-OS Software Upgrade and Downgrade Guide

Cisco NX-OS

- Cisco MDS 9000 Family NX-OS Licensing Guide
- Cisco MDS 9000 Family NX-OS Fundamentals Configuration Guide
- Cisco MDS 9000 Family NX-OS Interfaces Configuration Guide
- Cisco MDS 9000 Family NX-OS Fabric Configuration Guide
- Cisco MDS 9000 Family NX-OS Quality of Service Configuration Guide
- Cisco MDS 9000 Family NX-OS Security Configuration Guide
- Cisco MDS 9000 Family NX-OS IP Services Configuration Guide
- Cisco MDS 9000 Family NX-OS Intelligent Storage Services Configuration Guide
- Cisco MDS 9000 Family NX-OS High Availability and Redundancy Configuration Guide
- Cisco MDS 9000 Family NX-OS Inter-VSAN Routing Configuration Guide
- Cisco MDS 9000 Family Cookbook for Cisco MDS SAN-OS

Command-Line Interface

• Cisco MDS 9000 Family Command Reference

Intelligent Storage Networking Services Configuration Guides

- Cisco MDS 9000 Family I/O Acceleration Configuration Guide
- Cisco MDS 9000 Family SANTap Deployment Guide
- Cisco MDS 9000 Family Data Mobility Manager Configuration Guide
- Cisco MDS 9000 Family Storage Media Encryption Configuration Guide

Troubleshooting and Reference

- Cisco MDS 9000 Family and Nexus 7000 Series System Messages Reference
- Cisco MDS 9000 Family SAN-OS Troubleshooting Guide
- Cisco MDS 9000 Family NX-OS MIB Quick Reference
- Cisco DCNM for SAN Database Schema Reference

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.