



INDEX

F

Fibre Channel write acceleration

- default settings [2-2](#)
- enabling [2-3](#)
- estimating number of write buffers [2-1](#)
- licensing [2-2](#)
- modifying number of write buffers [2-3](#)

I

Intelligent Storage Services

- disabling (procedure) [3-6](#)
- disabling with force option [3-6](#)
- SCSI flow services [3-1 to 3-4](#)
- SCSI flow statistics [3-1 to 3-4](#)

S

SCSI flow configuration clients

- description [3-3, 4-3](#)

SCSI flow data path support

- description [3-3, 4-3](#)

SCSI flow managers

- description [3-3, 4-3](#)

SCSI flow services

- configuring (procedure) [3-5](#)
- configuring identifiers [3-5](#)
- default settings [3-4, 4-3](#)
- functional architecture (figure) [3-2](#)
- SCSI flow configuration clients [3-3, 4-3](#)
- SCSI flow data path support [3-3, 4-3](#)
- SCSI flow managers [3-3, 4-3](#)

SCSI flow statistics

- default settings [3-4, 4-3](#)
- enabling [4-4](#)

SCSI LUNs

- discovering targets [2-2, 3-3, 4-3](#)

SSMs

- disabling Intelligent Storage Services (procedure) [3-6](#)
- SCSI flow services [3-1 to 3-4](#)
- SCSI flow statistics [3-1 to 3-4](#)

Send documentation comments to dcnm-san-docfeedback@cisco.com