

I N D E X

A

appliance generated entities
 removing AVT LUNs [2-7](#)
 removing AVTs [2-7](#)
 removing ITLs [2-7](#)
 removing SANTap sessions [2-7](#)
application virtual targets. See AVTs
AVTs
 description [1-2](#)
 removing [2-7](#)

C

control virtual targets. See CVTs
CVTs
 creating [2-7](#)
 deleting [2-8, 2-18](#)
 description [1-2](#)

D

data virtual targets. See DVTs
documentation
 additional publications [i-ix](#)
 related documents [i-ix](#)
DVTs
 configuring [2-4](#)
 creating [2-9, 2-17](#)
 deleting [2-11, 2-19](#)
 description [1-2](#)

I

initiator-target-LUNs. See ITLs
ITLs
 description [2-7](#)
 removing [2-7](#)

R

removing sessions [2-7](#)

S

SANTap [2-7](#)
 configuring DVTs [2-4](#)
 creating CVTs [2-7](#)
 creating DVTs [2-9, 2-17](#)
 default settings [2-21](#)
 deleting CVT [2-8, 2-18](#)
 deleting DVTs [2-11, 2-19](#)
 description [1-1 to 1-4](#)
 displaying information [2-5 to 2-6, 2-15](#)
 enabling [2-2](#)
 DCNM for SAN tools [4-4](#)
 host login problems [4-8](#)
 limitations [4-3](#)
 mismatch problems [4-10](#)
 removing appliance generated entities [2-6](#)
SSMs
 configuring Intelligent Storage Services [1-1](#)

Send documentation comments to mdsfeedback-doc@cisco.com