



Preface

This preface describes the audience, organization, and conventions of the *Cisco MDS 9000 Family NX-OS Storage Media Encryption Configuration Guide*. The preface also provides information on how to obtain related documentation.

Audience

This guide is for experienced network administrators who are responsible for planning, installing, configuring, and maintaining the Cisco MDS 9000 Family Storage Media Encryption (SME) application.

Organization

This document is organized as follows:

Chapter	Title	Description
Chapter 1	Storage Media Encryption Overview	Presents an overview of the Cisco MDS SME feature and the software and hardware requirements.
Chapter 2	Configuring SME	Describes the installation, preliminary configuration tasks, and the configuration limits.
Chapter 3	Configuring SME Interfaces	Describes how to configure, start, add, and remove SME interfaces and switches.
Chapter 4	Configuring SME Cluster Management	Describes how to configure, monitor, and manage SME clusters.
Chapter 5	Configuring SME Tapes	Describes how to add and delete tape groups, devices, paths, and tape volume groups.
Chapter 6	Configuring SME Disks	Describes managing and configuring disks using SME.
Chapter 7	Configuring SME Key Management	Describes the comprehensive and secure key hierarchy system and how to export and import volume groups.
Chapter 8	Provisioning Certificates	Describes the configuring of SSL in SME.

Send documentation comments to mdsfeedback-doc@cisco.com

Chapter	Title	Description
Chapter 9	RSA Key Manager and SME	Describes the procedures to set up the RSA Key Manager to work with SME.
Chapter 10	SME Best Practices	Describes recommended steps to ensure proper operation of SME.
Chapter 11	SME Troubleshooting	Describes basic troubleshooting methods used to resolve issues with SME.
Appendix A	SME CLI Commands	Includes syntax and usage guidelines for the Cisco MDS SME CLI commands.
Appendix B	Offline Data Recovery in SME	Describes the Offline Data Restore Tool (ODRT).
Appendix C	Database Backup and Restore	Describes how to back up and restore DCNM-SAN Server databases.
Appendix D	Planning For SME Installation	Describes the steps and guidelines to ensure a successful SME installation.
Appendix E	Migrating SME Database Tables	Describes the utility for migration of SME database tables.

Document Conventions

Command descriptions use these conventions:

boldface font	Commands and keywords are in boldface.
<i>italic font</i>	Arguments for which you supply values are in italics.
[]	Elements in square brackets are optional.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.

Screen examples use these conventions:

<code>screen font</code>	Terminal sessions and information the switch displays are in screen font.
boldface screen font	Information you must enter is in boldface screen font.
<i>italic screen font</i>	Arguments for which you supply values are in italic screen font.
< >	Nonprinting characters, such as passwords, are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

This document uses the following conventions:



Note

Means reader *take note*. Notes contain helpful suggestions or references to material not covered in the manual.

Send documentation comments to mdsfeedback-doc@cisco.com



Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Related Documentation

The documentation set for the Cisco MDS 9000 Family includes the following documents. To find a document online, use the Cisco MDS NX-OS Documentation Locator at:

http://www.cisco.com/en/US/docs/storage/san_switches/mds9000/roadmaps/doclocator.htm

Release Notes

- *Cisco MDS 9000 Family Release Notes for Cisco MDS NX-OS Releases*
- *Cisco MDS 9000 Family Release Notes for MDS SAN-OS Releases*
- *Cisco MDS 9000 Family Release Notes for Cisco MDS 9000 EPLD Images*
- *Cisco DCNM Release Notes*

Regulatory Compliance and Safety Information

- *Regulatory Compliance and Safety Information for the Cisco MDS 9000 Family*

Compatibility Information

- *Cisco Data Center Interoperability Support Matrix*
- *Cisco MDS 9000 NX-OS Hardware and Software Compatibility Information and Feature Lists*
- *Cisco MDS 9000 Family Switch-to-Switch Interoperability Configuration Guide*

Hardware Installation

- *Cisco MDS 9500 Series Hardware Installation Guide*
- *Cisco MDS 9200 Series Hardware Installation Guide*
- *Cisco MDS 9100 Series Hardware Installation Guide*
- *Cisco MDS 9124 and Cisco MDS 9134 Multilayer Fabric Switch Quick Start Guide*

Software Installation and Upgrade

- *Cisco MDS 9000 NX-OS Software Upgrade and Downgrade Guide*

Send documentation comments to mdsfeedback-doc@cisco.com

Cisco NX-OS

- *Cisco MDS 9000 Family NX-OS Licensing Guide*
- *Cisco MDS 9000 Family NX-OS Fundamentals Configuration Guide*
- *Cisco MDS 9000 Family NX-OS System Management Configuration Guide*
- *Cisco MDS 9000 Family NX-OS Interfaces Configuration Guide*
- *Cisco MDS 9000 Family NX-OS Fabric Configuration Guide*
- *Cisco MDS 9000 Family NX-OS Quality of Service Configuration Guide*
- *Cisco MDS 9000 Family NX-OS Security Configuration Guide*
- *Cisco MDS 9000 Family NX-OS IP Services Configuration Guide*
- *Cisco MDS 9000 Family NX-OS Intelligent Storage Services Configuration Guide*
- *Cisco MDS 9000 Family NX-OS High Availability and Redundancy Configuration Guide*
- *Cisco MDS 9000 Family NX-OS Inter-VSAN Routing Configuration Guide*
- *Cisco MDS 9000 Family Cookbook for Cisco MDS SAN-OS*

Cisco DCNM

- *Cisco DCNM Fundamentals Guide, Release 6.x*
- *Cisco DCNM Installation and Licensing Guide, Release 6.x*

Cisco DCNM-SAN

- *System Management Configuration Guide, Cisco DCNM for SAN, Release 6.x*
- *Interfaces Configuration Guide, Cisco DCNM for SAN, Release 6.x*
- *Fabric Configuration Guide, Cisco DCNM for SAN, Release 6.x*
- *Quality of Service Configuration Guide, Cisco DCNM for SAN, Release 6.x*
- *Security Configuration Guide, Cisco DCNM for SAN, Release 6.x*
- *IP Services Configuration Guide, Cisco DCNM for SAN, Release 6.x*
- *Intelligent Storage Services Configuration Guide, Cisco DCNM for SAN, Release 6.x*
- *High Availability and Redundancy Configuration Guide, Cisco DCNM for SAN, Release 6.x*
- *Inter-VSAN Routing Configuration Guide, Cisco DCNM for SAN, Release 6.x*
- *SMI-S and Web Services Programming Guide, Cisco DCNM for SAN, Release 6.x*

Command-Line Interface

- *Cisco MDS 9000 Family Command Reference*

Send documentation comments to mdsfeedback-doc@cisco.com

Intelligent Storage Networking Services Configuration Guides

- *Cisco MDS 9000 Family I/O Acceleration Configuration Guide*
- *Cisco MDS 9000 Family SANTap Deployment Guide*
- *Cisco MDS 9000 Family Data Mobility Manager Configuration Guide*
- *Cisco MDS 9000 Family Storage Media Encryption Configuration Guide*

Troubleshooting and Reference

- *Cisco MDS 9000 Family and Nexus 7000 Series System Messages Reference*
- *Cisco MDS 9000 Family SAN-OS Troubleshooting Guide*
- *Cisco MDS 9000 Family NX-OS MIB Quick Reference*
- *Cisco DCNM for SAN Database Schema Reference*

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

- Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.

Send documentation comments to mdsfeedback-doc@cisco.com