

*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*



## M Commands

---

This chapter describes the Cisco NX-OS interface commands that begin with M.

*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*

## management

To configure a switch virtual interface (SVI) that should be used for in-band management, use the **management** command. To remove the in-band management access to a VLAN interface IP address, use the **no** form of this command.

**management**

**no management**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--------------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Interface configuration mode Switch profile configuration mode
----------------------	-------------------------------------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.1(3)N1(1)	This command was introduced.

<b>Usage Guidelines</b>	You can use this command on a VLAN interface.
-------------------------	-----------------------------------------------

<b>Examples</b>	This example shows how to configure a VLAN interface to allow in-band management access:
-----------------	------------------------------------------------------------------------------------------

```
switch# configure terminal
switch(config)# interface vlan 5
switch(config-if)# management
switch(config-if)#
```

This example shows how to remove the in-band management access to a VLAN interface:

```
switch# configure terminal
switch(config)# interface vlan 5
switch(config-if)# no management
switch(config-if)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show running-config interface</b>	Displays the running configuration information for an interface.