

*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*



## R Commands

---

This chapter describes the Cisco NX-OS MSDP commands that begin with R.

*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*

## restart msdp

To restart the Multicast Source Discovery Protocol (MSDP) process, use the **restart msdp** command.

**restart msdp**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

Command History	Release	Modification
	5.0(3)N1(1)	This command was introduced.

<b>Usage Guidelines</b>	This command requires the LAN Base Services license.
-------------------------	--

<b>Examples</b>	This example shows how to restart the MSDP process: <pre>switch(config)# <b>restart msdp</b></pre>
-----------------	---

Related Commands	Command	Description
	<b>ip msdp flush-routes</b>	Enables flushing routes when the MSDP process is restarted.