

# **N** Commands

This chapter describes the Cisco NX-OS Layer 3 interfaces commands that begin with N.

# Send comments to nexus5k-docfeedback@cisco.com

# no switchport

To configure the interface as a Layer 3 Ethernet interface, use the **no switchport** command.

#### no switchport

#### **Syntax Description**

This command has no arguments or keywords.

### **Command Default**

None

#### **Command Modes**

Interface configuration mode

#### **Command History**

Release	Modification
5.0(3)N1(1)	This command was introduced.

# **Usage Guidelines**

You can configure any Ethernet port as a routed interface. When you configure an interface as a Layer 3 interface, any configuration specific to Layer 2 on this interface is deleted.

If you want to configure a Layer 3 interface for Layer 2, enter the **switchport** command. Then, if you change a Layer 2 interface to a routed interface, enter the **no switchport** command.

# **Examples**

This example shows how to enable an interface as a Layer 3 routed interface:

```
switch(config)# interface ethernet 1/5
switch(config-if)# no switchport
switch(config-if)#
```

This example shows how to configure a Layer 3 interface as a Layer 2 interface:

```
switch(config)# interface ethernet 1/5
switch(config-if)# switchport
switch(config-if)#
```

#### **Related Commands**

Command	Description
copy running-config startup-config	Saves the running configuration to the startup configuration file.
ip address	Sets a primary or secondary IP address for an interface.
show interfaces	Displays interface information.