

*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*



## Show Commands

---

This chapter describes the Cisco NX-OS object tracking **show** commands.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

# show track

To show information about object tracking, use the **show track** command.

**show track** [*object-id*] [**interface** | **ip route**] [**brief**]

## Syntax Description

|                  |                                                              |
|------------------|--------------------------------------------------------------|
| <i>object-id</i> | (Optional) Tracking ID. The range can be from 1 to 500.      |
| <b>interface</b> | (Optional) Displays information about tracked interfaces.    |
| <b>ip route</b>  | (Optional) Displays information about tracked IP routes.     |
| <b>brief</b>     | (Optional) Displays brief information about tracked objects. |

## Command Default

Display information for all tracked objects.

## Command Modes

Any command mode

## Command History

| Release     | Modification                 |
|-------------|------------------------------|
| 5.0(3)N1(1) | This command was introduced. |

## Examples

This example shows how to display information about tracked interfaces:

```
switch# show track interface
```

This example shows how to display information about tracked IP routes:

```
switch# show track ip route
```

This example shows how to display brief information about tracked objects:

```
switch# show track brief
```

## Related Commands

| Command                | Description                       |
|------------------------|-----------------------------------|
| <b>track interface</b> | Tracks the state of an interface. |
| <b>track ip route</b>  | Tracks the state of an IP route.  |