



## INDEX

---

### A

administrator role [1-1](#)

---

### C

configuring a user with SAN administrator role  
example of [1-3](#)

---

### D

displaying user role configurations  
example of [1-5](#)

---

### E

enabling FCoE feature for the SAN administrator role  
example of [1-4](#)  
examples  
    configuring a user with SAN administrator role [1-3](#)  
    displaying user role configurations [1-5](#)  
    enabling FCoE feature for the SAN administrator role [1-4](#)  
    modifying the SAN administrator default role [1-4](#)  
    verifying the new SAN administrator role configuration [1-5](#)  
    verifying the SAN administrator role configuration [1-3](#)

---

### M

mapping  
    features to roles [1-2](#)  
modifying the SAN administrator default role

example of [1-4](#)

---

### R

RBAC  
    SAN administrator role [1-1](#)  
Role-Based Access Control (RBAC)  
    SAN administrator role [1-1](#)  
role-feature mapping [1-2](#)

---

### S

SAN administrator role  
    description [1-1](#)  
    overview [1-1](#)

---

### V

verifying the new SAN administrator role configuration  
    example of [1-5](#)  
verifying the SAN administrator role configuration  
    example of [1-3](#)

***Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)***

***Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)***

***Send documentation comments to [n5kdocfeedback@cisco.com](mailto:n5kdocfeedback@cisco.com)***