



Show Commands

This chapter describes the Cisco NX-OS object tracking **show** commands.

show track

To show information about object tracking, use the **show track** command.

show track [*object-id*] [**interface** | **ip route**] [**brief**]

Syntax Description	<i>object-id</i>	(Optional) Tracking ID. The range can be from 1 to 500.
	interface	(Optional) Displays information about tracked interfaces.
	ip route	(Optional) Displays information about tracked IP routes.
	brief	(Optional) Displays brief information about tracked objects.

Command Default	Display information for all tracked objects.
-----------------	--

Command Modes	Any command mode
---------------	------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display information about tracked interfaces:
	<pre>switch# show track interface</pre>
	This example shows how to display information about tracked IP routes:
	<pre>switch# show track ip route</pre>
	This example shows how to display brief information about tracked objects:
	<pre>switch# show track brief</pre>

Related Commands	Command	Description
	track interface	Tracks the state of an interface.
	track ip route	Tracks the state of an IP route.