



# Show Commands

---

This chapter describes the Cisco NX-OS object tracking **show** commands.

# show track

To show information about object tracking, use the **show track** command.

**show track** [*object-id*] [**interface** | **ip route**] [**brief**]

Syntax Description	<i>object-id</i>	(Optional) Tracking ID. The range can be from 1 to 500.
	<b>interface</b>	(Optional) Displays information about tracked interfaces.
	<b>ip route</b>	(Optional) Displays information about tracked IP routes.
	<b>brief</b>	(Optional) Displays brief information about tracked objects.

Command Default	Display information for all tracked objects.
-----------------	--

Command Modes	Any command mode
---------------	------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples	This example shows how to display information about tracked interfaces:  switch# <b>show track interface</b>
	This example shows how to display information about tracked IP routes:  switch# <b>show track ip route</b>
	This example shows how to display brief information about tracked objects:  switch# <b>show track brief</b>

Related Commands	Command	Description
	<b>track interface</b>	Tracks the state of an interface.
	<b>track ip route</b>	Tracks the state of an IP route.