



F Commands

This chapter describes the Cisco NX-OS virtual port channel (vPC) commands that begin with F.

feature vpc

To enable a virtual port channel (vPC), which allows links that are physically connected to two different Cisco Nexus 5000 Series devices to appear as a single port channel to a third device, use the **feature vpc** command. To disable vPC on the switch, use the **no** form of this command.

feature vpc

no feature vpc

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	Disabled
------------------------	----------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines	In a vPC configuration, the third device can be a Cisco Nexus 2000 Series Fabric Extender, switch, server, or any other networking device.
-------------------------	--

Examples	<p>This example shows how to enable vPC on the switch:</p> <pre>switch(config)# feature vpc</pre>
-----------------	--

Related Commands	Command	Description
	show vpc	Displays the vPC configuration status.
	show feature	Displays whether or not vPC is enabled on the switch.