



R Commands

This chapter describes the Cisco NX-OS MSDP commands that begin with R.

restart msdp

To restart the Multicast Source Discovery Protocol (MSDP) process, use the **restart msdp** command.

restart msdp

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.

Usage Guidelines This command requires the LAN Base Services license.

Examples This example shows how to restart the MSDP process:

```
switch(config)# restart msdp
```

Related Commands	Command	Description
	ip msdp flush-routes	Enables flushing routes when the MSDP process is restarted.