R Commands

This chapter describes the Cisco NX-OS MSDP commands that begin with R.

restart msdp

To restart the Multicast Source Discovery Protocol (MSDP) process, use the **restart msdp** command.

restart msdp

Syntax Description   This command has no arguments or keywords.

Command Default   None

Command Modes   Any command mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines   This command requires the LAN Base Services license.

Examples   This example shows how to restart the MSDP process:

```
switch(config)# restart msdp
```

Related Commands

Command	Description
ip msdp flush-routes	Enables flushing routes when the MSDP process is restarted.