



F Commands

This chapter describes the Cisco NX-OS Border Gateway Protocol (BGP) commands that begin with F.

Review Draft -- Cisco Confidential

feature bgp

To enable the Border Gateway Protocol (BGP), use the **feature bgp** command. To disable BGP, use the **no** form of this command.

feature bgp

no feature bgp

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	Disabled
------------------------	----------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modified
	6.0(2)N1(1)	This command was introduced.

Usage Guidelines	<p>You must enable the BGP feature before you can configure BGP.</p> <p>This command requires the LAN Enterprise Services license.</p>
-------------------------	--

Examples	This example shows how to enable a BGP configuration:
-----------------	---

```
switch# configure terminal
switch(config)# feature bgp
switch(config)#
```

This example shows how to disable the BGP feature:

```
switch# configure terminal
switch(config)# no feature bgp
switch(config)#
```

Related Commands	Command	Description
	router bgp	Creates a BGP instance.
	show bgp	Displays BGP configuration information.
	show feature	Displays the status of features on a switch.