



Cisco Nexus 7000 Series NX-OS Command Reference Master Index, Release 6.2(2)

September 20, 2013

This index contains an alphabetical list of all the commands documented for Cisco NX-OS. Use the Alphabet Key or your web browser's Find function to search for a command. To access the documentation for a particular command, click on the command name.

Although the PDF file for the Command Reference Master Index contains active links to the online command pages, the PDF file is intended to be used as a printed document.

Page Number Designators

FP	<i>Cisco Nexus 7000 Series NX-OS Fabric Path Command Reference</i>
FEX	<i>Cisco Nexus 7000 Series NX-OS FEX Command Reference</i>
FND	<i>Cisco Nexus 7000 Series NX-OS Fundamentals Command Reference</i>
HA	<i>Cisco Nexus 7000 Series NX-OS High Availability Command Reference</i>
IF	<i>Cisco Nexus 7000 Series NX-OS Interfaces Command Reference</i>
IPSLA	<i>Cisco Nexus 7000 Series NX-OS IP Service Level agreements Command Reference</i>
L2	<i>Cisco Nexus 7000 Series NX-OS Layer 2 Switching Command Reference</i>
L3	<i>Cisco Nexus 7000 Series NX-OS Unicast Routing Command Reference</i>
LISP	<i>Cisco Nexus 7000 Series NX-OS Locator/ID Separation Protocol Command Reference</i>
MCR	<i>Cisco Nexus 7000 Series NX-OS Multicast Routing Command Reference</i>
MPLS	<i>Cisco Nexus 7000 Series NX-OS Multiprotocol Label Switching Command Reference</i>
OTV	<i>Cisco Nexus 7000 Series NX-OS Overlay Transport Virtualization Command Reference</i>
QOS	<i>Cisco Nexus 7000 Series NX-OS Quality of Service Command Reference</i>
SEC	<i>Cisco Nexus 7000 Series NX-OS Security Command Reference</i>

SM	<i>Cisco Nexus 7000 Series NX-OS System Management Command Reference</i>
VDC	<i>Cisco Nexus 7000 Series NX-OS Virtual Device Context Command Reference</i>

S

sampler	364
sampling	366
sap modelist	SEC-488
sap pmk	SEC-490
save	367
scheduler	368
send	FND-115
send-community extended	MPLS-202
send-lifetime	MPLS-203 , SEC-492
serial	-16
server	SEC-494
service dhcp	SEC-496
service-policy	1-85
service-policy input	SEC-498
session protection	MPLS-205
session-limit	FND-118
set	MPLS-206
set as-path	329
set comm-list delete	331
set community	333
set cos	SEC-500
set cos (policy map type qos)	1-87
set cos (policy map type queuing)	1-88
set discard-class	1-90
set distance	336
set dscp (policy map class)	SEC-502
set dscp (QoS)	1-91

- set etxcommunity 339
- set extcomm-list delete 343
- set extcommunity cost 341
- set extcommunity rt 345
- set forwarding-address 347
- set interface 349
- set ip address prefix-list 351
- set ip default next-hop 353
- set ip next-hop 356
- set ip next-hop verify-availability 1-38
- set ipv6 default next-hop 358
- set ipv6 next-hop 361
- set level 363
- set local-preference 365
- set metric 367
- set metric-type 369
- set mpls experimental imposition MPLS-207
- set nssa-only 371
- set origin 373
- set path-selection all advertise 375
- set precedence (policy map class) SEC-504
- set precedence (QoS) 1-93
- set qos-group 1-95
- set table 1-96
- set tag 376
- set vrf 378
- set weight 380
- set-attached-bit 328
- set-overload-bit 1-69
- setup FND-116
- shape 1-98
- show SEC-607
- show access-list status module SEC-608
- show aaa accounting SEC-538
- show aaa authentication SEC-539
- show aaa authorization SEC-541
- show aaa groups SEC-543
- show aaa user default-role SEC-544
- show access-lists SEC-545
- show accounting log SEC-548
- show arp access-lists SEC-550
- show banner motd FND-119
- show bfd neighbors 1-53, 1-125
- show bgp 400
- show bgp community 402
- show bgp community-list 404
- show bgp extcommunity 406
- show bgp extcommunity-list 408
- show bgp ipv4 unicast labels 412
- show bgp neighbors 410
- show bgp sessions 413
- show bgp unicast neighbors vrf MPLS-226
- show bgp vpnv4 unicast 414
- show bgp vpnv6 unicast 416
- show boot 10, FND-120
- show bridge-domain MPLS-227
- show callhome 426
- show callhome transport 428
- show cdp 430
- show cdp neighbors 432
- show cfs application 433
- show cfs lock 435
- show cfs merge status 437
- show cfs peers 439
- show cfs regions 441
- show cfs status 443
- show checkpoint 445
- show class-map type control-plane SEC-552
- show class-map type network-qos 1-100
- show class-map type qos 1-102
- show class-map type queuing 1-104
- show cli alias FND-122
- show cli history FND-123
- show cli list FND-125
- show cli syntax FND-127
- show cli syntax roles network-admin SEC-553
- show cli syntax roles network-operator SEC-559
- show cli variables FND-129

- show clock [FND-130](#)
- show configuration session [447](#)
- show configuration session global-info [449](#)
- show copp diff profile [SEC-555](#)
- show copp profile [SEC-557](#)
- show copp status [SEC-561](#)
- show copyright [FND-132](#)
- show cores [12, 450](#)
- show crypto ca certificates [SEC-562](#)
- show crypto ca certstore [SEC-564](#)
- show crypto ca crl [SEC-565](#)
- show crypto ca remote-certstore [SEC-568](#)
- show crypto ca trustpoints [SEC-569](#)
- show crypto certificatemap [SEC-570](#)
- show crypto key mypubkey rsa [SEC-571](#)
- show crypto ssh-auth-map [SEC-572](#)
- show cts [SEC-573](#)
- show cts capability interface [SEC-574](#)
- show cts credentials [SEC-576](#)
- show cts environment-data [SEC-577](#)
- show cts interface [SEC-579](#)
- show cts pacs [SEC-583](#)
- show cts role-based access-list [SEC-585](#)
- show cts role-based counters [SEC-587](#)
- show cts role-based enable [SEC-589](#)
- show cts role-based policy [SEC-590](#)
- show cts role-based sgt vlan [SEC-592](#)
- show cts role-based sgt-map [SEC-593](#)
- show cts sap pmk [SEC-595](#)
- show cts sxp [SEC-596](#)
- show cts sxp connection [SEC-597](#)
- show device-alias [198](#)
- show diagnostic bootup level [452](#)
- show diagnostic content module [453](#)
- show diagnostic description module [455](#)
- show diagnostic events [456](#)
- show diagnostic ondemand setting [458](#)
- show diagnostic result [459](#)
- show diagnostic simulation [461](#)
- show diagnostic status [462](#)
- show diff rollback-patch [463](#)
- show dot1x [SEC-598](#)
- show dot1x all [SEC-599](#)
- show dot1x interface ethernet [SEC-601](#)
- show encryption service stat [SEC-603](#)
- show environment [464](#)
- show environment fex [-19](#)
- show environment power [467](#)
- show eou [SEC-604](#)
- show errdisable [1-129](#)
- show ethernet service instance [MPLS-228](#)
- show ethernet service instance id interface ethernet [MPLS-230](#)
- show ethernet service instance interface ethernet [MPLS-229](#)
- show event manager environment [469](#)
- show event manager event-types [470](#)
- show event manager events action-log policy [418](#)
- show event manager history events [471](#)
- show event manager policy [472](#)
- show event manager policy-state [419, 473](#)
- show event manager script [474](#)
- show event manager system-policy [475](#)
- show fabric-binding [1100](#)
- show fabricpath conflict [1-94](#)
- show fabricpath ftag [1-95](#)
- show fabricpath isis adjacency [1-70](#)
- show fabricpath isis database [1-72](#)
- show fabricpath isis ftag [1-74](#)
- show fabricpath isis hostname [1-75](#)
- show fabricpath isis interface [1-76](#)
- show fabricpath isis ip mroute [1-78](#)
- show fabricpath isis ip redistribute mroute [1-79](#)
- show fabricpath isis protocol [1-80](#)
- show fabricpath isis route [1-82](#)
- show fabricpath isis rrm [1-83](#)
- show fabricpath isis spf-log [1-84](#)
- show fabricpath isis srm [1-86](#)

- show fabricpath isis ssn 1-87
- show fabricpath isis statistics 1-88
- show fabricpath isis switch-id 1-89
- show fabricpath isis topology summary 1-90
- show fabricpath isis traffic 1-91
- show fabricpath isis trees 1-92
- show fabricpath isis vlan-range 1-93
- show fabricpath load-balance multicast 1-98
- show fabricpath load-balance unicast 1-96
- show fabricpath route 1-100
- show fabricpath static route 1-104
- show fabricpath switch-id 1-102
- show fabricpath system-id 1-105
- show fabricpath timers 1-106
- show fabricpath topology 1-107
- show fc2 1102
- show fcalias 1106
- show fcdomain 1107
- show fcdroplatency 1110
- show fcid-allocation 1111
- show fcns database 1113
- show fcns statistics 1115
- show fcroute 1116
- show fctimer 1118
- show fdmi 1120
- show feature-set 1-109, FND-133
- show fex -21
- show fex detail -23
- show fex transceiver -26
- show fex version -28
- show fhrp 717
- show file FND-134
- show fips status SEC-606
- show flogi 1122
- show flow exporter 477
- show flow interface 479
- show flow record 487
- show flow sw-monitor 481
- show flow timeout 489
- show forwarding 420, MPLS-231
- show forwarding consistency l2 34
- show forwarding distribution 422
- show forwarding distribution ip igmp snooping 12
- show forwarding distribution ipv6 multicast route 14
- show forwarding distribution l2 multicast vlan 16
- show forwarding distribution multicast 18
- show forwarding distribution multicast client 19
- show forwarding distribution multicast outgoing-interface-list 20
- show forwarding distribution multicast route 21
- show forwarding distribution otv multicast route 1-55
- show forwarding inconsistency 423
- show forwarding ipv6 multicast route 23
- show forwarding l2 multicast vlan 25
- show forwarding multicast outgoing-interface-list 27
- show forwarding multicast route 28
- show forwarding otv 1-57
- show forwarding otv multicast outgoing-interface-list 1-58
- show forwarding otv multicast route 1-59
- show forwarding otv overlay 1-61
- show fspf 1124
- show glbp 425
- show glbp capability 431
- show hardware capacity 491
- show hardware capacity interface 493, 495
- show hardware fabric-utilization 497
- show hardware fabric-utilization detail timestamp 498
- show hardware feature-capability 490
- show hardware flow 504
- show hardware flow aging 500
- show hardware flow entry 502
- show hardware flow l2 506
- show hardware flow sampler 508
- show hardware flow utilization 510
- show hardware forwarding dynamic-allocation status 433
- show hardware forwarding ip verify 438
- show hardware mac address-table 36

- show hardware proxy layer-3 counters 435
- show hardware proxy layer-3 detail 129, 437
- show hardware qos dscp-to-queue ingress -29
- show hardware queuing drops 1-106
- show hardware rate-limiter SEC-609
- show hostname FND-135
- show hsrp 1-110, 440
- show hsrp anycast 1-111
- show hsrp bfd-sessions 442
- show hsrp delay 443
- show hsrp mgo 444
- show hsrp summary 445
- show identity policy SEC-613
- show identity profile SEC-614
- show incompatibility system FND-136
- show install all FND-137
- show interface 1-131
- show interface brief 1-134
- show interface capabilities 1-136
- show interface counters 1-138
- show interface counters errors 1-141
- show interface counters storm-control 1-145
- show interface counters trunk 1-147
- show interface debounce 1-149
- show interface description 1-151
- show interface ethernet 1-153, 514
- show interface ethernet capabilities 512
- show interface ethernet counter detailed 516
- show interface fex-fabric -31
- show interface fex-intf -33
- show interface flowcontrol 1-155
- show interface mac-address 39
- show interface mgmt 1-157
- show interface port-channel 1-159
- show interface port-channel counters 1-163
- show interface priority-flow-control 1-108
- show interface private-vlan mapping 41
- show interface pruning 43
- show interface status 1-167
- show interface switchport 1-170, 44
- show interface transceiver 1-173
- show interface transceiver fex-fabric -34
- show interface trunk 1-175, 46
- show interface tunnel 1-177
- show interface vlan 48
- show interface vlan counters 51
- show inventory 518
- show inventory fex -36
- show ip access-lists SEC-615
- show ip access-lists capture session SEC-618
- show ip adjacency 447
- show ip adjacency summary 451
- show ip adjacency throttle statistics 452
- show ip arp 449
- show ip arp inspection SEC-619
- show ip arp inspection interface SEC-621
- show ip arp inspection log SEC-623
- show ip arp inspection statistics SEC-624
- show ip arp inspection vlan SEC-626
- show ip arp summary 453
- show ip as-path-access-list 454
- show ip bgp 455
- show ip bgp community-list 457
- show ip bgp dampening 459
- show ip bgp extcommunity 461
- show ip bgp extcommunity-list 462
- show ip bgp filter-list 463
- show ip bgp flap-statistics 464
- show ip bgp history-paths 465
- show ip bgp neighbors 466
- show ip bgp nexthop 468
- show ip bgp nexthop-database 469
- show ip bgp peer-policy 470
- show ip bgp peer-session 471
- show ip bgp peer-template 472
- show ip bgp prefix-list 474
- show ip client 475
- show ip community-list 476

- show ip device tracking [SEC-628](#)
- show ip dhcp relay [SEC-630](#)
- show ip dhcp relay address [SEC-631](#)
- show ip dhcp relay statistics [SEC-633](#)
- show ip dhcp snooping [SEC-634](#)
- show ip dhcp snooping binding [SEC-636](#)
- show ip dhcp snooping statistics [1-178, SEC-638](#)
- show ip eigrp [477](#)
- show ip eigrp accounting [478](#)
- show ip eigrp interfaces [480](#)
- show ip eigrp neighbors [482](#)
- show ip eigrp policy statistics [485](#)
- show ip eigrp route-map statistics [487](#)
- show ip eigrp topology [489](#)
- show ip eigrp traffic [493](#)
- show ip fib [495](#)
- show ip fib distribution [496](#)
- show ip igmp [38](#)
- show ip igmp event-history [30](#)
- show ip igmp groups [32](#)
- show ip igmp interface [34](#)
- show ip igmp local-groups [36](#)
- show ip igmp snooping [40](#)
- show ip igmp snooping event-history [41](#)
- show ip igmp snooping explicit-tracking [43](#)
- show ip igmp snooping groups [44](#)
- show ip igmp snooping look-up mode [45](#)
- show ip igmp snooping mac-oif [47](#)
- show ip igmp snooping mrouter [49](#)
- show ip igmp snooping mrouter otv [1-62](#)
- show ip igmp snooping querier [50](#)
- show ip igmp snooping statistics [51](#)
- show ip interface [497](#)
- show ip lisp [LSP-167](#)
- show ip lisp data-cache [LSP-171](#)
- show ip lisp database [LSP-172](#)
- show ip lisp locator-hash [LSP-174](#)
- show ip lisp map-cache [LSP-176](#)
- show ip lisp statistics [LSP-178](#)
- show ip lisp translation-cache [LSP-180](#)
- show ip load-sharing [499](#)
- show ip mbgp [500](#)
- show ip mbgp community [502](#)
- show ip mbgp community-list [503](#)
- show ip mbgp dampening [504](#)
- show ip mbgp extcommunity [505](#)
- show ip mbgp extcommunity-list [506](#)
- show ip mbgp filter-list [507](#)
- show ip mbgp flap-statistics [508](#)
- show ip mbgp history-paths [509](#)
- show ip mbgp neighbors [510](#)
- show ip mbgp nexthop [512](#)
- show ip mbgp nexthop-database [513](#)
- show ip mbgp prefix-list [514](#)
- show ip mroute [53](#)
- show ip mroute detail [LSP-181](#)
- show ip mroute summary [55](#)
- show ip msdp count [57](#)
- show ip msdp event-history [59](#)
- show ip msdp mesh-group [61](#)
- show ip msdp peer [62](#)
- show ip msdp policy statistics sa-policy [64](#)
- show ip msdp route [66](#)
- show ip msdp rpf [68](#)
- show ip msdp sa-cache [69](#)
- show ip msdp sources [71](#)
- show ip msdp summary [73](#)
- show ip netstack mroute [74](#)
- show ip ospf [515, MPLS-233](#)
- show ip ospf border-routers [517](#)
- show ip ospf database [519](#)
- show ip ospf interface [525](#)
- show ip ospf lsa-content-changed-list [527](#)
- show ip ospf memory [529](#)
- show ip ospf mpls ldp interface [MPLS-235](#)
- show ip ospf neighbors [531](#)
- show ip ospf policy statistics area [534](#)
- show ip ospf policy statistics redistribute [535](#)

- show ip ospf request-list 537
- show ip ospf retransmission-list 539
- show ip ospf routes 541
- show ip ospf statistics 543
- show ip ospf summary-address 545
- show ip ospf traffic 547
- show ip ospf virtual-links 549
- show ip pim df 76
- show ip pim event-history 77
- show ip pim group-range 78
- show ip pim interface 79
- show ip pim lisp encap LSP-182
- show ip pim mdt MPLS-236
- show ip pim mdt receive MPLS-238
- show ip pim mdt send MPLS-239
- show ip pim neighbor 81
- show ip pim oif-list 83
- show ip pim policy statistics auto-rp 85
- show ip pim policy statistics bsr 87
- show ip pim policy statistics jp-policy 89
- show ip pim policy statistics neighbor-policy 91
- show ip pim policy statistics register-policy 93
- show ip pim route 94
- show ip pim rp 96
- show ip pim rp-hash 97
- show ip pim statistics 98
- show ip pim vrf 100
- show ip policy 551
- show ip prefix-list 552, MPLS-240
- show ip process 553
- show ip rip 554
- show ip rip interface 556
- show ip rip neighbor 558
- show ip rip policy statistics 560
- show ip rip route 562
- show ip rip statistics 564
- show ip rip vrf MPLS-241
- show ip route 566
- show ip rsvp MPLS-242
- show ip rsvp authentication MPLS-244
- show ip rsvp counters MPLS-246
- show ip rsvp fast-reroute MPLS-248
- show ip rsvp hello client lsp MPLS-250
- show ip rsvp hello client neighbor MPLS-251
- show ip rsvp hello instance MPLS-252
- show ip rsvp interface MPLS-253
- show ip rsvp internal MPLS-255
- show ip rsvp neighbor MPLS-257
- show ip rsvp reservation MPLS-258
- show ip rsvp sender MPLS-260
- show ip rsvp session MPLS-262
- show ip rsvp signalling rate-limit MPLS-263
- show ip rsvp signalling refresh MPLS-264
- show ip sla application 1-46
- show ip sla configuration 1-39
- show ip sla group schedule 1-51
- show ip sla statistics 1-41
- show ip static-route 568
- show ip static-route track-table 569
- show ip traffic 570
- show ip verify source SEC-640
- show ip wccp 572
- show ipv6 access-lists SEC-641
- show ipv6 adjacency 576
- show ipv6 bgp 578
- show ipv6 bgp community 580
- show ipv6 bgp community-list 581
- show ipv6 bgp dampening 582
- show ipv6 bgp extcommunity-list 583
- show ipv6 bgp filter-list 584
- show ipv6 bgp flap-statistics 585
- show ipv6 bgp history-paths 586
- show ipv6 bgp neighbors 587
- show ipv6 bgp nexthop 589
- show ipv6 bgp nexthop-database 590
- show ipv6 bgp prefix-list 591
- show ipv6 client 592
- show ipv6 dhcp relay SEC-644

- show ipv6 dhcp relay statistics [SEC-645](#)
- show ipv6 eigrp [593](#)
- show ipv6 eigrp accounting [594](#)
- show ipv6 eigrp interfaces [596](#)
- show ipv6 eigrp neighbors [598](#)
- show ipv6 eigrp route-map statistics [601](#)
- show ipv6 eigrp topology [603](#)
- show ipv6 eigrp traffic [605](#)
- show ipv6 fragments [607](#)
- show ipv6 icmp interface [608](#)
- show ipv6 interface [609](#)
- show ipv6 lisp [LSP-183](#)
- show ipv6 lisp data-cache [LSP-186](#)
- show ipv6 lisp database [LSP-187](#)
- show ipv6 lisp locator-hash [LSP-189](#)
- show ipv6 lisp map-cache [LSP-191](#)
- show ipv6 lisp statistics [LSP-193](#)
- show ipv6 lisp translation-cache [LSP-195](#)
- show ipv6 local policy [1-110](#)
- show ipv6 mbgp [611](#)
- show ipv6 mbgp community [612](#)
- show ipv6 mbgp community-list [613](#)
- show ipv6 mbgp neighbors [614](#)
- show ipv6 mld groups [101](#)
- show ipv6 mld local-groups [103](#)
- show ipv6 mroute [105](#)
- show ipv6 mroute summary [107](#)
- show ipv6 nd interface [616](#)
- show ipv6 neighbor [618](#)
- show ipv6 pim df [109](#)
- show ipv6 pim event-history [110](#)
- show ipv6 pim group-range [111](#)
- show ipv6 pim interface [112](#)
- show ipv6 pim neighbor [114](#)
- show ipv6 pim oif-list [116](#)
- show ipv6 pim policy statistics jp-policy [118](#)
- show ipv6 pim policy statistics neighbor-policy [119](#)
- show ipv6 pim route [120](#)
- show ipv6 pim rp [121](#)
- show ipv6 pim rp-hash [123](#)
- show ipv6 pim statistics [124](#)
- show ipv6 pim vrf [126](#)
- show ipv6 policy [620](#)
- show ipv6 prefix-list [621](#)
- show ipv6 process [622](#)
- show ipv6 route [623](#)
- show ipv6 route static vrf [MPLS-266](#)
- show ipv6 routers [625](#)
- show ipv6 static-route [626](#)
- show ipv6 traffic [627](#)
- show isis [629](#)
- show isis adjacency [631](#)
- show isis database [633](#)
- show isis hostname [635](#)
- show isis interface [636](#)
- show isis ip route-map statistics redistribute [638](#)
- show isis mesh-group [640](#)
- show isis protocol [641](#)
- show isis redistribute route [643](#)
- show isis route [645](#)
- show isis route-map statistics distribute [648](#)
- show isis rrm [650](#)
- show isis spf-log [652](#)
- show isis srm [654](#)
- show isis ssn [656](#)
- show isis statistics [658](#)
- show isis summary-address [660](#)
- show isis traffic [662](#)
- show key chain [SEC-646](#)
- show l2 multicast trees ftag [1-113](#)
- show l2vpn atom [MPLS-269](#)
- show l2vpn atom vc detail [MPLS-267](#)
- show l2vpn service vfi [MPLS-270](#)
- show l2vpn service xconnect all [MPLS-272](#)
- show l2vpn vfi [MPLS-271](#)
- show lacp counters [1-179](#)
- show lacp interface [1-181](#)
- show lacp neighbor [1-183](#)

- show lacp port-channel [1-185](#)
- show lacp system-identifier [1-187](#)
- show ldap-search-map [SEC-648](#)
- show ldap-server [SEC-650](#)
- show ldap-server groups [SEC-651](#)
- show ldap-server statistics [SEC-653](#)
- show license [FND-140](#)
- show license feature package mapping [FND-142](#)
- show license host-id [FND-145](#)
- show license usage [FND-146](#)
- show line [FND-148](#)
- show lisp ddt queue [LSP-196](#)
- show lisp ddt referral-cache [LSP-197](#)
- show lisp ddt vrf [LSP-198](#)
- show lisp dynamic-eid [LSP-199](#)
- show lisp proxy-itr [LSP-201](#)
- show lisp site [LSP-202](#)
- show lldp dcbox interface ethernet [520](#)
- show lldp interface ethernet [522](#)
- show lldp neighbors [523](#)
- show lldp timers [525](#)
- show lldp tlv-select [526](#)
- show lldp traffic [527](#)
- show lldp traffic interface ethernet [528](#)
- show locator-led status [530](#)
- show logging console [531](#)
- show logging info [532](#)
- show logging ip access-list cache [534](#)
- show logging last [535](#)
- show logging level [536](#)
- show logging level fex [-32](#)
- show logging level otv isis [1-63](#)
- show logging logfile [537](#)
- show logging loopback [538](#)
- show logging module [539](#)
- show logging monitor [540](#)
- show logging nvram [541](#)
- show logging onboard [542, 549](#)
- show logging server [551](#)
- show logging session status [552](#)
- show logging status [553](#)
- show logging timestamp [554](#)
- show mac access-lists [SEC-655](#)
- show mac address-table [54](#)
- show mac address-table aging-time [57](#)
- show mac address-table learning-mode [1-118](#)
- show mac vdc [VDC-32](#)
- show mac-list [664](#)
- show module [555](#)
- show module fex [-37](#)
- show monitor [558](#)
- show monitor session [559](#)
- show mpls forwarding statistics [MPLS-273](#)
- show mpls interface detail [MPLS-275](#)
- show mpls interfaces [MPLS-276](#)
- show mpls ip bindings [MPLS-278](#)
- show mpls label range [MPLS-280](#)
- show mpls ldp backoff [MPLS-281](#)
- show mpls ldp capabilities [MPLS-282](#)
- show mpls ldp checkpoint [MPLS-283](#)
- show mpls ldp discovery [MPLS-284](#)
- show mpls ldp graceful-restart [MPLS-285](#)
- show mpls ldp igp sync [MPLS-286](#)
- show mpls ldp neighbor [MPLS-287](#)
- show mpls ldp neighbor graceful-restart [MPLS-274](#)
- show mpls ldp parameter [MPLS-289](#)
- show mpls oam [MPLS-291](#)
- show mpls static binding ipv4 [MPLS-293](#)
- show mpls static binding ipv4 vrf [MPLS-294](#)
- show mpls switching [MPLS-295](#)
- show mpls switching aggregate [MPLS-297](#)
- show mpls switching aggregate detail [MPLS-298](#)
- show mpls switching aggregate ipv4 [MPLS-299](#)
- show mpls switching aggregate ipv6 [MPLS-300](#)
- show mpls switching aggregate vrf [MPLS-301](#)
- show mpls switching clients [MPLS-302](#)
- show mpls switching detail [MPLS-304](#)
- show mpls switching interface [MPLS-305](#)

- show mpls switching labels [MPLS-306](#)
- show mpls switching traffic-eng lsp ipv4 [MPLS-307](#)
- show mpls switching traffic-eng tunnels [MPLS-309](#)
- show mpls switching vrf [MPLS-310](#)
- show mpls traffic-eng autoroute [MPLS-311](#)
- show mpls traffic-eng exp [MPLS-312](#)
- show mpls traffic-eng forwarding-adjacency [MPLS-313](#)
- show mpls traffic-eng high-availability [MPLS-314](#)
- show mpls traffic-eng link-management [MPLS-316](#)
- show mpls traffic-eng lsp attributes [MPLS-318](#)
- show mpls traffic-eng topology [MPLS-319](#)
- show mpls traffic-eng tunnels backup [MPLS-321](#)
- show mpls traffic-eng tunnels fast-reroute [MPLS-323](#)
- show mroute [1-114](#)
- show multicast trees [1-116](#)
- show mvpn bgp mdt-safi [MPLS-325](#)
- show mvpn mdt encap vrf [MPLS-326](#)
- show mvpn mdt route [MPLS-327](#)
- show ntp access-groups [562](#)
- show ntp authentication-keys [563](#)
- show ntp authentication-status [564](#)
- show ntp internal [565](#)
- show ntp logging-status [567](#)
- show ntp peer-status [569](#)
- show ntp peers [568](#)
- show ntp pending peers [571](#)
- show ntp pending-diff [570](#)
- show ntp rts-update [574](#)
- show ntp session status [572](#)
- show ntp source [575](#)
- show ntp source-interface [576](#)
- show ntp statistics [577](#)
- show ntp status [573, 578](#)
- show ntp trusted-keys [580](#)
- show ospfv3 [1-188, 667](#)
- show ospfv3 border-routers [669](#)
- show ospfv3 database [671](#)
- show ospfv3 interface [678](#)
- show ospfv3 memory [680](#)
- show ospfv3 neighbors [682](#)
- show ospfv3 policy statistics area [684](#)
- show ospfv3 policy statistics redistribute [685](#)
- show ospfv3 request-list [687](#)
- show ospfv3 retransmission-list [689](#)
- show ospfv3 routes [691](#)
- show ospfv3 statistics [693](#)
- show ospfv3 summary-address [695](#)
- show ospfv3 traffic [697](#)
- show ospfv3 virtual-links [699](#)
- show otv [1-64](#)
- show otv adjacency [1-67](#)
- show otv arp-nd-cache [1-69](#)
- show otv data-group [1-70](#)
- show otv isis active-source [1-73](#)
- show otv isis adjacency [1-75](#)
- show otv isis database [1-77](#)
- show otv isis hostname [1-79](#)
- show otv isis interface [1-80](#)
- show otv isis ip mroute [1-82](#)
- show otv isis ip redistribute mroute [1-84](#)
- show otv isis mac redistribute route [1-85](#)
- show otv isis protocol [1-87](#)
- show otv isis redistribute route [1-89](#)
- show otv isis route [1-90](#)
- show otv isis route-map statistics [1-91](#)
- show otv isis rrm [1-93](#)
- show otv isis site [1-94](#)
- show otv isis spf [1-95](#)
- show otv isis srm [1-96](#)
- show otv isis ssn [1-98](#)
- show otv isis statistics [1-100](#)
- show otv isis traffic [1-102](#)
- show otv isis vpn [1-104](#)
- show otv mroute [1-105](#)
- show otv mroute vlan [1-107](#)
- show otv route [1-108](#)
- show otv site [1-110](#)
- show otv statistics multicast [1-111](#)

- show otv vlan 1-112
- show otv vlan-mapping 1-65
- show otv vpn 1-114
- show otv-isis track-adjacency-nexthop 1-101
- show password strength-check SEC-657
- show platform hardware capacity interface resources 581
- show policy-map 1-111
- show policy-map interface 1-113
- show policy-map interface brief 1-116
- show policy-map interface control-plane SEC-658
- show policy-map system 1-118
- show policy-map system type network-qos 1-120
- show policy-map type control-plane SEC-660
- show policy-map type network-qos 1-122
- show policy-map type queuing 1-124
- show policy-map vlan 1-125
- show port-channel compatibility-parameters 1-190
- show port-channel database 1-193
- show port-channel load-balance 1-195
- show port-channel rbh-distribution 1-196
- show port-channel summary -30, 1-197
- show port-channel traffic 1-199
- show port-channel usage 1-201
- show port-monitor 582
- show port-monitor active 584
- show port-monitor status 586
- show port-profile 1-202
- show port-security SEC-661
- show port-security address SEC-663
- show port-security interface SEC-665
- show privilege SEC-667
- show process cpu sort 592
- show processes 587
- show processes cpu 589
- show processes cpu history 590
- show processes log 594
- show processes memory 597
- show ptp brief 599
- show ptp clock 601
- show ptp clock foreign-masters-record 603
- show ptp corrections 605
- show ptp parent 607
- show ptp port 609
- show ptp time-property 611
- show qos dcbxp 1-127
- show qos shared-policer 1-129
- show queuing interface -39, 1-130
- show radius SEC-668
- show radius-server SEC-670
- show redundancy status 613
- show resource VDC-33
- show resource monitor-session 615
- show resource monitor-session-extended 616
- show rlir 1126
- show rmon 617
- show role SEC-673
- show role feature SEC-676
- show role feature-group SEC-679
- show role pending SEC-682
- show role pending-diff SEC-683
- show role session SEC-684
- show role status SEC-685
- show route static vrf MPLS-328
- show routing 701, MPLS-329
- show routing hash 706
- show routing ip multicast event-history 127
- show routing ipv6 memory estimate routes 703
- show routing ipv6 multicast 130
- show routing ipv6 multicast clients 131
- show routing ipv6 multicast event-history 133
- show routing memory estimate 704
- show routing multicast 135
- show routing multicast clients 137
- show routing-context 705
- show rscn 1127
- show run mpls ldp all MPLS-336
- show run otv-isis 1-116

show running-config [FND-150](#)
show running-config aaa [SEC-686](#)
show running-config aclmgr [SEC-687](#)
show running-config cdp [619](#)
show running-config copp [SEC-690](#)
show running-config cts [SEC-692](#)
show running-config dhcp [SEC-694](#)
show running-config diagnostic [621](#)
show running-config diff [FND-152](#)
show running-config dot1x [SEC-696](#)
show running-config eem [622](#)
show running-config eou [SEC-697](#)
show running-config fabricpath [1-119](#)
show running-config fex [-43](#)
show running-config igmp [139](#)
show running-config interface [1-205, MPLS-330](#)
show running-config interface mgmt [1-208](#)
show running-config ipqos [1-132](#)
show running-config isis [MPLS-331](#)
show running-config l3vm [MPLS-332](#)
show running-config ldap [SEC-698](#)
show running-config lldp [623](#)
show running-config monitor [624](#)
show running-config mpls ldp [MPLS-333](#)
show running-config mpls traffic-eng [MPLS-334](#)
show running-config msdp [140](#)
show running-config netflow [625](#)
show running-config ntp [627](#)
show running-config ospf [MPLS-337](#)
show running-config pim [142](#)
show running-config pim6 [144](#)
show running-config port-security [SEC-699](#)
show running-config radius [SEC-700](#)
show running-config security [SEC-701](#)
show running-config snmp [629](#)
show running-config spanning-tree [58](#)
show running-config tacacs+ [SEC-702](#)
show running-config vdc [VDC-35](#)
show running-config vdc-all [VDC-37](#)
show running-config vlan [60](#)
show running-config vpc [1-209](#)
show running-config vrf [MPLS-338](#)
show running-config vtp [61](#)
show running-config wccp [707](#)
show sampler [630](#)
show scheduler [631](#)
show snmp [633](#)
show snmp community [636](#)
show snmp context [638](#)
show snmp engineID [639](#)
show snmp group [640](#)
show snmp host [642](#)
show snmp sessions [644](#)
show snmp source-interface [645](#)
show snmp trap [646](#)
show snmp user [648](#)
show sockets client [708](#)
show sockets connection [710](#)
show sockets statistics [712](#)
show spanning-tree [62](#)
show spanning-tree active [67](#)
show spanning-tree bridge [70](#)
show spanning-tree brief [72](#)
show spanning-tree detail [74](#)
show spanning-tree interface [76](#)
show spanning-tree mst [79](#)
show spanning-tree root [82](#)
show spanning-tree summary [84](#)
show spanning-tree vlan [86](#)
show sprom [650](#)
show sprom fex [-45](#)
show ssh key [SEC-703](#)
show ssh server [SEC-705](#)
show startup-config [FND-154](#)
show startup-config aaa [SEC-706](#)
show startup-config aclmgr [SEC-707](#)
show startup-config cdp [653](#)
show startup-config cfs [656](#)

- show startup-config copp [SEC-709](#)
- show startup-config dhcp [SEC-711](#)
- show startup-config diagnostic [655](#)
- show startup-config dot1x [SEC-713](#)
- show startup-config eem [657](#)
- show startup-config eou [SEC-714](#)
- show startup-config igmp [146](#)
- show startup-config interface [1-211](#)
- show startup-config ldap [SEC-715](#)
- show startup-config monitor [658](#)
- show startup-config mpls traffic-eng [MPLS-339](#)
- show startup-config msdp [147](#)
- show startup-config netflow [659](#)
- show startup-config ntp [661](#)
- show startup-config pim [149](#)
- show startup-config pim6 [151](#)
- show startup-config port-security [SEC-716](#)
- show startup-config radius [SEC-717](#)
- show startup-config security [SEC-718](#)
- show startup-config snmp [663](#)
- show startup-config tacacs+ [SEC-719](#)
- show startup-config vdc-all [VDC-41](#)
- show startup-config vlan [89](#)
- show startup-config vpc [1-213](#)
- show startup-config vrf [MPLS-341](#)
- show startup-config vtp [90](#)
- show switchname [FND-156](#)
- show system cores [13, 665](#)
- show system error-id [666](#)
- show system internal access-list feature bank-class map [SEC-720](#)
- show system internal dir [FND-157](#)
- show system internal pktmgr internal control sw-rate-limit [SEC-722](#)
- show system internal xbar fabric-flow-control-info [152](#)
- show system memory-status [667](#)
- show system pss shrink status [668](#)
- show system pss shrink status details [669](#)
- show system redundancy [14, 673](#)
- show system reset-reason [671](#)
- show system reset-reason fex [-49](#)
- show system resources [675](#)
- show system standby manual-boot [16, 676](#)
- show system uptime [677](#)
- show system vlan reserved [91](#)
- show table-map [1-137](#)
- show tacacs+ [SEC-723](#)
- show tacacs-server [SEC-725](#)
- show tech fex all [-50](#)
- show tech-support [FND-158](#)
- show tech-support all binary [678](#)
- show tech-support ascii-cfg [680](#)
- show tech-support cfs [682](#)
- show tech-support fex [-52](#)
- show tech-support mpls manager [MPLS-342](#)
- show tech-support session-mgr [684](#)
- show tech-support snmp [685](#)
- show telnet server [SEC-728](#)
- show terminal [FND-160](#)
- show time-range [SEC-729](#)
- show track [714](#)
- show trunk protocol [1129](#)
- show udd [1-214](#)
- show user-account [SEC-731](#)
- show username [SEC-732](#)
- show users [SEC-734](#)
- show vdc [1-216, VDC-42](#)
- show vdc current-vdc [VDC-44](#)
- show vdc membership [VDC-45](#)
- show vdc resource [VDC-47](#)
- show vdc resource template [VDC-50](#)
- show vdc shared membership [VDC-53](#)
- show version [FND-161](#)
- show version fex [-54](#)
- show version internal build-identifier [716](#)
- show vlan [92](#)
- show vlan access-list [SEC-735](#)
- show vlan access-map [SEC-736](#)

- show vlan counters 95
- show vlan dot1q tag native 97
- show vlan filter SEC-738
- show vlan id 98
- show vlan private-vlan 100
- show vpc brief 1-218
- show vpc consistency-parameters 1-222
- show vpc orphan-ports 1-225
- show vpc peer-keepalive 1-227
- show vpc role 1-229
- show vpc statistics 1-231
- show vrf MPLS-344
- show vrf interface MPLS-345
- show vrrp 718
- show vrrs client 720
- show vrrs pathway 721
- show vrrs server 722
- show vrrs tag 723
- show vsan 1130
- show vtp counter 102
- show vtp interface 104
- show vtp password 106
- show vtp status 107
- show wwn 1132
- show xml server status 686
- show zone 1133
- show zone analysis 1137
- show zone internal global-info 1140
- show zone internal vsan 1141
- show zone policy 1142
- show zone smart-zoning auto-conv 1143
- show zoneset 1144
- shut 371
- shutdown 1-121, 1-233
- shutdown (BGP) 382
- shutdown (EIGRP) 383
- shutdown (IS-IS) 384
- shutdown (LDP configuration mode) MPLS-208
- shutdown (OSPF) 385
- shutdown (OSPFv3) 386
- shutdown (TE configuration mode) MPLS-209
- shutdown (VLAN configuration) 109
- shutdown (VRRP) 387
- signaling protocol none MPLS-220
- signalling advertise explicit-null MPLS-210
- signalling client batch-time MPLS-211
- signalling hello graceful-restart MPLS-212
- signalling hello graceful-restart refresh interval MPLS-213
- signalling hello graceful-restart refresh misses MPLS-214
- signalling hello graceful-restart send recovery-time MPLS-215
- signalling hello graceful-restart send restart-time MPLS-216
- signalling hello reroute MPLS-217
- signalling initial-retransmit-delay MPLS-218
- signalling patherr state-removal MPLS-219
- signalling rate-limit MPLS-221
- signalling refresh interval MPLS-222
- signalling refresh misses MPLS-223
- signalling refresh reduction MPLS-224
- signalling refresh reduction ack-delay MPLS-225
- signalling refresh reduction bundle-max-size MPLS-226
- sleep FND-164
- slot FND-165
- snmp-server aaa-user cache-timeout 372
- snmp-server community 373
- snmp-server contact 375
- snmp-server context 376
- snmp-server enable traps 378
- snmp-server globalEnforcePriv 382
- snmp-server host 383
- snmp-server host filter-vrf 385
- snmp-server host use-vrf 386
- snmp-server location 387
- snmp-server mib community-map 388
- snmp-server protocol enable 390

- snmp-server source-interface 391
- snmp-server tcp-session 393
- snmp-server user 394
- snmp-server user enforcePriv 396
- snmp-trap 397
- soo MPLS-227
- source 399, 400, FND-167
- source exception 402
- source-interface SEC-506
- spanning-tree bpdupfilter 111
- spanning-tree bpduguard 113
- spanning-tree bridge assurance 115
- spanning-tree cost 117
- spanning-tree domain 1-123
- spanning-tree guard 119
- spanning-tree link-type 120
- spanning-tree loopguard default 121
- spanning-tree mode 122
- spanning-tree mst configuration 124
- spanning-tree mst cost 126
- spanning-tree mst forward-time 128
- spanning-tree mst hello-time 129
- spanning-tree mst max-age 130
- spanning-tree mst max-hops 131
- spanning-tree mst port-priority 132
- spanning-tree mst pre-standard 133
- spanning-tree mst priority 134
- spanning-tree mst root 135
- spanning-tree mst simulate pvst 137
- spanning-tree mst simulate pvst global 139
- spanning-tree pathcost method 141
- spanning-tree port type edge 143
- spanning-tree port type edge bpdupfilter default 145
- spanning-tree port type edge bpduguard default 147
- spanning-tree port type edge default 149
- spanning-tree port type network 151
- spanning-tree port type network default 153
- spanning-tree port-priority 155
- spanning-tree pseudo-information 157
- spanning-tree vlan 158
- speed 1-235
- spf-interval 1-117, 1-124, 388
- sscp FND-169
- ssh SEC-508
- ssh key SEC-510
- ssh login-attempts SEC-512
- ssh server enable SEC-514
- ssh6 SEC-515
- state 160
- state enabled 1-237, MPLS-229
- statistics per-entry SEC-516
- stopbits FND-170
- storm-control level SEC-518
- stub 390
- summary-address 392
- summary-address (OSPF) 394
- summary-address (OSPFv3) 396
- suppress-inactive 398
- switch-id 1-128
- switchname FND-172
- switchport 1-238
- switchport access vlan 1-240
- switchport allowed vlan MPLS-231
- switchport autostate exclude 1-242
- switchport dot1q ethertype 1-244
- switchport host 1-246
- switchport mode 1-248
- switchport mode dot1q-tunnel 1-250
- switchport mode fabricpath 1-126
- switchport mode fex-fabric -18
- switchport mode private-vlan host 161
- switchport mode private-vlan promiscuous 163
- switchport mode private-vlan promiscuous trunk 165
- switchport mode private-vlan trunk secondary 167
- switchport mode trunk 1145
- switchport monitor 404
- switchport port-security SEC-520
- switchport port-security aging time SEC-522

switchport port-security aging type [SEC-524](#)
 switchport port-security mac-address [SEC-526](#)
 switchport port-security mac-address sticky [SEC-528](#)
 switchport port-security maximum [SEC-530](#)
 switchport port-security violation [SEC-532](#), [SEC-535](#)
 switchport private-vlan host-association [171](#)
 switchport private-vlan mapping trunk [173](#)
 switchport private-vlan trunk allowed vlan [175](#)
 switchport private-vlan trunk native vlan [177](#)
 switchport trunk allowed vlan [1-251](#)
 switchport trunk native vlan [1-253](#)
 switchport trunk pruning vlan [179](#)
 switchto vdc [VDC-55](#)
 switchwide [VDC-54](#)
 system admin-vdc migrate [VDC-57](#)
 system bridge-domain [MPLS-230](#)
 system cores [17](#), [406](#)
 system default interface congestion mode [1-256](#)
 system default interface congestion timeout [1-257](#)
 system default interface pause mode [1-261](#)
 system default interface pause timeout [1-259](#)
 system default switchport [1-255](#), [1146](#)
 system default switchport fabricpath [1-127](#)
 system default zone [1150](#)
 system default zone default-zone permit [1148](#)
 system default zone smart-zone [1152](#)
 system hap-reset [19](#), [408](#)
 system heartbeat [20](#), [409](#)
 system jumbomtu [1-262](#)
 system module-type [1-265](#), [VDC-58](#)
 system no hap-reset [21](#), [410](#)
 system no heartbeat [411](#)
 system no standby manual-boot [412](#)
 system no watchdog [413](#)
 system no watchdog kgdb [414](#)
 system pss shrink [415](#)
 system standby manual-boot [22](#), [416](#)
 system startup-config init [417](#)
 system startup-config unlock [418](#)

system switchover [23](#), [421](#)
 system test-preupgrade running-ver [419](#)
 system trace [422](#)
 system vlan long-name [180](#)
 system vlan reserve [181](#)
 system watchdog [24](#), [423](#)
 system watchdog kgdb [424](#)
 system-mac [1-263](#)
 system-priority [1-266](#)

T

table-map [1-139](#), [MPLS-222](#)
 table-map (EIGRP) [994](#)
 table-map (OSPF) [995](#)
 table-map (OSPFv3) [996](#)
 tac-pac [FND-174](#)
 tacacs+ abort [SEC-740](#)
 tacacs+ commit [SEC-741](#)
 tacacs+ distribute [SEC-742](#)
 tacacs-server deadtime [SEC-743](#)
 tacacs-server directed-request [SEC-745](#)
 tacacs-server host [SEC-747](#)
 tacacs-server key [SEC-749](#)
 tacacs-server test [SEC-751](#)
 tacacs-server timeout [SEC-753](#)
 tag [1-26](#), [688](#)
 tail [FND-175](#)
 tar append [FND-177](#)
 tar create [FND-179](#)
 tar extract [FND-181](#)
 tar list [FND-183](#)
 tcp-connect [1-8](#)
 telnet [SEC-754](#)
 telnet server enable [SEC-756](#)
 telnet6 [SEC-757](#)
 template [VDC-60](#)
 template (BGP) [997](#)
 template data timeout [690](#)

- terminal alias [FND-184](#)
 - terminal color [FND-186](#)
 - terminal dont-ask [FND-188](#)
 - terminal edit-mode vi [FND-189](#)
 - terminal event-manager bypass [691](#)
 - terminal history no-exec-in-config [FND-191](#)
 - terminal length [FND-192](#)
 - terminal log-all [FND-194](#)
 - terminal redirection-mode [FND-195](#)
 - terminal session-timeout [FND-196](#)
 - terminal type [FND-197](#)
 - terminal verify-only [SEC-759](#)
 - terminal width [FND-198](#)
 - test aaa authorization command-type [SEC-761](#)
 - test forwarding distribution perf [1003](#)
 - test forwarding inconsistency [1004](#)
 - test watchdog [692](#)
 - threshold [1-25](#)
 - threshold percentage [1006](#)
 - threshold weight [1008](#)
 - time-range [SEC-763](#)
 - timeout [1-23](#)
 - timer [1-134](#)
 - timers (GLBP) [1010](#)
 - timers active-time [1012](#)
 - timers advertise [1013](#)
 - timers basic [1014](#)
 - timers lsa-arrival [MPLS-223](#)
 - timers lsa-arrival (OSPF) [1016](#)
 - timers lsa-arrival (OSPFv3) [1018](#)
 - timers lsa-group-pacing (OSPF) [1020](#)
 - timers lsa-group-pacing (OSPFv3) [1022](#)
 - timers nsf converge [1024](#)
 - timers nsf route-hold [1025](#)
 - timers nsf signal [1026](#)
 - timers redirect [1027](#)
 - timers throttle lsa [MPLS-224](#)
 - timers throttle lsa (OSPF) [1029](#)
 - timers throttle lsa (OSPFv3) [1031](#)
 - timers throttle spf (OSPF) [1033](#)
 - timers throttle spf (OSPFv3) [1035](#)
 - To display the entries in a Mshow local policy [665](#)
 - topology [MPLS-225](#)
 - tos [1-22](#)
 - traceroute [FND-199](#)
 - traceroute mpls [MPLS-226](#)
 - traceroute6 [FND-200](#)
 - track [1-27, 1-132, 1-267](#)
 - track (VRRP) [1037](#)
 - track interface [1039](#)
 - track interface (VRRP) [1041](#)
 - track ip route [1043](#)
 - track ipv6 route [1045](#)
 - track list [1046](#)
 - track-adjacency-nexthop [1-119](#)
 - transmit-delay (OSPF virtual link) [1048](#)
 - transmit-delay (OSPFv3 virtual link) [1049](#)
 - transport email mail-server [693](#)
 - transport http proxy enable [695](#)
 - transport http proxy server [696](#)
 - transport http use-vrf [697](#)
 - transport udp [698](#)
 - trunk protocol enable [1153](#)
 - trustedCert [SEC-764](#)
 - tunnel destination [1-269](#)
 - tunnel mode [1-270](#)
 - tunnel path-mtu-discovery [1-271](#)
 - tunnel source [1-273](#)
 - tunnel ttl [1-275](#)
 - tunnel use-vrf [1-274](#)
 - type [-55](#)
-
- ## U
- udld [1-276](#)
 - udld aggressive [1-278](#)
 - udld message-time [1-280](#)
 - udld reset [1-281](#)

[udp-echo 1-3](#)
[udp-jitter 1-5](#)
[unsuppress-map 1050](#)
[update license FND-201](#)
[update-source loopback MPLS-232](#)
[use-vrf SEC-766](#)
[user-certdn-match SEC-769](#)
[user-pubkey-match SEC-771](#)
[user-switch-bind SEC-773](#)
[username SEC-775](#)
[userprofile SEC-780](#)

V

[vdc VDC-61](#)
[vdc combined-hostname VDC-63](#)
[vdc resource template VDC-64](#)
[vdc restart VDC-66](#)
[vdc suspend VDC-67](#)
[ve id MPLS-230](#)
[ve range MPLS-231](#)
[verify 700](#)
[verify-data 1-21](#)
[version 5 701](#)
[version 9 702](#)
[vfhrp delay 726](#)
[vlan 1-129](#)
[vlan \(global configuration mode\) 183](#)
[vlan access-map SEC-782](#)
[vlan configuration 185](#)
[vlan dot1q tag native 1-282](#)
[vlan filter SEC-784](#)
[vlan policy deny SEC-786](#)
[vlan-pruning enable 1-131](#)
[vpc 1-284](#)
[vpc domain 1-286](#)
[vpc orphan-ports suspend 1-288](#)
[vpc peer-link 1-289](#)
[vpn MPLS-232](#)

[vrf 704, 727, MPLS-233](#)
[vrf context 730, MPLS-234](#)
[vrf member 732, MPLS-235](#)
[vrf policy deny SEC-788](#)
[vrrp 733](#)
[vrrpv3 address-family 735](#)
[vrrs leader 736](#)
[vrrs pathway 737](#)
[vsan 1154](#)
[vsan database 1157](#)
[vtp domain 186](#)
[vtp file 187](#)
[vtp mode 188](#)
[vtp mode transparent 190](#)
[vtp password 191](#)
[vtp pruning 192](#)
[vtp version 193](#)

W

[weight 740](#)
[weighting 741](#)
[weighting track 743](#)
[where FND-203](#)
[write erase FND-204](#)
[wwn secondary-mac 1158](#)
[wwn vsan 1159](#)

X

[xml server max-session 708](#)
[xml server terminate session 709](#)
[xml server timeout 710](#)
[xml server validate 711](#)
[xmlin 712](#)

Z

zone clone [1161](#)
zone commit [1162](#)
zone compact [1163](#)
zone convert smart-zoning [1164](#)
zone copy [1165](#)
zone default-zone [1167](#)
zone merge-control restrict vsan [1168](#)
zone mode enhanced [1169](#)
zone name (configuration mode) [1170](#)
zone name (zone set configuration mode) [1172](#)
zone rename [1173](#)
zone rscn address-format port [1174](#)
zone smart-zoning enable [1175](#)
zoneset (configuration mode) [1176](#)
zoneset (EXEC mode) [1178](#)

