



FINAL REVIEW - CISCO CONFIDENTIAL

INDEX

A

aaa authorization network command [2-1](#)
access groups
 IP [2-76](#)
access mode [2-450](#)
access ports [2-450](#)
ACLs
 displaying [2-221](#)
 IP [2-76](#)
 on Layer 2 interfaces [2-76](#)
aggregate-port learner [2-180](#)
allowed VLANs [2-454](#)
archive download-sw command [2-3](#)
archive tar command [2-6](#)
archive upload-sw command [2-9](#)
arp (boot loader) command [A-2](#)
audience [xv](#)
autonegotiation of duplex mode [2-58](#)

B

BackboneFast, for STP [2-392](#)
boot (boot loader) command [A-3](#)
boot config-file command [2-11](#)
boot enable-break command [2-12](#)
boot helper command [2-13](#)
boot helper-config file command [2-14](#)
booting
 Cisco IOS image [2-17](#)
 displaying environment variables [2-225](#)
 interrupting [2-12](#)
 manually [2-15](#)

boot loader
 accessing [A-1](#)
 booting
 Cisco IOS image [A-3](#)
 helper image [2-13](#)
 directories
 creating [A-19](#)
 displaying a list of [A-8](#)
 removing [A-23](#)
 displaying
 available commands [A-13](#)
 memory heap utilization [A-14](#)
 version [A-30](#)
 environment variables
 described [A-24](#)
 displaying settings [A-24](#)
 location of [A-25](#)
 setting [A-24](#)
 unsetting [A-28](#)
 files
 copying [A-6](#)
 deleting [A-7](#)
 displaying a list of [A-8](#)
 displaying the contents of [A-5, A-20, A-27](#)
 renaming [A-21](#)
 file system
 formatting [A-11](#)
 initializing flash [A-10](#)
 running a consistency check [A-12](#)
 prompt [A-1](#)
 resetting the system [A-22](#)
boot manual command [2-15](#)
boot private-config-file command [2-16](#)

FINAL REVIEW - CISCO CONFIDENTIAL

boot system command [2-17](#)

BPDU filtering, for spanning tree [2-393, 2-427](#)

BPDU guard, for spanning tree [2-395, 2-427](#)

C

candidate switches

See clusters

cat (boot loader) command [A-5](#)

caution, description [xvi](#)

channel-group command [2-18](#)

channel-protocol command [2-21](#)

Cisco Network Assistant

See Network Assistant

class command [2-22](#)

class-map command [2-24](#)

class maps

creating [2-24](#)

defining the match criteria [2-134](#)

displaying [2-228](#)

class of service

See CoS

clear eap command [2-26](#)

clear errdisable interface [2-27](#)

clear lacp command [2-28](#)

clear logging onboard command [2-29](#)

clear mac address-table command [2-30](#)

clear pagp command [2-31](#)

clear spanning-tree counters command [2-32](#)

clear spanning-tree detected-protocols command [2-33](#)

clear vtp counters command [2-34](#)

cluster commander-address command [2-35](#)

cluster discovery hop-count command [2-37](#)

cluster enable command [2-38](#)

cluster holdtime command [2-40](#)

cluster member command [2-41](#)

cluster outside-interface command [2-43](#)

cluster requirements [xvi](#)

cluster run command [2-44](#)

clusters

adding candidates [2-41](#)

building manually [2-41](#)

communicating with

devices outside the cluster [2-43](#)

members by using Telnet [2-200](#)

debug messages, display [B-2](#)

displaying

candidate switches [2-231](#)

debug messages [B-2](#)

member switches [2-233](#)

status [2-229](#)

hop-count limit for extended discovery [2-37](#)

SNMP trap [2-383](#)

cluster timer command [2-45](#)

command modes defined [1-1](#)

command switch

See clusters

configuration, initial

See getting started guide and hardware installation guide

configuration files

password recovery disable considerations [A-1](#)

specifying the name [2-11, 2-16](#)

configuring multiple interfaces [2-71](#)

config-vlan mode

commands [2-474](#)

description [1-4](#)

entering [2-473](#)

summary [1-2](#)

conventions

command [xv](#)

for examples [xvi](#)

publication [xv](#)

text [xv](#)

copy (boot loader) command [A-6](#)

copy logging onboard command [2-46](#)

CoS

assigning default value to incoming packets [2-143](#)

FINAL REVIEW - CISCO CONFIDENTIAL

overriding the incoming value [2-143](#)
 CoS-to-DSCP map [2-147](#)
 CPU ASIC statistics, displaying [2-235](#)
 crashinfo files [2-65](#)

D

debug cluster command [B-2](#)
 debug dtp command [B-4](#)
 debug eap command [B-5](#)
 debug etherchannel command [B-6](#)
 debug fastethernet command [B-7](#)
 debug interface command [B-8](#)
 debug ip igmp filter command [B-9](#)
 debug ip igmp max-groups command [B-10](#)
 debug ip igmp snooping command [B-11](#)
 debug lacp command [B-12](#)
 debug matm command [B-13](#)
 debug matm move update command [B-14](#)
 debug monitor command [B-15](#)
 debug nvram command [B-16](#)
 debug pagp command [B-17](#)
 debug platform acl command [B-18](#)
 debug platform configuration command [B-23](#)
 debug platform cpu-queues command [B-20](#)
 debug platform etherchannel command [B-22](#)
 debug platform ip igmp snooping command [B-24](#)
 debug platform led command [B-26](#)
 debug platform matm command [B-27](#)
 debug platform messaging application command [B-28](#)
 debug platform phy command [B-29](#)
 debug platform pm command [B-31](#)
 debug platform port-asic command [B-33](#)
 debug platform qos-acl-tcam command [B-34](#)
 debug platform resource-manager command [B-35](#)
 debug platform snmp command [B-36](#)
 debug platform span command [B-37](#)
 debug platform supervisor-asic command [B-38](#)
 debug platform sw-bridge command [B-39](#)
 debug platform tcam-driver command [B-40](#)
 debug platform udd command [B-42](#)
 debug platform vlan command [B-43](#)
 debug pm command [B-44](#)
 debug qos command [B-46](#)
 debug spanning-tree backbonefast command [B-49](#)
 debug spanning-tree bpdu command [B-50](#)
 debug spanning-tree bpdu-opt command [B-51](#)
 debug spanning-tree command [B-47](#)
 debug spanning-tree mstp command [B-52](#)
 debug spanning-tree switch command [B-54](#)
 debug spanning-tree uplinkfast command [B-56](#)
 debug sw-vlan command [B-57](#)
 debug sw-vlan ifs command [B-59](#)
 debug sw-vlan notification command [B-60](#)
 debug sw-vlan vtp command [B-61](#)
 debug udd command [B-63](#)
 debug vqpc command [B-65](#)
 define interface-range command [2-48](#)
 delete (boot loader) command [A-7](#)
 delete command [2-50](#)
 detect mechanism, causes [2-59](#)
 device manager requirements [xvi](#)
 Digital Optical Monitoring
 see DoM
 dir (boot loader) command [A-8](#)
 directories, deleting [2-50](#)
 documentation, related [xvi](#)
 document conventions [xv](#)
 DoM
 displaying supported transceivers [2-287](#)
 domain name, VTP [2-478, 2-482](#)
 DSCP-to-CoS map [2-147](#)
 DSCP-to-DSCP-mutation map [2-147](#)
 DTP [2-451](#)
 DTP flap
 error detection for [2-59](#)
 error recovery timer [2-62](#)
 DTP negotiation [2-452](#)

FINAL REVIEW - CISCO CONFIDENTIAL

duplex command [2-57](#)

dynamic-access ports

 configuring [2-446](#)

dynamic auto VLAN membership mode [2-450](#)

dynamic desirable VLAN membership mode [2-450](#)

Dynamic Trunking Protocol

 See DTP

E

environment variables, displaying [2-225](#)

errdisable detect cause command [2-59](#)

errdisable detect cause small-frame command [2-61](#)

errdisable recovery cause small-frame [2-64](#)

errdisable recovery command [2-62](#)

error conditions, displaying [2-264](#)

error disable detection [2-59](#)

error-disabled interfaces, displaying [2-276](#)

EtherChannel

 assigning Ethernet interface to channel group [2-18](#)

 creating port-channel logical interface [2-69](#)

 debug EtherChannel/PAgP, display [B-6](#)

 debug platform-specific events, display [B-22](#)

 displaying [2-267](#)

 interface information, displaying [2-276](#)

 LACP

 clearing channel-group information [2-28, 2-29](#)

 debug messages, display [B-12](#)

 displaying [2-310](#)

 modes [2-18](#)

 port priority for hot-standby ports [2-117](#)

 restricting a protocol [2-21](#)

 system priority [2-119](#)

 load-distribution methods [2-191](#)

 PAgP

 aggregate-port learner [2-180](#)

 clearing channel-group information [2-31](#)

 debug messages, display [B-17](#)

 displaying [2-351](#)

error detection for [2-59](#)

error recovery timer [2-62](#)

learn method [2-180](#)

modes [2-18](#)

physical-port learner [2-180](#)

priority of interface for transmitted traffic [2-182](#)

Ethernet controller, internal register display [2-237, 2-245](#)

Ethernet Management port, debugging [B-7](#)

Ethernet statistics, collecting [2-205](#)

examples, conventions for [xvi](#)

exception crashinfo command [2-65, 2-68](#)

extended discovery of candidate switches [2-37](#)

extended-range VLANs

 and allowed VLAN list [2-454](#)

 and pruning-eligible list [2-454](#)

 configuring [2-473](#)

extended system ID for STP [2-401](#)

F

fallback profile command [2-66](#)

fallback profiles, displaying [2-270](#)

fan information, displaying [2-260](#)

file name, VTP [2-478](#)

files, deleting [2-50](#)

flash_init (boot loader) command [A-10](#)

flowcontrol command [2-66](#)

format (boot loader) command [A-11](#)

forwarding results, display [C-5](#)

frame forwarding information, displaying [C-5](#)

front-end controller counter and status information [C-7](#)

fsck (boot loader) command [A-12](#)

G

global configuration mode [1-2, 1-3](#)

FINAL REVIEW - CISCO CONFIDENTIAL

H

hardware ACL statistics [2-221](#)
 health monitoring diagnostic tests [2-51](#)
 help (boot loader) command [A-13](#)
 hierarchical policy maps [2-189](#)
 hop-count limit for clusters [2-37](#)
 host connection, port configuration [2-449](#)

I

IGMP filters
 applying [2-82](#)
 debug messages, display [B-9](#)
 IGMP groups, setting maximum [2-83](#)
 IGMP maximum groups, debugging [B-10](#)
 IGMP profiles
 creating [2-85](#)
 displaying [2-292](#)
 IGMP snooping
 adding ports as a static member of a group [2-99](#)
 displaying [2-293, 2-298, 2-300](#)
 enabling [2-87](#)
 enabling the configurable-leave timer [2-89](#)
 enabling the Immediate-Leave feature [2-98](#)
 flooding query count [2-95](#)
 interface topology change notification behavior [2-97](#)
 multicast table [2-296](#)
 querier [2-91](#)
 query solicitation [2-95](#)
 report suppression [2-93](#)
 switch topology change notification behavior [2-95](#)
 images
 See software images
 Immediate-Leave processing
 IGMP [2-98](#)
 IPv6 [2-115](#)
 initial configuration

See getting started guide and hardware installation guide

interface configuration mode [1-2, 1-4](#)
 interface port-channel command [2-69](#)
 interface range command [2-71](#)
 interface-range macros [2-48](#)
 interfaces
 assigning Ethernet interface to channel group [2-18](#)
 configuring [2-57](#)
 configuring multiple [2-71](#)
 creating port-channel logical [2-69](#)
 debug messages, display [B-8](#)
 disabling [2-379](#)
 displaying the MAC address table [2-329](#)
 restarting [2-379](#)
 interface speed, configuring [2-438](#)
 interface vlan command [2-74](#)
 internal registers, displaying [2-237, 2-245, 2-247](#)
 Internet Group Management Protocol
 See IGMP
 invalid GBIC
 error detection for [2-59](#)
 error recovery timer [2-62](#)
 ip access-group command [2-76](#)
 ip address command [2-78](#)
 IP addresses, setting [2-78](#)
 ip admission command [2-80](#)
 ip admission name proxy http command [2-81](#)
 ip igmp filter command [2-82](#)
 ip igmp max-groups command [2-83](#)
 ip igmp profile command [2-85](#)
 ip igmp snooping command [2-87](#)
 ip igmp snooping last-member-query-interval command [2-89](#)
 ip igmp snooping querier command [2-91](#)
 ip igmp snooping report-suppression command [2-93](#)
 ip igmp snooping ten command [2-95](#)
 ip igmp snooping ten flood command [2-97](#)
 ip igmp snooping vlan immediate-leave command [2-98](#)

FINAL REVIEW - CISCO CONFIDENTIAL

ip igmp snooping vlan static command [2-99](#)

IP-precedence-to-DSCP map [2-147](#)

ip ssh command [2-101](#)

ipv6 mld snooping command [2-103](#)

ipv6 mld snooping last-listener-query count command [2-105](#)

ipv6 mld snooping last-listener-query-interval command [2-107](#)

ipv6 mld snooping listener-message-suppression command [2-109](#)

ipv6 mld snooping robustness-variable command [2-111](#)

ipv6 mld snooping tcn command [2-113](#)

ipv6 mld snooping vlan command [2-115](#)

IPv6 SDM template [2-206](#)

J

jumbo frames

See MTU

L

lACP port-priority command [2-117](#)

lACP system-priority command [2-119](#)

Layer 2 protocol-tunnel

error detection for [2-59](#)

error recovery timer [2-62](#)

Layer 2 traceroute

IP addresses [2-464](#)

MAC addresses [2-461](#)

line configuration mode [1-2, 1-4](#)

link flap

error detection for [2-59](#)

error recovery timer [2-62](#)

link state group command [2-121](#)

link state track command [2-123](#)

load-distribution methods for EtherChannel [2-191](#)

location (global configuration) command [2-124](#)

location (interface configuration) command [2-126](#)

logging file command [2-128](#)

logical interface [2-69](#)

loopback error

detection for [2-59](#)

recovery timer [2-62](#)

loop guard, for spanning tree [2-403, 2-407](#)

M

MAC addresses

displaying

aging time [2-323](#)

all [2-321](#)

dynamic [2-327](#)

number of addresses in a VLAN [2-325](#)

per interface [2-329](#)

per VLAN [2-333](#)

static [2-331](#)

static and dynamic entries [2-319](#)

dynamic

aging time [2-130](#)

deleting [2-30](#)

displaying [2-327](#)

static

adding and removing [2-131](#)

displaying [2-331](#)

dropping on an interface [2-132](#)

tables [2-321](#)

mac address-table aging-time command [2-130](#)

mac address-table static command [2-131](#)

mac address-table static drop command [2-132](#)

MAC frames

See MTU

macros

interface range [2-48, 2-71](#)

manual

audience [xv](#)

purpose of [xv](#)

maps

FINAL REVIEW - CISCO CONFIDENTIAL

- QoS
 - defining [2-147](#)
 - displaying [2-343](#)
- match (class-map configuration) command [2-134](#)
- maximum transmission unit
 - See MTU
- mdix auto command [2-137](#)
- member switches
 - See clusters
- memory (boot loader) command [A-14](#)
- mgmt_clr (boot loader) command [A-16](#)
- mgmt_init (boot loader) command [A-17, A-18](#)
- mkdir (boot loader) command [A-19](#)
- MLD snooping
 - configuring [2-109, 2-111](#)
 - configuring queries [2-105, 2-107](#)
 - configuring topology change notification [2-113](#)
 - displaying [2-302, 2-304, 2-306, 2-308](#)
 - enabling [2-103](#)
 - enabling on a VLAN [2-115](#)
- mls qos aggregate-policer command [2-141](#)
- mls qos command [2-139](#)
- mls qos cos command [2-143](#)
- mls qos dscp-mutation command [2-145](#)
- mls qos map command [2-147](#)
- mls qos queue-set output buffers command [2-151](#)
- mls qos queue-set output threshold command [2-153](#)
- mls qos rewrite ip dscp command [2-155](#)
- mls qos srr-queue input bandwidth command [2-157](#)
- mls qos srr-queue input buffers command [2-159](#)
- mls qos-srr-queue input cos-map command [2-161](#)
- mls qos srr-queue input dscp-map command [2-163](#)
- mls qos srr-queue input priority-queue command [2-165](#)
- mls qos srr-queue input threshold command [2-167](#)
- mls qos-srr-queue output cos-map command [2-169](#)
- mls qos srr-queue output dscp-map command [2-171](#)
- mls qos trust command [2-173](#)
- mls qos vlan-based command [2-175](#)
- Mode button, and password recovery [2-209](#)
- modes, commands [1-1](#)
- monitor session command [2-176](#)
- more (boot loader) command [A-20](#)
- MSTP
 - displaying [2-360](#)
 - interoperability [2-33](#)
 - link type [2-405](#)
 - MST region
 - aborting changes [2-411](#)
 - applying changes [2-411](#)
 - configuration name [2-411](#)
 - configuration revision number [2-411](#)
 - current or pending display [2-411](#)
 - displaying [2-360](#)
 - MST configuration mode [2-411](#)
 - VLANs-to-instance mapping [2-411](#)
 - path cost [2-413](#)
 - protocol mode [2-409](#)
 - restart protocol migration process [2-33](#)
 - root port
 - loop guard [2-403](#)
 - preventing from becoming designated [2-403](#)
 - restricting which can be root [2-403](#)
 - root guard [2-403](#)
 - root switch
 - affects of extended system ID [2-401](#)
 - hello-time [2-416, 2-423](#)
 - interval between BDPU messages [2-417](#)
 - interval between hello BPDU messages [2-416, 2-423](#)
 - max-age [2-417](#)
 - maximum hop count before discarding BPDU [2-418](#)
 - port priority for selection of [2-419](#)
 - primary or secondary [2-423](#)
 - switch priority [2-422](#)
 - state changes
 - blocking to forwarding state [2-430](#)
 - enabling BPDU filtering [2-393, 2-427](#)

FINAL REVIEW - CISCO CONFIDENTIAL

enabling BPDU guard [2-395, 2-427](#)
 enabling Port Fast [2-427, 2-430](#)
 forward-delay time [2-415](#)
 length of listening and learning states [2-415](#)
 rapid transition to forwarding [2-405](#)
 shutting down Port Fast-enabled ports [2-427](#)
 state information display [2-359](#)

MTU

configuring size [2-459](#)
 displaying global setting [2-365](#)
 MAC [2-459](#)

Multicast Listener Discovery

See MLD

Multicast Listener Discovery

See MLD

multicast router ports, IPv6 [2-115](#)

Multiple Spanning Tree Protocol

See MSTP

N

native VLANs [2-454](#)
 Network Assistant requirements [xvi](#)
 nonegotiate
 DTP messaging [2-452](#)
 speed [2-438](#)
 normal-range VLANs [2-473](#)
 note, description [xvi](#)
 no vlan command [2-473](#)

O

online diagnostics

configuring health monitoring diagnostic tests [2-51](#)
 displaying
 configured boot-up coverage level [2-251](#)
 current scheduled tasks [2-251](#)
 event logs [2-251](#)

supported test suites [2-251](#)

test ID [2-251](#)

test results [2-251](#)

test statistics [2-251](#)

enabling

scheduling [2-53](#)

syslog messages [2-51](#)

global configuration mode

clearing health monitoring diagnostic test schedule [2-51](#)

clearing test-based testing schedule [2-53](#)

setting health monitoring diagnostic testing [2-51](#)

setting test-based testing [2-53](#)

setting up health monitoring diagnostic test schedule [2-51](#)

setting up test-based testing [2-53](#)

removing scheduling [2-53](#)

scheduled switchover

disabling [2-53](#)

enabling [2-53](#)

setting test interval [2-53](#)

specifying health monitoring diagnostic tests [2-51](#)

starting testing [2-55](#)

P

PAGP

See EtherChannel

pagp learn-method command [2-180](#)

pagp port-priority command [2-182](#)

password, VTP [2-478, 2-482](#)

password-recovery mechanism, enabling and disabling [2-209](#)

per-VLAN spanning-tree plus

See STP

physical-port learner [2-180](#)

PID, displaying [2-291](#)

police aggregate command [2-186](#)

police command [2-184](#)

FINAL REVIEW - CISCO CONFIDENTIAL

- policed-DSCP map [2-147](#)
- policy-map command [2-188](#)
- policy maps
 - applying to an interface [2-211, 2-216](#)
 - creating [2-188](#)
 - displaying [2-353](#)
 - hierarchical [2-189](#)
 - policers
 - displaying [2-336](#)
 - for a single class [2-184](#)
 - for multiple classes [2-141, 2-186](#)
 - policed-DSCP map [2-147](#)
 - traffic classification
 - defining the class [2-22](#)
 - defining trust states [2-466](#)
 - setting DSCP or IP precedence values [2-214](#)
- Port Aggregation Protocol
 - See EtherChannel
- port-channel load-balance command [2-191](#)
- Port Fast, for spanning tree [2-430](#)
- port ranges, defining [2-46, 2-48](#)
- ports, debugging [B-44](#)
- port trust states for QoS [2-173](#)
- power information, displaying [2-260](#)
- priority-queue command [2-193](#)
- privileged EXEC mode [1-2, 1-3](#)
- product identification information, displaying [2-291](#)
- pruning
 - VLANs [2-454](#)
 - VTP
 - displaying interface information [2-276](#)
 - enabling [2-478, 2-482](#)
- pruning-eligible VLAN list [2-455](#)
- PVST+
 - See STP
- class maps
 - creating [2-24](#)
 - defining the match criteria [2-134](#)
 - displaying [2-228](#)
- defining the CoS value for an incoming packet [2-143](#)
- displaying configuration information [2-335](#)
- DSCP transparency [2-155](#)
- DSCP trusted ports
 - applying DSCP-to-DSCP-mutation map to [2-145](#)
 - defining DSCP-to-DSCP-mutation map [2-147](#)
- egress queues
 - allocating buffers [2-151](#)
 - defining the CoS output queue threshold map [2-169](#)
 - defining the DSCP output queue threshold map [2-171](#)
 - displaying buffer allocations [2-339](#)
 - displaying CoS output queue threshold map [2-343](#)
 - displaying DSCP output queue threshold map [2-343](#)
 - displaying queueing strategy [2-339](#)
 - displaying queue-set settings [2-346](#)
 - enabling bandwidth shaping and scheduling [2-442](#)
 - enabling bandwidth sharing and scheduling [2-444](#)
 - limiting the maximum output on a port [2-440](#)
 - mapping a port to a queue-set [2-195](#)
 - mapping CoS values to a queue and threshold [2-169](#)
 - mapping DSCP values to a queue and threshold [2-171](#)
 - setting maximum and reserved memory allocations [2-153](#)
 - setting WTD thresholds [2-153](#)
- enabling [2-139](#)
- ingress queues
 - allocating buffers [2-159](#)
 - assigning SRR scheduling weights [2-157](#)
 - defining the CoS input queue threshold map [2-161](#)

Q

QoS

FINAL REVIEW - CISCO CONFIDENTIAL

defining the DSCP input queue threshold map [2-163](#)

displaying buffer allocations [2-339](#)

displaying CoS input queue threshold map [2-343](#)

displaying DSCP input queue threshold map [2-343](#)

displaying queueing strategy [2-339](#)

displaying settings for [2-337](#)

enabling the priority queue [2-165](#)

mapping CoS values to a queue and threshold [2-161](#)

mapping DSCP values to a queue and threshold [2-163](#)

setting WTD thresholds [2-167](#)

maps

- defining [2-147, 2-161, 2-163, 2-169, 2-171](#)
- displaying [2-343](#)

policy maps

- applying an aggregate policer [2-186](#)
- applying to an interface [2-211, 2-216](#)
- creating [2-188](#)
- defining policers [2-141, 2-184](#)
- displaying policers [2-336](#)
- displaying policy maps [2-353](#)
- hierarchical [2-189](#)
- policed-DSCP map [2-147](#)
- setting DSCP or IP precedence values [2-214](#)
- traffic classifications [2-22](#)
- trust states [2-466](#)

port trust states [2-173](#)

queues, enabling the expedite [2-193](#)

statistics

- in-profile and out-of-profile packets [2-339](#)
- packets enqueued or dropped [2-339](#)
- sent and received CoS values [2-339](#)
- sent and received DSCP values [2-339](#)

VLAN-based [2-175](#)

quality of service

- See QoS

queue-set command [2-195](#)

R

radius-server dead-criteria command [2-196](#)

radius-server host command [2-198](#)

rapid per-VLAN spanning-tree plus

- See STP

rapid PVST+

- See STP

rcommand command [2-200](#)

receiving flow-control packets [2-66](#)

recovery mechanism

- causes [2-62](#)
- display [2-27, 2-262, 2-265](#)
- timer interval [2-62](#)

reload command [2-202](#)

remote-span command [2-203](#)

Remote Switched Port Analyzer

- See RSPAN

rename (boot loader) command [A-21](#)

requirements

- cluster [xvi](#)
- device manager [xvi](#)
- Network Assistant [xvi](#)

reset (boot loader) command [A-22](#)

resource templates, displaying [2-355](#)

rmdir (boot loader) command [A-23](#)

rmon collection stats command [2-205](#)

root guard, for spanning tree [2-403](#)

routing frames

- See MTU

RSPAN

- configuring [2-176](#)
- displaying [2-349](#)
- filter RSPAN traffic [2-176](#)
- remote-span command [2-203](#)
- sessions

 - add interfaces to [2-176](#)
 - displaying [2-349](#)
 - start new [2-176](#)

FINAL REVIEW - CISCO CONFIDENTIAL

S

scheduled switchover

disabling [2-53](#)

enabling [2-53](#)

sdm prefer command [2-206](#)

SDM templates

allowed resources [2-207](#)

displaying [2-355](#)

dual IPv4 and IPv6 [2-206](#)

sending flow-control packets [2-66](#)

service password-recovery command [2-209](#)

service-policy command [2-211](#)

set (boot loader) command [A-24](#)

set command [2-214](#)

setup command [2-216](#)

setup express command [2-219](#)

show access-lists command [2-221](#)

show archive status command [2-224](#)

show boot command [2-225](#)

show class-map command [2-228](#)

show cluster candidates command [2-231](#)

show cluster command [2-229](#)

show cluster members command [2-233](#)

show controllers cpu-interface command [2-235](#)

show controllers ethernet-controller command [2-237](#)

show controllers ethernet-controller fastethernet command [2-245](#)

show controllers tcam command [2-247](#)

show controller utilization command [2-249](#)

show dtp [2-255](#)

show eap command [2-257](#)

show env command [2-260](#)

show errdisable detect command [2-262](#)

show errdisable flap-values command [2-264](#)

show errdisable recovery command [2-265](#)

show etherchannel command [2-267](#)

show fallback profile command [2-270](#)

show flowcontrol command [2-272](#)

show idprom command [2-274](#)

show interfaces command [2-276](#)

show interfaces counters command [2-285](#)

show interface transceivers command [2-287](#)

show inventory command [2-291](#)

show ip igmp profile command [2-292](#)

show ip igmp snooping address command [2-304](#)

show ip igmp snooping command [2-293, 2-302](#)

show ip igmp snooping groups command [2-296](#)

show ip igmp snooping mrouter command [2-298, 2-306](#)

show ip igmp snooping querier command [2-300, 2-308](#)

show lacp command [2-310](#)

show link state group command [2-314](#)

show location [2-316](#)

show location command [2-316](#)

show mac address-table address command [2-321](#)

show mac address-table aging time command [2-323](#)

show mac address-table command [2-319](#)

show mac address-table count command [2-325](#)

show mac address-table dynamic command [2-327](#)

show mac address-table interface command [2-329](#)

show mac address-table notification command [B-14](#)

show mac address-table static command [2-331](#)

show mac address-table vlan command [2-333](#)

show mls qos aggregate-policer command [2-336](#)

show mls qos command [2-335](#)

show mls qos input-queue command [2-337](#)

show mls qos interface command [2-339](#)

show mls qos maps command [2-343](#)

show mls qos queue-set command [2-346](#)

show mls qos vlan command [2-348](#)

show monitor command [2-349](#)

show pagp command [2-351](#)

show platform acl command [C-2](#)

show platform dl command [C-3](#)

show platform etherchannel command [C-4](#)

show platform forward command [C-5](#)

show platform frontend-controller command [C-7](#)

show platform igmp snooping command [C-8](#)

FINAL REVIEW - CISCO CONFIDENTIAL

- show platform layer4op command [C-10](#)
- show platform mac-address-table command [C-11](#)
- show platform messaging command [C-12](#)
- show platform monitor command [C-13](#)
- show platform pm command [C-14](#)
- show platform port-asic command [C-15](#)
- show platform qos command [C-20](#)
- show platform resource-manager command [C-21](#)
- show platform snmp counters command [C-23](#)
- show platform spanning-tree synchronization command [C-24](#)
- show platform stp-instance command [C-25](#)
- show platform tcam command [C-26](#)
- show platform vlan command [C-28](#)
- show policy-map command [2-353](#)
- show sdm prefer command [2-355](#)
- show setup express command [2-358](#)
- show spanning-tree command [2-359](#)
- show system mtu command [2-365](#)
- show trust command [2-466](#)
- show uddl command [2-366](#)
- show version command [2-369](#)
- show vlan command [2-371](#)
- show vlan command, fields [2-373](#)
- show vtp command [2-375](#)
- shutdown command [2-379](#)
- shutdown vlan command [2-380](#)
- small-frame violation rate command [2-381](#)
- SNMP host, specifying [2-386](#)
- SNMP informs, enabling the sending of [2-383](#)
- snmp-server enable traps command [2-383](#)
- snmp-server host command [2-386](#)
- snmp trap mac-notification command [2-390](#)
- SNMP traps
 - enabling MAC address notification trap [2-390](#)
 - enabling the sending of [2-383](#)
- software images
 - deleting [2-50](#)
 - downloading [2-3](#)
 - upgrading [2-3](#)
 - uploading [2-9](#)
- software version, displaying [2-369](#)
- SPAN
 - configuring [2-176](#)
 - debug messages, display [B-15](#)
 - displaying [2-349](#)
 - filter SPAN traffic [2-176](#)
 - sessions
 - add interfaces to [2-176](#)
 - displaying [2-349](#)
 - start new [2-176](#)
- spanning-tree backbonefast command [2-392](#)
- spanning-tree bpduguard command [2-393](#)
- spanning-tree bpduguard command [2-395](#)
- spanning-tree cost command [2-397](#)
- spanning-tree etherchannel command [2-399](#)
- spanning-tree extend system-id command [2-401](#)
- spanning-tree guard command [2-403](#)
- spanning-tree link-type command [2-405](#)
- spanning-tree loopguard default command [2-407](#)
- spanning-tree mode command [2-409](#)
- spanning-tree mst configuration command [2-411](#)
- spanning-tree mst cost command [2-413](#)
- spanning-tree mst forward-time command [2-415](#)
- spanning-tree mst hello-time command [2-416](#)
- spanning-tree mst max-age command [2-417](#)
- spanning-tree mst max-hops command [2-418](#)
- spanning-tree mst port-priority command [2-419](#)
- spanning-tree mst pre-standard command [2-421](#)
- spanning-tree mst priority command [2-422](#)
- spanning-tree mst root command [2-423](#)
- spanning-tree portfast (global configuration) command [2-427](#)
- spanning-tree portfast (interface configuration) command [2-430](#)
- spanning-tree port-priority command [2-425](#)
- Spanning Tree Protocol
 - See STP

FINAL REVIEW - CISCO CONFIDENTIAL

- spanning-tree transmit hold-count command [2-432](#)
 - spanning-tree uplinkfast command [2-433](#)
 - spanning-tree vlan command [2-435](#)
 - speed command [2-438](#)
 - srr-queue bandwidth limit command [2-440](#)
 - srr-queue bandwidth shape command [2-442](#)
 - srr-queue bandwidth share command [2-444](#)
 - SSH, configuring version [2-101](#)
 - static-access ports, configuring [2-446](#)
 - statistics, Ethernet group [2-205](#)
 - STP
 - BackboneFast [2-392](#)
 - counters, clearing [2-32](#)
 - debug messages, display
 - BackboneFast events [B-49](#)
 - MSTP [B-52](#)
 - optimized BPDUs handling [B-51](#)
 - spanning-tree activity [B-47](#)
 - switch shim [B-54](#)
 - transmitted and received BPDUs [B-50](#)
 - UplinkFast [B-56](#)
 - detection of indirect link failures [2-392](#)
 - EtherChannel misconfiguration [2-399](#)
 - extended system ID [2-401](#)
 - path cost [2-397](#)
 - protocol modes [2-409](#)
 - root port
 - accelerating choice of new [2-433](#)
 - loop guard [2-403](#)
 - preventing from becoming designated [2-403](#)
 - restricting which can be root [2-403](#)
 - root guard [2-403](#)
 - UplinkFast [2-433](#)
 - root switch
 - affects of extended system ID [2-401, 2-436](#)
 - hello-time [2-435](#)
 - interval between BDPU messages [2-435](#)
 - interval between hello BPDU messages [2-435](#)
 - max-age [2-435](#)
 - port priority for selection of [2-425](#)
 - primary or secondary [2-435](#)
 - switch priority [2-435](#)
 - state changes
 - blocking to forwarding state [2-430](#)
 - enabling BPDU filtering [2-393, 2-427](#)
 - enabling BPDU guard [2-395, 2-427](#)
 - enabling Port Fast [2-427, 2-430](#)
 - enabling timer to recover from error state [2-62](#)
 - forward-delay time [2-435](#)
 - length of listening and learning states [2-435](#)
 - shutting down Port Fast-enabled ports [2-427](#)
 - state information display [2-359](#)
 - VLAN options [2-422, 2-435](#)
 - SVIs, creating [2-74](#)
 - SVI status calculation [2-447](#)
 - Switched Port Analyzer
 - See SPAN
 - switchport access command [2-446](#)
 - switchport autostate exclude command [2-447](#)
 - switchport host command [2-449](#)
 - switchport mode command [2-450](#)
 - switchport nonegotiate command [2-452](#)
 - switchports, displaying [2-276](#)
 - switchport trunk command [2-454](#)
 - system env temperature threshold yellow command [2-457](#)
 - system message logging, save message to flash [2-128](#)
 - system mtu command [2-459](#)
 - system resource templates [2-206](#)
-
- ## T
- tar files, creating, listing, and extracting [2-6](#)
 - Telnet, using to communicate to cluster switches [2-200](#)
 - temperature information, displaying [2-260](#)
 - templates, system resources [2-206](#)
 - traceroute mac command [2-461](#)
 - traceroute mac ip command [2-464](#)
 - trunking, VLAN mode [2-450](#)

FINAL REVIEW - CISCO CONFIDENTIAL

trunk mode [2-450](#)
 trunk ports [2-450](#)
 trunks, to non-DTP device [2-451](#)
 trusted port states for QoS [2-173](#)
 type (boot loader) command [A-27](#)

U

UDLD

aggressive mode [2-468, 2-470](#)
 debug messages, display [B-63](#)
 enable globally [2-468](#)
 enable per interface [2-470](#)
 error recovery timer [2-62](#)
 message timer [2-468](#)
 normal mode [2-468, 2-470](#)
 reset a shutdown interface [2-472](#)
 status [2-366](#)

udld command [2-468](#)

udld port command [2-470](#)

udld reset command [2-472](#)

UniDirectional Link Detection

See UDLD

unset (boot loader) command [A-28](#)

upgrading

downloading software images [2-3](#)
 software images, monitoring status of [2-224](#)

upgrading information

See release notes

UplinkFast, for STP [2-433](#)

user EXEC mode [1-2](#)

V

version (boot loader) command [A-30](#)

vlan (global configuration) command [2-473](#)

VLAN-based QoS [2-175](#)

VLAN configuration

rules [2-476](#)

saving [2-473](#)

VLAN configuration mode

commands

VTP [2-482](#)

VLAN ID range [2-473](#)

VLANs

adding [2-473](#)

configuring [2-473](#)

debug messages, display

ISL [B-60](#)

VLAN IOS file system error tests [B-59](#)

VLAN manager activity [B-57](#)

VTP [B-61](#)

displaying configurations [2-371](#)

extended-range [2-473](#)

MAC addresses

displaying [2-333](#)

number of [2-325](#)

media types [2-475](#)

normal-range [2-473](#)

restarting [2-380](#)

saving the configuration [2-473](#)

shutting down [2-380](#)

SNMP traps for VTP [2-384, 2-387](#)

suspending [2-380](#)

VLAN Trunking Protocol

See VTP

VTP

changing characteristics [2-478](#)

clearing pruning counters [2-34](#)

configuring

domain name [2-478, 2-482](#)

file name [2-478](#)

mode [2-478, 2-482](#)

password [2-478, 2-482](#)

counters display fields [2-376](#)

displaying information [2-375](#)

enabling

FINAL REVIEW - CISCO CONFIDENTIAL

pruning [2-478, 2-482](#)

Version 2 [2-478, 2-482](#)

mode [2-478, 2-482](#)

pruning [2-478, 2-482](#)

saving the configuration [2-473](#)

statistics [2-375](#)

status [2-375](#)

status display fields [2-377](#)

vtp (global configuration) command [2-478](#)

vtp (VLAN configuration) command [2-482](#)

FINAL REVIEW - CISCO CONFIDENTIAL