



INDEX

A

- aaa authorization network command [2-1](#)
- access groups
 - IP [2-74](#)
- access mode [2-396](#)
- access ports [2-396](#)
- ACLs
 - displaying [2-177](#)
 - IP [2-74](#)
 - on Layer 2 interfaces [2-74](#)
- aggregate-port learner [2-153](#)
- allowed VLANs [2-400](#)
- archive download-sw command [2-3](#)
- archive tar command [2-6](#)
- archive upload-sw command [2-9](#)
- arp (boot loader) command [A-2](#)
- autonegotiation of duplex mode [2-56](#)

B

- BackboneFast, for STP [2-338](#)
- boot (boot loader) command [A-3](#)
- boot config-file command [2-11](#)
- boot enable-break command [2-12](#)
- boot helper command [2-13](#)
- boot helper-config file command [2-14](#)
- booting
 - Cisco IOS image [2-17](#)
 - displaying environment variables [2-181](#)
 - interrupting [2-12](#)
 - manually [2-15](#)
- boot loader

- accessing [A-1](#)
- booting
 - Cisco IOS image [A-3](#)
 - helper image [2-13](#)
- directories
 - creating [A-19](#)
 - displaying a list of [A-8](#)
 - removing [A-23](#)
- displaying
 - available commands [A-13](#)
 - memory heap utilization [A-14](#)
 - version [A-30](#)
- environment variables
 - described [A-24](#)
 - displaying settings [A-24](#)
 - location of [A-25](#)
 - setting [A-24](#)
 - unsetting [A-28](#)
- files
 - copying [A-6](#)
 - deleting [A-7](#)
 - displaying a list of [A-8](#)
 - displaying the contents of [A-5, A-20, A-27](#)
 - renaming [A-21](#)
- file system
 - formatting [A-11](#)
 - initializing flash [A-10](#)
 - running a consistency check [A-12](#)
- prompt [A-1](#)
- resetting the system [A-22](#)
- boot manual command [2-15](#)
- boot private-config-file command [2-16](#)
- boot system command [2-17](#)

BPDU filtering, for spanning tree [2-339, 2-373](#)

BPDU guard, for spanning tree [2-341, 2-373](#)

C

candidate switches

See clusters

cat (boot loader) command [A-5](#)

channel-group command [2-18](#)

channel-protocol command [2-21](#)

class-map command [2-22](#)

class maps

creating [2-22](#)

defining the match criteria [2-132](#)

displaying [2-184](#)

class of service

See CoS

clear eap command [2-24](#)

clear errdisable interface [2-25](#)

clear lacp command [2-26](#)

clear logging onboard command [2-27](#)

clear mac address-table command [2-28](#)

clear pagp command [2-29](#)

clear spanning-tree counters command [2-30](#)

clear spanning-tree detected-protocols command [2-31](#)

clear vtp counters command [2-32](#)

cluster commander-address command [2-33](#)

cluster discovery hop-count command [2-35](#)

cluster enable command [2-36](#)

cluster holdtime command [2-38](#)

cluster member command [2-39](#)

cluster outside-interface command [2-41](#)

cluster run command [2-42](#)

clusters

adding candidates [2-39](#)

building manually [2-39](#)

communicating with

devices outside the cluster [2-41](#)

members by using Telnet [2-165](#)

debug messages, display [B-2](#)

displaying

candidate switches [2-187](#)

debug messages [B-2](#)

member switches [2-189](#)

status [2-185](#)

hop-count limit for extended discovery [2-35](#)

SNMP trap [2-329](#)

cluster timer command [2-43](#)

command modes defined [1-1](#)

command switch

See clusters

configuration files

password recovery disable considerations [A-1](#)

specifying the name [2-11, 2-16](#)

configuring multiple interfaces [2-69](#)

config-vlan mode

commands [2-418](#)

description [1-4](#)

entering [2-417](#)

summary [1-2](#)

copy (boot loader) command [A-6](#)

copy logging onboard command [2-44](#)

CoS

assigning default value to incoming packets [2-140](#)

overriding the incoming value [2-140](#)

CPU ASIC statistics, displaying [2-191](#)

crashinfo files [2-63](#)

D

debug cluster command [B-2](#)

debug dtp command [B-4](#)

debug eap command [B-5](#)

debug etherchannel command [B-6](#)

debug fastethernet command [B-7](#)

debug interface command [B-8](#)

debug ip igmp filter command [B-9](#)

debug ip igmp max-groups command [B-10](#)

debug ip igmp snooping command [B-11](#)
 debug lacp command [B-12](#)
 debug matm command [B-13](#)
 debug matm move update command [B-14](#)
 debug monitor command [B-15](#)
 debug nvram command [B-16](#)
 debug pagp command [B-17](#)
 debug platform acl command [B-18](#)
 debug platform configuration command [B-23](#)
 debug platform cpu-queues command [B-20](#)
 debug platform etherchannel command [B-22](#)
 debug platform ip igmp snooping command [B-24](#)
 debug platform led command [B-26](#)
 debug platform matm command [B-27](#)
 debug platform messaging application command [B-28](#)
 debug platform phy command [B-29](#)
 debug platform pm command [B-31](#)
 debug platform port-asic command [B-33](#)
 debug platform qos-acl-tcam command [B-34](#)
 debug platform resource-manager command [B-35](#)
 debug platform snmp command [B-36](#)
 debug platform span command [B-37](#)
 debug platform supervisor-asic command [B-38](#)
 debug platform sw-bridge command [B-39](#)
 debug platform tcam-driver command [B-40](#)
 debug platform uddl command [B-42](#)
 debug platform vlan command [B-43](#)
 debug pm command [B-44](#)
 debug qos command [B-46](#)
 debug spanning-tree backbonefast command [B-49](#)
 debug spanning-tree bpdu command [B-50](#)
 debug spanning-tree bpdu-opt command [B-51](#)
 debug spanning-tree command [B-47](#)
 debug spanning-tree mstp command [B-52](#)
 debug spanning-tree switch command [B-54](#)
 debug spanning-tree uplinkfast command [B-56](#)
 debug sw-vlan command [B-57](#)
 debug sw-vlan ifs command [B-59](#)
 debug sw-vlan notification command [B-60](#)

debug sw-vlan vtp command [B-62](#)
 debug uddl command [B-64](#)
 debug vqpc command [B-66](#)
 define interface-range command [2-46](#)
 delete (boot loader) command [A-7](#)
 delete command [2-48](#)
 detect mechanism, causes [2-57](#)
 Digital Optical Monitoring
 see DoM
 dir (boot loader) command [A-8](#)
 directories, deleting [2-48](#)
 DoM
 displaying supported transceivers [2-243](#)
 domain name, VTP [2-422](#), [2-426](#)
 DTP [2-397](#)
 DTP flap
 error detection for [2-57](#)
 error recovery timer [2-60](#)
 DTP negotiation [2-398](#)
 duplex command [2-55](#)
 dynamic-access ports
 configuring [2-392](#)
 dynamic auto VLAN membership mode [2-396](#)
 dynamic desirable VLAN membership mode [2-396](#)
 Dynamic Trunking Protocol
 See DTP

E

environment variables, displaying [2-181](#)
 errdisable detect cause command [2-57](#)
 errdisable detect cause small-frame command [2-59](#)
 errdisable recovery cause small-frame [2-62](#)
 errdisable recovery command [2-60](#)
 error conditions, displaying [2-220](#)
 error disable detection [2-57](#)
 error-disabled interfaces, displaying [2-232](#)
 EtherChannel
 assigning Ethernet interface to channel group [2-18](#)

creating port-channel logical interface [2-67](#)
 debug EtherChannel/PAGP, display [B-6](#)
 debug platform-specific events, display [B-22](#)
 displaying [2-223](#)
 interface information, displaying [2-232](#)
 LACP
 clearing channel-group information [2-26, 2-27](#)
 debug messages, display [B-12](#)
 displaying [2-266](#)
 modes [2-18](#)
 port priority for hot-standby ports [2-115](#)
 restricting a protocol [2-21](#)
 system priority [2-117](#)
 load-distribution methods [2-157](#)
 PAGP
 aggregate-port learner [2-153](#)
 clearing channel-group information [2-29](#)
 debug messages, display [B-17](#)
 displaying [2-301](#)
 error detection for [2-57](#)
 error recovery timer [2-60](#)
 learn method [2-153](#)
 modes [2-18](#)
 physical-port learner [2-153](#)
 priority of interface for transmitted traffic [2-155](#)
 Ethernet controller, internal register display [2-193, 2-201](#)
 Ethernet Management port, debugging [B-7](#)
 Ethernet statistics, collecting [2-169](#)
 exception crashinfo command [2-63, 2-66](#)
 extended discovery of candidate switches [2-35](#)
 extended-range VLANs
 and allowed VLAN list [2-400](#)
 and pruning-eligible list [2-400](#)
 configuring [2-417](#)
 extended system ID for STP [2-347](#)

F

fallback profile command [2-64](#)

fallback profiles, displaying [2-226](#)
 fan information, displaying [2-216](#)
 file name, VTP [2-422](#)
 files, deleting [2-48](#)
 flash_init (boot loader) command [A-10](#)
 flowcontrol command [2-64](#)
 format (boot loader) command [A-11](#)
 forwarding results, display [C-5](#)
 frame forwarding information, displaying [C-5](#)
 front-end controller counter and status information [C-7](#)
 fsck (boot loader) command [A-12](#)

G

global configuration mode [1-2, 1-3](#)

H

hardware ACL statistics [2-177](#)
 health monitoring diagnostic tests [2-49](#)
 help (boot loader) command [A-13](#)
 hop-count limit for clusters [2-35](#)
 host connection, port configuration [2-395](#)

I

IGMP filters
 applying [2-80](#)
 debug messages, display [B-9](#)
 IGMP groups, setting maximum [2-81](#)
 IGMP maximum groups, debugging [B-10](#)
 IGMP profiles
 creating [2-83](#)
 displaying [2-248](#)
 IGMP snooping
 adding ports as a static member of a group [2-97](#)
 displaying [2-249, 2-254, 2-256](#)
 enabling [2-85](#)

- enabling the configurable-leave timer [2-87](#)
 - enabling the Immediate-Leave feature [2-96](#)
 - flooding query count [2-93](#)
 - interface topology change notification behavior [2-95](#)
 - multicast table [2-252](#)
 - querier [2-89](#)
 - query solicitation [2-93](#)
 - report suppression [2-91](#)
 - switch topology change notification behavior [2-93](#)
 - images
 - See software images
 - Immediate-Leave processing
 - IGMP [2-96](#)
 - IPv6 [2-113](#)
 - interface configuration mode [1-2, 1-4](#)
 - interface port-channel command [2-67](#)
 - interface range command [2-69](#)
 - interface-range macros [2-46](#)
 - interfaces
 - assigning Ethernet interface to channel group [2-18](#)
 - configuring [2-55](#)
 - configuring multiple [2-69](#)
 - creating port-channel logical [2-67](#)
 - debug messages, display [B-8](#)
 - disabling [2-325](#)
 - displaying the MAC address table [2-285](#)
 - restarting [2-325](#)
 - interface speed, configuring [2-384](#)
 - interface vlan command [2-72](#)
 - internal registers, displaying [2-193, 2-201, 2-203](#)
 - Internet Group Management Protocol
 - See IGMP
 - invalid GBIC
 - error detection for [2-57](#)
 - error recovery timer [2-60](#)
 - ip access-group command [2-74](#)
 - ip address command [2-76](#)
 - IP addresses, setting [2-76](#)
 - ip admission command [2-78](#)
 - ip admission name proxy http command [2-79](#)
 - ip igmp filter command [2-80](#)
 - ip igmp max-groups command [2-81](#)
 - ip igmp profile command [2-83](#)
 - ip igmp snooping command [2-85](#)
 - ip igmp snooping last-member-query-interval command [2-87](#)
 - ip igmp snooping querier command [2-89](#)
 - ip igmp snooping report-suppression command [2-91](#)
 - ip igmp snooping tcn command [2-93](#)
 - ip igmp snooping tcn flood command [2-95](#)
 - ip igmp snooping vlan immediate-leave command [2-96](#)
 - ip igmp snooping vlan static command [2-97](#)
 - ip ssh command [2-99](#)
 - ipv6 mld snooping command [2-101](#)
 - ipv6 mld snooping last-listener-query count command [2-103](#)
 - ipv6 mld snooping last-listener-query-interval command [2-105](#)
 - ipv6 mld snooping listener-message-suppression command [2-107](#)
 - ipv6 mld snooping robustness-variable command [2-109](#)
 - ipv6 mld snooping tcn command [2-111](#)
 - ipv6 mld snooping vlan command [2-113](#)
-
- ## J
- jumbo frames
 - See MTU
-
- ## L
- lacp port-priority command [2-115](#)
 - lacp system-priority command [2-117](#)
 - Layer 2 protocol-tunnel
 - error detection for [2-57](#)
 - error recovery timer [2-60](#)
 - Layer 2 traceroute
 - IP addresses [2-409](#)
 - MAC addresses [2-406](#)

line configuration mode [1-2, 1-4](#)

link flap

- error detection for [2-57](#)
- error recovery timer [2-60](#)

link state group command [2-119](#)

link state track command [2-121](#)

load-distribution methods for EtherChannel [2-157](#)

location (global configuration) command [2-122](#)

location (interface configuration) command [2-124](#)

logging file command [2-126](#)

logical interface [2-67](#)

loopback error

- detection for [2-57](#)
- recovery timer [2-60](#)

loop guard, for spanning tree [2-349, 2-353](#)

M

MAC addresses

displaying

- aging time [2-279](#)
- all [2-277](#)
- dynamic [2-283](#)
- number of addresses in a VLAN [2-281](#)
- per interface [2-285](#)
- per VLAN [2-289](#)
- static [2-287](#)
- static and dynamic entries [2-275](#)

dynamic

- aging time [2-128](#)
- deleting [2-28](#)
- displaying [2-283](#)

static

- adding and removing [2-129](#)
- displaying [2-287](#)
- dropping on an interface [2-130](#)

tables [2-277](#)

mac address-table aging-time command [2-128](#)

mac address-table static command [2-129](#)

mac address-table static drop command [2-130](#)

MAC frames

See MTU

macros

interface range [2-46, 2-69](#)

maps

QoS

displaying [2-294](#)

match (class-map configuration) command [2-132](#)

maximum transmission unit

See MTU

mdix auto command [2-135](#)

media-type rj45 command [2-137](#)

member switches

See clusters

memory (boot loader) command [A-14](#)

mgmt_clr (boot loader) command [A-16](#)

mgmt_init (boot loader) command [A-17, A-18](#)

mkdir (boot loader) command [A-19](#)

MLD snooping

- configuring [2-107, 2-109](#)
- configuring queries [2-103, 2-105](#)
- configuring topology change notification [2-111](#)
- displaying [2-258, 2-260, 2-262, 2-264](#)
- enabling [2-101](#)
- enabling on a VLAN [2-113](#)

mls qos command [2-138](#)

mls qos cos command [2-140](#)

mls qos queue-set output buffers command [2-142](#)

mls qos queue-set output threshold command [2-144](#)

mls qos-srr-queue output cos-map command [2-146](#)

mls qos trust command [2-148](#)

Mode button, and password recovery [2-170](#)

modes, commands [1-1](#)

monitor session command [2-149](#)

more (boot loader) command [A-20](#)

MSTP

displaying [2-305](#)

interoperability [2-31](#)

link type [2-351](#)

MST region

 aborting changes [2-357](#)

 applying changes [2-357](#)

 configuration name [2-357](#)

 configuration revision number [2-357](#)

 current or pending display [2-357](#)

 displaying [2-305](#)

 MST configuration mode [2-357](#)

 VLANs-to-instance mapping [2-357](#)

path cost [2-359](#)

protocol mode [2-355](#)

restart protocol migration process [2-31](#)

root port

 loop guard [2-349](#)

 preventing from becoming designated [2-349](#)

 restricting which can be root [2-349](#)

 root guard [2-349](#)

root switch

 affects of extended system ID [2-347](#)

 hello-time [2-362, 2-369](#)

 interval between BPDU messages [2-363](#)

 interval between hello BPDU messages [2-362, 2-369](#)

 max-age [2-363](#)

 maximum hop count before discarding BPDU [2-364](#)

 port priority for selection of [2-365](#)

 primary or secondary [2-369](#)

 switch priority [2-368](#)

state changes

 blocking to forwarding state [2-376](#)

 enabling BPDU filtering [2-339, 2-373](#)

 enabling BPDU guard [2-341, 2-373](#)

 enabling Port Fast [2-373, 2-376](#)

 forward-delay time [2-361](#)

 length of listening and learning states [2-361](#)

 rapid transition to forwarding [2-351](#)

 shutting down Port Fast-enabled ports [2-373](#)

state information display [2-304](#)

MTU

 configuring size [2-404](#)

 displaying global setting [2-310](#)

 MAC [2-404](#)

Multicast Listener Discovery

 See MLD

Multicast Listener Discovery

 See MLD

multicast router ports, IPv6 [2-113](#)

Multiple Spanning Tree Protocol

 See MSTP

N

native VLANs [2-400](#)

nonegotiate

 DTP messaging [2-398](#)

 speed [2-384](#)

normal-range VLANs [2-417](#)

no vlan command [2-417](#)

O

online diagnostics

 configuring health monitoring diagnostic tests [2-49](#)

 displaying

 configured boot-up coverage level [2-207](#)

 current scheduled tasks [2-207](#)

 event logs [2-207](#)

 supported test suites [2-207](#)

 test ID [2-207](#)

 test results [2-207](#)

 test statistics [2-207](#)

 enabling

 scheduling [2-51](#)

 syslog messages [2-49](#)

 global configuration mode

- clearing health monitoring diagnostic test schedule [2-49](#)
- clearing test-based testing schedule [2-51](#)
- setting health monitoring diagnostic testing [2-49](#)
- setting test-based testing [2-51](#)
- setting up health monitoring diagnostic test schedule [2-49](#)
- setting up test-based testing [2-51](#)
- removing scheduling [2-51](#)
- scheduled switchover
 - disabling [2-51](#)
 - enabling [2-51](#)
- setting test interval [2-51](#)
- specifying health monitoring diagnostic tests [2-49](#)
- starting testing [2-53](#)

P

PAGP

See EtherChannel

- pagp learn-method command [2-153](#)
- pagp port-priority command [2-155](#)
- password, VTP [2-422, 2-426](#)
- password-recovery mechanism, enabling and disabling [2-170](#)
- per-VLAN spanning-tree plus
 - See STP
- physical-port learner [2-153](#)
- PID, displaying [2-247](#)
- policy maps
 - applying to an interface [2-172](#)
- Port Aggregation Protocol
 - See EtherChannel
- port-channel load-balance command [2-157](#)
- Port Fast, for spanning tree [2-376](#)
- port ranges, defining [2-44, 2-46](#)
- ports, debugging [B-44](#)
- port trust states for QoS [2-148](#)
- power information, displaying [2-216](#)

- priority-queue command [2-159](#)
- privileged EXEC mode [1-2, 1-3](#)
- product identification information, displaying [2-247](#)
- pruning
 - VLANs [2-400](#)
 - VTP
 - displaying interface information [2-232](#)
 - enabling [2-422, 2-426](#)
- pruning-eligible VLAN list [2-401](#)
- PVST+
 - See STP

Q

QoS

- class maps
 - creating [2-22](#)
 - defining the match criteria [2-132](#)
 - displaying [2-184](#)
- defining the CoS value for an incoming packet [2-140](#)
- displaying configuration information [2-291](#)
- egress queues
 - allocating buffers [2-142](#)
 - defining the CoS output queue threshold map [2-146](#)
 - displaying buffer allocations [2-292](#)
 - displaying CoS output queue threshold map [2-294](#)
 - displaying DSCP output queue threshold map [2-294](#)
 - displaying queueing strategy [2-292](#)
 - displaying queue-set settings [2-297](#)
 - enabling bandwidth shaping and scheduling [2-388](#)
 - enabling bandwidth sharing and scheduling [2-390](#)
 - limiting the maximum output on a port [2-386](#)
 - mapping CoS values to a queue and threshold [2-146](#)
 - setting maximum and reserved memory allocations [2-144](#)

- setting WTD thresholds [2-144](#)
- enabling [2-138](#)
- ingress queues
 - displaying buffer allocations [2-292](#)
 - displaying CoS input queue threshold map [2-294](#)
 - displaying DSCP input queue threshold map [2-294](#)
 - displaying queueing strategy [2-292](#)
- maps
 - defining [2-146](#)
 - displaying [2-294](#)
- policy maps
 - applying to an interface [2-172](#)
- port trust states [2-148](#)
- queues, enabling the expedite [2-159](#)
- statistics
 - in-profile and out-of-profile packets [2-292](#)
 - packets enqueued or dropped [2-292](#)
 - sent and received CoS values [2-292](#)
 - sent and received DSCP values [2-292](#)

R

- radius-server dead-criteria command [2-161](#)
- radius-server host command [2-163](#)
- rapid per-VLAN spanning-tree plus
 - See STP
- rapid PVST+
 - See STP
- rcommand command [2-165](#)
- receiving flow-control packets [2-64](#)
- recovery mechanism
 - causes [2-60](#)
 - display [2-25, 2-218, 2-221](#)
 - timer interval [2-60](#)
- reload command [2-167](#)
- Remote Switched Port Analyzer
 - See RSPAN
- rename (boot loader) command [A-21](#)

- reset (boot loader) command [A-22](#)
- rmdir (boot loader) command [A-23](#)
- rmon collection stats command [2-169](#)
- root guard, for spanning tree [2-349](#)
- routing frames
 - See MTU
- RSPAN
 - configuring [2-149](#)
 - displaying [2-299](#)
 - filter RSPAN traffic [2-149](#)
 - sessions
 - add interfaces to [2-149](#)
 - displaying [2-299](#)
 - start new [2-149](#)

S

- scheduled switchover
 - disabling [2-51](#)
 - enabling [2-51](#)
- sending flow-control packets [2-64](#)
- service password-recovery command [2-170](#)
- set (boot loader) command [A-24](#)
- setup command [2-172](#)
- setup express command [2-175](#)
- show access-lists command [2-177](#)
- show archive status command [2-180](#)
- show boot command [2-181](#)
- show class-map command [2-184](#)
- show cluster candidates command [2-187](#)
- show cluster command [2-185](#)
- show cluster members command [2-189](#)
- show controllers cpu-interface command [2-191](#)
- show controllers ethernet-controller command [2-193](#)
- show controllers ethernet-controller fastethernet command [2-201](#)
- show controllers tcam command [2-203](#)
- show controller utilization command [2-205](#)
- show dtp [2-211](#)

- show eap command [2-213](#)
- show env command [2-216](#)
- show errdisable detect command [2-218](#)
- show errdisable flap-values command [2-220](#)
- show errdisable recovery command [2-221](#)
- show etherchannel command [2-223](#)
- show fallback profile command [2-226](#)
- show flowcontrol command [2-228](#)
- show idprom command [2-230](#)
- show interfaces command [2-232](#)
- show interfaces counters command [2-241](#)
- show interface transceivers command [2-243](#)
- show inventory command [2-247](#)
- show ip igmp profile command [2-248](#)
- show ip igmp snooping address command [2-260](#)
- show ip igmp snooping command [2-249, 2-258](#)
- show ip igmp snooping groups command [2-252](#)
- show ip igmp snooping mrouter command [2-254, 2-262](#)
- show ip igmp snooping querier command [2-256, 2-264](#)
- show lacp command [2-266](#)
- show link state group command [2-270](#)
- show location [2-272](#)
- show location command [2-272](#)
- show mac address-table address command [2-277](#)
- show mac address-table aging time command [2-279](#)
- show mac address-table command [2-275](#)
- show mac address-table count command [2-281](#)
- show mac address-table dynamic command [2-283](#)
- show mac address-table interface command [2-285](#)
- show mac address-table notification command [B-14](#)
- show mac address-table static command [2-287](#)
- show mac address-table vlan command [2-289](#)
- show mls qos command [2-291](#)
- show mls qos interface command [2-292](#)
- show mls qos maps command [2-294](#)
- show mls qos queue-set command [2-297](#)
- show monitor command [2-299](#)
- show pagp command [2-301](#)
- show platform acl command [C-2](#)
- show platform dl command [C-3](#)
- show platform etherchannel command [C-4](#)
- show platform forward command [C-5](#)
- show platform frontend-controller command [C-7](#)
- show platform igmp snooping command [C-8](#)
- show platform layer4op command [C-10](#)
- show platform mac-address-table command [C-11](#)
- show platform messaging command [C-12](#)
- show platform monitor command [C-13](#)
- show platform pm command [C-14](#)
- show platform port-asic command [C-15](#)
- show platform qos command [C-20](#)
- show platform resource-manager command [C-21](#)
- show platform snmp counters command [C-23](#)
- show platform spanning-tree synchronization command [C-24](#)
- show platform stp-instance command [C-25](#)
- show platform team command [C-26](#)
- show platform vlan command [C-28](#)
- show setup express command [2-303](#)
- show spanning-tree command [2-304](#)
- show system mtu command [2-310](#)
- show udd command [2-311](#)
- show version command [2-314](#)
- show vlan command [2-316](#)
- show vlan command, fields [2-318](#)
- show vtp command [2-320](#)
- shutdown command [2-325](#)
- shutdown vlan command [2-326](#)
- small-frame violation rate command [2-327](#)
- SNMP host, specifying [2-332](#)
- SNMP informs, enabling the sending of [2-329](#)
- snmp-server enable traps command [2-329](#)
- snmp-server host command [2-332](#)
- snmp trap mac-notification command [2-336](#)
- SNMP traps
 - enabling MAC address notification trap [2-336](#)
 - enabling the sending of [2-329](#)
- software images

- deleting [2-48](#)
- downloading [2-3](#)
- upgrading [2-3](#)
- uploading [2-9](#)
- software version, displaying [2-314](#)
- SPAN
 - configuring [2-149](#)
 - debug messages, display [B-15](#)
 - displaying [2-299](#)
 - filter SPAN traffic [2-149](#)
 - sessions
 - add interfaces to [2-149](#)
 - displaying [2-299](#)
 - start new [2-149](#)
- spanning-tree backbonefast command [2-338](#)
- spanning-tree bpdufilter command [2-339](#)
- spanning-tree bpduguard command [2-341](#)
- spanning-tree cost command [2-343](#)
- spanning-tree etherchannel command [2-345](#)
- spanning-tree extend system-id command [2-347](#)
- spanning-tree guard command [2-349](#)
- spanning-tree link-type command [2-351](#)
- spanning-tree loopguard default command [2-353](#)
- spanning-tree mode command [2-355](#)
- spanning-tree mst configuration command [2-357](#)
- spanning-tree mst cost command [2-359](#)
- spanning-tree mst forward-time command [2-361](#)
- spanning-tree mst hello-time command [2-362](#)
- spanning-tree mst max-age command [2-363](#)
- spanning-tree mst max-hops command [2-364](#)
- spanning-tree mst port-priority command [2-365](#)
- spanning-tree mst pre-standard command [2-367](#)
- spanning-tree mst priority command [2-368](#)
- spanning-tree mst root command [2-369](#)
- spanning-tree portfast (global configuration) command [2-373](#)
- spanning-tree portfast (interface configuration) command [2-376](#)
- spanning-tree port-priority command [2-371](#)
- Spanning Tree Protocol
 - See STP
 - spanning-tree transmit hold-count command [2-378](#)
 - spanning-tree uplinkfast command [2-379](#)
 - spanning-tree vlan command [2-381](#)
 - speed command [2-384](#)
 - srr-queue bandwidth limit command [2-386](#)
 - srr-queue bandwidth shape command [2-388](#)
 - srr-queue bandwidth share command [2-390](#)
 - SSH, configuring version [2-99](#)
 - static-access ports, configuring [2-392](#)
 - statistics, Ethernet group [2-169](#)
- STP
 - BackboneFast [2-338](#)
 - counters, clearing [2-30](#)
 - debug messages, display
 - BackboneFast events [B-49](#)
 - MSTP [B-52](#)
 - optimized BPDUs handling [B-51](#)
 - spanning-tree activity [B-47](#)
 - switch shim [B-54](#)
 - transmitted and received BPDUs [B-50](#)
 - UplinkFast [B-56](#)
 - detection of indirect link failures [2-338](#)
 - EtherChannel misconfiguration [2-345](#)
 - extended system ID [2-347](#)
 - path cost [2-343](#)
 - protocol modes [2-355](#)
 - root port
 - accelerating choice of new [2-379](#)
 - loop guard [2-349](#)
 - preventing from becoming designated [2-349](#)
 - restricting which can be root [2-349](#)
 - root guard [2-349](#)
 - UplinkFast [2-379](#)
 - root switch
 - affects of extended system ID [2-347, 2-382](#)
 - hello-time [2-381](#)
 - interval between BDPU messages [2-381](#)

interval between hello BPDU messages [2-381](#)

max-age [2-381](#)

port priority for selection of [2-371](#)

primary or secondary [2-381](#)

switch priority [2-381](#)

state changes

blocking to forwarding state [2-376](#)

enabling BPDU filtering [2-339, 2-373](#)

enabling BPDU guard [2-341, 2-373](#)

enabling Port Fast [2-373, 2-376](#)

enabling timer to recover from error state [2-60](#)

forward-delay time [2-381](#)

length of listening and learning states [2-381](#)

shutting down Port Fast-enabled ports [2-373](#)

state information display [2-304](#)

VLAN options [2-368, 2-381](#)

SVIs, creating [2-72](#)

SVI status calculation [2-393](#)

Switched Port Analyzer

See SPAN

switchport access command [2-392](#)

switchport autostate exclude command [2-393](#)

switchport host command [2-395](#)

switchport mode command [2-396](#)

switchport nonegotiate command [2-398](#)

switchports, displaying [2-232](#)

switchport trunk command [2-400](#)

system env temperature threshold yellow command [2-403](#)

system message logging, save message to flash [2-126](#)

system mtu command [2-404](#)

T

tar files, creating, listing, and extracting [2-6](#)

Telnet, using to communicate to cluster switches [2-165](#)

temperature information, displaying [2-216](#)

traceroute mac command [2-406](#)

traceroute mac ip command [2-409](#)

trunking, VLAN mode [2-396](#)

trunk mode [2-396](#)

trunk ports [2-396](#)

trunks, to non-DTP device [2-397](#)

trusted port states for QoS [2-148](#)

type (boot loader) command [A-27](#)

U

UDLD

aggressive mode [2-411, 2-413](#)

debug messages, display [B-64](#)

enable globally [2-411](#)

enable per interface [2-413](#)

error recovery timer [2-60](#)

message timer [2-411](#)

normal mode [2-411, 2-413](#)

reset a shutdown interface [2-415](#)

status [2-311](#)

udld command [2-411](#)

udld port command [2-413](#)

udld reset command [2-415](#)

UniDirectional Link Detection

See UDLD

unset (boot loader) command [A-28](#)

upgrading

downloading software images [2-3](#)

software images, monitoring status of [2-180](#)

UplinkFast, for STP [2-379](#)

usb-inactivity-timeout (console configuration)
command [2-416](#)

user EXEC mode [1-2](#)

V

version (boot loader) command [A-30](#)

vlan (global configuration) command [2-417](#)

VLAN configuration

rules [2-420](#)

saving [2-417](#)

- VLAN configuration mode
 - commands
 - VTP [2-426](#)
- VLAN ID range [2-417](#)
- VLANs
 - adding [2-417](#)
 - configuring [2-417](#)
 - debug messages, display
 - ISL [B-60](#)
 - VLAN IOS file system error tests [B-59](#)
 - VLAN manager activity [B-57](#)
 - VTP [B-62](#)
 - displaying configurations [2-316](#)
 - extended-range [2-417](#)
 - MAC addresses
 - displaying [2-289](#)
 - number of [2-281](#)
 - media types [2-419](#)
 - normal-range [2-417](#)
 - restarting [2-326](#)
 - saving the configuration [2-417](#)
 - shutting down [2-326](#)
 - SNMP traps for VTP [2-330, 2-333](#)
 - suspending [2-326](#)
- VLAN Trunking Protocol
 - See VTP
- VTP
 - changing characteristics [2-422](#)
 - clearing pruning counters [2-32](#)
 - configuring
 - domain name [2-422, 2-426](#)
 - file name [2-422](#)
 - mode [2-422, 2-426](#)
 - password [2-422, 2-426](#)
 - counters display fields [2-321](#)
 - displaying information [2-320](#)
 - enabling
 - mode [2-422, 2-426](#)
 - pruning [2-422, 2-426](#)
 - saving the configuration [2-417](#)
 - statistics [2-320](#)
 - status [2-320](#)
 - status display fields [2-322](#)
 - vtp (global configuration) command [2-422](#)
 - vtp (VLAN configuration) command [2-426](#)

