



INDEX

A

- aaa accounting dot1x command [1](#)
- aaa authentication dot1x command [3](#)
- aaa authorization network command [5, 22, 27, 29, 31, 33, 136, 504, 5, 36](#)
- AAA methods [3](#)
- abort command [898](#)
- access control entries
 - See ACEs
- access control lists
 - See ACLs
- access groups
 - IP [200](#)
 - MAC, displaying [636](#)
- access list, IPv6 [271](#)
- access map configuration mode [349](#)
- access mode [839](#)
- access ports [839](#)
- ACEs [120, 425](#)
- ACLs
 - deny [118](#)
 - displaying [486](#)
 - for non-IP protocols [320](#)
 - IP [200](#)
 - matching [349](#)
 - on Layer 2 interfaces [200](#)
 - permit [423](#)
- action command [6](#)
- address aliasing [397](#)
- aggregate-port learner [411](#)
- allowed VLANs [859](#)
- apply command [898](#)
- archive copy-sw command [8](#)
- archive download-sw command [11](#)
- archive tar command [15](#)
- archive upload-sw command [18](#)
- arp access-list command [20](#)
- authentication control-direction command [22](#)
- authentication event command [24](#)
- authentication failed VLAN
 - See dot1x auth-fail vlan
- authentication fallback command [27](#)
- authentication host-mode command [29](#)
- authentication open command [31](#)
- authentication order command [33](#)
- authentication periodic command [35](#)
- authentication port-control command [37](#)
- authentication priority command [39](#)
- authentication timer command [41](#)
- authentication violation command [43](#)
- auth-fail max-attempts
 - See dot1x auth-fail max-attempts
- auth-fail vlan
 - See dot1x auth-fail vlan
- auth open command [31](#)
- auth order command [33](#)
- authorization state of controlled port [155](#)
- auth timer command [41](#)
- autonegotiation of duplex mode [169](#)
- auto qos voip command [45](#)

B

BackboneFast, for STP [759](#)

backup interfaces

 configuring [832](#)

 displaying [565](#)

boot (boot loader) command [2](#)

boot auto-copy-sw command [50](#)

boot auto-download-sw command [51](#)

boot config-file command [53](#)

boot enable-break command [54](#)

boot helper command [55](#)

boot helper-config file command [56](#)

booting

 Cisco IOS image [59](#)

 displaying environment variables [499](#)

 interrupting [51, 54](#)

 manually [57](#)

boot loader

 accessing [1](#)

 booting

 Cisco IOS image [2](#)

 helper image [55](#)

 directories

 creating [15](#)

 displaying a list of [7](#)

 removing [19](#)

 displaying

 available commands [12](#)

 memory heap utilization [13](#)

 version [26](#)

 environment variables

 described [20](#)

 displaying settings [20](#)

 location of [21](#)

 setting [20](#)

 unsetting [24](#)

boot loader (continued)

 files

 copying [5](#)

 deleting [6](#)

 displaying a list of [7](#)

 displaying the contents of [4, 16, 23](#)

 renaming [17](#)

 file system

 formatting [10](#)

 initializing flash [9](#)

 running a consistency check [11](#)

 prompt [1](#)

 resetting the system [18](#)

boot manual command [57](#)

boot private-config-file command [58](#)

boot system command [59](#)

BPDU filtering, for spanning tree [760, 795](#)

BPDU guard, for spanning tree [762, 795](#)

broadcast storm control [816](#)

C

candidate switches

 See clusters

cat (boot loader) command [4](#)

Catalyst 3750G Integrated Wireless LAN Controller Switch [475](#)

CDP, enabling protocol tunneling for [299](#)

channel-group command [61](#)

channel-protocol command [65](#)

Cisco SoftPhone

 auto-QoS configuration [45](#)

 trusting packets sent from [388](#)

CISP

 See Client Information Signalling Protocol

cisp

 debug platform cisp command [36](#)

cisp enable command [66](#)

class command [67](#)

- class-map command 69
- class maps
 - creating 69
 - defining the match criteria 351
 - displaying 505
- class of service
 - See CoS
- clear dot1x command 71
- clear eap sessions command 72
- clear energywise neighbors command 73
- clear errdisable interface 74
- clear ip arp inspection log command 75
- clear ip arp inspection statistics command 76
- clear ipc command 79
- clear ip dhcp snooping database command 77
- clear ipv6 dhcp conflict command 80
- clear l2protocol-tunnel counters command 81
- clear lacp command 82
- clear mac address-table command 83, 85
- clear nmsp statistics command 86
- clear pagp command 87
- clear port-security command 88
- clear spanning-tree counters command 90
- clear spanning-tree detected-protocols command 91
- clear vmpls statistics command 92
- clear vtp counters command 93
- Client Information Signalling Protocol 66, 136, 504, 5, 36
- cluster commander-address command 94
- cluster discovery hop-count command 96
- cluster enable command 97
- cluster holdtime command 98
- cluster member command 99
- cluster outside-interface command 101
- cluster run command 102
- clusters
 - adding candidates 99
 - binding to HSRP group 103
 - building manually 99
 - communicating with
 - devices outside the cluster 101
 - members by using Telnet 452
 - debug messages, display 6
 - displaying
 - candidate switches 508
 - debug messages 6
 - member switches 510
 - status 506
 - hop-count limit for extended discovery 96
 - HSRP standby groups 103
 - redundancy 103
 - SNMP trap 747
- cluster standby-group command 103
- cluster timer command 105
- command modes defined 2
- command switch
 - See clusters
- configuration files
 - password recovery disable considerations 1
 - specifying the name 53, 58
- configuring multiple interfaces 196
- config-vlan mode
 - commands 884
 - description 4
 - entering 883
 - summary 3
- controller, wireless 475
- copy (boot loader) command 5
- CoS
 - assigning default value to incoming packets 358
 - assigning to Layer 2 protocol packets 302
 - overriding the incoming value 358

CoS-to-DSCP map [362](#)
 CPU ASIC statistics, displaying [512](#)
 crashinfo files [189](#)

D

debug auto qos command [2](#)
 debug backup command [4](#)
 debug cisp command [5](#)
 debug cluster command [6](#)
 debug dot1x command [8](#)
 debug dtp command [10](#)
 debug eap command [11](#)
 debug etherchannel command [12](#)
 debug ilpower command [14](#)
 debug interface command [15](#)
 debug ip dhcp snooping command [17](#)
 debug ip igmp filter command [19](#)
 debug ip igmp max-groups command [20](#)
 debug ip igmp snooping command [21](#)
 debug ip verify source packet command [18](#)
 debug lacp command [22](#)
 debug lldp packets command [23](#)
 debug mac-notification command [24](#)
 debug matm command [25](#)
 debug matm move update command [26](#)
 debug monitor command [27](#)
 debug mvrdbg command [29](#)
 debug nmsp command [31](#)
 debug nvram command [32](#)
 debug pagp command [33](#)
 debug platform acl command [34](#)
 debug platform backup interface command [35](#)
 debug platform cisp command [36](#)
 debug platform cli-redirection main command [37](#)
 debug platform configuration command [38, 46](#)
 debug platform cpu-queues command [39](#)
 debug platform device-manager command [41](#)
 debug platform dot1x command [42](#)
 debug platform etherchannel command [43](#)
 debug platform fallback-bridging command [44](#)
 debug platform forw-team command [45](#)
 debug platform ip arp inspection command [48](#)
 debug platform ipc command [58](#)
 debug platform ip dhcp command [49](#)
 debug platform ip igmp snooping command [50](#)
 debug platform ip multicast command [52](#)
 debug platform ip source-guard command [54](#)
 debug platform ip unicast command [55](#)
 debug platform ip wccp command [57](#)
 debug platform led command [59](#)
 debug platform matm command [60](#)
 debug platform messaging application command [62](#)
 debug platform phy command [63](#)
 debug platform pm command [65](#)
 debug platform port-asic command [67](#)
 debug platform port-security command [68](#)
 debug platform qos-acl-team command [69](#)
 debug platform remote-commands command [70](#)
 debug platform resource-manager command [71](#)
 debug platform snmp command [72](#)
 debug platform span command [73](#)
 debug platform stack-manager command [74](#)
 debug platform supervisor-asic command [75](#)
 debug platform sw-bridge command [76](#)
 debug platform team command [77](#)
 debug platform udd command [80](#)
 debug platform vlan command [81](#)
 debug platform wireless-controller [107](#)
 debug pm command [82](#)
 debug port-security command [84](#)
 debug qos-manager command [85](#)
 debug spanning-tree backbonefast command [88](#)
 debug spanning-tree bpdu command [89](#)
 debug spanning-tree bpdu-opt command [90](#)
 debug spanning-tree command [86](#)
 debug spanning-tree mstp command [91](#)
 debug spanning-tree switch command [93](#)

- debug spanning-tree uplinkfast command 95
- debug sw-vlan command 96
- debug sw-vlan ifs command 98
- debug sw-vlan notification command 100
- debug sw-vlan vtp command 102
- debug udd command 104
- debug vqpc command 106
- define interface-range command 107
- delete (boot loader) command 6
- delete command 109
- deny (ARP access-list configuration) command 111
- deny (IPv6) command 113
- deny command 118
- detect mechanism, causes 180
- DHCP snooping
 - accepting untrusted packets from edge switch 228
 - enabling
 - on a VLAN 235
 - option 82 226, 228
 - trust on an interface 233
 - error recovery timer 186
 - rate limiting 232
- DHCP snooping binding database
 - binding file, configuring 224
 - bindings
 - adding 222
 - deleting 222
 - displaying 585
 - clearing database agent statistics 77
 - database agent, configuring 224
 - displaying
 - binding entries 585
 - database agent status 588, 590
 - renewing 460
- dir (boot loader) command 7
- directories, deleting 109
- domain name, VTP 909, 913
- dot1x auth-fail max-attempts 130
- dot1x auth-fail vlan 132
- dot1x command 128
- dot1x control-direction command 134
- dot1x credentials (global configuration) command 136
- dot1x critical global configuration command 137
- dot1x critical interface configuration command 139
- dot1x default command 141
- dot1x fallback command 142
- dot1x guest-vlan command 143
- dot1x host-mode command 146
- dot1x initialize command 148
- dot1x mac-auth-bypass command 149
- dot1x max-reauth-req command 151
- dot1x max-req command 152
- dot1x multiple-hosts command 153
- dot1x pae command 154
- dot1x port-control command 155
- dot1x re-authenticate command 157
- dot1x re-authentication command 158
- dot1x reauthentication command 159
- dot1x test eapol-capable command 160
- dot1x test timeout command 161
- dot1x timeout command 162
- dot1x violation-mode command 166
- dropping packets, with ACL matches 6
- drop threshold, Layer 2 protocol tunneling 299
- DSCP-to-CoS map 362
- DSCP-to-DSCP-mutation map 362
- DTP 840
- DTP flap
 - error detection for 180
 - error recovery timer 186
- DTP negotiation 844
- duplex command 168
- dynamic-access ports
 - configuring 828
 - restrictions 829

dynamic ARP inspection

ARP ACLs

apply to a VLAN [208](#)define [20](#)deny packets [111](#)display [490](#)permit packets [415](#)

clear

log buffer [75](#)statistics [76](#)

display

ARP ACLs [490](#)configuration and operating state [580](#)log buffer [580](#)statistics [580](#)trust state and rate limit [580](#)enable per VLAN [218](#)error detection for [180](#)error recovery timer [186](#)

log buffer

clear [75](#)configure [212](#)display [580](#)rate-limit incoming ARP packets [210](#)

statistics

clear [76](#)display [580](#)trusted interface state [214](#)type of packet logged [219](#)validation checks [216](#)dynamic auto VLAN membership mode [839](#)dynamic desirable VLAN membership mode [839](#)

Dynamic Host Configuration Protocol (DHCP)

See DHCP snooping

Dynamic Trunking Protocol

See DTP

E

EAP-request/identity frame

maximum number to send [152](#)response time before retransmitting [162](#)encapsulation methods [859](#)energywise (global configuration) command [170, 172](#)energywise domain command [174](#)energywise query command [176](#)environment variables, displaying [499](#)errdisable detect cause command [180](#)errdisable detect cause small-frame command [183](#)errdisable recovery cause small-frame [185](#)errdisable recovery command [186](#)error conditions, displaying [551](#)error disable detection [180](#)error-disabled interfaces, displaying [565](#)

EtherChannel

assigning Ethernet interface to channel group [61](#)creating port-channel logical interface [194](#)debug EtherChannel/PAgP, display [12](#)debug platform-specific events, display [43](#)displaying [555](#)

enabling Layer 2 protocol tunneling for

LACP [300](#)PAgP [300](#)UDLD [300](#)interface information, displaying [565](#)

LACP

clearing channel-group information [82](#)debug messages, display [22](#)displaying [627](#)modes [61](#)port priority for hot-standby ports [303](#)restricting a protocol [65](#)system priority [305](#)load-distribution methods [433](#)

EtherChannel (continued)

PAgP

- aggregate-port learner [411](#)
- clearing channel-group information [87](#)
- debug messages, display [33](#)
- displaying [687](#)
- error detection for [180](#)
- error recovery timer [186](#)
- learn method [411](#)
- modes [61](#)
- physical-port learner [411](#)
- priority of interface for transmitted traffic [413](#)

Ethernet controller, internal register display [514](#)

Ethernet statistics, collecting [465](#)

exception crashinfo command [189](#)

exit command [898](#)

extended discovery of candidate switches [96](#)

extended-range VLANs

- and allowed VLAN list [859](#)
- and pruning-eligible list [859](#)
- configuring [883](#)

extended system ID for STP [768](#)

F

fallback profile command [190](#)

fallback profiles, displaying [558](#)

fan information, displaying [546](#)

file name, VTP [909](#)

files, deleting [109](#)

flash_init (boot loader) command [9](#)

flexible authentication ordering [33](#)

Flex Links

- configuring [832](#)
- configuring preferred VLAN [835](#)
- displaying [565](#)

flowcontrol command [192](#)

format (boot loader) command [10](#)

forwarding packets, with ACL matches [6](#)

forwarding results, display [6](#)

frame forwarding information, displaying [6](#)

front-end controller, counter and status information [8](#)

fsck (boot loader) command [11](#)

G

global configuration mode [2, 4](#)

H

hardware ACL statistics [486](#)

help (boot loader) command [12](#)

hierarchical policy maps [431](#)

hop-count limit for clusters [96](#)

host connection, port configuration [838](#)

host ports, private VLANs [842](#)

Hot Standby Router Protocol

See HSRP

HSRP

binding HSRP group to cluster [103](#)

standby group [103](#)

I

IEEE 802.1Q trunk ports and native VLANs [900](#)

IEEE 802.1Q tunnel ports

- configuring [839](#)
- displaying [531](#)
- limitations [840](#)

IEEE 802.1x

- and switchport modes [840](#)
- violation error recovery [186](#)

See also port-based authentication

IEEE 802.1X Port Based Authentication

enabling guest VLAN supplicant [131, 142, 191](#)

IGMP filters

- applying [238](#)
- debug messages, display [19](#)

IGMP groups, setting maximum [240](#)IGMP maximum groups, debugging [20](#)

IGMP profiles

- creating [242](#)
- displaying [593](#)

IGMP snooping

- adding ports as a static member of a group [259](#)
- displaying [594, 599, 601](#)
- enabling [244](#)
- enabling the configurable-leave timer [246](#)
- enabling the Immediate-Leave feature [255](#)
- flooding query count [252](#)
- interface topology change notification behavior [254](#)
- multicast table [597](#)
- querier [248](#)
- query solicitation [252](#)
- report suppression [250](#)
- switch topology change notification behavior [252](#)

images

- See software images

Immediate-Leave feature, MVR [399](#)immediate-leave processing [255](#)Immediate-Leave processing, IPv6 [295](#)interface configuration mode [2, 4](#)interface port-channel command [194](#)interface range command [196](#)interface-range macros [107](#)

interfaces

- assigning Ethernet interface to channel group [61](#)
- configuring [168](#)
- configuring multiple [196](#)
- creating port-channel logical [194](#)
- debug messages, display [15](#)
- disabling [743](#)
- displaying the MAC address table [648](#)
- restarting [743](#)

interface speed, configuring [805](#)interface vlan command [198](#)internal registers, displaying [514, 524](#)

Internet Group Management Protocol

- See IGMP

invalid GBIC

- error detection for [180](#)
- error recovery timer [186](#)

ip access-group command [200](#)ip address command [203](#)IP addresses, setting [203](#)IP address matching [349](#)ip admission command [205](#)ip admission name proxy http command [206](#)ip arp inspection filter vlan command [208](#)ip arp inspection limit command [210](#)ip arp inspection log-buffer command [212](#)ip arp inspection trust command [214](#)ip arp inspection validate command [216](#)ip arp inspection vlan command [218](#)ip arp inspection vlan logging command [219](#)

IP DHCP snooping

- See DHCP snooping

ip dhcp snooping binding command [222](#)ip dhcp snooping command [221](#)ip dhcp snooping database command [224](#)ip dhcp snooping information option allow-untrusted command [228](#)ip dhcp snooping information option command [226](#)ip dhcp snooping information option format remote-id command [230](#)ip dhcp snooping limit rate command [232](#)ip dhcp snooping trust command [233](#)ip dhcp snooping verify command [234](#)ip dhcp snooping vlan command [235](#)ip dhcp snooping vlan information option format-type circuit-id string command [236](#)ip igmp filter command [238](#)ip igmp max-groups command [240, 266, 268](#)ip igmp profile command [242](#)

ip igmp snooping command [244](#)
 ip igmp snooping last-member-query-interval command [246](#)
 ip igmp snooping querier command [248](#)
 ip igmp snooping report-suppression command [250](#)
 ip igmp snooping tcn command [252](#)
 ip igmp snooping tcn flood command [254](#)
 ip igmp snooping vlan immediate-leave command [255](#)
 ip igmp snooping vlan mrouter command [257](#)
 ip igmp snooping vlan static command [259](#)
 IP multicast addresses [396](#)
 IP phones
 auto-QoS configuration [45](#)
 trusting packets sent from [388](#)
 IP-precedence-to-DSCP map [362](#)
 ip snap forwarding command [261](#)
 ip source binding command [262](#)
 IP source guard
 disabling [270](#)
 displaying
 binding entries [603](#)
 configuration [605](#)
 dynamic binding entries only [585](#)
 enabling [270](#)
 static IP source bindings [262](#)
 ip ssh command [264](#)
 IPv6 access list, deny conditions [113](#)
 ipv6 access-list command [271](#)
 ipv6 address dhcp command [274](#)
 ipv6 dhcp client request vendor command [275](#)
 ipv6 dhcp ping packets command [276](#)
 ipv6 dhcp pool command [278](#)
 ipv6 dhcp server command [281](#)
 ipv6 mld snooping command [283](#)
 ipv6 mld snooping last-listener-query count command [285](#)
 ipv6 mld snooping last-listener-query-interval command [287](#)
 ipv6 mld snooping listener-message-suppression command [289](#)

ipv6 mld snooping robustness-variable command [291](#)
 ipv6 mld snooping tcn command [293](#)
 ipv6 mld snooping vlan command [295](#)
 IPv6 SDM template [466](#)
 ipv6 traffic-filter command [297](#)
 ip verify source command [270](#)

J

jumbo frames
 See MTU

L

l2protocol-tunnel command [299](#)
 l2protocol-tunnel cos command [302](#)
 LACP
 See EtherChannel
 lacp port-priority command [303](#)
 lacp system-priority command [305](#)
 Layer 2 mode, enabling [826](#)
 Layer 2 protocol ports, displaying [624](#)
 Layer 2 protocol-tunnel
 error detection for [180](#)
 error recovery timer [186](#)
 Layer 2 protocol tunnel counters [81](#)
 Layer 2 protocol tunneling error recovery [300](#)
 Layer 2 traceroute
 IP addresses [874](#)
 MAC addresses [871](#)
 Layer 3 mode, enabling [826](#)
 line configuration mode [3, 5](#)
 Link Aggregation Control Protocol
 See EtherChannel
 link flap
 error detection for [180](#)
 error recovery timer [186](#)
 link state group command [311](#)

link state track command [313](#)
 load-distribution methods for EtherChannel [433](#)
 location (global configuration) command [307](#)
 location (interface configuration) command [309](#)
 logging event command [314](#)
 logging event power-inline-status command [315](#)
 logging file command [316](#)
 logical interface [194](#)
 loopback error
 detection for [180](#)
 recovery timer [186](#)
 loop guard, for spanning tree [770, 774](#)

M

mac access-group command [318](#)
 MAC access-groups, displaying [636](#)
 MAC access list configuration mode [320](#)
 mac access-list extended command [320](#)
 MAC access lists [118](#)
 MAC addresses
 disabling MAC address learning per VLAN [323](#)
 displaying
 aging time [642](#)
 all [640](#)
 dynamic [646](#)
 MAC address-table move updates [651](#)
 notification settings [650, 653](#)
 number of addresses in a VLAN [644](#)
 per interface [648](#)
 per VLAN [657](#)
 static [655](#)
 static and dynamic entries [638](#)
 dynamic
 aging time [322](#)
 deleting [83](#)
 displaying [646](#)
 enabling MAC address notification [327](#)
 enabling MAC address-table move update [325](#)

MAC addresses (continued)
 matching [349](#)
 persistent stack [813](#)
 static
 adding and removing [329](#)
 displaying [655](#)
 dropping on an interface [330](#)
 tables [640](#)
 MAC address notification, debugging [24](#)
 mac address-table aging-time [318, 349](#)
 mac address-table aging-time command [322](#)
 mac address-table learning command [323](#)
 mac address-table move update command [325](#)
 mac address-table notification command [327](#)
 mac address-table static command [329](#)
 mac address-table static drop command [330](#)
 macro apply command [332](#)
 macro auto execute command [335](#)
 macro auto global processing command [340](#)
 macro description command [342](#)
 macro global command [343](#)
 macro global description command [346](#)
 macro name command [347](#)
 macros
 adding a description [342](#)
 adding a global description [346](#)
 applying [343](#)
 creating [347](#)
 displaying [689](#)
 interface range [107, 196](#)
 specifying parameter values [343](#)
 tracing [343](#)

- maps
 - QoS
 - defining [362](#)
 - displaying [667](#)
 - VLAN
 - creating [895](#)
 - defining [349](#)
 - displaying [732](#)
- match (access-map configuration) command [349](#)
- match (class-map configuration) command [351](#)
- maximum transmission unit
 - See MTU
- mdix auto command [353](#)
- member switches
 - See clusters
- memory (boot loader) command [13](#)
- mkdir (boot loader) command [15](#)
- MLD snooping
 - configuring [289, 291](#)
 - configuring queries [285, 287](#)
 - configuring topology change notification [293](#)
 - displaying [614, 616, 618, 620](#)
 - enabling [283](#)
- MLD snooping on a VLAN, enabling [295](#)
- mls qos aggregate-policer command [356](#)
- mls qos command [354](#)
- mls qos cos command [358](#)
- mls qos dscp-mutation command [360](#)
- mls qos map command [362](#)
- mls qos queue-set output buffers command [366](#)
- mls qos queue-set output threshold command [368](#)
- mls qos rewrite ip dscp command [370](#)
- mls qos srr-queue input bandwidth command [372](#)
- mls qos srr-queue input buffers command [374](#)
- mls qos-srr-queue input cos-map command [376](#)
- mls qos srr-queue input dscp-map command [378](#)
- mls qos srr-queue input priority-queue command [380](#)
- mls qos srr-queue input threshold command [382](#)
- mls qos-srr-queue output cos-map command [384](#)
- mls qos srr-queue output dscp-map command [386](#)
- mls qos trust command [388](#)
- mls qos vlan-based command [390](#)
- mode, MVR [396](#)
- Mode button, and password recovery [470](#)
- modes, commands [2](#)
- monitor session command [391](#)
- more (boot loader) command [16](#)
- MSTP
 - displaying [708, 709](#)
 - interoperability [91](#)
 - link type [772](#)
 - MST region
 - aborting changes [778](#)
 - applying changes [778](#)
 - configuration name [778](#)
 - configuration revision number [778](#)
 - current or pending display [778](#)
 - displaying [708, 709](#)
 - MST configuration mode [778](#)
 - VLANs-to-instance mapping [778](#)
 - path cost [780](#)
 - protocol mode [776](#)
 - restart protocol migration process [91](#)
 - root port
 - loop guard [770](#)
 - preventing from becoming designated [770](#)
 - restricting which can be root [770](#)
 - root guard [770](#)
 - root switch
 - affects of extended system ID [768](#)
 - hello-time [783, 791](#)
 - interval between BDPU messages [784](#)
 - interval between hello BPDU messages [783, 791](#)
 - max-age [784](#)
 - maximum hop count before discarding BPDU [785](#)
 - port priority for selection of [787](#)

MSTP (continued)

- primary or secondary [791](#)

- switch priority [790](#)

- state changes

- blocking to forwarding state [797](#)

- enabling BPDU filtering [760, 795](#)

- enabling BPDU guard [762, 795](#)

- enabling Port Fast [795, 797](#)

- forward-delay time [782](#)

- length of listening and learning states [782](#)

- rapid transition to forwarding [772](#)

- shutting down Port Fast-enabled ports [795](#)

- state information display [707](#)

MTU

- configuring size [868](#)

- displaying global setting [721](#)

multicast group address, MVR [399](#)multicast groups, MVR [397](#)

Multicast Listener Discovery

- See MLD

multicast router learning method [257](#)multicast router ports, configuring [257](#)multicast router ports, IPv6 [295](#)multicast storm control [816](#)multicast VLAN, MVR [396](#)

multicast VLAN registration

- See MVR

Multiple Spanning Tree Protocol

- See MSTP

MVR

- and address aliasing [397](#)

- configuring [396](#)

- configuring interfaces [399](#)

- debug messages, display [29](#)

- displaying [676](#)

- displaying interface information [678](#)

- members, displaying [680](#)

mvr (global configuration) command [396](#)mvr (interface configuration) command [399](#)mvr vlan group command [400](#)

N
native VLANs [859](#)native VLAN tagging [900](#)Network Admission Control Software Configuration Guide [205, 207](#)network-policy (global configuration) command [403](#)network-policy command [402](#)network-policy profile (network-policy configuration) command [405](#)nmsp attachment suppress command [409](#)nmsp command [407](#)nonegotiate, speed [805](#)nonegotiating DTP messaging [844](#)

non-IP protocols

- denying [118](#)

- forwarding [423](#)

non-IP traffic access lists [320](#)

non-IP traffic forwarding

- denying [118](#)

- permitting [423](#)

non-stop forwarding [410](#)normal-range VLANs [883, 889](#)no vlan command [883, 893](#)nsf command [410](#)

O

online diagnostics

displaying

- configured boot-up coverage level [528](#)

- current scheduled tasks [528](#)

- event logs [528](#)

- supported test suites [528](#)

- test ID [528](#)

- test results [528](#)

- test statistics [528](#)

online diagnostics (continued)

global configuration mode

clearing health monitoring diagnostic test schedule [75](#)

clearing test-based testing schedule [124](#)

setting health monitoring diagnostic testing [75](#)

setting test-based testing [124](#)

setting up health monitoring diagnostic test schedule [75](#)

setting up test-based testing [124](#)

health monitoring diagnostic tests, configuring [121](#)

scheduled switchover

disabling [124](#)

enabling [124](#)

scheduling

enabling [124](#)

removing [124](#)

testing, starting [126](#)

test interval, setting [124](#)

P

PAgP

See EtherChannel

pagp learn-method command [411](#)

pagp port-priority command [413](#)

password, VTP [909, 913](#)

password-recovery mechanism, enabling and disabling [470](#)

permit (ARP access-list configuration) command [415](#)

permit (IPv6) command [417](#)

permit (MAC access-list configuration) command [423](#)

per-VLAN spanning-tree plus

See STP

physical-port learner [411](#)

PID, displaying [579](#)

PIM-DVMRP, as multicast router learning method [257](#)

PoE

configuring the power budget [438](#)

configuring the power management mode [435](#)

displaying controller register values [522](#)

displaying power management information [697](#)

logging of status [315](#)

police aggregate command [428](#)

police command [426](#)

policed-DSCP map [362](#)

policy-map command [430](#)

policy maps

applying to an interface [472, 479](#)

creating [430](#)

displaying [692](#)

hierarchical [431](#)

policers

displaying [660](#)

for a single class [426](#)

for multiple classes [356, 428](#)

policed-DSCP map [362](#)

traffic classification

defining the class [67](#)

defining trust states [876](#)

setting DSCP or IP precedence values [477](#)

Port Aggregation Protocol

See EtherChannel

port-based authentication

AAA method list [3](#)

configuring violation modes [166](#)

debug messages, display [8](#)

enabling IEEE 802.1x

globally [128](#)

per interface [155](#)

guest VLAN [143](#)

host modes [146](#)

IEEE 802.1x AAA accounting methods [1](#)

initialize an interface [148, 161](#)

MAC authentication bypass [149](#)

manual control of authorization state [155](#)

port-based authentication (continued)

- PAE as authenticator [154](#)
- periodic re-authentication
 - enabling [159](#)
 - time between attempts [162](#)
- quiet period between failed authentication exchanges [162](#)
- re-authenticating IEEE 802.1x-enabled ports [157](#)
- resetting configurable IEEE 802.1x parameters [141](#)
- switch-to-authentication server retransmission time [162](#)
- switch-to-client frame-retransmission number [151 to 152](#)
- switch-to-client retransmission time [162](#)
- test for IEEE 802.1x readiness [160](#)

port-channel load-balance command [433](#)Port Fast, for spanning tree [797](#)port ranges, defining [107](#)ports, debugging [82](#)ports, protected [857](#)

port security

- aging [851](#)
- debug messages, display [84](#)
- enabling [846](#)
- violation error recovery [186](#)

port trust states for QoS [388](#)port types, MVR [399](#)power information, displaying [546](#)power inline command [435](#)power inline consumption command [438](#)

Power over Ethernet

See PoE

priority-queue command [440](#)priority value, stack member [716, 821](#)private-vlan command [442](#)private-vlan mapping command [445](#)

private VLANs

- association [855](#)
- configuring [442](#)
- configuring ports [842](#)
- displaying [727](#)
- host ports [842](#)
- mapping
 - configuring [855](#)
 - displaying [565](#)
- promiscuous ports [842](#)

privileged EXEC mode [2, 3](#)product identification information, displaying [579](#)promiscuous ports, private VLANs [842](#)protected ports, displaying [570](#)

pruning

VLANs [859](#)

VTP

- displaying interface information [565](#)
- enabling [909, 913](#)

pruning-eligible VLAN list [861](#)

PVST+

See STP

Q

QoS

auto-QoS

- configuring [45](#)
- debug messages, display [2](#)
- displaying [495](#)

class maps

- creating [69](#)
- defining the match criteria [351](#)
- displaying [505](#)

defining the CoS value for an incoming packet [358](#)displaying configuration information [495, 659](#)DSCP transparency [370](#)

QoS (continued)

DSCP trusted ports

- applying DSCP-to-DSCP-mutation map to [360](#)

- defining DSCP-to-DSCP-mutation map [362](#)

egress queues

- allocating buffers [366](#)

- defining the CoS output queue threshold map [384](#)

- defining the DSCP output queue threshold map [386](#)

- displaying buffer allocations [663](#)

- displaying CoS output queue threshold map [667](#)

- displaying DSCP output queue threshold map [667](#)

- displaying queueing strategy [663](#)

- displaying queue-set settings [670](#)

- enabling bandwidth shaping and scheduling [809](#)

- enabling bandwidth sharing and scheduling [811](#)

- limiting the maximum output on a port [807](#)

- mapping a port to a queue-set [447](#)

- mapping CoS values to a queue and threshold [384](#)

- mapping DSCP values to a queue and threshold [386](#)

- setting maximum and reserved memory allocations [368](#)

- setting WTD thresholds [368](#)

- enabling [354](#)

ingress queues

- allocating buffers [374](#)

- assigning SRR scheduling weights [372](#)

- defining the CoS input queue threshold map [376](#)

- defining the DSCP input queue threshold map [378](#)

- displaying buffer allocations [663](#)

- displaying CoS input queue threshold map [667](#)

- displaying DSCP input queue threshold map [667](#)

- displaying queueing strategy [663](#)

- displaying settings for [661](#)

- enabling the priority queue [380](#)

QoS (continued)

- mapping CoS values to a queue and threshold [376](#)

- mapping DSCP values to a queue and threshold [378](#)

- setting WTD thresholds [382](#)

maps

- defining [362, 376, 378, 384, 386](#)

- displaying [667](#)

policy maps

- applying an aggregate policer [428](#)

- applying to an interface [472, 479](#)

- creating [430](#)

- defining policers [356, 426](#)

- displaying policers [660](#)

- displaying policy maps [692](#)

- hierarchical [431](#)

- policed-DSCP map [362](#)

- setting DSCP or IP precedence values [477](#)

- traffic classifications [67](#)

- trust states [876](#)

- port trust states [388](#)

- queues, enabling the expedite [440](#)

statistics

- in-profile and out-of-profile packets [663](#)

- packets enqueued or dropped [663](#)

- sent and received CoS values [663](#)

- sent and received DSCP values [663](#)

- trusted boundary for IP phones [388](#)

- VLAN-based [390](#)

quality of service

- See QoS

- querytime, MVR [396](#)

- queue-set command [447](#)

R

- radius-server dead-criteria command [448](#)

- radius-server host command [450](#)

rapid per-VLAN spanning-tree plus

See STP

rapid PVST+

See STP

rcommand command 452

re-authenticating IEEE 802.1x-enabled ports 157

re-authentication

periodic 159

time between attempts 162

receiver ports, MVR 399

receiving flow-control packets 192

recovery mechanism

causes 186

display 74, 501, 549, 553

timer interval 187

redundancy for cluster switches 103

reload command 454

remote command 456

remote-span command 458

Remote Switched Port Analyzer

See RSPAN

rename (boot loader) command 17

renew ip dhcp snooping database command 460

reset (boot loader) command 18

reset command 898

resource templates, displaying 700

restricted VLAN

See dot1x auth-fail vlan

rmdir (boot loader) command 19

rmon collection stats command 465

root guard, for spanning tree 770

routed ports

IP addresses on 204

number supported 204

RSPAN

configuring 391

displaying 673

filter RSPAN traffic 391

RSPAN (continued)

remote-span command 458

sessions

displaying 673

S

scheduled switchover

disabling 124

enabling 124

SDM mismatch mode 467, 717

sdm prefer command 466

SDM templates

allowed resources 468

and stacking 467

displaying 700

dual IPv4 and IPv6 466

secure ports, limitations 848

sending flow-control packets 192

service password-recovery command 470

service-policy command 472

session command 475

set (boot loader) command 20

set command 477

setup command 479

setup express command 482

shell trigger command 484

show access-lists command 486

show archive status command 489

show arp access-list command 490

show authentication command 491

show auto qos command 495

show boot command 499

show cable-diagnostics tdr command 501

show changes command 898

show cisp command 504

show class-map command 505

show cluster candidates command 508

show cluster command 506

- show cluster members command 510
- show controllers cpu-interface command 512
- show controllers ethernet-controller command 514
- show controllers power inline command 522
- show controllers tcam command 524
- show controller utilization command 526
- show current command 898
- show dot1q-tunnel command 531
- show dot1x command 532
- show dtp 537
- show eap command 539
- show energywise command 542
- show env command 546
- show errdisable detect command 549
- show errdisable flap-values command 551
- show errdisable recovery command 553
- show etherchannel command 555
- show fallback profile command 558
- show flowcontrol command 560
- show idprom command 562
- show interfaces command 565
- show interfaces counters command 576
- show inventory command 579
- show ip arp inspection command 580
- show ipc command 607
- show ip dhcp snooping binding command 585
- show ip dhcp snooping command 584
- show ip dhcp snooping database command 588, 590
- show ip igmp profile command 593
- show ip igmp snooping address command 616
- show ip igmp snooping command 594, 614
- show ip igmp snooping groups command 597
- show ip igmp snooping mrouter command 599, 618
- show ip igmp snooping querier command 601, 620
- show ip source binding command 603
- show ipv6 access-list command 611
- show ipv6 dhcp conflict command 613
- show ipv6 route updated 622
- show ip verify source command 605
- show l2protocol-tunnel command 624
- show lacp command 627
- show link state group command 634
- show location 631
- show mac access-group command 636
- show mac address-table address command 640
- show mac address-table aging time command 642
- show mac address-table command 638
- show mac address-table count command 644
- show mac address-table dynamic command 646
- show mac address-table interface command 648
- show mac address-table learning command 650
- show mac address-table move update command 651
- show mac address-table notification command 85, 653, 26
- show mac address-table static command 655
- show mac address-table vlan command 657
- show mls qos aggregate-policer command 660
- show mls qos command 659
- show mls qos input-queue command 661
- show mls qos interface command 663
- show mls qos maps command 667
- show mls qos queue-set command 670
- show mls qos vlan command 672
- show monitor command 673
- show mvr command 676
- show mvr interface command 678
- show mvr members command 680
- show network-policy profile command 682
- show nmsp command 684
- show pagp command 687
- show parser macro command 689
- show platform acl command 2
- show platform backup interface command 3
- show platform configuration command 4
- show platform etherchannel command 5
- show platform forward command 6
- show platform frontend-controller command 8
- show platform igmp snooping command 9
- show platform ipc trace command 17

- show platform ip multicast command [11](#)
- show platform ip unicast command [12](#)
- show platform ipv6 unicast command [18](#)
- show platform ip wccp command [16](#)
- show platform layer4op command [20](#)
- show platform mac-address-table command [21](#)
- show platform messaging command [22](#)
- show platform monitor command [23](#)
- show platform mvr table command [24](#)
- show platform pm command [25](#)
- show platform port-asic command [26](#)
- show platform port-security command [31](#)
- show platform qos command [32](#)
- show platform resource-manager command [33](#)
- show platform snmp counters command [35](#)
- show platform spanning-tree command [36](#)
- show platform stack manager command [38](#)
- show platform stp-instance command [37](#)
- show platform tb command [42](#)
- show platform team command [44](#)
- show platform vlan command [47](#)
- show policy-map command [692](#)
- show port security command [694](#)
- show power inline command [697](#)
- show proposed command [898](#)
- show sdm prefer command [700](#)
- show setup express command [703](#)
- show shell command [704](#)
- show spanning-tree command [707](#)
- show storm-control command [714](#)
- show switch command [716](#)
- show system mtu command [721](#)
- show trust command [876](#)
- show uddl command [722](#)
- show version command [725](#)
- show vlan access-map command [732](#)
- show vlan command [727](#)
- show vlan command, fields [729](#)
- show vlan filter command [734](#)
- show vmps command [735](#)
- show vtp command [738](#)
- shutdown command [743](#)
- shutdown threshold, Layer 2 protocol tunneling [299](#)
- shutdown vlan command [744](#)
- small violation-rate command [745](#)
- Smartports macros
 - See macros
- SNMP host, specifying [752](#)
- SNMP informs, enabling the sending of [747](#)
- snmp-server enable traps command [747](#)
- snmp-server host command [752](#)
- snmp trap mac-notification command [757](#)
- SNMP traps
 - enabling MAC address notification trap [757](#)
 - enabling the MAC address notification feature [327](#)
 - enabling the sending of [747](#)
- SoftPhone
 - See Cisco SoftPhone
- software images
 - copying [8](#)
 - deleting [109](#)
 - downloading [11](#)
 - upgrading [8, 11](#)
 - uploading [18](#)
- software version, displaying [725](#)
- source ports, MVR [399](#)
- SPAN
 - configuring [391](#)
 - debug messages, display [27](#)
 - displaying [673](#)
 - filter SPAN traffic [391](#)
 - sessions
 - add interfaces to [391](#)
 - displaying [673](#)
 - start new [391](#)
- spanning-tree backbonefast command [759](#)
- spanning-tree bpduguard command [760](#)
- spanning-tree bpduguard command [762](#)

- spanning-tree cost command [764](#)
- spanning-tree etherchannel command [766](#)
- spanning-tree extend system-id command [768](#)
- spanning-tree guard command [770](#)
- spanning-tree link-type command [772](#)
- spanning-tree loopguard default command [774](#)
- spanning-tree mode command [776](#)
- spanning-tree mst configuration command [778](#)
- spanning-tree mst cost command [780](#)
- spanning-tree mst forward-time command [782](#)
- spanning-tree mst hello-time command [783](#)
- spanning-tree mst max-age command [784](#)
- spanning-tree mst max-hops command [785](#)
- spanning-tree mst port-priority command [787](#)
- spanning-tree mst pre-standard command [789](#)
- spanning-tree mst priority command [790](#)
- spanning-tree mst root command [791](#)
- spanning-tree portfast (global configuration) command [795](#)
- spanning-tree portfast (interface configuration) command [797](#)
- spanning-tree port-priority command [793](#)
- Spanning Tree Protocol
 - See STP
- spanning-tree transmit hold-count command [799](#)
- spanning-tree uplinkfast command [800](#)
- spanning-tree vlan command [802](#)
- speed command [805](#)
- srr-queue bandwidth limit command [807](#)
- srr-queue bandwidth share command [811](#)
- SSH, configuring version [264](#)
- stack-mac persistent timer command [813](#)
- stack member
 - access [475](#)
 - number [716, 824](#)
 - priority value [821](#)
 - provisioning [822](#)
 - reloading [454](#)
- stacks, switch
 - disabling a member [819](#)
 - enabling a member [819](#)
 - MAC address [813](#)
 - provisioning a new member [822](#)
 - reloading [454](#)
 - stack member access [475](#)
 - stack member number [716, 824](#)
 - stack member priority value [716, 821](#)
- static-access ports, configuring [828](#)
- statistics, Ethernet group [465](#)
- sticky learning, enabling [846](#)
- storm-control command [816](#)
- STP
 - BackboneFast [759](#)
 - counters, clearing [90](#)
 - debug messages, display
 - BackboneFast events [88](#)
 - MSTP [91](#)
 - optimized BPDUs handling [90](#)
 - spanning-tree activity [86](#)
 - switch shim [93](#)
 - transmitted and received BPDUs [89](#)
 - UplinkFast [95](#)
 - detection of indirect link failures [759](#)
 - enabling protocol tunneling for [299](#)
 - EtherChannel misconfiguration [766](#)
 - extended system ID [768](#)
 - path cost [764](#)
 - protocol modes [776](#)
 - root port
 - accelerating choice of new [800](#)
 - loop guard [770](#)
 - preventing from becoming designated [770](#)
 - restricting which can be root [770](#)
 - root guard [770](#)
 - UplinkFast [800](#)

STP (continued)

root switch

- affects of extended system ID [768, 803](#)
- hello-time [802](#)
- interval between BPDU messages [802](#)
- interval between hello BPDU messages [802](#)
- max-age [802](#)
- port priority for selection of [793](#)
- primary or secondary [802](#)
- switch priority [802](#)

state changes

- blocking to forwarding state [797](#)
- enabling BPDU filtering [760, 795](#)
- enabling BPDU guard [762, 795](#)
- enabling Port Fast [795, 797](#)
- enabling timer to recover from error state [186](#)
- forward-delay time [802](#)
- length of listening and learning states [802](#)
- shutting down Port Fast-enabled ports [795](#)

state information display [707](#)VLAN options [790, 802](#)SVIs, creating [198](#)SVI status calculation [830](#)

Switched Port Analyzer

See SPAN

switching characteristics

- modifying [826](#)
- returning to interfaces [826](#)

switchport access command [828](#)switchport autostate exclude command [830](#)switchport backup interface command [832](#)switchport block command [837](#)switchport command [826](#)switchport host command [838](#)switchport mode command [839](#)switchport mode private-vlan command [842](#)switchport nonegotiate command [844](#)switchport port-security aging command [851](#)switchport port-security command [846](#)switchport priority extend command [853](#)switchport private-vlan command [855](#)switchport protected command [857](#)switchports, displaying [565](#)switchport trunk command [859](#)switchport voice vlan command [863, 864](#)switch priority command [819, 821](#)switch provision command [822](#)switch renumber command [824](#)system env temperature threshold yellow command [866](#)system message logging [315](#)system message logging, save message to flash [316](#)system mtu command [868](#)system resource templates [466](#)

T
tar files, creating, listing, and extracting [15](#)TDR, running [870](#)Telnet, using to communicate to cluster switches [452](#)temperature information, displaying [546](#)templates, system resources [466](#)test cable-diagnostics tdr command [870](#)test relay [871](#)traceroute mac command [871](#)traceroute mac ip command [874](#)trunking, VLAN mode [839](#)trunk mode [839](#)trunk ports [839](#)trunks, to non-DTP device [840](#)trusted boundary for QoS [388](#)trusted port states for QoS [388](#)tunnel ports, Layer 2 protocol, displaying [624](#)type (boot loader) command [23](#)

U

UDLD

- aggressive mode [878, 880](#)
- debug messages, display [104](#)
- enable globally [878](#)
- enable per interface [880](#)
- error recovery timer [186](#)
- message timer [878](#)
- normal mode [878, 880](#)
- reset a shutdown interface [882](#)
- status [722](#)
- udld command [878](#)
- udld port command [880](#)
- udld reset command [882](#)
- unicast storm control [816](#)
- UniDirectional Link Detection
 - See UDLD
- unknown multicast traffic, preventing [837](#)
- unknown unicast traffic, preventing [837](#)
- unset (boot loader) command [24](#)
- upgrading
 - software images
 - copying [8](#)
 - downloading [11](#)
 - monitoring status of [489](#)
- UplinkFast, for STP [800](#)
- user EXEC mode [2, 3](#)

V

- version (boot loader) command [26](#)
- version mismatch mode [717, 39](#)
- vlan (global configuration) command [883](#)
- vlan (VLAN configuration) command [889](#)
- vlan access-map command [895](#)
- VLAN access map configuration mode [895](#)

VLAN access maps

- actions [6](#)
- displaying [732](#)

VLAN-based QoS [390](#)

VLAN configuration

- rules [886, 891](#)
- saving [883, 893](#)

VLAN configuration mode

- commands
 - VLAN [889](#)
 - VTP [913](#)

description [5](#)

entering [897](#)

summary [3](#)

vlan database command [897](#)

vlan dot1q tag native command [900](#)

vlan filter command [902](#)

VLAN filters, displaying [734](#)

VLAN ID range [883, 889](#)

VLAN maps

- applying [902](#)
- creating [895](#)
- defining [349](#)
- displaying [732](#)

VLAN Query Protocol

See VQP

VLANs

- adding [883](#)
- configuring [883, 889](#)
- debug messages, display
 - ISL [100](#)
 - VLAN IOS file system error tests [98](#)
 - VLAN manager activity [96](#)
 - VTP [102](#)
- displaying configurations [727](#)
- enabling guest VLAN supplicant [131, 142, 191](#)
- extended-range [883](#)

VLANs (continued)

MAC addresses

displaying [657](#)number of [644](#)media types [886, 891](#)normal-range [883, 889](#)private [842](#)configuring [442](#)displaying [727](#)

See also private VLANs

restarting [744](#)saving the configuration [883](#)shutting down [744](#)SNMP traps for VTP [750, 754](#)suspending [744](#)variables [889](#)

VLAN Trunking Protocol

See VTP

VM mode [717, 39](#)

VMPS

configuring servers [907](#)displaying [735](#)error recovery timer [187](#)reconfirming dynamic VLAN assignments [904](#)vmps reconfirm (global configuration) command [905](#)vmps reconfirm (privileged EXEC) command [904](#)vmps retry command [906](#)vmps server command [907](#)

voice VLAN

configuring [863, 864](#)setting port priority [853](#)

VQP

and dynamic-access ports [829](#)clearing client statistics [92](#)displaying information [735](#)per-server retry count [906](#)reconfirmation interval [905](#)reconfirming dynamic VLAN assignments [904](#)

VTP

changing characteristics [909](#)clearing pruning counters [93](#)

configuring

domain name [909, 913](#)file name [909](#)mode [909, 913](#)password [909, 913](#)counters display fields [739](#)displaying information [738](#)

enabling

pruning [909, 913](#)tunneling for [299](#)Version 2 [909, 913](#)mode [909, 913](#)pruning [909, 913](#)saving the configuration [883, 893](#)statistics [738](#)status [738](#)status display fields [741](#)vtp (global configuration) command [909](#)vtp (VLAN configuration) command [913](#)

Wwireless controller, accessing [475](#)wireless controller switch. [107](#)

XXENPAK module serial EEPROM information [518, 562](#)