



INDEX

Symbols

- \$ matches the end of a string [1-7](#)
- () in commands [1-11](#)
- * matches 0 or more sequences of a pattern [1-7](#)
- + matches 1 or more sequences of a pattern [1-7](#)
- . matches any single character [1-7](#)
- ? command [1-1](#)
- ? matches 0 or 1 occurrence of a pattern [1-7](#)
- ^ matches the beginning of a string [1-7](#)
- _ matches a comma (,), left brace ({), left parenthesis [1-7](#)
- “ [1-10](#)

Numerics

- 10-Gigabit Ethernet uplink
 - selecting [2-233](#)
 - showing the mode [2-641, 2-642](#)
- 802.1Q trunk ports and native VLANs [2-1024](#)
- 802.1Q tunnel ports
 - configuring [2-956](#)
- 802.1S Multiple Spanning Tree
 - see MST
- 802.1X
 - configuring for multiple hosts [2-182](#)
 - configuring for single host [2-182](#)
 - configuring multiple domains [2-182](#)
 - disabling port control [2-174](#)
 - enabling port control [2-174](#)
- 802.1X Critical Authentication
 - disabling on a port [2-176](#)
 - disabling on a VLAN [2-179](#)
- EAPOL

- disabling send success packets [2-177](#)
- enabling send success packets [2-177](#)
- enabling on a port [2-176](#)
- enabling on a VLAN [2-179](#)
- returning delay time to default setting [2-178](#)
- setting delay time on a port [2-178](#)
- 802.1X critical authentication
 - configure parameters [2-25](#)
- 802.1X critical recovery delay, configuring [2-25](#)
- 802.1X Port Based Authentication
 - debugging 802.1X Port Based Authentication [2-122](#)
 - displaying port based authentication [2-621](#)
 - enabling accounting for authentication sessions [2-4](#)
 - enabling authentication on the system [2-193](#)
 - enabling guest VLAN [2-180](#)
 - enabling guest VLAN supplicant [2-172, 2-181](#)
 - enabling manual control of auth state [2-189](#)
 - enabling periodic re-authentication of the client [2-192](#)
 - initializing re-authentication of dot1x ports [2-191](#)
 - initializing state machines [2-184](#)
 - receive session termination message upon reboot [2-5](#)
 - setting maximum number for EAP requests [2-187](#)
 - setting the reauthentication timer [2-194](#)

A

- aaa authorization network command [2-175](#)
- abbreviating commands
 - context-sensitive help [1-1](#)
- Access Gateway Module
 - connecting to a module [2-22](#)
 - connecting to a remote module [2-533](#)
 - connecting to a specific remote module [2-562](#)

- access-group
 - displaying mac interface [2-756](#)
 - show mode interface [2-475, 2-583, 2-823](#)
- access groups
 - IP [2-6, 2-169](#)
- access lists
 - clearing an access template [2-79](#)
 - defining ARP [2-21](#)
 - displaying ARP information [2-587](#)
 - See also ACLs, MAC ACLs, and VACLs
- access maps
 - applying with VLAN filter [2-1026](#)
- access-node-identifier, setting for the switch [2-478](#)
- access-policies, applying using host-mode [2-30](#)
- ACLs
 - access-group mode [2-6](#)
 - balancing hardware regions [2-12](#)
 - capturing control packets [2-8](#)
 - determining ACL hardware programming [2-10](#)
 - disabling hardware statistics [2-227](#)
 - displaying mac access-group interface [2-756](#)
 - enabling hardware statistics [2-227](#)
 - using ACL naming conventions for MAC ACLs [2-358](#)
- action clause
 - specifying drop or forward action in a VACL [2-13](#)
- addresses, configuring a maximum [2-461](#)
- adjacency
 - debugging the adjacency table [2-115](#)
 - disabling the debug facility [2-115](#)
 - displaying information about the adjacency table [2-584](#)
 - displaying IPC table entries [2-115](#)
- aggregate policer
 - displaying information [2-824](#)
- aging time
 - displaying MAC address aging time [2-759](#)
 - MAC address table [2-361](#)
- alarms
 - displaying operational status [2-629](#)
- alternation
 - description [1-10](#)
- anchoring
 - description [1-10](#)
- anycp, show multicast [2-586](#)
- ANCP client
 - port identifier [2-16](#)
 - remote server [2-17](#)
 - set router to become [2-18](#)
- ARP
 - access list, displaying detailed information [2-587](#)
 - defining access-lists [2-21](#)
- ARP inspection
 - enforce certain types of checking [2-251](#)
- ARP packet
 - deny based on DHCP bindings [2-157](#)
 - permit based on DHCP bindings [2-439](#)
- authentication [2-25, 2-32](#)
 - changing the control-direction [2-23](#)
 - configure actions for events
 - configuring the actions [2-26](#)
 - configuring port-control [2-36](#)
 - enabling reauthentication [2-35](#)
 - enabling Webauth fallback [2-29](#)
 - host-mode configuration [2-30](#)
 - setting priority of methods [2-38](#)
 - setting the timer [2-40](#)
 - setting username [2-1011](#)
 - specifying the order of methods [2-33](#)
 - using an MD5-type encryption method [2-1011](#)
 - verifying MD5 signature [2-1013](#)
 - verifying the checksum for Flash memory [2-1013](#)
- authentication control-direction command [2-23](#)
- authentication critical recovery delay command [2-25](#)
- authentication event command [2-26](#)
- authentication fallback command [2-29](#)
- authentication host-mode [2-30](#)
- authentication methods, setting priority [2-38](#)

- authentication methods, specifying the order of attempts [2-33](#)
- authentication open command [2-32](#)
- authentication order command [2-33](#)
- authentication periodic command [2-35](#)
- authentication port-control command [2-36](#)
- authentication priority command [2-38](#)
- authentication timer, setting [2-40](#)
- authentication timer command [2-40](#)
- authentication violation command [2-42](#)
- auth fail VLAN
 - enable on a port [2-173](#)
 - set max number of attempts [2-172](#)
- Auth Manager
 - configuring
 - authentication timer [2-40](#)
- authorization state
 - enabling manual control [2-189](#)
- authorization state of a controlled port [2-189](#)
- automatic installation
 - displaying status [2-592](#)
- automatic medium-dependent interface crossover
 - See Auto-MDIX
- Auto-MDIX
 - disabling [2-406](#)
 - enabling [2-406](#)
- auto-negotiate interface speed
 - example [2-933](#)
- auto-QoS
 - configuring for VoIP [2-44](#)
 - displaying configuration [2-593](#)
- average-packet-size (netflow-lite monitor submode) command [2-48](#)

B

- baby giants
 - displaying the system MTU setting [2-858](#)
 - setting the maximum Layer 2 payload size [2-983](#)

- BackboneFast
 - displaying debugging messages [2-144](#)
 - displaying spanning tree status [2-847](#)
 - enabling debugging [2-144](#)
- bandwidth command [2-50](#)
- bindings
 - store for DHCP snooping [2-263](#)
- BOOT environment variable
 - displaying information [2-596](#)
- bootflash
 - displaying information [2-594](#)
- BPDUs
 - debugging spanning tree activities [2-142](#)
- bridge protocol data units
 - See BPDUs
- broadcast suppression level
 - configuring [2-934](#), [2-936](#)
 - enabling [2-934](#), [2-936](#)

C

- cable diagnostics
 - TDR
 - displaying test results [2-597](#)
 - testing conditions of copper cables [2-987](#)
- call home
 - displaying information [2-599](#)
 - e-mailing output [2-58](#)
 - entering configuration submode [2-53](#)
 - executing [2-58](#)
 - manually send test message [2-61](#)
 - receiving information [2-56](#)
 - sending alert group message [2-59](#)
 - submitting information [2-56](#)
- call home destination profiles
 - displaying [2-601](#)
- Catalyst 4507R [2-459](#)
- CDP
 - configuring tunneling encapsulation rate [2-345](#)

- displaying
 - neighbor information [2-604](#)
 - enabling protocol tunneling for [2-340](#)
 - set drop threshold for [2-343](#)
- CEF
 - displaying next-hop information [2-678](#)
 - displaying VLAN configuration information [2-678](#)
- chassis
 - displaying
 - chassis MAC address ranges [2-753](#)
 - current and peak traffic meter readings [2-753](#)
 - percentage of backplane utilization [2-753](#)
 - switching clock failure recovery mode [2-753](#)
- circuit-id
 - setting for an interface [2-480](#)
- circuit-id, setting for an interface VLAN range [2-481](#)
- cisco-desktop
 - macro apply [2-370](#)
- Cisco Express Forwarding
 - See CEF
- cisco-phone
 - macro apply [2-372](#)
- cisco-router
 - macro apply [2-374](#)
- cisco-switch
 - macro apply [2-376](#)
- CISP
 - See Client Information Signalling Protocol
- cisp enable command [2-66](#)
- class maps
 - creating [2-70](#)
 - defining the match criteria [2-399](#)
- clear commands
 - clearing Gigabit Ethernet interfaces [2-77](#)
 - clearing IGMP group cache entries [2-86](#)
 - clearing interface counters [2-72](#)
 - clearing IP access lists [2-79, 2-80](#)
 - clearing IP ARP inspection statistics VLAN [2-81](#)
 - clearing IP DHCP snooping database statistics [2-85](#)
 - clearing MFIB counters and routes [2-89](#)
 - clearing MFIB fastdrop entries [2-90](#)
 - clearing PAgP channel information [2-99](#)
 - clearing QoS aggregate counters [2-103](#)
 - clearing VLAN interfaces [2-78](#)
- clear energywise neighbors command [2-74](#)
- clear ip wccp command [2-91](#)
- clear netflow-lite exporter statistics command [2-96](#)
- clear netflow-lite monitor statistics interface command [2-97](#)
- clear nmsp statistics command [2-98](#)
- Client Information Signalling Protocol [2-175](#)
- Client Information Signalling Protocol, enabling [2-66](#)
- CLI string search
 - anchoring [1-10](#)
 - expressions [1-7](#)
 - filtering [1-6](#)
 - multiple-character patterns [1-8](#)
 - multipliers [1-9](#)
 - parentheses for recall [1-11](#)
 - searching outputs [1-6](#)
 - single-character patterns [1-7](#)
 - using [1-6](#)
- command modes
 - accessing privileged EXEC mode [1-5](#)
 - exiting [1-5](#)
 - understanding user EXEC and configuration modes [1-5](#)
- condition interface
 - debugging interface-related activities [2-117](#)
- condition vlan
 - debugging VLAN output [2-120](#)
- configuration, saving [1-11](#)
- configuring
 - root as secondary [2-917](#)
- configuring a SPAN session to monitor
 - limit SPAN source traffic [2-411](#)
- configuring critical recovery [2-25](#)
- configuring forward delay [2-913](#)

configuring root as primary [2-917](#)

CoPP

attaching

policy map to control plane [2-560](#)

displaying

policy-map class information [2-797](#)

entering configuration mode [2-107](#)

removing

service policy from control plane [2-560](#)

CoS

assigning to Layer 2 protocol packets [2-342](#)

cos (netflow-lite exporter submode) command [2-109](#)

CoS QoS default

defining value on an interface [2-509](#)

Cost of Service

See QoS CoS

counter command [2-111](#)

counters

clearing interface counters [2-72](#)

critical authentication, configure 802.1X parameters [2-25](#)

critical recovery, configuring 802.1X parameter [2-25](#)

D

DAI

clear statistics [2-81](#)

DBL

displaying qos dbl [2-825](#)

enabling DBL globally on the switch [2-510](#)

debug commands

debugging backup events [2-116](#)

debugging DHCP snooping events [2-127](#)

debugging DHCP snooping messages [2-128](#)

debugging EtherChannel/PAgP/shim [2-123](#)

debugging IPC activity [2-126](#)

debugging IP DHCP snooping security messages [2-129](#)

debugging NVRAM activities [2-133](#)

debugging PAgP activities [2-134](#)

debugging port manager activities [2-137](#)

debugging spanning tree activities [2-142](#)

debugging spanning tree backbonefast [2-144](#)

debugging spanning tree UplinkFast [2-147](#)

debugging supervisor redundancy [2-141](#)

debugging VLAN manager activities [2-148](#)

displaying monitor activity [2-131](#)

displaying the adjacency table [2-115](#)

enabling debug dot1x [2-122](#)

enabling debugging messages for ISL VLAN IDs [2-151](#)

enabling debugging messages for VTP [2-152](#)

enabling debugging of UDLD activity [2-153](#)

enabling switch shim debugging [2-145](#)

enabling VLAN manager file system error tests [2-149](#)

limiting debugging output for VLANs [2-120](#)

limiting interface debugging output [2-117](#)

limiting output for debugging standby state changes [2-118](#)

shortcut to the debug condition interface [2-125](#)

debugging

activity monitoring [2-131](#)

DHCP snooping events [2-127](#)

DHCP snooping packets [2-128](#)

IPC activities [2-126](#)

IP DHCP snooping security packets [2-129](#)

NVRAM activities [2-133](#)

PAgP activities [2-134](#)

PAgP shim [2-123](#)

PM activities [2-137](#)

PPPoE Intermediate Agent [2-139](#)

spanning tree BackboneFast events [2-144](#)

spanning tree switch shim [2-145](#)

spanning tree UplinkFast events [2-147](#)

VLAN manager activities [2-148](#)

VLAN manager IOS file system error tests [2-149](#)

VTP protocol debug messages [2-152](#)

debug nmosp command [2-132](#)

debug spanning tree switch [2-145](#)

- debug sw-vlan vtp [2-152](#)
- default CoS value [2-509](#)
- default form of a command, using [1-6](#)
- defining egress DSCP-to-CoS mapping [2-516](#)
- destination (netflow-lite exporter submode) command [2-159](#)
- DHCP
 - clearing database statistics [2-85](#)
- DHCP bindings
 - configuring bindings [2-261](#)
 - deny ARP packet based on matches [2-157](#)
 - permit ARP packet based on matches [2-439](#)
- DHCP snooping
 - clearing binding entries [2-82](#)
 - clearing database [2-84](#)
 - displaying binding table [2-681](#)
 - displaying configuration information [2-679](#)
 - displaying status of DHCP database [2-684](#)
 - displaying status of error detection [2-632](#)
 - enabling DHCP globally [2-260](#)
 - enabling IP source guard [2-302](#)
 - enabling on a VLAN [2-270](#)
 - enabling option 82 [2-265, 2-267](#)
 - enabling option-82 [2-272](#)
 - enabling rate limiting on an interface [2-268](#)
 - enabling trust on an interface [2-269](#)
 - establishing binding configuration [2-261](#)
 - renew binding database [2-535](#)
 - store generated bindings [2-263](#)
- diagnostic fpga soft-error recover command [2-169](#)
- diagnostic test
 - bootup packet memory [2-615](#)
 - displaying attributes [2-609](#)
 - display module-based results [2-611](#)
 - running [2-171](#)
 - show results for TDR [2-597](#)
 - testing conditions of copper cables [2-987](#)
- displaying error disable recovery [2-633](#)
- displaying inline power status [2-812](#)
- displaying monitoring activity [2-131](#)
- displaying PoE policing and monitoring status [2-820](#)
- displaying SEEPROM information
 - GBIC [2-643](#)
- displaying SPAN session information [2-858, 2-936](#)
- document conventions [1-xxii](#)
- document organization [1-xxi](#)
- DoS
 - CoPP
 - attaching policy map to control plane [2-560](#)
 - displaying policy-map class information [2-797](#)
 - entering configuration mode [2-107](#)
 - removing service policy from control plane [2-560](#)
 - entering
 - CoPP configuration mode [2-107](#)
- DOS attack
 - protecting system's resources [2-246](#)
- dot1x credentials (global configuration) command [2-175](#)
- drop threshold, Layer 2 protocol tunneling [2-343](#)
- dscp (netflow-lite exporter submode command [2-196](#)
- DSCP rewrite for IP packets
 - enable [2-520](#)
- dual-capable port
 - selecting a connector [2-408](#)
- duplex mode
 - configuring autonegotiation on an interface [2-198](#)
 - configuring full duplex on an interface [2-198](#)
 - configuring half duplex on an interface [2-198](#)
- dynamic ARP inspection
 - preventing [2-246](#)
- Dynamic Buffer Limiting
 - See DBL
- Dynamic Host Configuration Protocol
 - See DHCP

E

- EAP
 - restarting authentication process [2-187](#)

- EDCS-587028 [2-588, 2-753](#)
 - EIGRP (Enhanced IGRP)
 - filters
 - routing updates, preventing [2-436](#)
 - enabling
 - debugging for UDLD [2-153](#)
 - voice VLANs [2-949](#)
 - enabling open access [2-32](#)
 - EnergyWise
 - display power information through queries [2-207](#)
 - display setting, status of entity and PoE ports [2-625](#)
 - on an entity
 - enable, assign to domain, and set password [2-205](#)
 - on an entity, enable and configure [2-200](#)
 - on a PoE port
 - configuring on PoE port [2-202](#)
 - energywise (global configuration) command [2-200, 2-202](#)
 - energywise domain command [2-205](#)
 - EnergyWise neighbor table, deleting [2-74](#)
 - energywise query command [2-207](#)
 - environmental
 - alarms [2-629](#)
 - displaying information [2-629](#)
 - status [2-629](#)
 - temperature [2-629](#)
 - epm access control command [2-211](#)
 - erase a file [2-212](#)
 - error disable detection
 - clearing error disable on an interface [2-75](#)
 - enabling error disable detection [2-75, 2-215](#)
 - enabling per-VLAN on BPDU guard [2-215](#)
 - error-disabled state
 - displaying [2-662](#)
 - error disable recovery
 - configuring recovery mechanism variables [2-217](#)
 - displaying recovery timer information [2-633](#)
 - enabling ARP inspection timeout [2-217](#)
 - specifying recovery cause [2-217](#)
 - EtherChannel
 - assigning interfaces to EtherChannel groups [2-62](#)
 - debugging EtherChannel [2-123](#)
 - debugging PAgP shim [2-123](#)
 - debugging spanning tree activities [2-142](#)
 - displaying information for a channel [2-635](#)
 - removing interfaces from EtherChannel groups [2-62](#)
 - EtherChannel guard
 - detecting STP misconfiguration [2-903](#)
 - Explicit Host Tracking
 - clearing the database [2-88](#)
 - enabling per-VLAN [2-284](#)
 - exporter (netflow-lite monitor submode) command [2-222](#)
 - expressions
 - matching multiple expression occurrences [1-9](#)
 - multiple-character patterns [1-8](#)
 - multiplying pattern occurrence [1-11](#)
 - single-character patterns [1-7](#)
 - Extensible Authentication Protocol
 - See EAP
-
- ## F
- fallback profile, specifying [2-29](#)
 - field replaceable unit (FRU)
 - displaying status information [2-629](#)
 - filters
 - EIGRP
 - routing updates, preventing [2-436](#)
 - Flash memory file system
 - displaying file system information [2-594](#)
 - verifying checksum [2-1013](#)
 - flow control
 - configuring a gigabit interface for pause frames [2-224](#)
 - displaying per-interface statistics for flow control [2-639](#)
-
- ## G
- GBIC

- displaying SEEPROM information [2-643](#)
- generic-error-message, setting for the switch [2-478](#)
- Gigabit Ethernet interface
 - clearing the hardware logic [2-77](#)
- Gigabit Ethernet uplink
 - selecting [2-233](#)
 - showing the mode [2-641, 2-642](#)
- global configuration mode
 - using [1-5](#)

H

- hardware module
 - resetting a module by toggling the power [2-229](#)
- hardware statistics
 - disabling [2-227](#)
 - enabling [2-227](#)
- hardware uplink
 - selecting the mode [2-233](#)
 - showing the mode [2-641, 2-642](#)
- helper addresses, IP [2-699](#)
- hot standby protocol
 - debugging [2-118](#)
 - disabling debugging [2-118](#)
 - limiting output [2-118](#)
- hw-module system max-queue-limit command [2-230](#)
- hw-module uplink mode shared-backplane command [2-231](#)

I

- identifier-string, setting for the switch [2-478](#)
- ID mapping, creating an ANCP client [2-16](#)
- IDROMs
 - displaying SEEPROM information
 - chassis [2-643](#)
 - clock module [2-643](#)
 - fan trays [2-643](#)
 - module [2-643](#)

- mux buffer [2-643](#)
 - power supplies [2-643](#)
 - supervisor engine [2-643](#)
- ifIndex persistence
 - clearing SNMP ifIndex commands [2-885](#)
 - compress SNMP ifIndex table format [2-892](#)
 - disabling globally [2-891](#)
 - disabling on an interface [2-887](#)
 - enabling globally [2-891](#)
 - enabling on an interface [2-887](#)

IGMP

- applying filters for host joining on Layer 2 interfaces [2-274](#)
- clearing IGMP group cache entries [2-86](#)
- configuring frequency for IGMP host-query messages [2-277](#)
- creating an IGMP profile [2-276](#)
- displaying IGMP interface configuration information [2-686](#)
- displaying profiles [2-688](#)
- setting maximum group numbers [2-275](#)

IGMP profiles

- displaying [2-688](#)

IGMP snooping

- clearing the EHT database [2-88](#)
- configuring a Layer 2 interface as a group member [2-290](#)
- configuring a Layer 2 interface as a multicast router [2-288](#)
- configuring a static VLAN interface [2-290](#)
- displaying multicast information [2-695](#)
- displaying VLAN information [2-689, 2-693, 2-696](#)
- enabling [2-279](#)
- enabling immediate-leave processing [2-286](#)
- enabling on a VLAN [2-283](#)
- enabling per-VLAN Explicit Host Tracking [2-284](#)

informs

- enabling [2-889](#)

inline power

- displaying inline power status [2-812](#)

- In Service Software Upgrade
 - See ISSU
- inspection log
 - clearing log buffer [2-80](#)
- interface
 - displaying suppressed multicast bytes [2-656](#)
- interface capabilities
 - displaying [2-652](#)
- interface configuration mode
 - summary [1-5](#)
- interface link
 - display cable disconnect time [2-659](#)
- interfaces
 - configuring dot1q tunnel ports [2-956](#)
 - creating an interface-range macro [2-156](#)
 - debugging output of interface related activities [2-117](#)
 - displaying description [2-658](#)
 - displaying error-disabled state [2-662](#)
 - displaying information when tunneling is enabled [2-747](#)
 - displaying status [2-658](#)
 - displaying traffic for a specific interface [2-649](#)
 - entering interface configuration mode [2-237](#)
 - executing a command on multiple ports in a range [2-240](#)
 - selecting an interface to configure [2-237](#)
 - setting a CoS value for Layer 2 packets [2-342](#)
 - setting drop threshold for Layer 2 packets [2-343](#)
 - setting the interface type [2-956](#)
- interface speed
 - configuring interface speed [2-931](#)
- interface transceiver
 - displaying diagnostic data [2-666](#)
- internal VLAN allocation
 - configuring [2-1029](#)
 - default setting [2-1029](#)
 - displaying allocation information [2-872](#)
- Internet Group Management Protocol
 - See IGMP
- IP address of remote ANCP server, setting [2-17](#)
- IP ARP
 - applying ARP ACL to VLAN [2-244](#)
 - clearing inspection statistics [2-81](#)
 - clearing status of log buffer [2-80](#)
 - controlling packet logging [2-255](#)
 - enabling dynamic inspection [2-253](#)
 - limit rate of incoming requests [2-246](#)
 - set per-port config trust state [2-250](#)
 - showing status of dynamic ARP inspection [2-673](#)
 - showing status of log buffer [2-676](#)
- IPC
 - debugging IPC activities [2-126](#)
- IP DHCP Snooping
 - See DHCP snooping
- IP header validation
 - disabling [2-301](#)
 - enabling [2-301](#)
- IP interfaces
 - displaying usability status [2-698](#)
- IP multicast
 - displaying multicast routing table information [2-704](#)
- ip multicast multipath command [2-294](#)
- IP packets
 - enable DSCP rewrite [2-520](#)
- IP phone and standard desktop
 - enabling Cisco-recommended features [2-372](#)
- IP Port Security
 - enabling [2-302](#)
- IP source binding
 - adding or deleting [2-298](#)
 - displaying bindingstaggging [2-709](#)
- IP source guard
 - debugging messages [2-129](#)
 - displaying configuration and filters [2-710](#)
 - enabling on DHCP snooping [2-302](#)
- IPv4 statistics, enabling collection [2-111](#)
- IPv6 MLD
 - configuring queries [2-319, 2-321](#)

- configuring snooping
 - last-listener-query-intervals [2-321](#)
- configuring snooping
 - listener-message-suppression [2-323](#)
- configuring snooping robustness-variables [2-324](#)
- configuring tcn topology change notifications [2-326](#)
- counting snooping last-listener-queries [2-319](#)
- displaying information [2-722](#)
- displaying ports for a switch or VLAN [2-724](#)
- displaying querier information [2-725](#)
- enabling snooping [2-317](#)
- enabling snooping on a VLAN [2-327](#)
- IPv6 statistics, enabling collection [2-111](#)
- ip wccp check services all command [2-309](#)
- ip wccp command [2-306](#)
- ip wccp group-address command [2-306](#)
- ip wccp group-list command [2-306](#)
- ip wccp group-listen command [2-311](#)
- ip wccp password command [2-306](#), [2-308](#)
- ip wccp redirect command [2-313](#)
- ip wccp redirect exclude in command [2-315](#)
- ip wccp redirect-list command [2-306](#)
- ISSU
 - canceling process [2-329](#)
 - configuring rollback timer [2-339](#)
 - displaying capability [2-728](#)
 - displaying client information [2-730](#)
 - displaying compatibility matrix [2-732](#)
 - displaying endpoint information [2-737](#)
 - displaying entities [2-738](#)
 - displaying FSM session [2-739](#)
 - displaying messages [2-740](#)
 - displaying negotiated [2-742](#)
 - displaying rollback-timer [2-743](#)
 - displaying session information [2-744](#)
 - displaying software version [2-745](#)
 - displaying state [2-745](#)
 - forcing switchover to standby supervisor engine [2-337](#)
 - loading new image [2-333](#)

- starting process [2-335](#)
- stopping rollback timer [2-331](#)

J

- Jumbo frames
 - enabling jumbo frames [2-417](#)

L

- LACP
 - deselecting channeling protocol [2-64](#)
 - enabling LACP on an interface [2-64](#)
 - setting channeling protocol [2-64](#)
- lacp system-priority command [2-348](#)
- Layer 2
 - displaying ACL configuration [2-756](#)
- Layer 2 interface type
 - specifying a nontrunking, nontagged single VLAN interface [2-956](#)
 - specifying a trunking VLAN interface [2-956](#)
- Layer 2 protocol ports
 - displaying [2-747](#)
- Layer 2 protocol tunneling error recovery [2-345](#)
- Layer 2 switching
 - enabling voice VLANs [2-949](#)
 - modifying switching characteristics [2-949](#)
- Layer 2 traceroute
 - IP addresses [2-992](#)
- Layer 3 interface, assign counters [2-111](#)
- Layer 3 switching
 - displaying information about an adjacency table [2-584](#)
 - displaying port status [2-664](#)
 - displaying status of native VLAN tagging [2-664](#)
- link-status event messages
 - disabling
 - globally [2-350](#), [2-353](#)
 - on an interface [2-351](#), [2-354](#)

- enabling
 - globally [2-350, 2-353](#)
 - on an interface [2-351, 2-354](#)

LLDP

- enabling power negotiation [2-349](#)
- lldp tlv-select power-management command [2-349](#)
- log buffer
 - show status [2-676](#)
- logging
 - controlling IP ARP packets [2-255](#)

M

- MAB, display information [2-753](#)
- MAB, enable and configure [2-356](#)
- mab command [2-356](#)
- MAC Access Control Lists
 - See MAC ACLs
- MAC ACLs
 - defining extended MAC access list [2-358](#)
 - displaying MAC ACL information [2-868](#)
 - naming an ACL [2-358](#)
- MAC addresses
 - disabling MAC address learning per VLAN [2-365](#)
 - displaying
 - notification settings [2-211, 2-727, 2-767](#)
- MAC address filtering
 - configuring [2-369](#)
 - disabling [2-369](#)
 - enabling [2-369](#)
- MAC address learning on a VLAN, enabling [2-365](#)
- MAC address table
 - adding static entries [2-396](#)
 - clearing dynamic entries [2-93, 2-95](#)
 - configuring aging time [2-361](#)
 - displaying dynamic table entry information [2-763](#)
 - displaying entry count [2-761](#)
 - displaying information [2-757](#)
 - displaying interface-based information [2-765](#)

- displaying multicast information [2-768](#)
- displaying notification information [2-770](#)
- displaying protocol-based information [2-772](#)
- displaying static table entry information [2-774](#)
- displaying the MAC address aging time [2-759](#)
- displaying VLAN-based information [2-777](#)
- enabling authentication bypass [2-185](#)
- enabling notifications [2-367](#)
- learning in the protocol buckets [2-362](#)
- removing static entries [2-396](#)

- mac address-table learning vlan command [2-365](#)

MAC address tables

- adding static entries [2-369](#)
- deleting secure or specific addresses [2-100](#)
- disabling IGMP snooping on static MAC addresses [2-369](#)
- removing static entries [2-369](#)

- mac-address-table static [2-369](#)

MAC address unicast filtering

- dropping unicast traffic [2-369](#)

- MAC authentication bypass (MAB), display information [2-753](#)

- MAC authorization bypass(MAB), enable and configure [2-356](#)

macro

- displaying descriptions [2-395](#)

- macro auto global processing command [2-378, 2-380, 2-383, 2-385, 2-387, 2-389, 2-390, 2-392, 2-779](#)

macro keywords

- help strings [2-2](#)

macros

- adding a global description [2-395](#)
- cisco global [2-393](#)
- system-cpp [2-394](#)

- mapping secondary VLANs to MST instance [2-494](#)

- mapping VLAN(s) to an MST instance [2-235](#)

- match (class-map configuration) command [2-14, 2-161, 2-163, 2-165, 2-167, 2-399, 2-937, 2-939, 2-941, 2-943, 2-947](#)

maximum transmission unit (MTU)

- displaying the system MTU setting [2-858](#)

setting the maximum Layer 2 payload size [2-983](#)

MD5

verifying MD5 signature [2-1013](#)

message digest 5

See MD5

MFIB

clearing ip mfib counters [2-89](#)

clearing ip mfib fastdrop [2-90](#)

displaying all active MFIB routes [2-701](#)

displaying MFIB fastdrop table entries [2-703](#)

enabling IP MFIB fastdrops [2-293](#)

MLD

configuring snooping

last-listener-query-intervals [2-321](#)

configuring snooping

listener-message-suppression [2-323](#)

configuring snooping robustness-variables [2-324](#)

configuring topology change notifications [2-326](#)

counting snooping last-listener-queries [2-319](#)

enabling snooping [2-317](#)

enabling snooping on a VLAN [2-327](#)

MLD snooping

displaying [2-725](#)

modes

access-group [2-6](#)

show access-group interface [2-475](#), [2-583](#), [2-823](#)

switching between PVST+, MST, and Rapid PVST [2-908](#)

See also command modes

module password clearing [2-76](#)

module reset

resetting a module by toggling the power [2-229](#)

--More-- prompt

filter [1-6](#)

search [1-7](#)

MST

designating the primary and secondary root [2-917](#)

displaying MST protocol information [2-852](#)

displaying region configuration information [2-852](#)

displaying spanning tree information [2-852](#)

entering MST configuration submode [2-911](#)

setting configuration revision number [2-552](#)

setting path cost and port priority for instances [2-909](#)

setting the forward delay timer for all instances [2-913](#)

setting the hello-time delay timer for all instances [2-914](#)

setting the max-age timer for all instances [2-915](#)

setting the MST region name [2-418](#)

specifying the maximum number of hops [2-916](#)

switching between PVST+ and Rapid PVST [2-908](#)

using the MST configuration submode revision command [2-552](#)

using the submode name command [2-418](#)

MTU

displaying global MTU settings [2-858](#)

multi-auth, setting [2-30](#)

Multicast Listener Discovery

See MLD

multicast

enabling storm control [2-936](#)

show ancp [2-586](#)

multicast/unicast packets

prevent forwarding [2-955](#)

Multicast Forwarding Information Base

See MFIB

multi-domain, setting [2-30](#)

multiple-character patterns [1-8](#)

Multiple Spanning Tree

See MST

N

native VLAN

controlling tagging of traffic [2-976](#)

displaying ports eligible for native tagging [2-870](#)

displaying ports eligible for tagging [2-870](#)

enabling tagging on 802.1Q trunk ports [2-1024](#)

specifying the tagging of traffic [2-977](#)

NetFlow

- enabling NetFlow statistics [2-296](#)
- including infer fields in routing statistics [2-296](#)
- netflow-lite exporter command [2-419](#)
- netflow-lite monitor command [2-421](#)
- netflow-lite sampler command [2-423](#)
- next-hop
 - displaying CEF VLAN information [2-678](#)
- nmsp attachment suppress command [2-426](#)
- nmsp command [2-425](#)
- no form of a command, using [1-6](#)
- NVRAM
 - debugging NVRAM activities [2-133](#)

O

- open access on a port, enabling [2-32](#)
- options timeout (netflow-lite exporter submode) command [2-220, 2-427](#)
- output
 - pattern searches [1-7](#)

P

- packet counters (statistics)
 - clear for PPPoE Intermediate Agent [2-102](#)
- packet counters, display for PPPoE Intermediate Agent [2-821](#)
- packet forwarding
 - prevent unknown packets [2-955](#)
- packet memory failure
 - direct switch action upon detection [2-170](#)
- packet memory test
 - bootup, displaying results [2-615, 2-617](#)
 - ongoing, displaying results [2-619](#)
- packet-offset (netflow-lite sampler submode) command [2-429](#)
- packet rate (netflow-lite sampler submode) command [2-430](#)
- packet-section size (netflow-lite sampler submode) command [2-432](#)

PACL

- access-group mode [2-6](#)

paging prompt

- see --More-- prompt

PAgP

- clearing port channel information [2-99](#)
- debugging PAgP activity [2-134](#)
- deselecting channeling protocol [2-64](#)
- displaying port channel information [2-794](#)
- hot standby mode
 - returning to defaults [2-435](#)
 - selecting ports [2-435](#)
- input interface of incoming packets
 - learning [2-434](#)
 - returning to defaults [2-434](#)
- setting channeling protocol [2-64](#)

parentheses [1-11](#)

password

- clearing on an intelligent line module [2-76](#)
- establishing enhanced password security [2-1011](#)
- setting username [2-1011](#)

PBR

- displaying route maps [1-xxii](#)
- redistributing route maps [1-xxii](#)

PM activities

- debugging [2-137](#)
- disabling debugging [2-137](#)

PoE policing

- configure on an interface [2-470](#)

PoE policing and monitoring

- displaying status [2-820](#)

- police (percent) command [2-446](#)

- police (two rates) command [2-448, 2-450](#)

- police command [2-441](#)

- policing, configure PoE [2-470](#)

- policing and monitoring status

- displaying PoE [2-820](#)

Policy Based Routing

- See PBR

policy maps

creating [2-454](#)marking [2-564](#)

See also QoS, hierarchical policies

traffic classification

defining the class

defining trust states [2-999](#)

port, dual-capable

selecting the connector [2-408](#)

Port Aggregation Protocol

See PAgP

port-based authentication

displaying debug messages [2-122](#)displaying statistics and status [2-621](#)enabling 802.1X [2-189](#)host modes [2-182](#)manual control of authorization state [2-189](#)

periodic re-authentication

enabling [2-192](#)re-authenticating 802.1X-enabled ports [2-191](#)switch-to-client frame-retransmission number [2-187](#)

port channel

accessing [2-239](#)creating [2-239](#)displaying information [2-794](#)

load distribution method

resetting to defaults [2-456](#)setting [2-456](#)port-channel standalone-disable command [2-458](#)port control, changing from unidirectional or bidirectional [2-23](#)port-control value, configuring [2-36](#)

port range

executing [2-240](#)

port security

debugging ports security [2-138](#)deleting secure or specific addresses [2-100](#)displaying settings for an interface or switch [2-805](#)enabling [2-961](#)filter source IP and MAC addresses [2-302](#)setting action upon security violation [2-961](#)setting the rate limit for bad packets [2-961](#)sticky port [2-961](#)

Port Trust Device

displaying [2-826](#)power efficient-ethernet auto command [2-464](#)power inline logging global command [2-469](#)power negotiation through LLDP, enabling [2-349](#)

power status

displaying inline power [2-812](#)displaying power status [2-812](#)

power supply

configuring combined and redundant power on the Catalyst 4507R [2-459](#)configuring inline power [2-465](#)configuring power consumption [2-459](#)displaying the SEEPROM [2-643](#)setting inline power state [2-463](#)

PPPoE Discovery

enable vendor-tag stripping on packetsPPPoE Server

enable vendor-tag stripping on Discovery packets [2-484](#)PPPoE Discovery packets, limit rate arriving on an interface [2-482](#)

PPPoE Intermediate Agent

clear statistics (packet counters) [2-102](#)debugging [2-139](#)

pppoe intermediate-agent

enable intermediate agent on a switch [2-474](#)enable on an interface VLAN range [2-477](#)enable PPPoE Intermediate Agent on an interface [2-475](#)enable vendor-tag stripping of Discovery packets [2-484](#)format-type (global) [2-478](#)limit rate of PPPoE Discovery packets [2-482](#)set circuit-id or remote-id for an interface [2-480](#)set circuit-id or remote-id for an interface VLAN range [2-481](#)

set trust configuration on an interface [2-482, 2-483](#)

PPPoE Intermediate Agent, display configuration and statistics (packet counters) [2-821](#)

priority command [2-485](#)

priority-queue command [2-113](#)

Private VLAN

See PVLANS

privileged EXEC mode, summary [1-5](#)

prompts

system [1-5](#)

protocol tunneling

configuring encapsulation rate [2-345](#)

disabling [2-340](#)

displaying port information [2-747](#)

enabling [2-340](#)

setting a CoS value for Layer 2 packets [2-342](#)

setting a drop threshold for Layer 2 packets [2-343](#)

PVLANS

configuring isolated, primary, and community PVLANS [2-487](#)

controlling tagging of native VLAN traffic [2-976](#)

disabling sticky-ARP [2-299](#)

displaying map information for VLAN SVIs [2-661](#)

displaying PVLAN information [2-876](#)

enabling interface configuration mode [2-956](#)

enabling sticky-ARP [2-299](#)

mapping VLANs to the same SVI [2-491](#)

specifying host ports [2-956](#)

specifying promiscuous ports [2-956](#)

PVST+

switching between PVST and MST [2-908](#)

Q

QoS

account Layer 2 encapsulation [2-501](#)

attaching a policy-map to an interface [2-555](#)

automatic configuration [2-44](#)

class maps

creating [2-70](#)

defining the match criteria [2-399](#)

clearing aggregate counters [2-103](#)

configuring auto [2-44](#)

defining a named aggregate policer [2-503](#)

defining default CoS value [2-509](#)

defining ingress CoS-to-DSCP mapping [2-514](#)

displaying aggregate policer information [2-824](#)

displaying auto configuration [2-593](#)

displaying class maps information [2-607](#)

displaying configuration information [2-593](#)

displaying configurations of policies [2-800](#)

displaying policy map information [2-796, 2-803](#)

displaying QoS information [2-823](#)

displaying QoS map information [2-828](#)

egress queue-sets

enabling the priority queue [2-113](#)

enabling global configuration mode [2-497](#)

enabling on control packets [2-506](#)

enabling per-VLAN QoS for a Layer 2 interface [2-523](#)

enabling QoS on an interface [2-498](#)

hierarchical policies

average-rate traffic shaping on a class [2-577](#)

bandwidth allocation for a class [2-50, 2-69](#)

creating a service policy [2-558](#)

marking [2-564](#)

strict priority queueing (LLQ) [2-485](#)

mapping DSCP values to transmit queues [2-516](#)

mapping egress DSCP-to-CoS [2-516](#)

mapping the DSCP-to-CoS value [2-516](#)

policy maps

creating [2-454](#)

marking [2-564](#)

traffic classifications

trust states [2-999](#)

setting the mapping of policed DSCP values [2-518](#)

setting the trust state [2-521](#)

specifying flow-based match criteria [2-402](#)

Supervisor Engine 6-E

setting CoS [2-566](#)setting DSCP [2-569](#)setting precedence values [2-572](#)setting QoS group identifiers [2-575](#)

QoS CoS

configuring for tunneled Layer 2 protocol packets [2-342](#)defining default CoS value [2-509](#)qos dbl [2-510](#)

quality of service

See QoS

question command [1-1](#)

queueing information

displaying [2-826](#)

queue limiting

configuring packet limits [2-525](#)

R

Rapid PVST

switching between PVST and MST [2-908](#)re-authenticating 802.1X-enabled ports [2-191](#)

re-authentication

periodic [2-192](#)set the time [2-194](#)reauthentication, enabling [2-35](#)

reboots

restoring bindings across [2-261](#)

redundancy

accessing the main CPU [2-527](#)changing from active to standby supervisor engine [2-531](#)displaying information [2-830](#)displaying ISSU config-sync failure information [2-834](#)displaying redundancy facility information [2-830](#)displaying RF client list [2-830](#)displaying RF operational counters [2-830](#)displaying RF states [2-830](#)enabling automatic synchronization [2-47](#)forcing switchover to standby supervisor engine [2-531](#)mismatched command listing [2-529](#)set the mode [2-409](#)synchronizing the route processor configurations [2-396](#)related documentation [1-xxi](#)remote-id, setting for an interface [2-480](#)remote-id, setting for an interface VLAN range [2-481](#)

remote SPAN

See RSPAN

renew commands

ip dhcp snooping database [2-535](#)rep admin vlan command [2-536](#)rep block port command [2-537](#)rep lsl-age-timer command [2-541](#)rep preempt delay command [2-543](#)rep preempt segment command [2-545](#)rep segment command [2-546](#)rep stcn command [2-549](#)

resetting PVLAN trunk

setting switchport to trunk [2-956](#)retry failed authentication, configuring [2-26](#)rj45 connector, selecting the connector [2-408](#)

ROM monitor mode

summary [1-6](#)

Route Processor Redundancy

See redundancy

router, set to become ANCP client [2-18](#)

RPF

disabling IPv4 exists-only checks [2-304](#)enabling IPv4 exists-only checks [2-304](#)

RPR

set the redundancy mode [2-409](#)

RSPAN

converting VLAN to RSPAN VLAN [2-534](#)displaying list [2-878](#)

S

- sampler (netflow-lite monitor submode) command [2-553](#)
- saving configuration changes [1-11](#)
- secure address, configuring [2-459](#)
- secure ports, limitations [2-962](#)
- server (AAA) alive actions, configuring [2-26](#)
- server (AAA) dead actions, configuring [2-26](#)
- service-policy command (policy-map class) [2-558](#)
- session classification, defining [2-30](#)
- set the redundancy mode [2-409](#)
- sfp connector, selecting the connector [2-408](#)
- shape command [2-577](#)
- shell trigger command [2-581, 2-840](#)
- show ancp multicast [2-586](#)
- show authentication interface command [2-588](#)
- show authentication registration command [2-588](#)
- show authentication sessions command [2-588](#)
- show commands
 - filtering parameters [1-7](#)
 - searching and filtering [1-6](#)
 - show platform commands [1-11](#)
- show energywise command [2-625](#)
- show ipv6 snooping counters command [2-727](#)
- show ip wccp command [2-713](#)
- show ip wccp detail command [2-713](#)
- show ip wccp view command [2-713](#)
- show mab command [2-753](#)
- show mac address-table learning command [2-211, 2-767](#)
- show netflow-lite exporter command [2-786](#)
- show netflow-lite monitor command [2-788](#)
- show netflow-lite sampler command [2-790](#)
- show nmsp command [2-791](#)
- show vlan group command [2-871](#)
- show vlan mapping command [2-873](#)
- Simple Network Management Protocol
 - See SNMP
- single-character patterns
 - special characters [1-7](#)
- single-host, setting [2-30](#)
- slaveslot0
 - displaying information on the standby supervisor [2-843](#)
- slot0
 - displaying information about the system [2-845](#)
- SNMP
 - debugging spanning tree activities [2-142](#)
 - ifIndex persistence
 - clearing SNMP ifIndex commands [2-885](#)
 - compress SNMP ifIndex table format [2-892](#)
 - disabling globally [2-891](#)
 - disabling on an interface [2-887](#)
 - enabling globally [2-891](#)
 - enabling on an interface [2-887](#)
 - informs
 - disabling [2-889](#)
 - enabling [2-889](#)
 - traps
 - configuring to send when storm occurs [2-934](#)
 - disabling [2-889](#)
 - enabling [2-889](#)
 - mac-notification
 - adding [2-893](#)
 - removing [2-893](#)
- source (netflow-lite exporter submode) command [2-894](#)
- SPAN commands
 - configuring a SPAN session to monitor [2-411](#)
 - displaying SPAN session information [2-858, 2-936](#)
- SPAN enhancements
 - displaying status [2-784](#)
- Spanning Tree Protocol
 - See STP
- SPAN session
 - displaying session information [2-784](#)
 - filter ACLs [2-411](#)
 - specify encaps type [2-411](#)
 - turn off host learning based on ingress packets [2-411](#)
- special characters

- anchoring, table [1-10](#)
- SSO [2-409](#)
- standard desktop
 - enabling Cisco-recommended features [2-370](#)
- standard desktop and Cisco IP phone
 - enabling Cisco-recommended features [2-372](#)
- sticky address, configuring [2-460](#)
- sticky-ARP
 - disabling on PVLANS [2-299](#)
 - enabling on PVLANS [2-299](#)
- sticky port
 - deleting [2-100](#)
 - enabling security [2-961](#)
- storm control
 - configuring for action when storm occurs [2-934](#)
 - disabling suppression mode [2-632](#)
 - displaying settings [2-855](#)
 - enabling [2-934](#)
 - enabling broadcast [2-934, 2-936](#)
 - enabling multicast [2-934, 2-936](#)
 - enabling suppression mode [2-632](#)
 - enabling timer to recover from error disable [2-217](#)
 - enabling unicast [2-934, 2-936](#)
 - multicast, enabling [2-936](#)
 - setting high and low levels [2-934](#)
 - setting suppression level [2-632](#)
- STP
 - configuring link type for a port [2-906](#)
 - configuring tunneling encapsulation rate [2-345](#)
 - debugging all activities [2-142](#)
 - debugging spanning tree activities [2-142](#)
 - debugging spanning tree BackboneFast events [2-144](#)
 - debugging spanning tree UplinkFast [2-147](#)
 - detecting misconfiguration [2-903](#)
 - displaying active interfaces only [2-847](#)
 - displaying BackboneFast status [2-847](#)
 - displaying bridge status and configuration [2-847](#)
 - displaying spanning tree debug messages [2-142](#)
 - displaying summary of interface information [2-847](#)
 - enabling BPDU filtering by default on all PortFast ports [2-922](#)
 - enabling BPDU filtering on an interface [2-899](#)
 - enabling BPDU guard by default on all PortFast ports [2-924](#)
 - enabling BPDU guard on an interface [2-901](#)
 - enabling extended system ID [2-904](#)
 - enabling loop guard as a default on all ports [2-907](#)
 - enabling PortFast by default on all access ports [2-925](#)
 - enabling PortFast mode [2-920](#)
 - enabling protocol tunneling for [2-340](#)
 - enabling root guard [2-905](#)
 - enabling spanning tree BackboneFast [2-898](#)
 - enabling spanning tree on a per VLAN basis [2-929](#)
 - enabling spanning tree UplinkFast [2-927](#)
 - setting an interface priority [2-926](#)
 - setting drop threshold for [2-343](#)
 - setting pathcost [2-902](#)
 - setting the default pathcost calculation method [2-919](#)
- subinterface configuration mode, summary [1-6](#)
- SVI
 - creating a Layer 3 interface on a VLAN [2-242](#)
- switching characteristics
 - excluding from link-up calculation [2-953](#)
 - modifying [2-953](#)
 - returning to interfaces
 - capture function [2-953](#)
- switchport [2-977](#)
- switchport interfaces
 - displaying status of Layer 3 port [2-664](#)
 - displaying status of native VLAN tagging [2-664](#)
- switchport vlan mapping command [2-981](#)
- switch shim
 - debugging [2-145](#)
 - disabling debugging [2-145](#)
- switch to router connection
 - enabling Cisco-recommended features [2-374](#)
- switch to switch connection
 - enabling Cisco-recommended features [2-376](#)

switch virtual interface

See SVI

sw-vlan [2-148](#)

system prompts [1-5](#)

T

Tab key

command completion [1-1](#)

tables

characters with special meaning [1-7](#)

mac access-list extended subcommands [2-358](#)

multipliers [1-9](#)

relationship between duplex and speed
commands [2-932](#)

show cable-diagnostics tdr command output
fields [2-598](#)

show cdp neighbors detail field descriptions [2-606](#)

show cdp neighbors field descriptions [2-605](#)

show ip dhcp snooping command output [2-589, 2-753](#)

show ip interface field descriptions [2-699](#)

show policy-map control-plane field
descriptions [2-799](#)

show vlan command output fields [2-877](#)

show vtp command output fields [2-882](#)

special characters [1-9](#)

special characters used for anchoring [1-10](#)

speed command options [2-402, 2-932](#)

valid interface types [2-237](#)

TAC

displaying information useful to TAC [2-859](#)

TCAM

debugging spanning tree activities [2-142](#)

TDR

displaying cable diagnostic test results [2-597](#)

test condition of copper cables [2-987](#)

temperature readings

displaying information [2-629](#)

template data timeout (netflow-lite exporter submode)
command [2-985](#)

timer information [2-633](#)

traffic monitor

display status [2-753](#)

traffic shaping

enable on an interface [2-579](#)

transport udp (netflow-lite exporter submode)
command [2-995](#)

transport udp load-share (netflow-lite exporter submode)
command [2-997](#)

traps, enabling [2-889](#)

trunk encapsulation

setting format [2-977](#)

trunk interfaces

displaying trunk interfaces information [2-671](#)

trunk port, configuring VLAN mapping [2-981](#)

trunk ports, display VLAN mapping information [2-873](#)

trust configuration, setting on an interface [2-482, 2-483](#)

trust state

setting [2-250](#)

ttl (netflow-lite exporter submode) command [2-1001](#)

tunnel ports

displaying information about Layer 2 protocol [2-747](#)

TX queues

allocating bandwidth [2-1003](#)

returning to default values [2-1003](#)

setting priority to high [2-1003](#)

specifying burst size [2-1003](#)

specifying traffic rate [2-1003](#)

U

UDLD

displaying administrative and operational
status [2-861](#)

enabling by default on all fiber interfaces [2-1005](#)

enabling on an individual interface [2-1007](#)

preventing a fiber interface from being
enabled [2-1007](#)

resetting all shutdown ports [2-1009](#)

setting the message timer [2-1005](#)

Unidirectional Link Detection

See UDLD

unidirection port control, changing from
bidirectional [2-23](#)unknown multicast traffic, preventing [2-955](#)unknown unicast traffic, preventing [2-955](#)user EXEC mode, summary [1-5](#)

username

setting password and privilege level [2-1011](#)**V**

VACLs

access-group mode [2-6](#)applying VLAN access maps [2-1026](#)displaying VLAN access map information [2-868](#)specifying an action in a VLAN access map [2-13](#)specifying the match clause for a VLAN access-map
sequence [2-397](#)using a VLAN filter [2-1026](#)

VLAN

applying an ARP ACL [2-244](#)configuring [2-1015](#)configuring service policies [2-1020](#)converting to RSPAN VLAN [2-534](#)displaying CEF information [2-678](#)displaying CEF next-hop information [2-678](#)displaying information on switch interfaces [2-689](#),
[2-693](#)displaying information on VLAN switch
interfaces [2-696](#)displaying information sorted by group IP
address [2-689](#), [2-693](#)displaying IP address and version information [2-689](#),
[2-693](#)displaying Layer 2 VLAN information [2-864](#)displaying statistical information [2-782](#)displaying VLAN information [2-866](#)enabling dynamic ARP inspection [2-253](#)enabling Explicit Host Tracking [2-284](#)enabling guest per-port [2-180](#)enabling guest VLAN supplicant [2-172](#), [2-181](#)entering VLAN configuration mode [2-1020](#), [2-1022](#)

native frames

enabling tagging on all 802.1Q trunk ports [2-1024](#)pruning the list for VTP [2-977](#)setting the list of allowed [2-977](#)VLAN, create or modify a group [2-1027](#)

VLAN Access Control Lists

See VACLs

VLAN access map

See VACLs

VLAN database

resetting [2-551](#)

VLAN debugging

limiting output [2-120](#)vlan group command [2-1027](#)VLAN groups, display VLANs mapped [2-871](#)

VLAN link-up calculation

excluding a switch port [2-953](#)including a switch port [2-953](#)

VLAN manager

debugging [2-148](#)disabling debugging [2-148](#)

IOS file system error tests

debugging [2-149](#)disabling debugging [2-149](#)

VLAN mapping

configuring [2-981](#)displaying [2-873](#)VLAN mapping, configure on trunk port [2-981](#)VLAN mapping on trunk ports, display information [2-873](#)

VLAN Query Protocol

See VQP

VLAN query protocol (VQPC)

debugging [2-155](#)

VLANs

clearing

counters [2-105](#)

clearing hardware logic [2-78](#)

configuring

internal allocation scheme [2-1029](#)

displaying

internal VLAN allocation information [2-872](#)

RSPAN VLANs [2-878](#)

entering VLAN configuration mode [2-1022](#)

VMPS

configuring servers [2-1033](#)

reconfirming dynamic VLAN assignments [2-155](#),
[2-1031](#)

voice VLANs

enabling [2-949](#)

VoIP

configuring auto-QoS [2-44](#)

VQP

per-server retry count [2-1032](#)

reconfirming dynamic VLAN assignments [2-155](#),
[2-1031](#)

vrf (netflow-lite exporter submode) command [2-1035](#)

VTP

configuring the administrative domain name [2-1039](#)

configuring the device in VTP client mode [2-1038](#)

configuring the device in VTP server mode [2-1042](#)

configuring the device in VTP transparent
mode [2-1043](#)

configuring tunnel encapsulation rate [2-345](#)

creating a VTP domain password [2-1040](#)

displaying domain information [2-881](#)

displaying statistics information [2-881](#)

enabling protocol tunneling for [2-340](#)

enabling pruning in the VLAN database [2-1041](#)

enabling VTP version 2 mode [2-1044](#)

modifying the VTP configuration storage file
name [2-1037](#)

set drop threshold for [2-343](#)

VTP protocol code

activating debug messages [2-152](#)

deactivating debug messages [2-152](#)

W

Webauth fallback, enabling [2-29](#)

