



Symbols

- \$ matches the end of a string [7](#)
- () in commands [10](#)
- * matches 0 or more sequences of a pattern [7](#)
- + matches 1 or more sequences of a pattern [7](#)
- . matches any single character [7](#)
- ? command [1](#)
- ? matches 0 or 1 occurrence of a pattern [7](#)
- ^ matches the beginning of a string [7](#)
- _ matches a comma (,), left brace ({), left parenthesis [7](#)
- “ [10](#)

Numerics

- 10-Gigabit Ethernet uplink
 - selecting [114](#)
 - showing the mode [320](#)
- 802.1Q trunk ports and native VLANs [569](#)
- 802.1Q tunnel ports
 - configuring [526](#)
- 802.1S Multiple Spanning Tree
 - see MST
- 802.1X
 - configuring for multiple hosts [88](#)
 - configuring for single host [88](#)
 - configuring multiple domains [88](#)
- 802.1X Port Based Authentication
 - debugging 802.1X Port Based Authentication [50](#)
 - displaying port based authentication [306](#)
 - enabling accounting for authentication sessions [3](#)
 - enabling authentication on the system [97](#)
 - enabling guest VLAN [86](#)

- enabling guest VLAN supplicant [84, 87](#)
- enabling manual control of auth state [93](#)
- enabling periodic re-authentication of the client [96](#)
- initializing re-authentication of dot1x ports [95](#)
- initializing state machines [90](#)
- receive session termination message upon reboot [4](#)
- setting maximum number for EAP requests [92](#)
- setting the reauthentication timer [98](#)

A

- abbreviating commands
 - context-sensitive help [1](#)
- Access Gateway Module
 - connecting to a module [11](#)
 - connecting to a remote module [265](#)
 - connecting to a specific remote module [273](#)
- access-group
 - displaying mac interface [393](#)
 - show mode interface [277](#)
- access groups
 - IP [5](#)
- access lists
 - clearing an access template [27](#)
 - defining ARP [10](#)
 - displaying ARP information [280](#)
 - See also ACLs, MAC ACLs, and VACLs
- access maps
 - applying with VLAN filter [570](#)
- ACLs
 - access-group mode [5](#)
 - determining ACL hardware programming [6](#)
 - displaying mac access-group interface [393](#)

- using ACL naming conventions for MAC ACLs [187](#)
- action clause
 - specifying drop or forward action in a VACL [8](#)
- addresses, configuring a maximum [235](#)
- adjacency
 - debugging the adjacency table [44](#)
 - disabling the debug facility [44](#)
 - displaying information about the adjacency table [278](#)
 - displaying IPC table entries [44](#)
- aggregate policer
 - displaying information [432](#)
- aging time
 - displaying MAC address aging time [396](#)
 - MAC address table [190](#)
- alarms
 - displaying operational status [309](#)
- alternation
 - description [9](#)
- anchoring
 - description [10](#)
- ARP
 - access list, displaying detailed information [280](#)
 - defining access-lists [10](#)
- ARP inspection
 - enforce certain types of checking [132](#)
- ARP packet
 - deny based on DHCP bindings [80](#)
 - permit based on DHCP bindings [221](#)
- authentication
 - setting username [560](#)
 - using an MD5-type encryption method [560](#)
 - verifying MD5 signature [561](#)
 - verifying the checksum for Flash memory [561](#)
- auth fail VLAN
 - enable on a port [85](#)
 - set max number of attempts [84](#)
- authorization state
 - enabling manual control [93](#)
- authorization state of a controlled port [93](#)

- automatic installation
 - displaying status [281](#)
- auto-negotiate interface speed
 - example [517](#)
- auto-QoS
 - configuring for VoIP [12](#)
 - displaying configuration [282](#)

B

- baby giants
 - displaying the system MTU setting [457](#)
 - setting the maximum Layer 2 payload size [543](#)
- BackboneFast
 - displaying debugging messages [69](#)
 - displaying spanning tree status [448](#)
 - enabling debugging [69](#)
- bindings
 - store for DHCP snooping [141](#)
- BOOT environment variable
 - displaying information [286](#)
- bootflash
 - displaying information [284](#)
- BPDU's
 - debugging spanning tree activities [68](#)
- bridge protocol data units
 - See BPDU's
- broadcast suppression level
 - configuring [518, 520](#)
 - enabling [518, 520](#)

C

- cable diagnostics
 - TDR
 - displaying test results [287](#)
 - testing conditions of copper cables [544](#)
- Catalyst 4507R [231](#)

- power redundancy mode [236](#)
- CDP
 - configuring tunneling encapsulation rate [177](#)
 - displaying
 - neighbor information [289](#)
 - enabling protocol tunneling for [173](#)
 - set drop threshold for [175](#)
- CEF
 - displaying next-hop information [353](#)
 - displaying VLAN configuration information [353](#)
- cisco-desktop
 - macro apply [196](#)
- Cisco Express Forwarding
 - See CEF
- cisco-phone
 - macro apply [198](#)
- cisco-router
 - macro apply [200](#)
- cisco-switch
 - macro apply [202](#)
- clear commands
 - clearing Gigabit Ethernet interfaces [25](#)
 - clearing IGMP group cache entries [32](#)
 - clearing interface counters [22](#)
 - clearing IP access lists [27, 28](#)
 - clearing IP ARP inspection statistics VLAN [29](#)
 - clearing IP DHCP snooping database [30](#)
 - clearing IP DHCP snooping database statistics [31](#)
 - clearing MFIB counters and routes [35](#)
 - clearing MFIB fastdrop entries [36](#)
 - clearing PAgP channel information [39](#)
 - clearing QoS aggregate counters [41](#)
 - clearing VLAN interfaces [26](#)
- CLI string search
 - anchoring [10](#)
 - expressions [7](#)
 - filtering [6](#)
 - multiple-character patterns [8](#)
 - multipliers [9](#)

- parentheses for recall [10](#)
- searching outputs [6](#)
- single-character patterns [7](#)
- using [6](#)
- command modes
 - accessing privileged EXEC mode [4](#)
 - exiting [4](#)
 - understanding user EXEC and configuration modes [4](#)
- condition interface
 - debugging interface-related activities [46](#)
- condition vlan
 - debugging VLAN output [49](#)
- configuration, saving [11](#)
- configuring
 - root as secondary [501](#)
- configuring a SPAN session to monitor
 - limit SPAN source traffic [213](#)
- configuring forward delay [497](#)
- configuring root as primary [501](#)
- CoS
 - assigning to Layer 2 protocol packets [174](#)
- CoS QoS default
 - defining value on an interface [249](#)
- Cost of Service
 - See QoS CoS
- counters
 - clearing interface counters [22](#)

D

- DAI
 - clear statistics [29](#)
- DBL
 - displaying qos dbl [433](#)
 - enabling DBL globally on the switch [250](#)
- debug commands
 - debugging backup events [45](#)
 - debugging DHCP snooping events [55](#)
 - debugging DHCP snooping messages [56](#)

- debugging EtherChannel/PAgP/shim [51](#)
- debugging IPC activity [54](#)
- debugging IP DHCP snooping security messages [57](#)
- debugging NVRAM activities [60](#)
- debugging PAgP activities [61](#)
- debugging port manager activities [64](#)
- debugging software MAC filter updates [67](#)
- debugging spanning tree activities [68](#)
- debugging spanning tree backbonefast [69](#)
- debugging spanning tree UplinkFast [72](#)
- debugging supervisor redundancy [66](#)
- debugging VLAN manager activities [73](#)
- displaying monitor activity [59](#)
- displaying the adjacency table [44](#)
- enabling debug dot1x [50](#)
- enabling debugging messages for ISL VLAN IDs [75](#)
- enabling debugging messages for VTP [76](#)
- enabling debugging of UDLD activity [77](#)
- enabling switch shim debugging [70](#)
- enabling VLAN manager file system error tests [74](#)
- limiting debugging output for VLANs [49](#)
- limiting interface debugging output [46](#)
- limiting output for debugging standby state changes [47](#)
- shortcut to the debug condition interface [53](#)
- debugging
 - activity monitoring [59](#)
 - DHCP snooping events [55](#)
 - DHCP snooping packets [56](#)
 - IPC activities [54](#)
 - IP DHCP snooping security packets [57](#)
 - NVRAM activities [60](#)
 - PAgP activities [61](#)
 - PAgP shim [51](#)
 - PM activities [64](#)
 - SMF address insertions and deletions [67](#)
 - spanning tree BackboneFast events [69](#)
 - spanning tree switch shim [70](#)
 - spanning tree UplinkFast events [72](#)
 - VLAN manager activities [73](#)
 - VLAN manager IOS file system error tests [74](#)
 - VTP protocol debug messages [76](#)
- debug spanning tree switch [70](#)
- debug sw-vlan vtp [76](#)
- default CoS value [249](#)
- default form of a command, using [6](#)
- defining egress DSCP-to-CoS mapping [255](#)
- DHCP
 - clearing database statistics [31](#)
- DHCP bindings
 - configuring bindings [140](#)
 - deny ARP packet based on matches [80](#)
 - permit ARP packet based on matches [221](#)
- DHCP snooping
 - clearing database [30](#)
 - displaying binding table [355](#)
 - displaying configuration information [354](#)
 - displaying status of DHCP database [358](#)
 - displaying status of error detection [312](#)
 - enabling DHCP globally [139](#)
 - enabling IP source guard [171](#)
 - enabling on a VLAN [147](#)
 - enabling option 82 [143, 144](#)
 - enabling rate limiting on an interface [145](#)
 - enabling trust on an interface [146](#)
 - establishing binding configuration [140](#)
 - renew binding database [267](#)
 - store generated bindings [141](#)
- diagnostic test
 - bootup packet memory [300](#)
 - displaying attributes [294](#)
 - display module-based results [296](#)
 - running [83](#)
 - show results for TDR [287](#)
 - testing conditions of copper cables [544](#)
- displaying error disable recovery [313](#)
- displaying inline power status [424](#)
- displaying monitoring activity [59](#)
- displaying SEEPROM information

- GBIC [321](#)
- displaying SPAN session information [456, 519](#)
- document conventions [16](#)
- document organization [15](#)
- DOS attack
 - protecting system's resources [127](#)
- drop threshold, Layer 2 protocol tunneling [175](#)
- DSCP rewrite for IP packets
 - enable [258](#)
- dual-capable port
 - selecting a connector [210](#)
- duplex mode
 - configuring autonegotiation on an interface [100](#)
 - configuring full duplex on an interface [100](#)
 - configuring half duplex on an interface [100](#)
- dynamic ARP inspection
 - preventing [127](#)
- Dynamic Buffer Limiting
 - See DBL
- Dynamic Host Configuration Protocol
 - See DHCP

E

- EAP
 - restarting authentication process [92](#)
- enabling
 - debugging for UDLD [77](#)
 - voice VLANs [521](#)
- environmental
 - alarms [309](#)
 - displaying information [309](#)
 - status [309](#)
 - temperature [309](#)
- erase a file [102](#)
- error disable detection
 - enabling error disable detection [105](#)
- error-disabled state
 - displaying [339](#)

- error disable recovery
 - configuring recovery mechanism variables [107](#)
 - displaying recovery timer information [313](#)
 - enabling ARP inspection timeout [107](#)
 - specifying recovery cause [107](#)
- EtherChannel
 - assigning interfaces to EtherChannel groups [16](#)
 - debugging EtherChannel [51](#)
 - debugging PAgP shim [51](#)
 - debugging spanning tree activities [68](#)
 - displaying information for a channel [314](#)
 - removing interfaces from EtherChannel groups [16](#)
- EtherChannel guard
 - detecting STP misconfiguration [488](#)
- Explicit Host Tracking
 - clearing the database [34](#)
 - enabling per-VLAN [158](#)
- expressions
 - matching multiple expression occurrences [9](#)
 - multiple-character patterns [8](#)
 - multiplying pattern occurrence [10](#)
 - single-character patterns [7](#)
- Extensible Authentication Protocol
 - See EAP

F

- field replaceable unit (FRU)
 - displaying status information [309](#)
- Flash memory file system
 - displaying file system information [284](#)
 - verifying checksum [561](#)
- flow control
 - configuring a gigabit interface for pause frames [110](#)
 - displaying per-interface statistics for flow control [318](#)

G

GBIC

displaying SEEPROM information [321](#)

Gigabit Ethernet interface

clearing the hardware logic [25](#)

Gigabit Ethernet uplink

selecting [114](#)

showing the mode [320](#)

global configuration mode

using [5](#)

H

hardware module

resetting a module by toggling the power [113](#)

hardware uplink

selecting the mode [114](#)

showing the mode [320](#)

helper addresses, IP [372](#)

hot standby protocol

debugging [47](#)

disabling debugging [47](#)

limiting output [47](#)

I

IDPROMs

displaying SEEPROM information

chassis [321](#)

clock module [321](#)

fan trays [321](#)

module [321](#)

mux buffer [321](#)

power supplies [321](#)

supervisor engine [321](#)

ifIndex persistence

clearing SNMP ifIndex commands [477](#)

compress SNMP ifIndex table format [482](#)

disabling globally [481](#)

disabling on an interface [478](#)

enabling globally [481](#)

enabling on an interface [478](#)

IGMP

applying filters for host joining on Layer 2 interfaces [149](#)

clearing IGMP group cache entries [32](#)

configuring frequency for IGMP host-query messages [152](#)

creating an IGMP profile [151](#)

displaying IGMP interface configuration information [360](#)

displaying profiles [362](#)

setting maximum group numbers [150](#)

IGMP profiles

displaying [362](#)

IGMP snooping

clearing the EHT database [34](#)

configuring a Layer 2 interface as a group member [162](#)

configuring a Layer 2 interface as a multicast router [160](#)

configuring a static VLAN interface [162](#)

displaying multicast information [369](#)

displaying VLAN information [363, 367, 370](#)

enabling [153](#)

enabling immediate-leave processing [159](#)

enabling on a VLAN [157](#)

enabling per-VLAN Explicit Host Tracking [158](#)

informs

enabling [479](#)

inline power

displaying inline power status [424](#)

inspection log

clearing log buffer [28](#)

interface

displaying suppressed multicast bytes [333](#)

interface capabilities

displaying [330](#)

interface configuration mode

summary [5](#)

- interface link
 - display cable disconnect time [336](#)
 - interfaces
 - configuring dot1q tunnel ports [526](#)
 - creating an interface-range macro [79](#)
 - debugging output of interface related activities [46](#)
 - displaying description [335](#)
 - displaying error-disabled state [339](#)
 - displaying information when tunneling is enabled [387](#)
 - displaying status [335](#)
 - displaying traffic for a specific interface [327](#)
 - entering interface configuration mode [119](#)
 - executing a command on multiple ports in a range [122](#)
 - selecting an interface to configure [119](#)
 - setting a CoS value for Layer 2 packets [174](#)
 - setting drop threshold for Layer 2 packets [175](#)
 - setting the interface type [526](#)
 - interface speed
 - configuring interface speed [515](#)
 - interface transceiver
 - displaying diagnostic data [342](#)
 - internal VLAN allocation
 - configuring [571](#)
 - default setting [571](#)
 - displaying allocation information [468](#)
 - Internet Group Management Protocol
 - See IGMP
 - IP ARP
 - applying ARP ACL to VLAN [125](#)
 - clearing inspection statistics [29](#)
 - clearing status of log buffer [28](#)
 - controlling packet logging [135](#)
 - enabling dynamic inspection [134](#)
 - limit rate of incoming requests [127](#)
 - set per-port config trust state [131](#)
 - showing status of dynamic ARP inspection [349](#)
 - showing status of log buffer [352](#)
 - IPC
 - debugging IPC activities [54](#)
 - IP DHCP Snooping
 - See DHCP snooping
 - IP header validation
 - disabling [170](#)
 - enabling [170](#)
 - IP interfaces
 - displaying usability status [371](#)
 - IP multicast
 - displaying multicast routing table information [377](#)
 - IP packets
 - enable DSCP rewrite [258](#)
 - IP phone and standard desktop
 - enabling Cisco-recommended features [198](#)
 - IP source binding
 - adding or deleting [167](#)
 - displaying bindingstagging [382](#)
 - IP source guard
 - debugging messages [57](#)
 - displaying configuration and filters [383](#)
 - enabling on DHCP snooping [171](#)
-
- ## J
- Jumbo frames
 - enabling jumbo frames [217](#)
-
- ## L
- LACP
 - deselecting channeling protocol [18](#)
 - enabling LACP on an interface [18](#)
 - setting channeling protocol [18](#)
 - Layer 2
 - displaying ACL configuration [393](#)
 - Layer 2 interface type
 - specifying a nontrunking, nontagged single VLAN interface [526](#)
 - specifying a trunking VLAN interface [526](#)
 - Layer 2 protocol ports

- displaying [387](#)
- Layer 2 protocol tunneling error recovery [177](#)
- Layer 2 switching
 - enabling voice VLANs [521](#)
 - modifying switching characteristics [521](#)
- Layer 2 traceroute
 - IP addresses [549](#)
- Layer 3 switching
 - displaying information about an adjacency table [278](#)
 - displaying port status [340](#)
 - displaying status of native VLAN tagging [340](#)
- link-status event messages
 - disabling
 - globally [181, 184](#)
 - on an interface [182, 185](#)
 - enabling
 - globally [181, 184](#)
 - on an interface [182, 185](#)
- log buffer
 - show status [352](#)
- logging
 - controlling IP ARP packets [135](#)

M

MAC Access Control Lists

See MAC ACLs

MAC ACLs

- defining extended MAC access list [187](#)
- displaying MAC ACL information [465](#)
- naming an ACL [187](#)

MAC address filtering

- configuring [194](#)
- disabling [194](#)
- enabling [194](#)

MAC address table

- adding static entries [204](#)
- clearing dynamic entries [38](#)
- configuring aging time [190](#)

- displaying dynamic table entry information [398](#)
- displaying entry count [397](#)
- displaying information [394](#)
- displaying interface-based information [400](#)
- displaying multicast information [402](#)
- displaying protocol-based information [404](#)
- displaying static table entry information [406](#)
- displaying the MAC address aging time [396](#)
- displaying VLAN-based information [408](#)
- learning in the protocol buckets [191](#)
- removing static entries [204](#)

MAC address tables

- adding static entries [194](#)
- deleting secure or specific addresses [40](#)
- disabling IGMP snooping on static MAC addresses [194](#)
- removing static entries [194](#)

mac-address-table static [194](#)

MAC address unicast filtering

- dropping unicast traffic [194](#)

macro keywords

- help strings [2](#)

mapping secondary VLANs to MST instance [241](#)

mapping VLAN(s) to an MST instance [116](#)

match subcommand

- accessing [20](#)

maximum transmission unit (MTU)

- displaying the system MTU setting [457](#)
- setting the maximum Layer 2 payload size [543](#)

MD5

- verifying MD5 signature [561](#)

message digest 5

- See MD5

MFIB

- clearing ip mfib counters [35](#)
- clearing ip mfib fastdrop [36](#)
- displaying all active MFIB routes [374](#)
- displaying MFIB fastdrop table entries [376](#)
- enabling IP MFIB fastdrops [164](#)

modes

access-group [5](#)
 show access-group interface [277](#)
 switching between PVST+, MST, and Rapid PVST [493](#)
 See also command modes
 module password clearing [24](#)
 module reset
 resetting a module by toggling the power [113](#)
 --More-- prompt
 filter [6](#)
 search [7](#)
 MST
 designating the primary and secondary root [501](#)
 displaying MST protocol information [452](#)
 displaying region configuration information [452](#)
 displaying spanning tree information [452](#)
 entering MST configuration submode [495](#)
 setting configuration revision number [269](#)
 setting path cost and port priority for instances [494](#)
 setting the forward delay timer for all instances [497](#)
 setting the hello-time delay timer for all instances [498](#)
 setting the max-age timer for all instances [499](#)
 setting the MST region name [218](#)
 specifying the maximum number of hops [500](#)
 switching between PVST+ and Rapid PVST [493](#)
 using the MST configuration submode revision command [269](#)
 using the submode name command [218](#)
 MTU
 displaying global MTU settings [457](#)
 multicast
 enabling storm control [520](#)
 multicast/unicast packets
 prevent forwarding [525](#)
 Multicast Forwarding Information Base
 See MFIB
 multiple-character patterns [8](#)
 Multiple Spanning Tree
 See MST

N

native VLAN
 controlling tagging of traffic [539](#)
 displaying ports eligible for native tagging [467](#)
 displaying ports eligible for tagging [467](#)
 enabling tagging on 802.1Q trunk ports [569](#)
 specifying the tagging of traffic [540](#)
 NetFlow
 enabling NetFlow statistics [165](#)
 including infer fields in routing statistics [165](#)
 next-hop
 displaying CEF VLAN information [353](#)
 no form of a command, using [6](#)
 NVRAM
 debugging NVRAM activities [60](#)

O

output
 pattern searches [7](#)

P

packet forwarding
 prevent unknown packets [525](#)
 packet memory failure
 direct switch action upon detection [82](#)
 packet memory test
 bootup, displaying results [300, 302](#)
 ongoing, displaying results [304](#)
 PACL
 access-group mode [5](#)
 paging prompt
 see --More-- prompt
 PAgP
 clearing port channel information [39](#)
 debugging PAgP activity [61](#)
 deselecting channeling protocol [18](#)

- displaying port channel information [414](#)
- hot standby mode
 - returning to defaults [220](#)
 - selecting ports [220](#)
- input interface of incoming packets
 - learning [219](#)
 - returning to defaults [219](#)
- setting channeling protocol [18](#)
- parentheses [10](#)
- password
 - clearing on an intelligent line module [24](#)
 - establishing enhanced password security [560](#)
 - setting username [560](#)
- PBR
 - displaying route maps [16](#)
 - redistributing route maps [16](#)
- PM activities
 - debugging [64](#)
 - disabling debugging [64](#)
- Policy Based Routing
 - See PBR
- port, dual-capable
 - selecting the connector [210](#)
- Port Aggregation Protocol
 - See PAgP
- port-based authentication
 - displaying debug messages [50](#)
 - displaying statistics and status [306](#)
 - enabling 802.1X [93](#)
 - host modes [88](#)
 - manual control of authorization state [93](#)
 - periodic re-authentication
 - enabling [96](#)
 - re-authenticating 802.1X-enabled ports [95](#)
 - switch-to-client frame-retransmission number [92](#)
- port channel
 - accessing [121](#)
 - creating [121](#)
 - displaying information [414](#)
 - load distribution method
 - resetting to defaults [225](#)
 - setting [225](#)
- port range
 - executing [122](#)
- port security
 - debugging ports security [65](#)
 - deleting secure or specific addresses [40](#)
 - displaying settings for an interface or switch [421](#)
 - enabling [528](#)
 - filter source IP and MAC addresses [171](#)
 - setting action upon security violation [528](#)
 - setting the rate limit for bad packets [528](#)
 - sticky port [528](#)
- Port Trust Device
 - displaying [434](#)
- power status
 - displaying inline power [424](#)
 - displaying power status [424](#)
- power supply
 - configuring combined and redundant power on the Catalyst 4507R [231](#)
 - configuring inline power [228](#)
 - configuring power consumption [230](#)
 - configuring power redundancy on the Catalyst 4507R [236](#)
 - displaying the SEEPROM [321](#)
 - setting inline power state [227](#)
- Private VLAN
 - See PVLANS
- privileged EXEC mode, summary [5](#)
- prompts
 - system [5](#)
- protocol tunneling
 - configuring encapsulation rate [177](#)
 - disabling [173](#)
 - displaying port information [387](#)
 - enabling [173](#)
 - setting a CoS value for Layer 2 packets [174](#)

setting a drop threshold for Layer 2 packets [175](#)

PVLANs

configuring isolated, primary, and community
PVLANs [237](#)

controlling tagging of native VLAN traffic [539](#)

disabling sticky-ARP [168](#)

displaying map information for VLAN SVIs [338](#)

displaying PVLAN information [470](#)

enabling interface configuration mode [526](#)

enabling sticky-ARP [168](#)

mapping VLANs to the same SVI [239](#)

specifying host ports [526](#)

specifying promiscuous ports [526](#)

PVST+

switching between PVST and MST [493](#)

Q

QoS

account Layer 2 encapsulation [244](#)

attaching a policy-map to an interface [270](#)

automatic configuration [12](#)

clearing aggregate counters [41](#)

configuring a QoS policy map [223](#)

configuring auto [12](#)

defining a named aggregate policer [246](#)

defining default CoS value [249](#)

defining ingress CoS-to-DSCP mapping [253](#)

displaying aggregate policer information [432](#)

displaying auto configuration [282](#)

displaying class maps information [292](#)

displaying configuration information [282](#)

displaying configurations of policies [417](#)

displaying policy map information [416, 420](#)

displaying QoS information [431](#)

displaying QoS map information [435](#)

enabling global configuration mode [242](#)

enabling per-VLAN QoS for a Layer 2 interface [261](#)

enabling QoS on an interface [243](#)

mapping DSCP values to transmit queues [255](#)

mapping egress DSCP-to-CoS [255](#)

mapping the DSCP-to-CoS value [255](#)

setting the mapping of policed DSCP values [257](#)

setting the trust state [259](#)

specifying flow-based match criteria [206](#)

QoS CoS

configuring for tunneled Layer 2 protocol packets [174](#)

defining default CoS value [249](#)

qos dbl [250](#)

question command [1](#)

queueing information

displaying [434](#)

R

Rapid PVST

switching between PVST and MST [493](#)

re-authenticating 802.1X-enabled ports [95](#)

re-authentication

periodic [96](#)

set the time [98](#)

reboots

restoring bindings across [140](#)

redundancy

accessing the main CPU [262](#)

changing from active to standby supervisor engine [263](#)

displaying information [437](#)

displaying redundancy facility information [437](#)

displaying RF client list [437](#)

displaying RF operational counters [437](#)

displaying RF states [437](#)

enabling automatic synchronization [15](#)

forcing switchover to standby supervisor engine [263](#)

set the mode [211](#)

synchronizing the route processor configurations [204](#)

related documentation [15](#)

remote SPAN

See RSPAN

- renew commands
 - ip dhcp snooping database [267](#)
 - resetting PVLAN trunk
 - setting switchport to trunk [526](#)
 - rj45 connector, selecting the connector [210](#)
 - ROM monitor mode
 - summary [6](#)
 - Route Processor Redundancy
 - See redundancy
 - RPR
 - set the redundancy mode [211](#)
 - RSPAN
 - converting VLAN to RSPAN VLAN [266](#)
 - displaying list [472](#)
-
- S**
- saving configuration changes [11](#)
 - secure address, configuring [233](#)
 - secure ports, limitations [529](#)
 - set the redundancy mode [211](#)
 - sfp connector, selecting the connector [210](#)
 - show commands
 - filtering parameters [7](#)
 - searching and filtering [6](#)
 - show platform commands [11](#)
 - Simple Network Management Protocol
 - See SNMP
 - single-character patterns
 - special characters [7](#)
 - slaveslot0
 - displaying information on the standby supervisor [444](#)
 - slot0
 - displaying information about the system [446](#)
 - SMF
 - debugging address insertions and deletions [67](#)
 - SNMP
 - debugging spanning tree activities [68](#)
 - ifIndex persistence
 - clearing SNMP ifIndex commands [477](#)
 - compress SNMP ifIndex table format [482](#)
 - disabling globally [481](#)
 - disabling on an interface [478](#)
 - enabling globally [481](#)
 - enabling on an interface [478](#)
 - informs
 - disabling [479](#)
 - enabling [479](#)
 - traps
 - configuring to send when storm occurs [518](#)
 - disabling [479](#)
 - enabling [479](#)
 - software MAC filter
 - See SMF
 - SPAN commands
 - configuring a SPAN session to monitor [213](#)
 - displaying SPAN session information [456, 519](#)
 - SPAN enhancements
 - displaying status [412](#)
 - Spanning Tree Protocol
 - See STP
 - SPAN session
 - displaying session information [412](#)
 - filter ACLs [213](#)
 - specify encaps type [213](#)
 - turn off host learning based on ingress packets [213](#)
 - special characters
 - anchoring, table [10](#)
 - SSO [211](#)
 - standard desktop
 - enabling Cisco-recommended features [196](#)
 - standard desktop and Cisco IP phone
 - enabling Cisco-recommended features [198](#)
 - sticky address, configuring [234](#)
 - sticky-ARP
 - disabling on PVLANS [168](#)
 - enabling on PVLANS [168](#)
 - sticky port

- deleting [40](#)
- enabling security [528](#)
- storm control
 - configuring for action when storm occurs [518](#)
 - disabling suppression mode [312](#)
 - displaying settings [455](#)
 - enabling [518](#)
 - enabling broadcast [518, 520](#)
 - enabling multicast [518, 520](#)
 - enabling suppression mode [312](#)
 - enabling timer to recover from error disable [107](#)
 - enabling unicast [518, 520](#)
 - multicast, enabling [520](#)
 - setting high and low levels [518](#)
 - setting suppression level [312](#)
- STP
 - configuring link type for a port [491](#)
 - configuring tunneling encapsulation rate [177](#)
 - debugging all activities [68](#)
 - debugging spanning tree activities [68](#)
 - debugging spanning tree BackboneFast events [69](#)
 - debugging spanning tree UplinkFast [72](#)
 - detecting misconfiguration [488](#)
 - displaying active interfaces only [448](#)
 - displaying BackboneFast status [448](#)
 - displaying bridge status and configuration [448](#)
 - displaying spanning tree debug messages [68](#)
 - displaying summary of interface information [448](#)
 - enabling BPDU filtering by default on all PortFast ports [506](#)
 - enabling BPDU filtering on an interface [484](#)
 - enabling BPDU guard by default on all PortFast ports [508](#)
 - enabling BPDU guard on an interface [486](#)
 - enabling extended system ID [489](#)
 - enabling loop guard as a default on all ports [492](#)
 - enabling PortFast by default on all access ports [509](#)
 - enabling PortFast mode [504](#)
 - enabling protocol tunneling for [173](#)

- enabling root guard [490](#)
- enabling spanning tree BackboneFast [483](#)
- enabling spanning tree on a per VLAN basis [513](#)
- enabling spanning tree UplinkFast [511](#)
- setting an interface priority [510](#)
- setting drop threshold for [175](#)
- setting pathcost [487](#)
- setting the default pathcost calculation method [503](#)
- subinterface configuration mode, summary [6](#)
- SVI
 - creating a Layer 3 interface on a VLAN [124](#)
- switchport [540](#)
- switchport interfaces
 - displaying status of Layer 3 port [340](#)
 - displaying status of native VLAN tagging [340](#)
- switch shim
 - debugging [70](#)
 - disabling debugging [70](#)
- switch to router connection
 - enabling Cisco-recommended features [200](#)
- switch to switch connection
 - enabling Cisco-recommended features [202](#)
- switch virtual interface
 - See SVI
- sw-vlan [73](#)
- system prompts [5](#)

T

- Tab key
 - command completion [1](#)
- tables
 - characters with special meaning [7](#)
 - mac access-list extended subcommands [187](#)
 - match syntax description [21](#)
 - multipliers [9](#)
 - relationship between duplex and speed commands [516](#)
 - show cable-diagnostics tdr command output fields [288](#)
 - show cdp neighbors detail field descriptions [291](#)

- show cdp neighbors field descriptions [290](#)
- show ip interface field descriptions [372](#)
- show vlan command output fields [471](#)
- show vtp command output fields [475](#)
- special characters [9](#)
- special characters used for anchoring [10](#)
- speed command options [206, 515](#)
- valid interface types [119](#)
- TAC
 - displaying information useful to TAC [458](#)
- TCAM
 - debugging spanning tree activities [68](#)
- TDR
 - displaying cable diagnostic test results [287](#)
 - test condition of copper cables [544](#)
- temperature readings
 - displaying information [309](#)
- timer information [313](#)
- traffic shaping
 - enable on an interface [274](#)
- traps, enabling [479](#)
- trunk encapsulation
 - setting format [540](#)
- trunk interfaces
 - displaying trunk interfaces information [347](#)
- trust state
 - setting [131](#)
- tunnel ports
 - displaying information about Layer 2 protocol [387](#)
- TX queues
 - allocating bandwidth [552](#)
 - returning to default values [552](#)
 - setting priority to high [552](#)
 - specifying burst size [552](#)
 - specifying traffic rate [552](#)

U

UDLD

- displaying administrative and operational status [460](#)
- enabling by default on all fiber interfaces [554](#)
- enabling on an individual interface [556](#)
- preventing a fiber interface from being enabled [556](#)
- resetting all shutdown ports [558](#)
- setting the message timer [554](#)
- Unidirectional Link Detection
 - See UDLD
- unknown multicast traffic, preventing [525](#)
- unknown unicast traffic, preventing [525](#)
- user EXEC mode, summary [5](#)
- username
 - setting password and privilege level [560](#)

V

VACLs

- access-group mode [5](#)
- applying VLAN access maps [570](#)
- displaying VLAN access map information [465](#)
- specifying an action in a VLAN access map [8](#)
- specifying the match clause for a VLAN access-map sequence [205](#)
- using a VLAN filter [570](#)

VLAN

- applying an ARP ACL [125](#)
- configuring [563](#)
- converting to RSPAN VLAN [266](#)
- displaying CEF information [353](#)
- displaying CEF next-hop information [353](#)
- displaying information on switch interfaces [363, 367](#)
- displaying information on VLAN switch interfaces [370](#)
- displaying information sorted by group IP address [363, 367](#)
- displaying IP address and version information [363, 367](#)
- displaying Layer 2 VLAN information [462](#)
- displaying statistical information [410](#)
- displaying VLAN information [464](#)
- enabling dynamic ARP inspection [134](#)

- enabling Explicit Host Tracking [158](#)
- enabling guest per-port [86](#)
- enabling guest VLAN supplicant [84, 87](#)
- entering VLAN configuration mode [567](#)
- native frames
 - enabling tagging on all 802.1Q trunk ports [569](#)
- pruning the list for VTP [540](#)
- setting the list of allowed [540](#)
- VLAN Access Control Lists
 - See VACLs
- VLAN access map
 - See VACLs
- VLAN database
 - resetting [268](#)
- VLAN debugging
 - limiting output [49](#)
- VLAN manager
 - debugging [73](#)
 - disabling debugging [73](#)
 - IOS file system error tests
 - debugging [74](#)
 - disabling debugging [74](#)
- VLAN Query Protocol
 - See VQP
- VLAN query protocol (VQPC)
 - debugging [78](#)
- VLANs
 - clearing
 - counters [42](#)
 - clearing hardware logic [26](#)
 - configuring
 - internal allocation scheme [571](#)
 - displaying
 - internal VLAN allocation information [468](#)
 - RSPAN VLANs [472](#)
 - entering VLAN configuration mode [567](#)
- VMPS
 - configuring servers [575](#)
 - reconfirming dynamic VLAN assignments [573](#)
- voice VLANs
 - enabling [521](#)
- VoIP
 - configuring auto-QoS [12](#)
- VQP
 - per-server retry count [574](#)
 - reconfirming dynamic VLAN assignments [573](#)
- VTP
 - configuring the administrative domain name [579](#)
 - configuring the device in VTP client mode [578](#)
 - configuring the device in VTP server mode [582](#)
 - configuring the device in VTP transparent mode [583](#)
 - configuring tunnel encapsulation rate [177](#)
 - creating a VTP domain password [580](#)
 - displaying domain information [474](#)
 - displaying statistics information [474](#)
 - enabling protocol tunneling for [173](#)
 - enabling pruning in the VLAN database [581](#)
 - enabling VTP version 2 mode [584](#)
 - modifying the VTP configuration storage file name [577](#)
 - set drop threshold for [175](#)
- VTP protocol code
 - activating debug messages [76](#)
 - deactivating debug messages [76](#)

