

INDEX

Symbols

- \$ matches the end of a string [1-7](#)
- () in commands [1-11](#)
- * matches 0 or more sequences of a pattern [1-7](#)
- + matches 1 or more sequences of a pattern [1-7](#)
- . matches any single character [1-7](#)
- ? command [1-1](#)
- ? matches 0 or 1 occurrence of a pattern [1-7](#)
- ^ matches the beginning of a string [1-7](#)
- _ matches a comma (,), left brace ({), left parenthesis [1-7](#)
- “ [1-10](#)

Numerics

- 10-Gigabit Ethernet uplink
 - selecting [2-127](#)
 - showing the mode [2-357](#)
- 802.1Q trunk ports and native VLANs [2-648](#)
- 802.1Q tunnel ports
 - configuring [2-597](#)
- 802.1S Multiple Spanning Tree
 - see MST
- 802.1X
 - configuring for multiple hosts [2-100](#)
 - configuring for single host [2-100](#)
 - configuring multiple domains [2-100](#)
 - disabling port control [2-93](#)
 - enabling port control [2-93](#)
- 802.1X Critical Authentication
 - disabling on a port [2-94](#)
 - disabling on a VLAN [2-97](#)

EAPOL

- disabling send success packets [2-95](#)
 - enabling send success packets [2-95](#)
- enabling on a port [2-94](#)
- enabling on a VLAN [2-97](#)
- returning delay time to default setting [2-96](#)
- setting delay time on a port [2-96](#)
- 802.1X Port Based Authentication
 - debugging 802.1X Port Based Authentication [2-57](#)
 - displaying port based authentication [2-342](#)
 - enabling accounting for authentication sessions [2-3](#)
 - enabling authentication on the system [2-110](#)
 - enabling guest VLAN [2-98](#)
 - enabling guest VLAN supplicant [2-91, 2-99](#)
 - enabling manual control of auth state [2-106](#)
 - enabling periodic re-authentication of the client [2-109](#)
 - initializing re-authentication of dot1x ports [2-108](#)
 - initializing state machines [2-102](#)
 - receive session termination message upon reboot [2-4](#)
 - setting maximum number for EAP requests [2-105](#)
 - setting the reauthentication timer [2-111](#)

A

- abbreviating commands
 - context-sensitive help [1-1](#)
- Access Gateway Module
 - connecting to a module [2-12](#)
 - connecting to a remote module [2-299](#)
 - connecting to a specific remote module [2-309](#)
- access-group
 - displaying mac interface [2-450](#)
 - show mode interface [2-313](#)

- access groups
 - IP [2-5](#)
- access lists
 - clearing an access template [2-28](#)
 - defining ARP [2-11](#)
 - displaying ARP information [2-316](#)
 - See also ACLs, MAC ACLs, and VACLs
- access maps
 - applying with VLAN filter [2-649](#)
- ACLs
 - access-group mode [2-5](#)
 - balancing hardware regions [2-8](#)
 - determining ACL hardware programming [2-6](#)
 - displaying mac access-group interface [2-450](#)
 - using ACL naming conventions for MAC ACLs [2-211](#)
- action clause
 - specifying drop or forward action in a VACL [2-9](#)
- addresses, configuring a maximum [2-268](#)
- adjacency
 - debugging the adjacency table [2-51](#)
 - disabling the debug facility [2-51](#)
 - displaying information about the adjacency table [2-314](#)
 - displaying IPC table entries [2-51](#)
- aggregate policer
 - displaying information [2-498](#)
- aging time
 - displaying MAC address aging time [2-453](#)
 - MAC address table [2-214](#)
- alarms
 - displaying operational status [2-346](#)
- alternation
 - description [1-10](#)
- anchoring
 - description [1-10](#)
- ARP
 - access list, displaying detailed information [2-316](#)
 - defining access-lists [2-11](#)
 - ARP inspection
 - enforce certain types of checking [2-144](#)
 - ARP packet
 - deny based on DHCP bindings [2-87](#)
 - permit based on DHCP bindings [2-254](#)
 - authentication
 - setting username [2-639](#)
 - using an MD5-type encryption method [2-639](#)
 - verifying MD5 signature [2-640](#)
 - verifying the checksum for Flash memory [2-640](#)
 - auth fail VLAN
 - enable on a port [2-92](#)
 - set max number of attempts [2-91](#)
 - authorization state
 - enabling manual control [2-106](#)
 - authorization state of a controlled port [2-106](#)
 - automatic installation
 - displaying status [2-317](#)
 - automatic medium-dependent interface crossover
 - See Auto-MDIX
 - Auto-MDIX
 - disabling [2-238](#)
 - enabling [2-238](#)
 - auto-negotiate interface speed
 - example [2-586](#)
 - auto-QoS
 - configuring for VoIP [2-13](#)
 - displaying configuration [2-318](#)

B

- baby giants
 - displaying the system MTU setting [2-524](#)
 - setting the maximum Layer 2 payload size [2-622](#)
- BackboneFast
 - displaying debugging messages [2-76](#)
 - displaying spanning tree status [2-514](#)
 - enabling debugging [2-76](#)

bindings
 store for DHCP snooping [2-154](#)

BOOT environment variable
 displaying information [2-322](#)

bootflash
 displaying information [2-320](#)

BPDUs
 debugging spanning tree activities [2-74](#)

bridge protocol data units
 See BPDUs

broadcast suppression level
 configuring [2-587](#), [2-589](#)
 enabling [2-587](#), [2-589](#)

C

cable diagnostics
 TDR
 displaying test results [2-323](#)
 testing conditions of copper cables [2-623](#)

Catalyst 4507R [2-264](#)

CDP
 configuring tunneling encapsulation rate [2-201](#)
 displaying
 neighbor information [2-325](#)
 enabling protocol tunneling for [2-197](#)
 set drop threshold for [2-199](#)

CEF
 displaying next-hop information [2-391](#)
 displaying VLAN configuration information [2-391](#)

cisco-desktop
 macro apply [2-221](#)

Cisco Express Forwarding
 See CEF

cisco-phone
 macro apply [2-223](#)

cisco-router
 macro apply [2-225](#)

cisco-switch
 macro apply [2-227](#)

clear commands
 clearing Gigabit Ethernet interfaces [2-26](#)
 clearing IGMP group cache entries [2-33](#)
 clearing interface counters [2-23](#)
 clearing IP access lists [2-28](#), [2-29](#)
 clearing IP ARP inspection statistics VLAN [2-30](#)
 clearing IP DHCP snooping database [2-31](#)
 clearing IP DHCP snooping database statistics [2-32](#)
 clearing MFIB counters and routes [2-36](#)
 clearing MFIB fastdrop entries [2-37](#)
 clearing PAgP channel information [2-42](#)
 clearing QoS aggregate counters [2-45](#)
 clearing VLAN interfaces [2-27](#)

CLI string search
 anchoring [1-10](#)
 expressions [1-7](#)
 filtering [1-6](#)
 multiple-character patterns [1-8](#)
 multipliers [1-9](#)
 parentheses for recall [1-11](#)
 searching outputs [1-6](#)
 single-character patterns [1-7](#)
 using [1-6](#)

command modes
 accessing privileged EXEC mode [1-5](#)
 exiting [1-5](#)
 understanding user EXEC and configuration modes [1-5](#)

condition interface
 debugging interface-related activities [2-53](#)

condition vlan
 debugging VLAN output [2-56](#)

configuration, saving [1-11](#)

configuring
 root as secondary [2-570](#)

configuring a SPAN session to monitor
 limit SPAN source traffic [2-243](#)

- configuring forward delay [2-566](#)
 - configuring root as primary [2-570](#)
 - CoPP
 - attaching
 - policy map to control plane [2-307](#)
 - displaying
 - policy-map class information [2-476](#)
 - entering configuration mode [2-49](#)
 - removing
 - service policy from control plane [2-307](#)
 - CoS
 - assigning to Layer 2 protocol packets [2-198](#)
 - CoS QoS default
 - defining value on an interface [2-283](#)
 - Cost of Service
 - See QoS CoS
 - counters
 - clearing interface counters [2-23](#)
-
- ## D
- DAI
 - clear statistics [2-30](#)
 - DBL
 - displaying qos dbl [2-499](#)
 - enabling DBL globally on the switch [2-284](#)
 - debug commands
 - debugging backup events [2-52](#)
 - debugging DHCP snooping events [2-62](#)
 - debugging DHCP snooping messages [2-63](#)
 - debugging EtherChannel/PAgP/shim [2-58](#)
 - debugging IPC activity [2-61](#)
 - debugging IP DHCP snooping security messages [2-64](#)
 - debugging NVRAM activities [2-67](#)
 - debugging PAgP activities [2-68](#)
 - debugging port manager activities [2-71](#)
 - debugging spanning tree activities [2-74](#)
 - debugging spanning tree backbonefast [2-76](#)
 - debugging spanning tree UplinkFast [2-79](#)
 - debugging supervisor redundancy [2-73](#)
 - debugging VLAN manager activities [2-80](#)
 - displaying monitor activity [2-66](#)
 - displaying the adjacency table [2-51](#)
 - enabling debug dot1x [2-57](#)
 - enabling debugging messages for ISL VLAN IDs [2-82](#)
 - enabling debugging messages for VTP [2-83](#)
 - enabling debugging of UDLD activity [2-84](#)
 - enabling switch shim debugging [2-77](#)
 - enabling VLAN manager file system error tests [2-81](#)
 - limiting debugging output for VLANs [2-56](#)
 - limiting interface debugging output [2-53](#)
 - limiting output for debugging standby state changes [2-54](#)
 - shortcut to the debug condition interface [2-60](#)
 - debugging
 - activity monitoring [2-66](#)
 - DHCP snooping events [2-62](#)
 - DHCP snooping packets [2-63](#)
 - IPC activities [2-61](#)
 - IP DHCP snooping security packets [2-64](#)
 - NVRAM activities [2-67](#)
 - PAgP activities [2-68](#)
 - PAgP shim [2-58](#)
 - PM activities [2-71](#)
 - spanning tree BackboneFast events [2-76](#)
 - spanning tree switch shim [2-77](#)
 - spanning tree UplinkFast events [2-79](#)
 - VLAN manager activities [2-80](#)
 - VLAN manager IOS file system error tests [2-81](#)
 - VTP protocol debug messages [2-83](#)
 - debug spanning tree switch [2-77](#)
 - debug sw-vlan vtp [2-83](#)
 - default CoS value [2-283](#)
 - default form of a command, using [1-6](#)
 - defining egress DSCP-to-CoS mapping [2-289](#)

DHCP

- clearing database statistics [2-32](#)

DHCP bindings

- configuring bindings [2-153](#)
- deny ARP packet based on matches [2-87](#)
- permit ARP packet based on matches [2-254](#)

DHCP snooping

- clearing database [2-31](#)
- displaying binding table [2-393](#)
- displaying configuration information [2-392](#)
- displaying status of DHCP database [2-396](#)
- displaying status of error detection [2-349](#)
- enabling DHCP globally [2-152](#)
- enabling IP source guard [2-185](#)
- enabling on a VLAN [2-160](#)
- enabling option 82 [2-156, 2-157](#)
- enabling rate limiting on an interface [2-158](#)
- enabling trust on an interface [2-159](#)
- establishing binding configuration [2-153](#)
- renew binding database [2-301](#)
- store generated bindings [2-154](#)

diagnostic test

- bootup packet memory [2-336](#)
- displaying attributes [2-330](#)
- display module-based results [2-332](#)
- running [2-90](#)
- show results for TDR [2-323](#)
- testing conditions of copper cables [2-623](#)

- displaying error disable recovery [2-350](#)

- displaying inline power status [2-490](#)

- displaying monitoring activity [2-66](#)

- displaying SEEPROM information

- GBIC [2-358](#)

- displaying SPAN session information [2-523, 2-588](#)

- document conventions [xviii](#)

- document organization [xvii](#)

DoS

CoPP

- attaching policy map to control plane [2-307](#)
- displaying policy-map class information [2-476](#)
- entering configuration mode [2-49](#)
- removing service policy from control plane [2-307](#)

- entering

- CoPP configuration mode [2-49](#)

DOS attack

- protecting system's resources [2-139](#)

- drop threshold, Layer 2 protocol tunneling [2-199](#)

DSCP rewrite for IP packets

- enable [2-292](#)

dual-capable port

- selecting a connector [2-240](#)

duplex mode

- configuring autonegotiation on an interface [2-113](#)

- configuring full duplex on an interface [2-113](#)

- configuring half duplex on an interface [2-113](#)

dynamic ARP inspection

- preventing [2-139](#)

Dynamic Buffer Limiting

- See DBL

Dynamic Host Configuration Protocol

- See DHCP

E

EAP

- restarting authentication process [2-105](#)

EIGRP (Enhanced IGRP)

- filters

- routing updates, preventing [2-251](#)

enabling

- debugging for UDLD [2-84](#)

- voice VLANs [2-590](#)

environmental

- alarms [2-346](#)

- displaying information [2-346](#)

- status [2-346](#)
- temperature [2-346](#)
- erase a file [2-115](#)
- error disable detection
 - enabling error disable detection [2-118](#)
- error-disabled state
 - displaying [2-377](#)
- error disable recovery
 - configuring recovery mechanism variables [2-120](#)
 - displaying recovery timer information [2-350](#)
 - enabling ARP inspection timeout [2-120](#)
 - specifying recovery cause [2-120](#)
- EtherChannel
 - assigning interfaces to EtherChannel groups [2-17](#)
 - debugging EtherChannel [2-58](#)
 - debugging PAgP shim [2-58](#)
 - debugging spanning tree activities [2-74](#)
 - displaying information for a channel [2-351](#)
 - removing interfaces from EtherChannel groups [2-17](#)
- EtherChannel guard
 - detecting STP misconfiguration [2-557](#)
- Explicit Host Tracking
 - clearing the database [2-35](#)
 - enabling per-VLAN [2-172](#)
- expressions
 - matching multiple expression occurrences [1-9](#)
 - multiple-character patterns [1-8](#)
 - multiplying pattern occurrence [1-11](#)
 - single-character patterns [1-7](#)
- Extensible Authentication Protocol
 - See EAP

F

- field replaceable unit (FRU)
 - displaying status information [2-346](#)
- filters
 - EIGRP
 - routing updates, preventing [2-251](#)
- Flash memory file system
 - displaying file system information [2-320](#)
 - verifying checksum [2-640](#)
- flow control
 - configuring a gigabit interface for pause frames [2-123](#)
 - displaying per-interface statistics for flow control [2-355](#)

G

- GBIC
 - displaying EEPROM information [2-358](#)
- Gigabit Ethernet interface
 - clearing the hardware logic [2-26](#)
- Gigabit Ethernet uplink
 - selecting [2-127](#)
 - showing the mode [2-357](#)
- global configuration mode
 - using [1-5](#)

H

- hardware module
 - resetting a module by toggling the power [2-126](#)
- hardware uplink
 - selecting the mode [2-127](#)
 - showing the mode [2-357](#)
- helper addresses, IP [2-410](#)
- hot standby protocol
 - debugging [2-54](#)
 - disabling debugging [2-54](#)
 - limiting output [2-54](#)

IDPROMs

displaying SEEPROM information

chassis [2-358](#)

clock module [2-358](#)

fan trays [2-358](#)

module [2-358](#)

mux buffer [2-358](#)

power supplies [2-358](#)

supervisor engine [2-358](#)

ifIndex persistence

clearing SNMP ifIndex commands [2-545](#)

compress SNMP ifIndex table format [2-550](#)

disabling globally [2-549](#)

disabling on an interface [2-546](#)

enabling globally [2-549](#)

enabling on an interface [2-546](#)

IGMP

applying filters for host joining on Layer 2 interfaces [2-162](#)

clearing IGMP group cache entries [2-33](#)

configuring frequency for IGMP host-query messages [2-165](#)

creating an IGMP profile [2-164](#)

displaying IGMP interface configuration information [2-398](#)

displaying profiles [2-400](#)

setting maximum group numbers [2-163](#)

IGMP profiles

displaying [2-400](#)

IGMP snooping

clearing the EHT database [2-35](#)

configuring a Layer 2 interface as a group member [2-176](#)

configuring a Layer 2 interface as a multicast router [2-174](#)

configuring a static VLAN interface [2-176](#)

displaying multicast information [2-407](#)

displaying VLAN information [2-401, 2-405, 2-408](#)

enabling [2-167](#)

enabling immediate-leave processing [2-173](#)

enabling on a VLAN [2-171](#)

enabling per-VLAN Explicit Host Tracking [2-172](#)

informs

enabling [2-547](#)

inline power

displaying inline power status [2-490](#)

In Service Software Upgrade

See ISSU

inspection log

clearing log buffer [2-29](#)

interface

displaying suppressed multicast bytes [2-371](#)

interface capabilities

displaying [2-367](#)

interface configuration mode

summary [1-5](#)

interface link

display cable disconnect time [2-374](#)

interfaces

configuring dot1q tunnel ports [2-597](#)

creating an interface-range macro [2-86](#)

debugging output of interface related activities [2-53](#)

displaying description [2-373](#)

displaying error-disabled state [2-377](#)

displaying information when tunneling is enabled [2-444](#)

displaying status [2-373](#)

displaying traffic for a specific interface [2-364](#)

entering interface configuration mode [2-131](#)

executing a command on multiple ports in a range [2-134](#)

selecting an interface to configure [2-131](#)

setting a CoS value for Layer 2 packets [2-198](#)

setting drop threshold for Layer 2 packets [2-199](#)

setting the interface type [2-597](#)

interface speed

configuring interface speed [2-584](#)

- interface transceiver
 - displaying diagnostic data [2-380](#)
 - internal VLAN allocation
 - configuring [2-650](#)
 - default setting [2-650](#)
 - displaying allocation information [2-536](#)
 - Internet Group Management Protocol
 - See IGMP
 - IP ARP
 - applying ARP ACL to VLAN [2-137](#)
 - clearing inspection statistics [2-30](#)
 - clearing status of log buffer [2-29](#)
 - controlling packet logging [2-147](#)
 - enabling dynamic inspection [2-146](#)
 - limit rate of incoming requests [2-139](#)
 - set per-port config trust state [2-143](#)
 - showing status of dynamic ARP inspection [2-387](#)
 - showing status of log buffer [2-390](#)
 - IPC
 - debugging IPC activities [2-61](#)
 - IP DHCP Snooping
 - See DHCP snooping
 - IP header validation
 - disabling [2-184](#)
 - enabling [2-184](#)
 - IP interfaces
 - displaying usability status [2-409](#)
 - IP multicast
 - displaying multicast routing table information [2-415](#)
 - IP packets
 - enable DSCP rewrite [2-292](#)
 - IP phone and standard desktop
 - enabling Cisco-recommended features [2-223](#)
 - IP Port Security
 - enabling [2-185](#)
 - IP source binding
 - adding or deleting [2-181](#)
 - displaying bindingstagging [2-420](#)
 - IP source guard
 - debugging messages [2-64](#)
 - displaying configuration and filters [2-421](#)
 - enabling on DHCP snooping [2-185](#)
 - ISSU
 - canceling process [2-187](#)
 - configuring rollback timer [2-196](#)
 - displaying capability [2-425](#)
 - displaying client information [2-427](#)
 - displaying compatibility matrix [2-429](#)
 - displaying config-sync failure information [2-433](#)
 - displaying endpoint information [2-435](#)
 - displaying entities [2-436](#)
 - displaying FSM session [2-437](#)
 - displaying messages [2-438](#)
 - displaying negotiated [2-439](#)
 - displaying rollback-timer [2-440](#)
 - displaying session information [2-441](#)
 - displaying software version [2-442](#)
 - displaying state [2-442](#)
 - forcing switchover to standby supervisor engine [2-195](#)
 - loading new image [2-190](#)
 - mismatched command listing [2-192](#)
 - starting process [2-194](#)
 - stopping rollback timer [2-188](#)
-
- ## J
- Jumbo frames
 - enabling jumbo frames [2-247](#)
-
- ## L
- LACP
 - deselecting channeling protocol [2-19](#)
 - enabling LACP on an interface [2-19](#)
 - setting channeling protocol [2-19](#)

Layer 2

displaying ACL configuration [2-450](#)

Layer 2 interface type

specifying a nontrunking, nontagged single VLAN interface [2-597](#)

specifying a trunking VLAN interface [2-597](#)

Layer 2 protocol ports

displaying [2-444](#)

Layer 2 protocol tunneling error recovery [2-201](#)

Layer 2 switching

enabling voice VLANs [2-590](#)

modifying switching characteristics [2-590](#)

Layer 2 traceroute

IP addresses [2-628](#)

Layer 3 switching

displaying information about an adjacency table [2-314](#)

displaying port status [2-378](#)

displaying status of native VLAN tagging [2-378](#)

link-status event messages

disabling

globally [2-205, 2-208](#)

on an interface [2-206, 2-209](#)

enabling

globally [2-205, 2-208](#)

on an interface [2-206, 2-209](#)

log buffer

show status [2-390](#)

logging

controlling IP ARP packets [2-147](#)

M

MAC Access Control Lists

See MAC ACLs

MAC ACLs

defining extended MAC access list [2-211](#)

displaying MAC ACL information [2-533](#)

naming an ACL [2-211](#)

MAC address filtering

configuring [2-220](#)

disabling [2-220](#)

enabling [2-220](#)

MAC address table

adding static entries [2-232](#)

clearing dynamic entries [2-39, 2-41](#)

configuring aging time [2-214](#)

displaying dynamic table entry information [2-455](#)

displaying entry count [2-454](#)

displaying information [2-451](#)

displaying interface-based information [2-457](#)

displaying multicast information [2-459](#)

displaying notification information [2-461](#)

displaying protocol-based information [2-463](#)

displaying static table entry information [2-465](#)

displaying the MAC address aging time [2-453](#)

displaying VLAN-based information [2-467](#)

enabling authentication bypass [2-103](#)

enabling notifications [2-218](#)

learning in the protocol buckets [2-215](#)

removing static entries [2-232](#)

MAC address tables

adding static entries [2-220](#)

deleting secure or specific addresses [2-43](#)

disabling IGMP snooping on static MAC addresses [2-220](#)

removing static entries [2-220](#)

mac-address-table static [2-220](#)

MAC address unicast filtering

dropping unicast traffic [2-220](#)

macro

displaying descriptions [2-231](#)

macro keywords

help strings [2-2](#)

macros

adding a global description [2-231](#)

cisco global [2-229](#)

system-cpp [2-230](#)

mapping secondary VLANs to MST instance [2-275](#)

mapping VLAN(s) to an MST instance [2-129](#)

match subcommand

accessing [2-21](#)

maximum transmission unit (MTU)

displaying the system MTU setting [2-524](#)

setting the maximum Layer 2 payload size [2-622](#)

MD5

verifying MD5 signature [2-640](#)

message digest 5

See MD5

MFIB

clearing ip mfib counters [2-36](#)

clearing ip mfib fastdrop [2-37](#)

displaying all active MFIB routes [2-412](#)

displaying MFIB fastdrop table entries [2-414](#)

enabling IP MFIB fastdrops [2-178](#)

modes

access-group [2-5](#)

show access-group interface [2-313](#)

switching between PVST+, MST, and Rapid PVST [2-562](#)

See also command modes

module password clearing [2-25](#)

module reset

resetting a module by toggling the power [2-126](#)

--More-- prompt

filter [1-6](#)

search [1-7](#)

MST

designating the primary and secondary root [2-570](#)

displaying MST protocol information [2-519](#)

displaying region configuration information [2-519](#)

displaying spanning tree information [2-519](#)

entering MST configuration submode [2-564](#)

setting configuration revision number [2-303](#)

setting path cost and port priority for instances [2-563](#)

setting the forward delay timer for all instances [2-566](#)

setting the hello-time delay timer for all instances [2-567](#)

setting the max-age timer for all instances [2-568](#)

setting the MST region name [2-248](#)

specifying the maximum number of hops [2-569](#)

switching between PVST+ and Rapid PVST [2-562](#)

using the MST configuration submode revision command [2-303](#)

using the submode name command [2-248](#)

MTU

displaying global MTU settings [2-524](#)

multicast

enabling storm control [2-589](#)

multicast/unicast packets

prevent forwarding [2-596](#)

Multicast Forwarding Information Base

See MFIB

multiple-character patterns [1-8](#)

Multiple Spanning Tree

See MST

N

native VLAN

controlling tagging of traffic [2-617](#)

displaying ports eligible for native tagging [2-535](#)

displaying ports eligible for tagging [2-535](#)

enabling tagging on 802.1Q trunk ports [2-648](#)

specifying the tagging of traffic [2-618](#)

NetFlow

enabling NetFlow statistics [2-179](#)

including infer fields in routing statistics [2-179](#)

next-hop

displaying CEF VLAN information [2-391](#)

no form of a command, using [1-6](#)

NVRAM

debugging NVRAM activities [2-67](#)

O

output

pattern searches [1-7](#)

P

packet forwarding

prevent unknown packets [2-596](#)

packet memory failure

direct switch action upon detection [2-89](#)

packet memory test

bootup, displaying results [2-336, 2-338](#)

ongoing, displaying results [2-340](#)

PACL

access-group mode [2-5](#)

paging prompt

see --More-- prompt

PAgP

clearing port channel information [2-42](#)

debugging PAgP activity [2-68](#)

deselecting channeling protocol [2-19](#)

displaying port channel information [2-473](#)

hot standby mode

returning to defaults [2-250](#)

selecting ports [2-250](#)

input interface of incoming packets

learning [2-249](#)

returning to defaults [2-249](#)

setting channeling protocol [2-19](#)

parentheses [1-11](#)

password

clearing on an intelligent line module [2-25](#)

establishing enhanced password security [2-639](#)

setting username [2-639](#)

PBR

displaying route maps [xviii](#)

redistributing route maps [xviii](#)

PM activities

debugging [2-71](#)

disabling debugging [2-71](#)

Policy Based Routing

See PBR

port, dual-capable

selecting the connector [2-240](#)

Port Aggregation Protocol

See PAgP

port-based authentication

displaying debug messages [2-57](#)

displaying statistics and status [2-342](#)

enabling 802.1X [2-106](#)

host modes [2-100](#)

manual control of authorization state [2-106](#)

periodic re-authentication

enabling [2-109](#)

re-authenticating 802.1X-enabled ports [2-108](#)

switch-to-client frame-retransmission number [2-105](#)

port channel

accessing [2-133](#)

creating [2-133](#)

displaying information [2-473](#)

load distribution method

resetting to defaults [2-258](#)

setting [2-258](#)

port range

executing [2-134](#)

port security

debugging ports security [2-72](#)

deleting secure or specific addresses [2-43](#)

displaying settings for an interface or switch [2-483](#)

enabling [2-602](#)

filter source IP and MAC addresses [2-185](#)

setting action upon security violation [2-602](#)

setting the rate limit for bad packets [2-602](#)

sticky port [2-602](#)

Port Trust Device

displaying [2-500](#)

power status

displaying inline power [2-490](#)displaying power status [2-490](#)

power supply

configuring combined and redundant power on the Catalyst 4507R [2-264](#)configuring inline power [2-261](#)configuring power consumption [2-263](#)displaying the SEEPROM [2-358](#)setting inline power state [2-260](#)

Private VLAN

See PVLANS

privileged EXEC mode, summary [1-5](#)

prompts

system [1-5](#)

protocol tunneling

configuring encapsulation rate [2-201](#)disabling [2-197](#)displaying port information [2-444](#)enabling [2-197](#)setting a CoS value for Layer 2 packets [2-198](#)setting a drop threshold for Layer 2 packets [2-199](#)

PVLANS

configuring isolated, primary, and community PVLANS [2-269](#)controlling tagging of native VLAN traffic [2-617](#)disabling sticky-ARP [2-182](#)displaying map information for VLAN SVIs [2-376](#)displaying PVLAN information [2-538](#)enabling interface configuration mode [2-597](#)enabling sticky-ARP [2-182](#)mapping VLANs to the same SVI [2-273](#)specifying host ports [2-597](#)specifying promiscuous ports [2-597](#)

PVST+

switching between PVST and MST [2-562](#)**Q**

QoS

account Layer 2 encapsulation [2-278](#)attaching a policy-map to an interface [2-304](#)automatic configuration [2-13](#)clearing aggregate counters [2-45](#)configuring a QoS policy map [2-256](#)configuring auto [2-13](#)defining a named aggregate policer [2-280](#)defining default CoS value [2-283](#)defining ingress CoS-to-DSCP mapping [2-287](#)displaying aggregate policer information [2-498](#)displaying auto configuration [2-318](#)displaying class maps information [2-328](#)displaying configuration information [2-318](#)displaying configurations of policies [2-479](#)displaying policy map information [2-475, 2-482](#)displaying QoS information [2-497](#)displaying QoS map information [2-501](#)enabling global configuration mode [2-276](#)enabling per-VLAN QoS for a Layer 2 interface [2-295](#)enabling QoS on an interface [2-277](#)mapping DSCP values to transmit queues [2-289](#)mapping egress DSCP-to-CoS [2-289](#)mapping the DSCP-to-CoS value [2-289](#)setting the mapping of policed DSCP values [2-291](#)setting the trust state [2-293](#)specifying flow-based match criteria [2-234](#)

QoS CoS

configuring for tunneled Layer 2 protocol packets [2-198](#)defining default CoS value [2-283](#)qos dbl [2-284](#)question command [1-1](#)

queueing information

displaying [2-500](#)

R

Rapid PVST

switching between PVST and MST [2-562](#)

re-authenticating 802.1X-enabled ports [2-108](#)

re-authentication

periodic [2-109](#)

set the time [2-111](#)

reboots

restoring bindings across [2-153](#)

redundancy

accessing the main CPU [2-296](#)

changing from active to standby supervisor engine [2-297](#)

displaying information [2-503](#)

displaying redundancy facility information [2-503](#)

displaying RF client list [2-503](#)

displaying RF operational counters [2-503](#)

displaying RF states [2-503](#)

enabling automatic synchronization [2-16](#)

forcing switchover to standby supervisor engine [2-297](#)

set the mode [2-241](#)

synchronizing the route processor configurations [2-232](#)

related documentation [xvii](#)

remote SPAN

See RSPAN

renew commands

ip dhcp snooping database [2-301](#)

resetting PVLAN trunk

setting switchport to trunk [2-597](#)

rj45 connector, selecting the connector [2-240](#)

ROM monitor mode

summary [1-6](#)

Route Processor Redundancy

See redundancy

RPR

set the redundancy mode [2-241](#)

RSPAN

converting VLAN to RSPAN VLAN [2-300](#)

displaying list [2-540](#)

S

saving configuration changes [1-11](#)

secure address, configuring [2-266](#)

secure ports, limitations [2-603](#)

set the redundancy mode [2-241](#)

sfp connector, selecting the connector [2-240](#)

show commands

filtering parameters [1-7](#)

searching and filtering [1-6](#)

show platform commands [1-11](#)

Simple Network Management Protocol

See SNMP

single-character patterns

special characters [1-7](#)

slaveslot0

displaying information on the standby supervisor [2-510](#)

slot0

displaying information about the system [2-512](#)

SNMP

debugging spanning tree activities [2-74](#)

ifIndex persistence

clearing SNMP ifIndex commands [2-545](#)

compress SNMP ifIndex table format [2-550](#)

disabling globally [2-549](#)

disabling on an interface [2-546](#)

enabling globally [2-549](#)

enabling on an interface [2-546](#)

informs

disabling [2-547](#)

enabling [2-547](#)

- traps
 - configuring to send when storm occurs [2-587](#)
 - disabling [2-547](#)
 - enabling [2-547](#)
 - mac-notification
 - adding [2-551](#)
 - removing [2-551](#)
- SPAN commands
 - configuring a SPAN session to monitor [2-243](#)
 - displaying SPAN session information [2-523, 2-588](#)
- SPAN enhancements
 - displaying status [2-471](#)
- Spanning Tree Protocol
 - See STP
- SPAN session
 - displaying session information [2-471](#)
 - filter ACLs [2-243](#)
 - specify encap type [2-243](#)
 - turn off host learning based on ingress packets [2-243](#)
- special characters
 - anchoring, table [1-10](#)
- SSO [2-241](#)
- standard desktop
 - enabling Cisco-recommended features [2-221](#)
- standard desktop and Cisco IP phone
 - enabling Cisco-recommended features [2-223](#)
- sticky address, configuring [2-267](#)
- sticky-ARP
 - disabling on PVLANS [2-182](#)
 - enabling on PVLANS [2-182](#)
- sticky port
 - deleting [2-43](#)
 - enabling security [2-602](#)
- storm control
 - configuring for action when storm occurs [2-587](#)
 - disabling suppression mode [2-349](#)
 - displaying settings [2-522](#)
 - enabling [2-587](#)
 - enabling broadcast [2-587, 2-589](#)
 - enabling multicast [2-587, 2-589](#)
 - enabling suppression mode [2-349](#)
 - enabling timer to recover from error disable [2-120](#)
 - enabling unicast [2-587, 2-589](#)
 - multicast, enabling [2-589](#)
 - setting high and low levels [2-587](#)
 - setting suppression level [2-349](#)
- STP
 - configuring link type for a port [2-560](#)
 - configuring tunneling encapsulation rate [2-201](#)
 - debugging all activities [2-74](#)
 - debugging spanning tree activities [2-74](#)
 - debugging spanning tree BackboneFast events [2-76](#)
 - debugging spanning tree UplinkFast [2-79](#)
 - detecting misconfiguration [2-557](#)
 - displaying active interfaces only [2-514](#)
 - displaying BackboneFast status [2-514](#)
 - displaying bridge status and configuration [2-514](#)
 - displaying spanning tree debug messages [2-74](#)
 - displaying summary of interface information [2-514](#)
 - enabling BPDU filtering by default on all PortFast ports [2-575](#)
 - enabling BPDU filtering on an interface [2-553](#)
 - enabling BPDU guard by default on all PortFast ports [2-577](#)
 - enabling BPDU guard on an interface [2-555](#)
 - enabling extended system ID [2-558](#)
 - enabling loop guard as a default on all ports [2-561](#)
 - enabling PortFast by default on all access ports [2-578](#)
 - enabling PortFast mode [2-573](#)
 - enabling protocol tunneling for [2-197](#)
 - enabling root guard [2-559](#)
 - enabling spanning tree BackboneFast [2-552](#)
 - enabling spanning tree on a per VLAN basis [2-582](#)
 - enabling spanning tree UplinkFast [2-580](#)
 - setting an interface priority [2-579](#)
 - setting drop threshold for [2-199](#)
 - setting pathcost [2-556](#)
 - setting the default pathcost calculation method [2-572](#)

subinterface configuration mode, summary [1-6](#)

SVI

creating a Layer 3 interface on a VLAN [2-136](#)

switching characteristics

excluding from link-up calculation [2-594](#)

modifying [2-594](#)

returning to interfaces

capture function [2-594](#)

switchport [2-618](#)

switchport interfaces

displaying status of Layer 3 port [2-378](#)

displaying status of native VLAN tagging [2-378](#)

switch shim

debugging [2-77](#)

disabling debugging [2-77](#)

switch to router connection

enabling Cisco-recommended features [2-225](#)

switch to switch connection

enabling Cisco-recommended features [2-227](#)

switch virtual interface

See SVI

sw-vlan [2-80](#)

system prompts [1-5](#)

T

Tab key

command completion [1-1](#)

tables

characters with special meaning [1-7](#)

mac access-list extended subcommands [2-211](#)

match syntax description [2-22](#)

multipliers [1-9](#)

relationship between duplex and speed
commands [2-585](#)

show cable-diagnostics tdr command output
fields [2-324](#)

show cdp neighbors detail field descriptions [2-327](#)

show cdp neighbors field descriptions [2-326](#)

show ip interface field descriptions [2-410](#)

show policy-map control-plane field
descriptions [2-478](#)

show vlan command output fields [2-539](#)

show vtp command output fields [2-543](#)

special characters [1-9](#)

special characters used for anchoring [1-10](#)

speed command options [2-234, 2-585](#)

valid interface types [2-131](#)

TAC

displaying information useful to TAC [2-525](#)

TCAM

debugging spanning tree activities [2-74](#)

TDR

displaying cable diagnostic test results [2-323](#)

test condition of copper cables [2-623](#)

temperature readings

displaying information [2-346](#)

timer information [2-350](#)

traffic shaping

enable on an interface [2-311](#)

traps, enabling [2-547](#)

trunk encapsulation

setting format [2-618](#)

trunk interfaces

displaying trunk interfaces information [2-385](#)

trust state

setting [2-143](#)

tunnel ports

displaying information about Layer 2 protocol [2-444](#)

TX queues

allocating bandwidth [2-631](#)

returning to default values [2-631](#)

setting priority to high [2-631](#)

specifying burst size [2-631](#)

specifying traffic rate [2-631](#)

U

UDLD

- displaying administrative and operational status [2-527](#)
- enabling by default on all fiber interfaces [2-633](#)
- enabling on an individual interface [2-635](#)
- preventing a fiber interface from being enabled [2-635](#)
- resetting all shutdown ports [2-637](#)
- setting the message timer [2-633](#)

Unidirectional Link Detection

See UDLD

- unknown multicast traffic, preventing [2-596](#)
- unknown unicast traffic, preventing [2-596](#)
- user EXEC mode, summary [1-5](#)
- username
 - setting password and privilege level [2-639](#)

V

VACLs

- access-group mode [2-5](#)
- applying VLAN access maps [2-649](#)
- displaying VLAN access map information [2-533](#)
- specifying an action in a VLAN access map [2-9](#)
- specifying the match clause for a VLAN access-map sequence [2-233](#)
- using a VLAN filter [2-649](#)

VLAN

- applying an ARP ACL [2-137](#)
- configuring [2-642](#)
- converting to RSPAN VLAN [2-300](#)
- displaying CEF information [2-391](#)
- displaying CEF next-hop information [2-391](#)
- displaying information on switch interfaces [2-401, 2-405](#)
- displaying information on VLAN switch interfaces [2-408](#)
- displaying information sorted by group IP address [2-401, 2-405](#)

displaying IP address and version information [2-401, 2-405](#)

displaying Layer 2 VLAN information [2-529](#)

displaying statistical information [2-469](#)

displaying VLAN information [2-531](#)

enabling dynamic ARP inspection [2-146](#)

enabling Explicit Host Tracking [2-172](#)

enabling guest per-port [2-98](#)

enabling guest VLAN supplicant [2-91, 2-99](#)

entering VLAN configuration mode [2-646](#)

native frames

enabling tagging on all 802.1Q trunk ports [2-648](#)

pruning the list for VTP [2-618](#)

setting the list of allowed [2-618](#)

VLAN Access Control Lists

See VACLs

VLAN access map

See VACLs

VLAN database

resetting [2-302](#)

VLAN debugging

limiting output [2-56](#)

VLAN link-up calculation

excluding a switch port [2-594](#)

including a switch port [2-594](#)

VLAN manager

debugging [2-80](#)

disabling debugging [2-80](#)

IOS file system error tests

debugging [2-81](#)

disabling debugging [2-81](#)

VLAN Query Protocol

See VQP

VLAN query protocol (VQPC)

debugging [2-85](#)

VLANs

clearing

counters [2-47](#)

clearing hardware logic [2-27](#)

configuring

internal allocation scheme [2-650](#)

displaying

internal VLAN allocation information [2-536](#)

RSPAN VLANs [2-540](#)

entering VLAN configuration mode [2-646](#)

VMPS

configuring servers [2-654](#)

reconfirming dynamic VLAN assignments [2-652](#)

voice VLANs

enabling [2-590](#)

VoIP

configuring auto-QoS [2-13](#)

VQP

per-server retry count [2-653](#)

reconfirming dynamic VLAN assignments [2-652](#)

VTP

configuring the administrative domain name [2-658](#)

configuring the device in VTP client mode [2-657](#)

configuring the device in VTP server mode [2-661](#)

configuring the device in VTP transparent mode [2-662](#)

configuring tunnel encapsulation rate [2-201](#)

creating a VTP domain password [2-659](#)

displaying domain information [2-542](#)

displaying statistics information [2-542](#)

enabling protocol tunneling for [2-197](#)

enabling pruning in the VLAN database [2-660](#)

enabling VTP version 2 mode [2-663](#)

modifying the VTP configuration storage file name [2-656](#)

set drop threshold for [2-199](#)

VTP protocol code

activating debug messages [2-83](#)

deactivating debug messages [2-83](#)

