

INDEX

Symbols

- \$ matches the end of a string [1-7](#)
- () in commands [1-11](#)
- * matches 0 or more sequences of a pattern [1-7](#)
- + matches 1 or more sequences of a pattern [1-7](#)
- . matches any single character [1-7](#)
- ? command [1-1](#)
- ? matches 0 or 1 occurrence of a pattern [1-7](#)
- ^ matches the beginning of a string [1-7](#)
- _ matches a comma (,), left brace ({), left parenthesis [1-7](#)
- “ [1-10](#)

Numerics

- 10-Gigabit Ethernet uplink
 - selecting [2-151](#)
 - showing the mode [2-455, 2-456](#)
- 802.1Q trunk ports and native VLANs [2-778](#)
- 802.1Q tunnel ports
 - configuring [2-720](#)
- 802.1S Multiple Spanning Tree
 - see MST
- 802.1X
 - configuring for multiple hosts [2-119](#)
 - configuring for single host [2-119](#)
 - configuring multiple domains [2-119](#)
 - disabling port control [2-112](#)
 - enabling port control [2-112](#)
- 802.1X Critical Authentication
 - disabling on a port [2-113](#)
 - disabling on a VLAN [2-116](#)

EAPOL

- disabling send success packets [2-114](#)
 - enabling send success packets [2-114](#)
- enabling on a port [2-113](#)
- enabling on a VLAN [2-116](#)
- returning delay time to default setting [2-115](#)
- setting delay time on a port [2-115](#)
- 802.1X Port Based Authentication
 - debugging 802.1X Port Based Authentication [2-74](#)
 - displaying port based authentication [2-439](#)
 - enabling accounting for authentication sessions [2-4](#)
 - enabling authentication on the system [2-130](#)
 - enabling guest VLAN [2-117](#)
 - enabling guest VLAN supplicant [2-110, 2-118](#)
 - enabling manual control of auth state [2-126](#)
 - enabling periodic re-authentication of the client [2-129](#)
 - initializing re-authentication of dot1x ports [2-128](#)
 - initializing state machines [2-121](#)
 - receive session termination message upon reboot [2-5](#)
 - setting maximum number for EAP requests [2-124](#)
 - setting the reauthentication timer [2-131](#)

A

- abbreviating commands
 - context-sensitive help [1-1](#)
- Access Gateway Module
 - connecting to a module [2-17](#)
 - connecting to a remote module [2-380](#)
 - connecting to a specific remote module [2-392](#)

- access-group
 - displaying mac interface [2-560](#)
 - show mode interface [2-411](#)
- access groups
 - IP [2-6](#)
- access lists
 - clearing an access template [2-39](#)
 - defining ARP [2-16](#)
 - displaying ARP information [2-414](#)
 - See also ACLs, MAC ACLs, and VACLs
- access maps
 - applying with VLAN filter [2-780](#)
- ACLs
 - access-group mode [2-6](#)
 - balancing hardware regions [2-12](#)
 - capturing control packets [2-8](#)
 - determining ACL hardware programming [2-10](#)
 - disabling hardware statistics [2-146](#)
 - displaying mac access-group interface [2-560](#)
 - enabling hardware statistics [2-146](#)
 - using ACL naming conventions for MAC ACLs [2-258](#)
- action clause
 - specifying drop or forward action in a VACL [2-13](#)
- addresses, configuring a maximum [2-335](#)
- adjacency
 - debugging the adjacency table [2-67](#)
 - disabling the debug facility [2-67](#)
 - displaying information about the adjacency table [2-412](#)
 - displaying IPC table entries [2-67](#)
- aggregate policer
 - displaying information [2-612](#)
- aging time
 - displaying MAC address aging time [2-563](#)
 - MAC address table [2-261](#)
- alarms
 - displaying operational status [2-443](#)
- alternation
 - description [1-10](#)
- anchoring
 - description [1-10](#)
- ARP
 - access list, displaying detailed information [2-414](#)
 - defining access-lists [2-16](#)
- ARP inspection
 - enforce certain types of checking [2-168](#)
- ARP packet
 - deny based on DHCP bindings [2-106](#)
 - permit based on DHCP bindings [2-308](#)
- authentication
 - setting username [2-765](#)
 - using an MD5-type encryption method [2-765](#)
 - verifying MD5 signature [2-767](#)
 - verifying the checksum for Flash memory [2-767](#)
- auth fail VLAN
 - enable on a port [2-111](#)
 - set max number of attempts [2-110](#)
- authorization state
 - enabling manual control [2-126](#)
- authorization state of a controlled port [2-126](#)
- automatic installation
 - displaying status [2-415](#)
- automatic medium-dependent interface crossover
 - See Auto-MDIX
- Auto-MDIX
 - disabling [2-290](#)
 - enabling [2-290](#)
- auto-negotiate interface speed
 - example [2-709](#)
- auto-QoS
 - configuring for VoIP [2-18](#)
 - displaying configuration [2-416](#)

B

- baby giants
 - displaying the system MTU setting [2-643](#)
 - setting the maximum Layer 2 payload size [2-745](#)
- BackboneFast
 - displaying debugging messages [2-93](#)
 - displaying spanning tree status [2-633](#)
 - enabling debugging [2-93](#)
- bandwidth command [2-22](#)
- bindings
 - store for DHCP snooping [2-180](#)
- BOOT environment variable
 - displaying information [2-419](#)
- bootflash
 - displaying information [2-417](#)
- BPDUs
 - debugging spanning tree activities [2-91](#)
- bridge protocol data units
 - See BPDUs
- broadcast
 - counters [2-64](#)
- broadcast suppression level
 - configuring [2-710, 2-712](#)
 - enabling [2-710, 2-712](#)

C

- cable diagnostics
 - TDR
 - displaying test results [2-420](#)
 - testing conditions of copper cables [2-747](#)
- Catalyst 4507R [2-331](#)
- CDP
 - configuring tunneling encapsulation rate [2-248](#)
 - displaying
 - neighbor information [2-422](#)
 - enabling protocol tunneling for [2-243](#)
 - set drop threshold for [2-246](#)

CEF

- displaying next-hop information [2-492](#)
- displaying VLAN configuration information [2-492](#)
- cisco-desktop
 - macro apply [2-268](#)
- Cisco Express Forwarding
 - See CEF
- cisco-phone
 - macro apply [2-270](#)
- cisco-router
 - macro apply [2-272](#)
- cisco-switch
 - macro apply [2-274](#)
- class maps
 - creating [2-32](#)
 - defining the match criteria [2-283](#)
- clear commands
 - clearing Gigabit Ethernet interfaces [2-37](#)
 - clearing IGMP group cache entries [2-46](#)
 - clearing interface counters [2-34](#)
 - clearing IP access lists [2-39, 2-40](#)
 - clearing IP ARP inspection statistics VLAN [2-41](#)
 - clearing IP DHCP snooping database statistics [2-45](#)
 - clearing MFIB counters and routes [2-49](#)
 - clearing MFIB fastdrop entries [2-50](#)
 - clearing PAgP channel information [2-55](#)
 - clearing QoS aggregate counters [2-58](#)
 - clearing VLAN interfaces [2-38](#)
- CLI string search
 - anchoring [1-10](#)
 - expressions [1-7](#)
 - filtering [1-6](#)
 - multiple-character patterns [1-8](#)
 - multipliers [1-9](#)
 - parentheses for recall [1-11](#)
 - searching outputs [1-6](#)
 - single-character patterns [1-7](#)
 - using [1-6](#)

command modes

- accessing privileged EXEC mode [1-5](#)
- exiting [1-5](#)
- understanding user EXEC and configuration modes [1-5](#)

condition interface

- debugging interface-related activities [2-69](#)

condition vlan

- debugging VLAN output [2-72](#)

configuration, saving [1-11](#)

configuring

- root as secondary [2-693](#)

configuring a SPAN session to monitor

- limit SPAN source traffic [2-295](#)

configuring forward delay [2-689](#)configuring root as primary [2-693](#)

CoPP

attaching

- policy map to control plane [2-390](#)

displaying

- policy-map class information [2-589](#)

entering configuration mode [2-62](#)

removing

- service policy from control plane [2-390](#)

CoS

- assigning to Layer 2 protocol packets [2-245](#)

CoS QoS default

- defining value on an interface [2-356](#)

Cost of Service

- See QoS CoS

counters

- clearing interface counters [2-34](#)

D

DAI

- clear statistics [2-41](#)

DBL

- displaying qos dbl [2-613](#)

- enabling DBL globally on the switch [2-357](#)

debug commands

- debugging backup events [2-68](#)

- debugging DHCP snooping events [2-79](#)

- debugging DHCP snooping messages [2-80](#)

- debugging EtherChannel/PAgP/shim [2-75](#)

- debugging IPC activity [2-78](#)

- debugging IP DHCP snooping security messages [2-81](#)

- debugging NVRAM activities [2-84](#)

- debugging PAgP activities [2-85](#)

- debugging port manager activities [2-88](#)

- debugging spanning tree activities [2-91](#)

- debugging spanning tree backbonefast [2-93](#)

- debugging spanning tree UplinkFast [2-96](#)

- debugging supervisor redundancy [2-90](#)

- debugging VLAN manager activities [2-97](#)

- displaying monitor activity [2-83](#)

- displaying the adjacency table [2-67](#)

- enabling debug dot1x [2-74](#)

- enabling debugging messages for ISL VLAN IDs [2-100](#)

- enabling debugging messages for VTP [2-101](#)

- enabling debugging of UDLD activity [2-102](#)

- enabling switch shim debugging [2-94](#)

- enabling VLAN manager file system error tests [2-98](#)

- limiting debugging output for VLANs [2-72](#)

- limiting interface debugging output [2-69](#)

- limiting output for debugging standby state changes [2-70](#)

- shortcut to the debug condition interface [2-77](#)

debugging

- activity monitoring [2-83](#)

- DHCP snooping events [2-79](#)

- DHCP snooping packets [2-80](#)

- IPC activities [2-78](#)

- IP DHCP snooping security packets [2-81](#)

- NVRAM activities [2-84](#)

- PAgP activities [2-85](#)
- PAgP shim [2-75](#)
- PM activities [2-88](#)
- spanning tree BackboneFast events [2-93](#)
- spanning tree switch shim [2-94](#)
- spanning tree UplinkFast events [2-96](#)
- VLAN manager activities [2-97](#)
- VLAN manager IOS file system error tests [2-98](#)
- VTP protocol debug messages [2-101](#)
- debug spanning tree switch [2-94](#)
- debug sw-vlan vtp [2-101](#)
- default CoS value [2-356](#)
- default form of a command, using [1-6](#)
- defining egress DSCP-to-CoS mapping [2-363](#)
- DHCP
 - clearing database statistics [2-45](#)
- DHCP bindings
 - configuring bindings [2-178](#)
 - deny ARP packet based on matches [2-106](#)
 - permit ARP packet based on matches [2-308](#)
- DHCP snooping
 - clearing binding entries [2-42](#)
 - clearing database [2-44](#)
 - displaying binding table [2-495](#)
 - displaying configuration information [2-493](#)
 - displaying status of DHCP database [2-498](#)
 - displaying status of error detection [2-446](#)
 - enabling DHCP globally [2-177](#)
 - enabling IP source guard [2-217](#)
 - enabling on a VLAN [2-187](#)
 - enabling option 82 [2-182, 2-184](#)
 - enabling option-82 [2-189](#)
 - enabling rate limiting on an interface [2-185](#)
 - enabling trust on an interface [2-186](#)
 - establishing binding configuration [2-178](#)
 - renew binding database [2-382](#)
 - store generated bindings [2-180](#)
- diagnostic test
 - bootup packet memory [2-433](#)
 - displaying attributes [2-427](#)
 - display module-based results [2-429](#)
 - running [2-109](#)
 - show results for TDR [2-420](#)
 - testing conditions of copper cables [2-747](#)
- displaying error disable recovery [2-447](#)
- displaying inline power status [2-604](#)
- displaying monitoring activity [2-83](#)
- displaying SEEPROM information
 - GBIC [2-457](#)
- displaying SPAN session information [2-642, 2-711](#)
- document conventions [1-xviii](#)
- document organization [1-xvii](#)
- DoS
 - CoPP
 - attaching policy map to control plane [2-390](#)
 - displaying policy-map class information [2-589](#)
 - entering configuration mode [2-62](#)
 - removing service policy from control plane [2-390](#)
 - entering
 - CoPP configuration mode [2-62](#)
- DOS attack
 - protecting system's resources [2-163](#)
- drop threshold, Layer 2 protocol tunneling [2-246](#)
- DSCP rewrite for IP packets
 - enable [2-367](#)
- dual-capable port
 - selecting a connector [2-292](#)
- duplex mode
 - configuring autonegotiation on an interface [2-133](#)
 - configuring full duplex on an interface [2-133](#)
 - configuring half duplex on an interface [2-133](#)
- dynamic ARP inspection
 - preventing [2-163](#)
- Dynamic Buffer Limiting
 - See DBL

Dynamic Host Configuration Protocol

See DHCP

E

EAP

restarting authentication process [2-124](#)

EIGRP (Enhanced IGRP)

filters

routing updates, preventing [2-305](#)

enabling

debugging for UDLD [2-102](#)

voice VLANs [2-713](#)

environmental

alarms [2-443](#)

displaying information [2-443](#)

status [2-443](#)

temperature [2-443](#)

erase a file [2-135](#)

error disable detection

enabling error disable detection [2-138](#)

error-disabled state

displaying [2-476](#)

error disable recovery

configuring recovery mechanism variables [2-140](#)

displaying recovery timer information [2-447](#)

enabling ARP inspection timeout [2-140](#)

specifying recovery cause [2-140](#)

EtherChannel

assigning interfaces to EtherChannel groups [2-25](#)

debugging EtherChannel [2-75](#)

debugging PAgP shim [2-75](#)

debugging spanning tree activities [2-91](#)

displaying information for a channel [2-449](#)

removing interfaces from EtherChannel groups [2-25](#)

EtherChannel guard

detecting STP misconfiguration [2-679](#)

Explicit Host Tracking

clearing the database [2-48](#)

enabling per-VLAN [2-201](#)

expressions

matching multiple expression occurrences [1-9](#)

multiple-character patterns [1-8](#)

multiplying pattern occurrence [1-11](#)

single-character patterns [1-7](#)

Extensible Authentication Protocol

See EAP

F

field replaceable unit (FRU)

displaying status information [2-443](#)

filters

EIGRP

routing updates, preventing [2-305](#)

Flash memory file system

displaying file system information [2-417](#)

verifying checksum [2-767](#)

flow control

configuring a gigabit interface for pause frames [2-143](#)

displaying per-interface statistics for flow control [2-453](#)

G

GBIC

displaying SEEPROM information [2-457](#)

Gigabit Ethernet interface

clearing the hardware logic [2-37](#)

Gigabit Ethernet uplink

selecting [2-151](#)

showing the mode [2-455, 2-456](#)

global configuration mode

using [1-5](#)

H

hardware module

resetting a module by toggling the power [2-148](#)

hardware statistics

disabling [2-146](#)

enabling [2-146](#)

hardware uplink

changing the mode [2-149](#)

selecting the mode [2-151](#)

showing the mode [2-455, 2-456](#)

helper addresses, IP [2-513](#)

hot standby protocol

debugging [2-70](#)

disabling debugging [2-70](#)

limiting output [2-70](#)

I

IDPROMs

displaying SEEPROM information

chassis [2-457](#)

clock module [2-457](#)

fan trays [2-457](#)

module [2-457](#)

mux buffer [2-457](#)

power supplies [2-457](#)

supervisor engine [2-457](#)

ifIndex persistence

clearing SNMP ifIndex commands [2-665](#)

compress SNMP ifIndex table format [2-672](#)

disabling globally [2-671](#)

disabling on an interface [2-667](#)

enabling globally [2-671](#)

enabling on an interface [2-667](#)

IGMP

applying filters for host joining on Layer 2 interfaces [2-191](#)

clearing IGMP group cache entries [2-46](#)

configuring frequency for IGMP host-query messages [2-194](#)

creating an IGMP profile [2-193](#)

displaying IGMP interface configuration information [2-500](#)

displaying profiles [2-502](#)

setting maximum group numbers [2-192](#)

IGMP profiles

displaying [2-502](#)

IGMP snooping

clearing the EHT database [2-48](#)

configuring a Layer 2 interface as a group member [2-207](#)

configuring a Layer 2 interface as a multicast router [2-205](#)

configuring a static VLAN interface [2-207](#)

displaying multicast information [2-509](#)

displaying VLAN information [2-503, 2-507, 2-510](#)

enabling [2-196](#)

enabling immediate-leave processing [2-203](#)

enabling on a VLAN [2-200](#)

enabling per-VLAN Explicit Host Tracking [2-201](#)

informs

enabling [2-669](#)

inline power

displaying inline power status [2-604](#)

In Service Software Upgrade

See ISSU

inspection log

clearing log buffer [2-40](#)

interface

displaying suppressed multicast bytes [2-470](#)

interface capabilities

displaying [2-466](#)

interface configuration mode

summary [1-5](#)

interface link

display cable disconnect time [2-473](#)

interfaces

- configuring dot1q tunnel ports [2-720](#)
- creating an interface-range macro [2-105](#)
- debugging output of interface related activities [2-69](#)
- displaying description [2-472](#)
- displaying error-disabled state [2-476](#)
- displaying information when tunneling is enabled [2-554](#)
- displaying status [2-472](#)
- displaying traffic for a specific interface [2-463](#)
- entering interface configuration mode [2-155](#)
- executing a command on multiple ports in a range [2-158](#)
- selecting an interface to configure [2-155](#)
- setting a CoS value for Layer 2 packets [2-245](#)
- setting drop threshold for Layer 2 packets [2-246](#)
- setting the interface type [2-720](#)

interface speed

- configuring interface speed [2-707](#)

interface transceiver

- displaying diagnostic data [2-480](#)

internal VLAN allocation

- configuring [2-781](#)
- default setting [2-781](#)
- displaying allocation information [2-655](#)

Internet Group Management Protocol

- See IGMP

IP ARP

- applying ARP ACL to VLAN [2-161](#)
- clearing inspection statistics [2-41](#)
- clearing status of log buffer [2-40](#)
- controlling packet logging [2-172](#)
- enabling dynamic inspection [2-170](#)
- limit rate of incoming requests [2-163](#)
- set per-port config trust state [2-167](#)
- showing status of dynamic ARP inspection [2-487](#)
- showing status of log buffer [2-490](#)

IPC

- debugging IPC activities [2-78](#)

IP DHCP Snooping

- See DHCP snooping

IP header validation

- disabling [2-216](#)
- enabling [2-216](#)

IP interfaces

- displaying usability status [2-512](#)

IP multicast

- displaying multicast routing table information [2-518](#)

IP packets

- enable DSCP rewrite [2-367](#)

IP phone and standard desktop

- enabling Cisco-recommended features [2-270](#)

IP Port Security

- enabling [2-217](#)

IP source binding

- adding or deleting [2-213](#)
- displaying bindingstaggering [2-523](#)

IP source guard

- debugging messages [2-81](#)
- displaying configuration and filters [2-525](#)
- enabling on DHCP snooping [2-217](#)

IPv6 MLD

- configuring queries [2-223, 2-225](#)
- configuring snooping
- last-listener-query-intervals [2-225](#)
- configuring snooping
- listener-message-suppression [2-227](#)
- configuring snooping robustness-variables [2-228](#)
- configuring tcn topology change notifications [2-230](#)
- counting snooping last-listener-queries [2-223](#)
- displaying information [2-530](#)
- displaying ports for a switch or VLAN [2-532](#)
- displaying querier information [2-533](#)
- enabling snooping [2-221](#)
- enabling snooping on a VLAN [2-231](#)

ISSU

- canceling process [2-233](#)
- configuring rollback timer [2-242](#)
- displaying capability [2-535](#)
- displaying client information [2-537](#)
- displaying compatibility matrix [2-539](#)
- displaying endpoint information [2-544](#)
- displaying entities [2-545](#)
- displaying FSM session [2-546](#)
- displaying messages [2-547](#)
- displaying negotiated [2-549](#)
- displaying rollback-timer [2-550](#)
- displaying session information [2-551](#)
- displaying software version [2-552](#)
- displaying state [2-552](#)
- forcing switchover to standby supervisor engine [2-241](#)
- loading new image [2-237](#)
- starting process [2-239](#)
- stopping rollback timer [2-235](#)

J

Jumbo frames

- enabling jumbo frames [2-301](#)

L

LACP

- deselecting channeling protocol [2-27](#)
- enabling LACP on an interface [2-27](#)
- setting channeling protocol [2-27](#)

Layer 2

- displaying ACL configuration [2-560](#)

Layer 2 interface type

- specifying a nontrunking, nontagged single VLAN interface [2-720](#)
- specifying a trunking VLAN interface [2-720](#)

Layer 2 protocol ports

- displaying [2-554](#)

Layer 2 protocol tunneling error recovery [2-248](#)

Layer 2 switching

- enabling voice VLANs [2-713](#)
- modifying switching characteristics [2-713](#)

Layer 2 traceroute

- IP addresses [2-752](#)

Layer 3 switching

- displaying information about an adjacency table [2-412](#)
- displaying port status [2-478](#)
- displaying status of native VLAN tagging [2-478](#)

link-status event messages

- disabling
 - globally [2-252, 2-255](#)
 - on an interface [2-253, 2-256](#)
- enabling
 - globally [2-252, 2-255](#)
 - on an interface [2-253, 2-256](#)

log buffer

- show status [2-490](#)

logging

- controlling IP ARP packets [2-172](#)

M

MAC Access Control Lists

- See MAC ACLs

MAC ACLs

- defining extended MAC access list [2-258](#)
- displaying MAC ACL information [2-652](#)
- naming an ACL [2-258](#)

MAC address filtering

- configuring [2-267](#)
- disabling [2-267](#)
- enabling [2-267](#)

MAC address table

- adding static entries [2-279](#)
- clearing dynamic entries [2-52, 2-54](#)
- configuring aging time [2-261](#)
- displaying dynamic table entry information [2-567](#)
- displaying entry count [2-565](#)
- displaying information [2-561](#)
- displaying interface-based information [2-569](#)
- displaying multicast information [2-571](#)
- displaying notification information [2-573](#)
- displaying protocol-based information [2-575](#)
- displaying static table entry information [2-577](#)
- displaying the MAC address aging time [2-563](#)
- displaying VLAN-based information [2-580](#)
- enabling authentication bypass [2-122](#)
- enabling notifications [2-265](#)
- learning in the protocol buckets [2-262](#)
- removing static entries [2-279](#)

MAC address tables

- adding static entries [2-267](#)
- deleting secure or specific addresses [2-56](#)
- disabling IGMP snooping on static MAC addresses [2-267](#)
- removing static entries [2-267](#)

mac-address-table static [2-267](#)

MAC address unicast filtering

- dropping unicast traffic [2-267](#)

macro

- displaying descriptions [2-278](#)

macro keywords

- help strings [2-2](#)

macros

- adding a global description [2-278](#)
- cisco global [2-276](#)
- system-cpp [2-277](#)

mapping secondary VLANs to MST instance [2-346](#)mapping VLAN(s) to an MST instance [2-153](#)match (class-map configuration) command [2-283](#)

maximum transmission unit (MTU)

- displaying the system MTU setting [2-643](#)
- setting the maximum Layer 2 payload size [2-745](#)

MD5

- verifying MD5 signature [2-767](#)

message digest 5

- See MD5

MFIB

- clearing ip mfib counters [2-49](#)
- clearing ip mfib fastdrop [2-50](#)
- displaying all active MFIB routes [2-515](#)
- displaying MFIB fastdrop table entries [2-517](#)
- enabling IP MFIB fastdrops [2-210](#)

MLD

- configuring snooping
 - last-listener-query-intervals [2-225](#)
- configuring snooping
 - listener-message-suppression [2-227](#)
- configuring snooping robustness-variables [2-228](#)
- configuring topology change notifications [2-230](#)
- counting snooping last-listener-queries [2-223](#)
- enabling snooping [2-221](#)
- enabling snooping on a VLAN [2-231](#)

MLD snooping

- displaying [2-533](#)

modes

- access-group [2-6](#)
- show access-group interface [2-411](#)
- switching between PVST+, MST, and Rapid PVST [2-684](#)
- See also command modes

module password clearing [2-36](#)

module reset

- resetting a module by toggling the power [2-148](#)

--More-- prompt

- filter [1-6](#)
- search [1-7](#)

MST

- designating the primary and secondary root [2-693](#)
- displaying MST protocol information [2-638](#)
- displaying region configuration information [2-638](#)
- displaying spanning tree information [2-638](#)
- entering MST configuration submode [2-687](#)
- setting configuration revision number [2-384](#)
- setting path cost and port priority for instances [2-685](#)
- setting the forward delay timer for all instances [2-689](#)
- setting the hello-time delay timer for all instances [2-690](#)
- setting the max-age timer for all instances [2-691](#)
- setting the MST region name [2-302](#)
- specifying the maximum number of hops [2-692](#)
- switching between PVST+ and Rapid PVST [2-684](#)
- using the MST configuration submode revision command [2-384](#)
- using the submode name command [2-302](#)

MTU

- displaying global MTU settings [2-643](#)

Multicast Listener Discovery

See MLD

multicast

- counters [2-64](#)
- enabling storm control [2-712](#)

multicast/unicast packets

- prevent forwarding [2-719](#)

Multicast Forwarding Information Base

See MFIB

multiple-character patterns [1-8](#)**Multiple Spanning Tree**

See MST

N**native VLAN**

- controlling tagging of traffic [2-740](#)
- displaying ports eligible for native tagging [2-654](#)
- displaying ports eligible for tagging [2-654](#)

enabling tagging on 802.1Q trunk ports [2-778](#)

specifying the tagging of traffic [2-741](#)

NetFlow

- enabling NetFlow statistics [2-211](#)
- including infer fields in routing statistics [2-211](#)

next-hop

displaying CEF VLAN information [2-492](#)

no form of a command, using [1-6](#)

NVRAM

debugging NVRAM activities [2-84](#)

O**output**

pattern searches [1-7](#)

P**packet forwarding**

prevent unknown packets [2-719](#)

packet memory failure

direct switch action upon detection [2-108](#)

packet memory test

- bootup, displaying results [2-433](#), [2-435](#)
- ongoing, displaying results [2-437](#)

PACL

access-group mode [2-6](#)

paging prompt

see --More-- prompt

PAgP

- clearing port channel information [2-55](#)
- debugging PAgP activity [2-85](#)
- deselecting channeling protocol [2-27](#)
- displaying port channel information [2-586](#)
- hot standby mode
 - returning to defaults [2-304](#)
 - selecting ports [2-304](#)

- input interface of incoming packets
 - learning [2-303](#)
 - returning to defaults [2-303](#)
 - setting channeling protocol [2-27](#)
- parentheses [1-11](#)
- password
 - clearing on an intelligent line module [2-36](#)
 - establishing enhanced password security [2-765](#)
 - setting username [2-765](#)
- PBR
 - displaying route maps [1-xviii](#)
 - redistributing route maps [1-xviii](#)
- PM activities
 - debugging [2-88](#)
 - disabling debugging [2-88](#)
- police (percent) command [2-315](#)
- police (two rates) command [2-317, 2-319](#)
- police command [2-310](#)
- Policy Based Routing
 - See PBR
- policy maps
 - creating [2-323](#)
 - marking [2-394](#)
 - See also QoS, hierarchical policies
 - traffic classification
 - defining the class
 - defining trust states [2-755](#)
- port, dual-capable
 - selecting the connector [2-292](#)
- Port Aggregation Protocol
 - See PAgP
- port-based authentication
 - displaying debug messages [2-74](#)
 - displaying statistics and status [2-439](#)
 - enabling 802.1X [2-126](#)
 - host modes [2-119](#)
 - manual control of authorization state [2-126](#)
- periodic re-authentication
 - enabling [2-129](#)
- re-authenticating 802.1X-enabled ports [2-128](#)
- switch-to-client frame-retransmission number [2-124](#)
- port channel
 - accessing [2-157](#)
 - creating [2-157](#)
 - displaying information [2-586](#)
 - load distribution method
 - resetting to defaults [2-325](#)
 - setting [2-325](#)
- port range
 - executing [2-158](#)
- port security
 - debugging ports security [2-89](#)
 - deleting secure or specific addresses [2-56](#)
 - displaying settings for an interface or switch [2-597](#)
 - enabling [2-725](#)
 - filter source IP and MAC addresses [2-217](#)
 - setting action upon security violation [2-725](#)
 - setting the rate limit for bad packets [2-725](#)
 - sticky port [2-725](#)
- Port Trust Device
 - displaying [2-614](#)
- power status
 - displaying inline power [2-604](#)
 - displaying power status [2-604](#)
- power supply
 - configuring combined and redundant power on the Catalyst 4507R [2-331](#)
 - configuring inline power [2-328](#)
 - configuring power consumption [2-330](#)
 - displaying the SEEPROM [2-457](#)
 - setting inline power state [2-327](#)
- priority command [2-337](#)
- priority-queue command [2-65](#)
- Private VLAN
 - See PVLANS
- privileged EXEC mode, summary [1-5](#)

prompts

- system [1-5](#)

protocol tunneling

- configuring encapsulation rate [2-248](#)
- disabling [2-243](#)
- displaying port information [2-554](#)
- enabling [2-243](#)
- setting a CoS value for Layer 2 packets [2-245](#)
- setting a drop threshold for Layer 2 packets [2-246](#)

PVLANs

- configuring isolated, primary, and community PVLANs [2-339](#)
- controlling tagging of native VLAN traffic [2-740](#)
- disabling sticky-ARP [2-214](#)
- displaying map information for VLAN SVIs [2-475](#)
- displaying PVLAN information [2-657](#)
- enabling interface configuration mode [2-720](#)
- enabling sticky-ARP [2-214](#)
- mapping VLANs to the same SVI [2-343](#)
- specifying host ports [2-720](#)
- specifying promiscuous ports [2-720](#)

PVST+

- switching between PVST and MST [2-684](#)

Q

QoS

- account Layer 2 encapsulation [2-349](#)
- attaching a policy-map to an interface [2-385](#)
- automatic configuration [2-18](#)
- class maps
 - creating [2-32](#)
 - defining the match criteria [2-283](#)
- clearing aggregate counters [2-58](#)
- configuring auto [2-18](#)
- defining a named aggregate policer [2-351](#)
- defining default CoS value [2-356](#)
- defining ingress CoS-to-DSCP mapping [2-361](#)
- displaying aggregate policer information [2-612](#)

- displaying auto configuration [2-416](#)

- displaying class maps information [2-425](#)

- displaying configuration information [2-416](#)

- displaying configurations of policies [2-592](#)

- displaying policy map information [2-588, 2-595](#)

- displaying QoS information [2-611](#)

- displaying QoS map information [2-616](#)

egress queue-sets

- enabling the priority queue [2-65](#)

- enabling global configuration mode [2-347](#)

- enabling on control packets [2-354](#)

- enabling per-VLAN QoS for a Layer 2 interface [2-370](#)

- enabling QoS on an interface [2-348](#)

hierarchical policies

- average-rate traffic shaping on a class [2-407](#)

- bandwidth allocation for a class [2-22, 2-31](#)

- creating a service policy [2-388](#)

- marking [2-394](#)

- strict priority queueing (LLQ) [2-337](#)

- mapping DSCP values to transmit queues [2-363](#)

- mapping egress DSCP-to-CoS [2-363](#)

- mapping the DSCP-to-CoS value [2-363](#)

policy maps

- creating [2-323](#)

- marking [2-394](#)

- traffic classifications

- trust states [2-755](#)

- setting the mapping of policed DSCP values [2-365](#)

- setting the trust state [2-368](#)

- specifying flow-based match criteria [2-286](#)

Supervisor Engine 6-E

- setting CoS [2-396](#)

- setting DSCP [2-399](#)

- setting precedence values [2-402](#)

- setting QoS group identifiers [2-405](#)

QoS CoS

configuring for tunneled Layer 2 protocol packets [2-245](#)

defining default CoS value [2-356](#)

qos dbl [2-357](#)

quality of service

See QoS

question command [1-1](#)

queueing information

displaying [2-614](#)

queue limiting

configuring packet limits [2-372](#)

R

Rapid PVST

switching between PVST and MST [2-684](#)

re-authenticating 802.1X-enabled ports [2-128](#)

re-authentication

periodic [2-129](#)

set the time [2-131](#)

reboots

restoring bindings across [2-178](#)

redundancy

accessing the main CPU [2-374](#)

changing from active to standby supervisor engine [2-378](#)

displaying information [2-618](#)

displaying ISSU config-sync failure information [2-622](#)

displaying redundancy facility information [2-618](#)

displaying RF client list [2-618](#)

displaying RF operational counters [2-618](#)

displaying RF states [2-618](#)

enabling automatic synchronization [2-21](#)

forcing switchover to standby supervisor engine [2-378](#)

mismatched command listing [2-376](#)

set the mode [2-293](#)

synchronizing the route processor configurations [2-279](#)

related documentation [1-xvii](#)

remote SPAN

See RSPAN

renew commands

ip dhcp snooping database [2-382](#)

resetting PVLAN trunk

setting switchport to trunk [2-720](#)

rj45 connector, selecting the connector [2-292](#)

ROM monitor mode

summary [1-6](#)

Route Processor Redundancy

See redundancy

RPF

disabling IPv4 exists-only checks [2-219](#)

enabling IPv4 exists-only checks [2-219](#)

RPR

set the redundancy mode [2-293](#)

RSPAN

converting VLAN to RSPAN VLAN [2-381](#)

displaying list [2-659](#)

S

saving configuration changes [1-11](#)

secure address, configuring [2-333](#)

secure ports, limitations [2-726](#)

service-policy command (policy-map class) [2-388](#)

set the redundancy mode [2-293](#)

sfp connector, selecting the connector [2-292](#)

shape command [2-407](#)

show commands

filtering parameters [1-7](#)

searching and filtering [1-6](#)

show platform commands [1-11](#)

Simple Network Management Protocol

See SNMP

- single-character patterns
 - special characters [1-7](#)
- slaveslot0
 - displaying information on the standby supervisor [2-629](#)
- slot0
 - displaying information about the system [2-631](#)
- SNMP
 - debugging spanning tree activities [2-91](#)
 - ifIndex persistence
 - clearing SNMP ifIndex commands [2-665](#)
 - compress SNMP ifIndex table format [2-672](#)
 - disabling globally [2-671](#)
 - disabling on an interface [2-667](#)
 - enabling globally [2-671](#)
 - enabling on an interface [2-667](#)
 - informs
 - disabling [2-669](#)
 - enabling [2-669](#)
 - traps
 - configuring to send when storm occurs [2-710](#)
 - disabling [2-669](#)
 - enabling [2-669](#)
 - mac-notification
 - adding [2-673](#)
 - removing [2-673](#)
- SPAN commands
 - configuring a SPAN session to monitor [2-295](#)
 - displaying SPAN session information [2-642, 2-711](#)
- SPAN enhancements
 - displaying status [2-584](#)
- Spanning Tree Protocol
 - See STP
- SPAN session
 - displaying session information [2-584](#)
 - filter ACLs [2-295](#)
 - specify encap type [2-295](#)
 - turn off host learning based on ingress packets [2-295](#)
- special characters
 - anchoring, table [1-10](#)
- SSO [2-293](#)
- standard desktop
 - enabling Cisco-recommended features [2-268](#)
- standard desktop and Cisco IP phone
 - enabling Cisco-recommended features [2-270](#)
- sticky address, configuring [2-334](#)
- sticky-ARP
 - disabling on PVLANS [2-214](#)
 - enabling on PVLANS [2-214](#)
- sticky port
 - deleting [2-56](#)
 - enabling security [2-725](#)
- storm control
 - configuring for action when storm occurs [2-710](#)
 - disabling suppression mode [2-446](#)
 - displaying settings [2-641](#)
 - enabling [2-710](#)
 - enabling broadcast [2-710, 2-712](#)
 - enabling multicast [2-710, 2-712](#)
 - enabling suppression mode [2-446](#)
 - enabling timer to recover from error disable [2-140](#)
 - enabling unicast [2-710, 2-712](#)
 - multicast, enabling [2-712](#)
 - setting high and low levels [2-710](#)
 - setting suppression level [2-446](#)
- STP
 - configuring link type for a port [2-682](#)
 - configuring tunneling encapsulation rate [2-248](#)
 - debugging all activities [2-91](#)
 - debugging spanning tree activities [2-91](#)
 - debugging spanning tree BackboneFast events [2-93](#)
 - debugging spanning tree UplinkFast [2-96](#)
 - detecting misconfiguration [2-679](#)
 - displaying active interfaces only [2-633](#)
 - displaying BackboneFast status [2-633](#)
 - displaying bridge status and configuration [2-633](#)
 - displaying spanning tree debug messages [2-91](#)

- displaying summary of interface information [2-633](#)
- enabling BPDU filtering by default on all PortFast ports [2-698](#)
- enabling BPDU filtering on an interface [2-675](#)
- enabling BPDU guard by default on all PortFast ports [2-700](#)
- enabling BPDU guard on an interface [2-677](#)
- enabling extended system ID [2-680](#)
- enabling loop guard as a default on all ports [2-683](#)
- enabling PortFast by default on all access ports [2-701](#)
- enabling PortFast mode [2-696](#)
- enabling protocol tunneling for [2-243](#)
- enabling root guard [2-681](#)
- enabling spanning tree BackboneFast [2-674](#)
- enabling spanning tree on a per VLAN basis [2-705](#)
- enabling spanning tree UplinkFast [2-703](#)
- setting an interface priority [2-702](#)
- setting drop threshold for [2-246](#)
- setting pathcost [2-678](#)
- setting the default pathcost calculation method [2-695](#)
- subinterface configuration mode, summary [1-6](#)
- SVI
 - creating a Layer 3 interface on a VLAN [2-160](#)
- switching characteristics
 - excluding from link-up calculation [2-717](#)
 - modifying [2-717](#)
 - returning to interfaces
 - capture function [2-717](#)
- switchport [2-741](#)
- switchport interfaces
 - displaying status of Layer 3 port [2-478](#)
 - displaying status of native VLAN tagging [2-478](#)
- switch shim
 - debugging [2-94](#)
 - disabling debugging [2-94](#)
- switch to router connection
 - enabling Cisco-recommended features [2-272](#)

- switch to switch connection
 - enabling Cisco-recommended features [2-274](#)
- switch virtual interface
 - See SVI
- sw-vlan [2-97](#)
- system prompts [1-5](#)

T

- Tab key
 - command completion [1-1](#)
- tables
 - characters with special meaning [1-7](#)
 - mac access-list extended subcommands [2-258](#)
 - multipliers [1-9](#)
 - relationship between duplex and speed commands [2-708](#)
 - show cable-diagnostics tdr command output fields [2-421](#)
 - show cdp neighbors detail field descriptions [2-424](#)
 - show cdp neighbors field descriptions [2-423](#)
 - show ip interface field descriptions [2-513](#)
 - show policy-map control-plane field descriptions [2-591](#)
 - show vlan command output fields [2-658](#)
 - show vtp command output fields [2-663](#)
 - special characters [1-9](#)
 - special characters used for anchoring [1-10](#)
 - speed command options [2-286, 2-708](#)
 - valid interface types [2-155](#)
- TAC
 - displaying information useful to TAC [2-644](#)
- TCAM
 - debugging spanning tree activities [2-91](#)
- TDR
 - displaying cable diagnostic test results [2-420](#)
 - test condition of copper cables [2-747](#)
- temperature readings
 - displaying information [2-443](#)

Ten-Gigabit Ethernet uplink

blocking ports on redundant Supervisor Engine 6-E [2-149](#)

timer information [2-447](#)

traffic shaping

enable on an interface [2-409](#)

traps, enabling [2-669](#)

trunk encapsulation

setting format [2-741](#)

trunk interfaces

displaying trunk interfaces information [2-485](#)

trust state

setting [2-167](#)

tunnel ports

displaying information about Layer 2 protocol [2-554](#)

TX queues

allocating bandwidth [2-757](#)

returning to default values [2-757](#)

setting priority to high [2-757](#)

specifying burst size [2-757](#)

specifying traffic rate [2-757](#)

U

UDLD

displaying administrative and operational status [2-646](#)

enabling by default on all fiber interfaces [2-759](#)

enabling on an individual interface [2-761](#)

preventing a fiber interface from being enabled [2-761](#)

resetting all shutdown ports [2-763](#)

setting the message timer [2-759](#)

unicast

counters [2-64](#)

Unidirectional Link Detection

See UDLD

unknown multicast traffic, preventing [2-719](#)

unknown unicast traffic, preventing [2-719](#)

user EXEC mode, summary [1-5](#)

username

setting password and privilege level [2-765](#)

V

VACLs

access-group mode [2-6](#)

applying VLAN access maps [2-780](#)

displaying VLAN access map information [2-652](#)

specifying an action in a VLAN access map [2-13](#)

specifying the match clause for a VLAN access-map sequence [2-281](#)

using a VLAN filter [2-780](#)

VLAN

applying an ARP ACL [2-161](#)

configuring [2-769](#)

configuring service policies [2-774](#)

converting to RSPAN VLAN [2-381](#)

displaying CEF information [2-492](#)

displaying CEF next-hop information [2-492](#)

displaying information on switch interfaces [2-503, 2-507](#)

displaying information on VLAN switch interfaces [2-510](#)

displaying information sorted by group IP address [2-503, 2-507](#)

displaying IP address and version information [2-503, 2-507](#)

displaying Layer 2 VLAN information [2-648](#)

displaying statistical information [2-582](#)

displaying VLAN information [2-650](#)

enabling dynamic ARP inspection [2-170](#)

enabling Explicit Host Tracking [2-201](#)

enabling guest per-port [2-117](#)

enabling guest VLAN supplicant [2-110, 2-118](#)

entering VLAN configuration mode [2-774, 2-776](#)

native frames

enabling tagging on all 802.1Q trunk ports [2-778](#)

pruning the list for VTP [2-741](#)

setting the list of allowed [2-741](#)

VLAN Access Control Lists

See VACLs

VLAN access map

See VACLs

VLAN database

resetting [2-383](#)

VLAN debugging

limiting output [2-72](#)

VLAN link-up calculation

excluding a switch port [2-717](#)

including a switch port [2-717](#)

VLAN manager

debugging [2-97](#)

disabling debugging [2-97](#)

IOS file system error tests

debugging [2-98](#)

disabling debugging [2-98](#)

VLAN Query Protocol

See VQP

VLAN query protocol (VQPC)

debugging [2-104](#)

VLANs

clearing

counters [2-60](#)

clearing hardware logic [2-38](#)

configuring

internal allocation scheme [2-781](#)

displaying

internal VLAN allocation information [2-655](#)

RSPAN VLANs [2-659](#)

entering VLAN configuration mode [2-776](#)

VMPS

configuring servers [2-785](#)

reconfirming dynamic VLAN assignments [2-104](#),
[2-783](#)

voice VLANs

enabling [2-713](#)

VoIP

configuring auto-QoS [2-18](#)

VQP

per-server retry count [2-784](#)

reconfirming dynamic VLAN assignments [2-104](#),
[2-783](#)

VTP

configuring the administrative domain name [2-789](#)

configuring the device in VTP client mode [2-788](#)

configuring the device in VTP server mode [2-792](#)

configuring the device in VTP transparent
mode [2-793](#)

configuring tunnel encapsulation rate [2-248](#)

creating a VTP domain password [2-790](#)

displaying domain information [2-662](#)

displaying statistics information [2-662](#)

enabling protocol tunneling for [2-243](#)

enabling pruning in the VLAN database [2-791](#)

enabling VTP version 2 mode [2-794](#)

modifying the VTP configuration storage file
name [2-787](#)

set drop threshold for [2-246](#)

VTP protocol code

activating debug messages [2-101](#)

deactivating debug messages [2-101](#)