



INDEX

Symbols

- \$ matches the end of a string [1-7](#)
- () in commands [1-11](#)
- * matches 0 or more sequences of a pattern [1-7](#)
- + matches 1 or more sequences of a pattern [1-7](#)
- . matches any single character [1-7](#)
- ? command [1-1](#)
- ? matches 0 or 1 occurrence of a pattern [1-7](#)
- ^ matches the beginning of a string [1-7](#)
- _ matches a comma (,), left brace ({), left parenthesis [1-7](#)
- “ [1-10](#)

Numerics

- 10-Gigabit Ethernet uplink
 - selecting [2-210](#)
 - showing the mode [2-549, 2-550](#)
- 802.1Q trunk ports and native VLANs [2-894](#)
- 802.1Q tunnel ports
 - configuring [2-836](#)
- 802.1S Multiple Spanning Tree
 - see MST
- 802.1X
 - configuring for multiple hosts [2-167](#)
 - configuring for single host [2-167](#)
 - configuring multiple domains [2-167](#)
 - disabling port control [2-160](#)
 - enabling port control [2-160](#)
- 802.1X Critical Authentication
 - disabling on a port [2-161](#)
 - disabling on a VLAN [2-164](#)
- EAPOL

- disabling send success packets [2-162](#)
- enabling send success packets [2-162](#)
- enabling on a port [2-161](#)
- enabling on a VLAN [2-164](#)
- returning delay time to default setting [2-163](#)
- setting delay time on a port [2-163](#)
- 802.1X critical authentication
 - configure parameters [2-25](#)
- 802.1X critical recovery delay, configuring [2-25](#)
- 802.1X Port Based Authentication
 - debugging 802.1X Port Based Authentication [2-111](#)
 - displaying port based authentication [2-529](#)
 - enabling accounting for authentication sessions [2-4](#)
 - enabling authentication on the system [2-178](#)
 - enabling guest VLAN [2-165](#)
 - enabling guest VLAN supplicant [2-158, 2-166](#)
 - enabling manual control of auth state [2-174](#)
 - enabling periodic re-authentication of the client [2-177](#)
 - initializing re-authentication of dot1x ports [2-176](#)
 - initializing state machines [2-169](#)
 - receive session termination message upon reboot [2-5](#)
 - setting maximum number for EAP requests [2-172](#)
 - setting the reauthentication timer [2-179](#)

A

- abbreviating commands
 - context-sensitive help [1-1](#)
- Access Gateway Module
 - connecting to a module [2-22](#)
 - connecting to a remote module [2-460](#)
 - connecting to a specific remote module [2-472](#)
- access-group

- displaying mac interface [2-656](#)
- show mode interface [2-405, 2-491, 2-714](#)
- access groups
 - IP [2-6](#)
- access lists
 - clearing an access template [2-74](#)
 - defining ARP [2-21](#)
 - displaying ARP information [2-495](#)
 - See also ACLs, MAC ACLs, and VACLs
- access maps
 - applying with VLAN filter [2-896](#)
- access-node-identifier, setting for the switch [2-408](#)
- access-policies, applying using host-mode [2-29](#)
- ACLs
 - access-group mode [2-6](#)
 - balancing hardware regions [2-12](#)
 - capturing control packets [2-8](#)
 - determining ACL hardware programming [2-10](#)
 - disabling hardware statistics [2-205](#)
 - displaying mac access-group interface [2-656](#)
 - enabling hardware statistics [2-205](#)
 - using ACL naming conventions for MAC ACLs [2-322](#)
- action clause
 - specifying drop or forward action in a VACL [2-13](#)
- addresses, configuring a maximum [2-394](#)
- adjacency
 - debugging the adjacency table [2-104](#)
 - disabling the debug facility [2-104](#)
 - displaying information about the adjacency table [2-492](#)
 - displaying IPC table entries [2-104](#)
- aggregate policer
 - displaying information [2-715](#)
- aging time
 - displaying MAC address aging time [2-659](#)
 - MAC address table [2-325](#)
- alarms
 - displaying operational status [2-537](#)
- alternation
 - description [1-10](#)
- anchoring
 - description [1-10](#)
- anycp, show multicast [2-494](#)
- ANCP client
 - port identifier [2-16](#)
 - remote server [2-17](#)
 - set router to become [2-18](#)
- ARP
 - access list, displaying detailed information [2-495](#)
 - defining access-lists [2-21](#)
- ARP inspection
 - enforce certain types of checking [2-228](#)
- ARP packet
 - deny based on DHCP bindings [2-146](#)
 - permit based on DHCP bindings [2-373](#)
- authentication [2-25, 2-31](#)
 - changing the control-direction [2-23](#)
 - configure actions for events
 - configuring the actions [2-26](#)
 - configuring port-control [2-35](#)
 - enabling reauthentication [2-34](#)
 - enabling Webauth fallback [2-28](#)
 - host-mode configuration [2-29](#)
 - setting priority of methods [2-37](#)
 - setting the timer [2-39](#)
 - setting username [2-881](#)
 - specifying the order of methods [2-32](#)
 - using an MD5-type encryption method [2-881](#)
 - verifying MD5 signature [2-883](#)
 - verifying the checksum for Flash memory [2-883](#)
- authentication control-direction command [2-23](#)
- authentication critical recovery delay command [2-25](#)
- authentication event command [2-26](#)
- authentication fallback command [2-28](#)
- authentication host-mode [2-29](#)
- authentication methods, setting priority [2-37](#)

authentication methods, specifying the order of attempts [2-32](#)
 authentication open command [2-31](#)
 authentication order command [2-32](#)
 authentication periodic command [2-34](#)
 authentication port-control command [2-35](#)
 authentication priority command [2-37](#)
 authentication timer, setting [2-39](#)
 authentication timer command [2-39](#)
 authentication violation command [2-41](#)
 auth fail VLAN
 enable on a port [2-159](#)
 set max number of attempts [2-158](#)
 Auth Manager
 configuring
 authentication timer [2-39](#)
 authorization state
 enabling manual control [2-174](#)
 authorization state of a controlled port [2-174](#)
 automatic installation
 displaying status [2-500](#)
 automatic medium-dependent interface crossover
 See Auto-MDIX
 Auto-MDIX
 disabling [2-353](#)
 enabling [2-353](#)
 auto-negotiate interface speed
 example [2-813](#)
 auto-QoS
 configuring for VoIP [2-42](#)
 displaying configuration [2-501](#)

B

baby giants
 displaying the system MTU setting [2-746](#)
 setting the maximum Layer 2 payload size [2-861](#)
 BackboneFast
 displaying debugging messages [2-133](#)

 displaying spanning tree status [2-736](#)
 enabling debugging [2-133](#)
 bandwidth command [2-46](#)
 bindings
 store for DHCP snooping [2-240](#)
 BOOT environment variable
 displaying information [2-504](#)
 bootflash
 displaying information [2-502](#)
 BPDUs
 debugging spanning tree activities [2-131](#)
 bridge protocol data units
 See BPDUs
 broadcast
 counters [2-101](#)
 broadcast suppression level
 configuring [2-814, 2-816](#)
 enabling [2-814, 2-816](#)

C

cable diagnostics
 TDR
 displaying test results [2-505](#)
 testing conditions of copper cables [2-863](#)
 call home
 displaying information [2-507](#)
 e-mailing output [2-54](#)
 entering configuration submenu [2-49](#)
 executing [2-54](#)
 manually send test message [2-57](#)
 receiving information [2-52](#)
 sending alert group message [2-55](#)
 submitting information [2-52](#)
 call home destination profiles
 displaying [2-509](#)
 Catalyst 4507R [2-392](#)
 CDP
 configuring tunneling encapsulation rate [2-309](#)

- displaying
 - neighbor information [2-512](#)
- enabling protocol tunneling for [2-304](#)
- set drop threshold for [2-307](#)
- CEF
 - displaying next-hop information [2-586](#)
 - displaying VLAN configuration information [2-586](#)
- chassis
 - displaying
 - chassis MAC address ranges [2-653](#)
 - current and peak traffic meter readings [2-653](#)
 - percentage of backplane utilization [2-653](#)
 - switching clock failure recovery mode [2-653](#)
- circuit-id
 - setting for an interface [2-410](#)
- circuit-id, setting for an interface VLAN range [2-411](#)
- cisco-desktop
 - macro apply [2-332](#)
- Cisco Express Forwarding
 - See CEF
- cisco-phone
 - macro apply [2-334](#)
- cisco-router
 - macro apply [2-336](#)
- cisco-switch
 - macro apply [2-338](#)
- class maps
 - creating [2-65](#)
 - defining the match criteria [2-346](#)
- clear commands
 - clearing Gigabit Ethernet interfaces [2-72](#)
 - clearing IGMP group cache entries [2-81](#)
 - clearing interface counters [2-67](#)
 - clearing IP access lists [2-74, 2-75](#)
 - clearing IP ARP inspection statistics VLAN [2-76](#)
 - clearing IP DHCP snooping database statistics [2-80](#)
 - clearing MFIB counters and routes [2-84](#)
 - clearing MFIB fastdrop entries [2-85](#)
 - clearing PAgP channel information [2-91](#)
 - clearing QoS aggregate counters [2-95](#)
 - clearing VLAN interfaces [2-73](#)
- clear energywise neighbors command [2-69](#)
- clear nmsp statistics command [2-90](#)
- CLI string search
 - anchoring [1-10](#)
 - expressions [1-7](#)
 - filtering [1-6](#)
 - multiple-character patterns [1-8](#)
 - multipliers [1-9](#)
 - parentheses for recall [1-11](#)
 - searching outputs [1-6](#)
 - single-character patterns [1-7](#)
 - using [1-6](#)
- command modes
 - accessing privileged EXEC mode [1-5](#)
 - exiting [1-5](#)
 - understanding user EXEC and configuration modes [1-5](#)
- condition interface
 - debugging interface-related activities [2-106](#)
- condition vlan
 - debugging VLAN output [2-109](#)
- configuration, saving [1-11](#)
- configuring
 - root as secondary [2-797](#)
- configuring a SPAN session to monitor
 - limit SPAN source traffic [2-358](#)
- configuring critical recovery [2-25](#)
- configuring forward delay [2-793](#)
- configuring root as primary [2-797](#)
- CoPP
 - attaching
 - policy map to control plane [2-470](#)
 - displaying
 - policy-map class information [2-688](#)
 - entering configuration mode [2-99](#)
 - removing
 - service policy from control plane [2-470](#)

CoS

- assigning to Layer 2 protocol packets [2-306](#)

CoS QoS default

- defining value on an interface [2-436](#)

Cost of Service

- See QoS CoS

counters

- clearing interface counters [2-67](#)

- critical authentication, configure 802.1X parameters [2-25](#)

- critical recovery, configuring 802.1X parameter [2-25](#)

D

DAI

- clear statistics [2-76](#)

DBL

- displaying qos dbl [2-716](#)

- enabling DBL globally on the switch [2-437](#)

debug commands

- debugging backup events [2-105](#)

- debugging DHCP snooping events [2-116](#)

- debugging DHCP snooping messages [2-117](#)

- debugging EtherChannel/PAgP/shim [2-112](#)

- debugging IPC activity [2-115](#)

- debugging IP DHCP snooping security messages [2-118](#)

- debugging NVRAM activities [2-122](#)

- debugging PAgP activities [2-123](#)

- debugging port manager activities [2-126](#)

- debugging spanning tree activities [2-131](#)

- debugging spanning tree backbonefast [2-133](#)

- debugging spanning tree UplinkFast [2-136](#)

- debugging supervisor redundancy [2-130](#)

- debugging VLAN manager activities [2-137](#)

- displaying monitor activity [2-120](#)

- displaying the adjacency table [2-104](#)

- enabling debug dot1x [2-111](#)

- enabling debugging messages for ISL VLAN IDs [2-140](#)

- enabling debugging messages for VTP [2-141](#)

- enabling debugging of UDLD activity [2-142](#)

- enabling switch shim debugging [2-134](#)

- enabling VLAN manager file system error tests [2-138](#)

- limiting debugging output for VLANs [2-109](#)

- limiting interface debugging output [2-106](#)

- limiting output for debugging standby state changes [2-107](#)

- shortcut to the debug condition interface [2-114](#)

debugging

- activity monitoring [2-120](#)

- DHCP snooping events [2-116](#)

- DHCP snooping packets [2-117](#)

- IPC activities [2-115](#)

- IP DHCP snooping security packets [2-118](#)

- NVRAM activities [2-122](#)

- PAgP activities [2-123](#)

- PAgP shim [2-112](#)

- PM activities [2-126](#)

- PPPoE Intermediate Agent [2-128](#)

- spanning tree BackboneFast events [2-133](#)

- spanning tree switch shim [2-134](#)

- spanning tree UplinkFast events [2-136](#)

- VLAN manager activities [2-137](#)

- VLAN manager IOS file system error tests [2-138](#)

- VTP protocol debug messages [2-141](#)

- debug nmsp command [2-121](#)

- debug spanning tree switch [2-134](#)

- debug sw-vlan vtp [2-141](#)

- default CoS value [2-436](#)

- default form of a command, using [1-6](#)

- defining egress DSCP-to-CoS mapping [2-443](#)

DHCP

- clearing database statistics [2-80](#)

DHCP bindings

- configuring bindings [2-238](#)

- deny ARP packet based on matches [2-146](#)

- permit ARP packet based on matches [2-373](#)

DHCP snooping

- clearing binding entries [2-77](#)
- clearing database [2-79](#)
- displaying binding table [2-589](#)
- displaying configuration information [2-587](#)
- displaying status of DHCP database [2-592](#)
- displaying status of error detection [2-540](#)
- enabling DHCP globally [2-237](#)
- enabling IP source guard [2-277](#)
- enabling on a VLAN [2-247](#)
- enabling option 82 [2-242, 2-244](#)
- enabling option-82 [2-249](#)
- enabling rate limiting on an interface [2-245](#)
- enabling trust on an interface [2-246](#)
- establishing binding configuration [2-238](#)
- renew binding database [2-462](#)
- store generated bindings [2-240](#)
- diagnostic test
 - bootup packet memory [2-523](#)
 - displaying attributes [2-517](#)
 - display module-based results [2-519](#)
 - running [2-157](#)
 - show results for TDR [2-505](#)
 - testing conditions of copper cables [2-863](#)
- displaying error disable recovery [2-541](#)
- displaying inline power status [2-703](#)
- displaying monitoring activity [2-120](#)
- displaying PoE policing and monitoring status [2-711](#)
- displaying SEEPROM information
 - GBIC [2-551](#)
- displaying SPAN session information [2-745, 2-816](#)
- document conventions [1-xx](#)
- document organization [1-xix](#)
- DoS
 - CoPP
 - attaching policy map to control plane [2-470](#)
 - displaying policy-map class information [2-688](#)
 - entering configuration mode [2-99](#)
 - removing service policy from control plane [2-470](#)
 - entering

- CoPP configuration mode [2-99](#)
- DOS attack
 - protecting system's resources [2-223](#)
- drop threshold, Layer 2 protocol tunneling [2-307](#)
- DSCP rewrite for IP packets
 - enable [2-447](#)
- dual-capable port
 - selecting a connector [2-355](#)
- duplex mode
 - configuring autonegotiation on an interface [2-181](#)
 - configuring full duplex on an interface [2-181](#)
 - configuring half duplex on an interface [2-181](#)
- dynamic ARP inspection
 - preventing [2-223](#)
- Dynamic Buffer Limiting
 - See DBL
- Dynamic Host Configuration Protocol
 - See DHCP

E

- EAP
 - restarting authentication process [2-172](#)
- EDCS-587028 [2-496, 2-653](#)
- EIGRP (Enhanced IGRP)
 - filters
 - routing updates, preventing [2-370](#)
- enabling
 - debugging for UDLD [2-142](#)
 - voice VLANs [2-829](#)
- enabling open access [2-31](#)
- EnergyWise
 - display power information through queries [2-190](#)
 - display setting, status of entity and PoE ports [2-533](#)
 - on an entity
 - enable, assign to domain, and set password [2-188](#)
 - on an entity, enable and configure [2-183](#)
 - on a PoE port
 - configuring on PoE port [2-185](#)

energywise (global configuration) command [2-183, 2-185](#)

energywise domain command [2-188](#)

EnergyWise neighbor table, deleting [2-69](#)

energywise query command [2-190](#)

environmental

alarms [2-537](#)

displaying information [2-537](#)

status [2-537](#)

temperature [2-537](#)

erase a file [2-194](#)

error disable detection

clearing error disable on an interface [2-70](#)

enabling error disable detection [2-70, 2-197](#)

enabling per-VLAN on BPDU guard [2-197](#)

error-disabled state

displaying [2-570](#)

error disable recovery

configuring recovery mechanism variables [2-199](#)

displaying recovery timer information [2-541](#)

enabling ARP inspection timeout [2-199](#)

specifying recovery cause [2-199](#)

EtherChannel

assigning interfaces to EtherChannel groups [2-58](#)

debugging EtherChannel [2-112](#)

debugging PAgP shim [2-112](#)

debugging spanning tree activities [2-131](#)

displaying information for a channel [2-543](#)

removing interfaces from EtherChannel groups [2-58](#)

EtherChannel guard

detecting STP misconfiguration [2-783](#)

Explicit Host Tracking

clearing the database [2-83](#)

enabling per-VLAN [2-261](#)

expressions

matching multiple expression occurrences [1-9](#)

multiple-character patterns [1-8](#)

multiplying pattern occurrence [1-11](#)

single-character patterns [1-7](#)

Extensible Authentication Protocol

See EAP

F

fallback profile, specifying [2-28](#)

field replaceable unit (FRU)

displaying status information [2-537](#)

filters

EIGRP

routing updates, preventing [2-370](#)

Flash memory file system

displaying file system information [2-502](#)

verifying checksum [2-883](#)

flow control

configuring a gigabit interface for pause frames [2-202](#)

displaying per-interface statistics for flow control [2-547](#)

G

GBIC

displaying SEEPROM information [2-551](#)

generic-error-message, setting for the switch [2-408](#)

Gigabit Ethernet interface

clearing the hardware logic [2-72](#)

Gigabit Ethernet uplink

selecting [2-210](#)

showing the mode [2-549, 2-550](#)

global configuration mode

using [1-5](#)

H

hardware module

resetting a module by toggling the power [2-207](#)

hardware statistics

disabling [2-205](#)

enabling [2-205](#)

hardware uplink

- changing the mode [2-208](#)
- selecting the mode [2-210](#)
- showing the mode [2-549, 2-550](#)

helper addresses, IP [2-607](#)

hot standby protocol

- debugging [2-107](#)
- disabling debugging [2-107](#)
- limiting output [2-107](#)

identifier-string, setting for the switch [2-408](#)

ID mapping, creating an ANCP client [2-16](#)

IDROMs

- displaying SEEPROM information
 - chassis [2-551](#)
 - clock module [2-551](#)
 - fan trays [2-551](#)
 - module [2-551](#)
 - mux buffer [2-551](#)
 - power supplies [2-551](#)
 - supervisor engine [2-551](#)

ifIndex persistence

- clearing SNMP ifIndex commands [2-769](#)
- compress SNMP ifIndex table format [2-776](#)
- disabling globally [2-775](#)
- disabling on an interface [2-771](#)
- enabling globally [2-775](#)
- enabling on an interface [2-771](#)

IGMP

- applying filters for host joining on Layer 2 interfaces [2-251](#)
- clearing IGMP group cache entries [2-81](#)
- configuring frequency for IGMP host-query messages [2-254](#)
- creating an IGMP profile [2-253](#)
- displaying IGMP interface configuration information [2-594](#)
- displaying profiles [2-596](#)

- setting maximum group numbers [2-252](#)

IGMP profiles

- displaying [2-596](#)

IGMP snooping

- clearing the EHT database [2-83](#)
- configuring a Layer 2 interface as a group member [2-267](#)
- configuring a Layer 2 interface as a multicast router [2-265](#)
- configuring a static VLAN interface [2-267](#)
- displaying multicast information [2-603](#)
- displaying VLAN information [2-597, 2-601, 2-604](#)
- enabling [2-256](#)
- enabling immediate-leave processing [2-263](#)
- enabling on a VLAN [2-260](#)
- enabling per-VLAN Explicit Host Tracking [2-261](#)

informs

- enabling [2-773](#)

inline power

- displaying inline power status [2-703](#)

In Service Software Upgrade

- See ISSU

inspection log

- clearing log buffer [2-75](#)

interface

- displaying suppressed multicast bytes [2-564](#)

interface capabilities

- displaying [2-560](#)

interface configuration mode

- summary [1-5](#)

interface link

- display cable disconnect time [2-567](#)

interfaces

- configuring dot1q tunnel ports [2-836](#)
- creating an interface-range macro [2-145](#)
- debugging output of interface related activities [2-106](#)
- displaying description [2-566](#)
- displaying error-disabled state [2-570](#)
- displaying information when tunneling is enabled [2-647](#)

- displaying status [2-566](#)
- displaying traffic for a specific interface [2-557](#)
- entering interface configuration mode [2-215](#)
- executing a command on multiple ports in a range [2-218](#)
- selecting an interface to configure [2-215](#)
- setting a CoS value for Layer 2 packets [2-306](#)
- setting drop threshold for Layer 2 packets [2-307](#)
- setting the interface type [2-836](#)
- interface speed
 - configuring interface speed [2-811](#)
- interface transceiver
 - displaying diagnostic data [2-574](#)
- internal VLAN allocation
 - configuring [2-897](#)
 - default setting [2-897](#)
 - displaying allocation information [2-758](#)
- Internet Group Management Protocol
 - See IGMP
- IP address of remote ANCP server, setting [2-17](#)
- IP ARP
 - applying ARP ACL to VLAN [2-221](#)
 - clearing inspection statistics [2-76](#)
 - clearing status of log buffer [2-75](#)
 - controlling packet logging [2-232](#)
 - enabling dynamic inspection [2-230](#)
 - limit rate of incoming requests [2-223](#)
 - set per-port config trust state [2-227](#)
 - showing status of dynamic ARP inspection [2-581](#)
 - showing status of log buffer [2-584](#)
- IPC
 - debugging IPC activities [2-115](#)
- IP DHCP Snooping
 - See DHCP snooping
- IP header validation
 - disabling [2-276](#)
 - enabling [2-276](#)
- IP interfaces
 - displaying usability status [2-606](#)
- IP multicast
 - displaying multicast routing table information [2-612](#)
- IP packets
 - enable DSCP rewrite [2-447](#)
- IP phone and standard desktop
 - enabling Cisco-recommended features [2-334](#)
- IP Port Security
 - enabling [2-277](#)
- IP source binding
 - adding or deleting [2-273](#)
 - displaying bindingstagging [2-617](#)
- IP source guard
 - debugging messages [2-118](#)
 - displaying configuration and filters [2-618](#)
 - enabling on DHCP snooping [2-277](#)
- IPv6 MLD
 - configuring queries [2-283, 2-285](#)
 - configuring snooping
 - last-listener-query-intervals [2-285](#)
 - configuring snooping
 - listener-message-suppression [2-287](#)
 - configuring snooping robustness-variables [2-288](#)
 - configuring tcn topology change notifications [2-290](#)
 - counting snooping last-listener-queries [2-283](#)
 - displaying information [2-623](#)
 - displaying ports for a switch or VLAN [2-625](#)
 - displaying querier information [2-626](#)
 - enabling snooping [2-281](#)
 - enabling snooping on a VLAN [2-291](#)
- ISSU
 - canceling process [2-293](#)
 - configuring rollback timer [2-303](#)
 - displaying capability [2-628](#)
 - displaying client information [2-630](#)
 - displaying compatibility matrix [2-632](#)
 - displaying endpoint information [2-637](#)
 - displaying entities [2-638](#)
 - displaying FSM session [2-639](#)
 - displaying messages [2-640](#)

- displaying negotiated [2-642](#)
- displaying rollback-timer [2-643](#)
- displaying session information [2-644](#)
- displaying software version [2-645](#)
- displaying state [2-645](#)
- forcing switchover to standby supervisor engine [2-301](#)
- loading new image [2-297](#)
- starting process [2-299](#)
- stopping rollback timer [2-295](#)

J

- Jumbo frames
 - enabling jumbo frames [2-364](#)

L

- LACP
 - deselecting channeling protocol [2-60](#)
 - enabling LACP on an interface [2-60](#)
 - setting channeling protocol [2-60](#)
- Layer 2
 - displaying ACL configuration [2-656](#)
- Layer 2 interface type
 - specifying a nontrunking, nontagged single VLAN interface [2-836](#)
 - specifying a trunking VLAN interface [2-836](#)
- Layer 2 protocol ports
 - displaying [2-647](#)
- Layer 2 protocol tunneling error recovery [2-309](#)
- Layer 2 switching
 - enabling voice VLANs [2-829](#)
 - modifying switching characteristics [2-829](#)
- Layer 2 traceroute
 - IP addresses [2-868](#)
- Layer 3 switching
 - displaying information about an adjacency table [2-492](#)

- displaying port status [2-572](#)
- displaying status of native VLAN tagging [2-572](#)
- link-status event messages
 - disabling
 - globally [2-314, 2-317](#)
 - on an interface [2-315, 2-318](#)
 - enabling
 - globally [2-314, 2-317](#)
 - on an interface [2-315, 2-318](#)
- lldp run command [2-313](#)
- log buffer
 - show status [2-584](#)
- logging
 - controlling IP ARP packets [2-232](#)

M

- MAB, display information [2-653](#)
- MAB, enable and configure [2-320](#)
- mab command [2-320](#)
- MAC Access Control Lists
 - See MAC ACLs
- MAC ACLs
 - defining extended MAC access list [2-322](#)
 - displaying MAC ACL information [2-755](#)
 - naming an ACL [2-322](#)
- MAC address filtering
 - configuring [2-331](#)
 - disabling [2-331](#)
 - enabling [2-331](#)
- MAC address table
 - adding static entries [2-343](#)
 - clearing dynamic entries [2-87, 2-89](#)
 - configuring aging time [2-325](#)
 - displaying dynamic table entry information [2-663](#)
 - displaying entry count [2-661](#)
 - displaying information [2-657](#)
 - displaying interface-based information [2-665](#)
 - displaying multicast information [2-667](#)

- displaying notification information [2-669](#)
- displaying protocol-based information [2-671](#)
- displaying static table entry information [2-673](#)
- displaying the MAC address aging time [2-659](#)
- displaying VLAN-based information [2-676](#)
- enabling authentication bypass [2-170](#)
- enabling notifications [2-329](#)
- learning in the protocol buckets [2-326](#)
- removing static entries [2-343](#)
- MAC address tables
 - adding static entries [2-331](#)
 - deleting secure or specific addresses [2-92](#)
 - disabling IGMP snooping on static MAC addresses [2-331](#)
 - removing static entries [2-331](#)
- mac-address-table static [2-331](#)
- MAC address unicast filtering
 - dropping unicast traffic [2-331](#)
- MAC authentication bypass (MAB), display information [2-653](#)
- MAC authorization bypass(MAB), enable and configure [2-320](#)
- macro
 - displaying descriptions [2-342](#)
- macro keywords
 - help strings [2-2](#)
- macros
 - adding a global description [2-342](#)
 - cisco global [2-340](#)
 - system-cpp [2-341](#)
- mapping secondary VLANs to MST instance [2-424](#)
- mapping VLAN(s) to an MST instance [2-212](#)
- match (class-map configuration) command [2-14](#), [2-148](#), [2-150](#), [2-152](#), [2-154](#), [2-346](#), [2-817](#), [2-819](#), [2-821](#), [2-823](#), [2-827](#)
- maximum transmission unit (MTU)
 - displaying the system MTU setting [2-746](#)
 - setting the maximum Layer 2 payload size [2-861](#)
- MD5
 - verifying MD5 signature [2-883](#)
- message digest 5
 - See MD5
- MFIB
 - clearing ip mfib counters [2-84](#)
 - clearing ip mfib fastdrop [2-85](#)
 - displaying all active MFIB routes [2-609](#)
 - displaying MFIB fastdrop table entries [2-611](#)
 - enabling IP MFIB fastdrops [2-270](#)
- MLD
 - configuring snooping
 - last-listener-query-intervals [2-285](#)
 - configuring snooping
 - listener-message-suppression [2-287](#)
 - configuring snooping robustness-variables [2-288](#)
 - configuring topology change notifications [2-290](#)
 - counting snooping last-listener-queries [2-283](#)
 - enabling snooping [2-281](#)
 - enabling snooping on a VLAN [2-291](#)
- MLD snooping
 - displaying [2-626](#)
- modes
 - access-group [2-6](#)
 - show access-group interface [2-405](#), [2-491](#), [2-714](#)
 - switching between PVST+, MST, and Rapid PVST [2-788](#)
 - See also command modes
- module password clearing [2-71](#)
- module reset
 - resetting a module by toggling the power [2-207](#)
- More-- prompt
 - filter [1-6](#)
 - search [1-7](#)
- MST
 - designating the primary and secondary root [2-797](#)
 - displaying MST protocol information [2-741](#)
 - displaying region configuration information [2-741](#)
 - displaying spanning tree information [2-741](#)
 - entering MST configuration submenu [2-791](#)
 - setting configuration revision number [2-464](#)
 - setting path cost and port priority for instances [2-789](#)
 - setting the forward delay timer for all instances [2-793](#)

- setting the hello-time delay timer for all instances [2-794](#)
- setting the max-age timer for all instances [2-795](#)
- setting the MST region name [2-365](#)
- specifying the maximum number of hops [2-796](#)
- switching between PVST+ and Rapid PVST [2-788](#)
- using the MST configuration submode revision command [2-464](#)
- using the submode name command [2-365](#)

MTU

- displaying global MTU settings [2-746](#)

- multi-auth, setting [2-29](#)

Multicast Listener Discovery

- See MLD

multicast

- counters [2-101](#)
- enabling storm control [2-816](#)
- show ancp [2-494](#)

multicast/unicast packets

- prevent forwarding [2-835](#)

Multicast Forwarding Information Base

- See MFIB

- multi-domain, setting [2-29](#)

- multiple-character patterns [1-8](#)

Multiple Spanning Tree

- See MST

N

native VLAN

- controlling tagging of traffic [2-856](#)
- displaying ports eligible for native tagging [2-757](#)
- displaying ports eligible for tagging [2-757](#)
- enabling tagging on 802.1Q trunk ports [2-894](#)
- specifying the tagging of traffic [2-857](#)

NetFlow

- enabling NetFlow statistics [2-271](#)
- including infer fields in routing statistics [2-271](#)

next-hop

- displaying CEF VLAN information [2-586](#)

- nmsp attachment suppress command [2-367](#)

- nmsp command [2-366](#)

- no form of a command, using [1-6](#)

NVRAM

- debugging NVRAM activities [2-122](#)

O

- open access on a port, enabling [2-31](#)

output

- pattern searches [1-7](#)

P

packet counters (statistics)

- clear for PPPoE Intermediate Agent [2-94](#)

- packet counters, display for PPPoE Intermediate Agent [2-712](#)

packet forwarding

- prevent unknown packets [2-835](#)

packet memory failure

- direct switch action upon detection [2-156](#)

packet memory test

- bootup, displaying results [2-523](#), [2-525](#)
- ongoing, displaying results [2-527](#)

PACL

- access-group mode [2-6](#)

paging prompt

- see --More-- prompt

PAGP

- clearing port channel information [2-91](#)

- debugging PAGP activity [2-123](#)

- deselecting channeling protocol [2-60](#)

- displaying port channel information [2-685](#)

hot standby mode

- returning to defaults [2-369](#)

- selecting ports [2-369](#)

- input interface of incoming packets

- learning [2-368](#)
 - returning to defaults [2-368](#)
 - setting channeling protocol [2-60](#)
- parentheses [1-11](#)
- password
 - clearing on an intelligent line module [2-71](#)
 - establishing enhanced password security [2-881](#)
 - setting username [2-881](#)
- PBR
 - displaying route maps [1-xx](#)
 - redistributing route maps [1-xx](#)
- PM activities
 - debugging [2-126](#)
 - disabling debugging [2-126](#)
- PoE policing
 - configure on an interface [2-400](#)
- PoE policing and monitoring
 - displaying status [2-711](#)
- police (percent) command [2-380](#)
- police (two rates) command [2-382, 2-384](#)
- police command [2-375](#)
- policing, configure PoE [2-400](#)
- policing and monitoring status
 - displaying PoE [2-711](#)
- Policy Based Routing
 - See PBR
- policy maps
 - creating [2-388](#)
 - marking [2-474](#)
 - See also QoS, hierarchical policies
 - traffic classification
 - defining the class
 - defining trust states [2-871](#)
- port, dual-capable
 - selecting the connector [2-355](#)
- Port Aggregation Protocol
 - See PAgP
- port-based authentication
 - displaying debug messages [2-111](#)
 - displaying statistics and status [2-529](#)
 - enabling 802.1X [2-174](#)
 - host modes [2-167](#)
 - manual control of authorization state [2-174](#)
 - periodic re-authentication
 - enabling [2-177](#)
 - re-authenticating 802.1X-enabled ports [2-176](#)
 - switch-to-client frame-retransmission number [2-172](#)
- port channel
 - accessing [2-217](#)
 - creating [2-217](#)
 - displaying information [2-685](#)
 - load distribution method
 - resetting to defaults [2-390](#)
 - setting [2-390](#)
- port control, changing from unidirectional or bidirectional [2-23](#)
- port-control value, configuring [2-35](#)
- port range
 - executing [2-218](#)
- port security
 - debugging ports security [2-127](#)
 - deleting secure or specific addresses [2-92](#)
 - displaying settings for an interface or switch [2-696](#)
 - enabling [2-841](#)
 - filter source IP and MAC addresses [2-277](#)
 - setting action upon security violation [2-841](#)
 - setting the rate limit for bad packets [2-841](#)
 - sticky port [2-841](#)
- Port Trust Device
 - displaying [2-717](#)
- power status
 - displaying inline power [2-703](#)
 - displaying power status [2-703](#)
- power supply
 - configuring combined and redundant power on the Catalyst 4507R [2-392](#)
 - configuring inline power [2-397](#)
 - configuring power consumption [2-392](#)

displaying the SEEPROM [2-551](#)

setting inline power state [2-396](#)

PPPoE Discovery

enable vendor-tag stripping on packets PPPoE Server

enable vendor-tag stripping on Discovery packets [2-414](#)

PPPoE Discovery packets, limit rate arriving on an interface [2-412](#)

PPPoE Intermediate Agent

clear statistics (packet counters) [2-94](#)

debugging [2-128](#)

pppoe intermediate-agent

enable intermediate agent on a switch [2-404](#)

enable on an interface VLAN range [2-407](#)

enable PPPoE Intermediate Agent on an interface [2-405](#)

enable vendor-tag stripping of Discovery packets [2-414](#)

format-type (global) [2-408](#)

limit rate of PPPoE Discovery packets [2-412](#)

set circuit-id or remote-id for an interface [2-410](#)

set circuit-id or remote-id for an interface VLAN range [2-411](#)

set trust configuration on an interface [2-412, 2-413](#)

PPPoE Intermediate Agent, display configuration and statistics (packet counters) [2-712](#)

priority command [2-415](#)

priority-queue command [2-102](#)

Private VLAN

See PVLANS

privileged EXEC mode, summary [1-5](#)

prompts

system [1-5](#)

protocol tunneling

configuring encapsulation rate [2-309](#)

disabling [2-304](#)

displaying port information [2-647](#)

enabling [2-304](#)

setting a CoS value for Layer 2 packets [2-306](#)

setting a drop threshold for Layer 2 packets [2-307](#)

PVLANS

configuring isolated, primary, and community PVLANS [2-417](#)

controlling tagging of native VLAN traffic [2-856](#)

disabling sticky-ARP [2-274](#)

displaying map information for VLAN SVIs [2-569](#)

displaying PVLAN information [2-760](#)

enabling interface configuration mode [2-836](#)

enabling sticky-ARP [2-274](#)

mapping VLANs to the same SVI [2-421](#)

specifying host ports [2-836](#)

specifying promiscuous ports [2-836](#)

PVST+

switching between PVST and MST [2-788](#)

Q

QoS

account Layer 2 encapsulation [2-429](#)

attaching a policy-map to an interface [2-465](#)

automatic configuration [2-42](#)

class maps

creating [2-65](#)

defining the match criteria [2-346](#)

clearing aggregate counters [2-95](#)

configuring auto [2-42](#)

defining a named aggregate policer [2-431](#)

defining default CoS value [2-436](#)

defining ingress CoS-to-DSCP mapping [2-441](#)

displaying aggregate policer information [2-715](#)

displaying auto configuration [2-501](#)

displaying class maps information [2-515](#)

displaying configuration information [2-501](#)

displaying configurations of policies [2-691](#)

displaying policy map information [2-687, 2-694](#)

displaying QoS information [2-714](#)

displaying QoS map information [2-719](#)

egress queue-sets

enabling the priority queue [2-102](#)

- enabling global configuration mode [2-427](#)
- enabling on control packets [2-434](#)
- enabling per-VLAN QoS for a Layer 2 interface [2-450](#)
- enabling QoS on an interface [2-428](#)
- hierarchical policies
 - average-rate traffic shaping on a class [2-487](#)
 - bandwidth allocation for a class [2-46, 2-64](#)
 - creating a service policy [2-468](#)
 - marking [2-474](#)
 - strict priority queueing (LLQ) [2-415](#)
- mapping DSCP values to transmit queues [2-443](#)
- mapping egress DSCP-to-CoS [2-443](#)
- mapping the DSCP-to-CoS value [2-443](#)
- policy maps
 - creating [2-388](#)
 - marking [2-474](#)
 - traffic classifications
 - trust states [2-871](#)
- setting the mapping of policed DSCP values [2-445](#)
- setting the trust state [2-448](#)
- specifying flow-based match criteria [2-349](#)
- Supervisor Engine 6-E
 - setting CoS [2-476](#)
 - setting DSCP [2-479](#)
 - setting precedence values [2-482](#)
 - setting QoS group identifiers [2-485](#)
- QoS CoS
 - configuring for tunneled Layer 2 protocol packets [2-306](#)
 - defining default CoS value [2-436](#)
- qos dbl [2-437](#)
- quality of service
 - See QoS
- question command [1-1](#)
- queueing information
 - displaying [2-717](#)
- queue limiting
 - configuring packet limits [2-452](#)

R

- Rapid PVST
 - switching between PVST and MST [2-788](#)
- re-authenticating 802.1X-enabled ports [2-176](#)
- re-authentication
 - periodic [2-177](#)
 - set the time [2-179](#)
- reauthentication, enabling [2-34](#)
- reboots
 - restoring bindings across [2-238](#)
- redundancy
 - accessing the main CPU [2-454](#)
 - changing from active to standby supervisor engine [2-458](#)
 - displaying information [2-721](#)
 - displaying ISSU config-sync failure information [2-725](#)
 - displaying redundancy facility information [2-721](#)
 - displaying RF client list [2-721](#)
 - displaying RF operational counters [2-721](#)
 - displaying RF states [2-721](#)
 - enabling automatic synchronization [2-45](#)
 - forcing switchover to standby supervisor engine [2-458](#)
 - mismatched command listing [2-456](#)
 - set the mode [2-356](#)
 - synchronizing the route processor configurations [2-343](#)
- related documentation [1-xix](#)
- remote-id, setting for an interface [2-410](#)
- remote-id, setting for an interface VLAN range [2-411](#)
- remote SPAN
 - See RSPAN
- renew commands
 - ip dhcp snooping database [2-462](#)
- resetting PVLAN trunk
 - setting switchport to trunk [2-836](#)
- retry failed authentication, configuring [2-26](#)
- rj45 connector, selecting the connector [2-355](#)

ROM monitor mode

summary [1-6](#)

Route Processor Redundancy

See redundancy

router, set to become ANCP client [2-18](#)

RPF

disabling IPv4 exists-only checks [2-279](#)enabling IPv4 exists-only checks [2-279](#)

RPR

set the redundancy mode [2-356](#)

RSPAN

converting VLAN to RSPAN VLAN [2-461](#)displaying list [2-762](#)

Ssaving configuration changes [1-11](#)secure address, configuring [2-392](#)secure ports, limitations [2-842](#)server (AAA) alive actions, configuring [2-26](#)server (AAA) dead actions, configuring [2-26](#)service-policy command (policy-map class) [2-468](#)session classification, defining [2-29](#)set the redundancy mode [2-356](#)sfp connector, selecting the connector [2-355](#)shape command [2-487](#)show ancp multicast [2-494](#)show authentication interface command [2-496](#)show authentication registration command [2-496](#)show authentication sessions command [2-496](#)

show commands

filtering parameters [1-7](#)searching and filtering [1-6](#)show platform commands [1-11](#)show energywise command [2-533](#)show mab command [2-653](#)show nmsp command [2-682](#)

Simple Network Management Protocol

See SNMP

single-character patterns

special characters [1-7](#)single-host, setting [2-29](#)

slaveslot0

displaying information on the standby supervisor [2-732](#)

slot0

displaying information about the system [2-734](#)

SNMP

debugging spanning tree activities [2-131](#)

ifIndex persistence

clearing SNMP ifIndex commands [2-769](#)compress SNMP ifIndex table format [2-776](#)disabling globally [2-775](#)disabling on an interface [2-771](#)enabling globally [2-775](#)enabling on an interface [2-771](#)

informs

disabling [2-773](#)enabling [2-773](#)

traps

configuring to send when storm occurs [2-814](#)disabling [2-773](#)enabling [2-773](#)

mac-notification

adding [2-777](#)removing [2-777](#)

SPAN commands

configuring a SPAN session to monitor [2-358](#)displaying SPAN session information [2-745, 2-816](#)

SPAN enhancements

displaying status [2-680](#)

Spanning Tree Protocol

See STP

SPAN session

displaying session information [2-680](#)filter ACLs [2-358](#)specify encaps type [2-358](#)turn off host learning based on ingress packets [2-358](#)

- special characters
 - anchoring, table [1-10](#)
- SSO [2-356](#)
- standard desktop
 - enabling Cisco-recommended features [2-332](#)
- standard desktop and Cisco IP phone
 - enabling Cisco-recommended features [2-334](#)
- sticky address, configuring [2-393](#)
- sticky-ARP
 - disabling on PVLANS [2-274](#)
 - enabling on PVLANS [2-274](#)
- sticky port
 - deleting [2-92](#)
 - enabling security [2-841](#)
- storm control
 - configuring for action when storm occurs [2-814](#)
 - disabling suppression mode [2-540](#)
 - displaying settings [2-744](#)
 - enabling [2-814](#)
 - enabling broadcast [2-814, 2-816](#)
 - enabling multicast [2-814, 2-816](#)
 - enabling suppression mode [2-540](#)
 - enabling timer to recover from error disable [2-199](#)
 - enabling unicast [2-814, 2-816](#)
 - multicast, enabling [2-816](#)
 - setting high and low levels [2-814](#)
 - setting suppression level [2-540](#)
- STP
 - configuring link type for a port [2-786](#)
 - configuring tunneling encapsulation rate [2-309](#)
 - debugging all activities [2-131](#)
 - debugging spanning tree activities [2-131](#)
 - debugging spanning tree BackboneFast events [2-133](#)
 - debugging spanning tree UplinkFast [2-136](#)
 - detecting misconfiguration [2-783](#)
 - displaying active interfaces only [2-736](#)
 - displaying BackboneFast status [2-736](#)
 - displaying bridge status and configuration [2-736](#)
 - displaying spanning tree debug messages [2-131](#)
 - displaying summary of interface information [2-736](#)
 - enabling BPDU filtering by default on all PortFast ports [2-802](#)
 - enabling BPDU filtering on an interface [2-779](#)
 - enabling BPDU guard by default on all PortFast ports [2-804](#)
 - enabling BPDU guard on an interface [2-781](#)
 - enabling extended system ID [2-784](#)
 - enabling loop guard as a default on all ports [2-787](#)
 - enabling PortFast by default on all access ports [2-805](#)
 - enabling PortFast mode [2-800](#)
 - enabling protocol tunneling for [2-304](#)
 - enabling root guard [2-785](#)
 - enabling spanning tree BackboneFast [2-778](#)
 - enabling spanning tree on a per VLAN basis [2-809](#)
 - enabling spanning tree UplinkFast [2-807](#)
 - setting an interface priority [2-806](#)
 - setting drop threshold for [2-307](#)
 - setting pathcost [2-782](#)
 - setting the default pathcost calculation method [2-799](#)
- subinterface configuration mode, summary [1-6](#)
- SVI
 - creating a Layer 3 interface on a VLAN [2-220](#)
- switching characteristics
 - excluding from link-up calculation [2-833](#)
 - modifying [2-833](#)
 - returning to interfaces
 - capture function [2-833](#)
- switchport [2-857](#)
- switchport interfaces
 - displaying status of Layer 3 port [2-572](#)
 - displaying status of native VLAN tagging [2-572](#)
- switch shim
 - debugging [2-134](#)
 - disabling debugging [2-134](#)
- switch to router connection
 - enabling Cisco-recommended features [2-336](#)
- switch to switch connection
 - enabling Cisco-recommended features [2-338](#)

switch virtual interface

See SVI

sw-vlan [2-137](#)

system prompts [1-5](#)

T

Tab key

command completion [1-1](#)

tables

characters with special meaning [1-7](#)

mac access-list extended subcommands [2-322](#)

multipliers [1-9](#)

relationship between duplex and speed
commands [2-812](#)

show cable-diagnostics tdr command output
fields [2-506](#)

show cdp neighbors detail field descriptions [2-514](#)

show cdp neighbors field descriptions [2-513](#)

show ip dhcp snooping command output [2-497, 2-653](#)

show ip interface field descriptions [2-607](#)

show policy-map control-plane field
descriptions [2-690](#)

show vlan command output fields [2-761](#)

show vtp command output fields [2-766](#)

special characters [1-9](#)

special characters used for anchoring [1-10](#)

speed command options [2-349, 2-812](#)

valid interface types [2-215](#)

TAC

displaying information useful to TAC [2-747](#)

TCAM

debugging spanning tree activities [2-131](#)

TDR

displaying cable diagnostic test results [2-505](#)

test condition of copper cables [2-863](#)

temperature readings

displaying information [2-537](#)

Ten-Gigabit Ethernet uplink

blocking ports on redundant Supervisor Engine
6-E [2-208](#)

timer information [2-541](#)

traffic monitor

display status [2-653](#)

traffic shaping

enable on an interface [2-489](#)

traps, enabling [2-773](#)

trunk encapsulation

setting format [2-857](#)

trunk interfaces

displaying trunk interfaces information [2-579](#)

trust configuration, setting on an interface [2-412, 2-413](#)

trust state

setting [2-227](#)

tunnel ports

displaying information about Layer 2 protocol [2-647](#)

TX queues

allocating bandwidth [2-873](#)

returning to default values [2-873](#)

setting priority to high [2-873](#)

specifying burst size [2-873](#)

specifying traffic rate [2-873](#)

U

UDLD

displaying administrative and operational
status [2-749](#)

enabling by default on all fiber interfaces [2-875](#)

enabling on an individual interface [2-877](#)

preventing a fiber interface from being enabled [2-877](#)

resetting all shutdown ports [2-879](#)

setting the message timer [2-875](#)

unicast

counters [2-101](#)

Unidirectional Link Detection

See UDLD

unidirection port control, changing from
bidirectional [2-23](#)

unknown multicast traffic, preventing [2-835](#)

unknown unicast traffic, preventing [2-835](#)

user EXEC mode, summary [1-5](#)

username

 setting password and privilege level [2-881](#)

V

VACLs

 access-group mode [2-6](#)

 applying VLAN access maps [2-896](#)

 displaying VLAN access map information [2-755](#)

 specifying an action in a VLAN access map [2-13](#)

 specifying the match clause for a VLAN access-map
 sequence [2-344](#)

 using a VLAN filter [2-896](#)

VLAN

 applying an ARP ACL [2-221](#)

 configuring [2-885](#)

 configuring service policies [2-890](#)

 converting to RSPAN VLAN [2-461](#)

 displaying CEF information [2-586](#)

 displaying CEF next-hop information [2-586](#)

 displaying information on switch interfaces [2-597,](#)
[2-601](#)

 displaying information on VLAN switch
 interfaces [2-604](#)

 displaying information sorted by group IP
 address [2-597, 2-601](#)

 displaying IP address and version information [2-597,](#)
[2-601](#)

 displaying Layer 2 VLAN information [2-751](#)

 displaying statistical information [2-678](#)

 displaying VLAN information [2-753](#)

 enabling dynamic ARP inspection [2-230](#)

 enabling Explicit Host Tracking [2-261](#)

 enabling guest per-port [2-165](#)

 enabling guest VLAN supplicant [2-158, 2-166](#)

 entering VLAN configuration mode [2-890, 2-892](#)

 native frames

 enabling tagging on all 802.1Q trunk ports [2-894](#)

 pruning the list for VTP [2-857](#)

 setting the list of allowed [2-857](#)

VLAN Access Control Lists

 See VACLs

VLAN access map

 See VACLs

VLAN database

 resetting [2-463](#)

VLAN debugging

 limiting output [2-109](#)

VLAN link-up calculation

 excluding a switch port [2-833](#)

 including a switch port [2-833](#)

VLAN manager

 debugging [2-137](#)

 disabling debugging [2-137](#)

 IOS file system error tests

 debugging [2-138](#)

 disabling debugging [2-138](#)

VLAN Query Protocol

 See VQP

VLAN query protocol (VQPC)

 debugging [2-144](#)

VLANs

 clearing

 counters [2-97](#)

 clearing hardware logic [2-73](#)

 configuring

 internal allocation scheme [2-897](#)

 displaying

 internal VLAN allocation information [2-758](#)

 RSPAN VLANs [2-762](#)

 entering VLAN configuration mode [2-892](#)

VMPS

 configuring servers [2-901](#)

reconfirming dynamic VLAN assignments [2-144](#),
[2-899](#)

voice VLANs

enabling [2-829](#)

VoIP

configuring auto-QoS [2-42](#)

VQP

per-server retry count [2-900](#)

reconfirming dynamic VLAN assignments [2-144](#),
[2-899](#)

VTP

configuring the administrative domain name [2-905](#)

configuring the device in VTP client mode [2-904](#)

configuring the device in VTP server mode [2-908](#)

configuring the device in VTP transparent
mode [2-909](#)

configuring tunnel encapsulation rate [2-309](#)

creating a VTP domain password [2-906](#)

displaying domain information [2-765](#)

displaying statistics information [2-765](#)

enabling protocol tunneling for [2-304](#)

enabling pruning in the VLAN database [2-907](#)

enabling VTP version 2 mode [2-910](#)

modifying the VTP configuration storage file
name [2-903](#)

set drop threshold for [2-307](#)

VTP protocol code

activating debug messages [2-141](#)

deactivating debug messages [2-141](#)

W

Webauth fallback, enabling [2-28](#)