



INDEX

Symbols

- \$ matches the end of a string [1-7](#)
- () in commands [1-11](#)
- * matches 0 or more sequences of a pattern [1-7](#)
- + matches 1 or more sequences of a pattern [1-7](#)
- . matches any single character [1-7](#)
- ? command [1-1](#)
- ? matches 0 or 1 occurrence of a pattern [1-7](#)
- ^ matches the beginning of a string [1-7](#)
- _ matches a comma (,), left brace ({), left parenthesis [1-7](#)
- “ [1-10](#)

Numerics

- 10-Gigabit Ethernet uplink
 - selecting [2-211](#)
 - showing the mode [2-553, 2-554](#)
- 802.1Q trunk ports and native VLANs [2-898](#)
- 802.1Q tunnel ports
 - configuring [2-840](#)
- 802.1S Multiple Spanning Tree
 - see MST
- 802.1X
 - configuring for multiple hosts [2-168](#)
 - configuring for single host [2-168](#)
 - configuring multiple domains [2-168](#)
 - disabling port control [2-161](#)
 - enabling port control [2-161](#)
- 802.1X Critical Authentication
 - disabling on a port [2-162](#)
 - disabling on a VLAN [2-165](#)
- EAPOL

- disabling send success packets [2-163](#)
- enabling send success packets [2-163](#)
- enabling on a port [2-162](#)
- enabling on a VLAN [2-165](#)
- returning delay time to default setting [2-164](#)
- setting delay time on a port [2-164](#)
- 802.1X critical authentication
 - configure parameters [2-25](#)
- 802.1X critical recovery delay, configuring [2-25](#)
- 802.1X Port Based Authentication
 - debugging 802.1X Port Based Authentication [2-111](#)
 - displaying port based authentication [2-533](#)
 - enabling accounting for authentication sessions [2-4](#)
 - enabling authentication on the system [2-179](#)
 - enabling guest VLAN [2-166](#)
 - enabling guest VLAN supplicant [2-159, 2-167](#)
 - enabling manual control of auth state [2-175](#)
 - enabling periodic re-authentication of the client [2-178](#)
 - initializing re-authentication of dot1x ports [2-177](#)
 - initializing state machines [2-170](#)
 - receive session termination message upon reboot [2-5](#)
 - setting maximum number for EAP requests [2-173](#)
 - setting the reauthentication timer [2-180](#)

A

- abbreviating commands
 - context-sensitive help [1-1](#)
- Access Gateway Module
 - connecting to a module [2-22](#)
 - connecting to a remote module [2-463](#)
 - connecting to a specific remote module [2-475](#)
- access-group

- displaying mac interface [2-660](#)
- show mode interface [2-408, 2-495, 2-718](#)
- access groups
 - IP [2-6, 2-156](#)
- access lists
 - clearing an access template [2-74](#)
 - defining ARP [2-21](#)
 - displaying ARP information [2-499](#)
 - See also ACLs, MAC ACLs, and VACLs
- access maps
 - applying with VLAN filter [2-900](#)
- access-node-identifier, setting for the switch [2-411](#)
- access-policies, applying using host-mode [2-29](#)
- ACLs
 - access-group mode [2-6](#)
 - balancing hardware regions [2-12](#)
 - capturing control packets [2-8](#)
 - determining ACL hardware programming [2-10](#)
 - disabling hardware statistics [2-206](#)
 - displaying mac access-group interface [2-660](#)
 - enabling hardware statistics [2-206](#)
 - using ACL naming conventions for MAC ACLs [2-324](#)
- action clause
 - specifying drop or forward action in a VACL [2-13](#)
- addresses, configuring a maximum [2-396](#)
- adjacency
 - debugging the adjacency table [2-104](#)
 - disabling the debug facility [2-104](#)
 - displaying information about the adjacency table [2-496](#)
 - displaying IPC table entries [2-104](#)
- aggregate policer
 - displaying information [2-719](#)
- aging time
 - displaying MAC address aging time [2-663](#)
 - MAC address table [2-327](#)
- alarms
 - displaying operational status [2-541](#)
- alternation
 - description [1-10](#)
- anchoring
 - description [1-10](#)
- anycp, show multicast [2-498](#)
- ANCP client
 - port identifier [2-16](#)
 - remote server [2-17](#)
 - set router to become [2-18](#)
- ARP
 - access list, displaying detailed information [2-499](#)
 - defining access-lists [2-21](#)
- ARP inspection
 - enforce certain types of checking [2-228](#)
- ARP packet
 - deny based on DHCP bindings [2-146](#)
 - permit based on DHCP bindings [2-375](#)
- authentication [2-25, 2-31](#)
 - changing the control-direction [2-23](#)
 - configure actions for events
 - configuring the actions [2-26](#)
 - configuring port-control [2-35](#)
 - enabling reauthentication [2-34](#)
 - enabling Webauth fallback [2-28](#)
 - host-mode configuration [2-29](#)
 - setting priority of methods [2-37](#)
 - setting the timer [2-39](#)
 - setting username [2-885](#)
 - specifying the order of methods [2-32](#)
 - using an MD5-type encryption method [2-885](#)
 - verifying MD5 signaturemessage digest 5
 - See MD5
 - verifying the checksum for Flash memory [2-887](#)
- authentication control-direction command [2-23](#)
- authentication critical recovery delay command [2-25](#)
- authentication event command [2-26](#)
- authentication fallback command [2-28](#)
- authentication host-mode [2-29](#)
- authentication methods, setting priority [2-37](#)

authentication methods, specifying the order of attempts [2-32](#)
 authentication open command [2-31](#)
 authentication order command [2-32](#)
 authentication periodic command [2-34](#)
 authentication port-control command [2-35](#)
 authentication priority command [2-37](#)
 authentication timer, setting [2-39](#)
 authentication timer command [2-39](#)
 authentication violation command [2-41](#)
 auth fail VLAN
 enable on a port [2-160](#)
 set max number of attempts [2-159](#)
 Auth Manager
 configuring
 authentication timer [2-39](#)
 authorization state
 enabling manual control [2-175](#)
 authorization state of a controlled port [2-175](#)
 automatic installation
 displaying status [2-504](#)
 automatic medium-dependent interface crossover
 See Auto-MDIX
 Auto-MDIX
 disabling [2-355](#)
 enabling [2-355](#)
 auto-negotiate interface speed
 example [2-817](#)
 auto-QoS
 configuring for VoIP [2-42](#)
 displaying configuration [2-505](#)

B

baby giants
 displaying the system MTU setting [2-751](#)
 setting the maximum Layer 2 payload size [2-865](#)
 BackboneFast
 displaying debugging messages [2-133](#)

 displaying spanning tree status [2-740](#)
 enabling debugging [2-133](#)
 bandwidth command [2-46](#)
 bindings
 store for DHCP snooping [2-240](#)
 BOOT environment variable
 displaying information [2-508](#)
 bootflash
 displaying information [2-506](#)
 BPDUs
 debugging spanning tree activities [2-131](#)
 bridge protocol data units
 See BPDUs
 broadcast
 counters [2-101](#)
 broadcast suppression level
 configuring [2-818, 2-820](#)
 enabling [2-818, 2-820](#)

C

cable diagnostics
 TDR
 displaying test results [2-509](#)
 testing conditions of copper cables [2-867](#)
 call home
 displaying information [2-511](#)
 e-mailing output [2-54](#)
 entering configuration submenu [2-49](#)
 executing [2-54](#)
 manually send test message [2-57](#)
 receiving information [2-52](#)
 sending alert group message [2-55](#)
 submitting information [2-52](#)
 call home destination profiles
 displaying [2-513](#)
 Catalyst 4507R [2-394](#)
 CDP
 configuring tunneling encapsulation rate [2-311](#)

- displaying
 - neighbor information [2-516](#)
 - enabling protocol tunneling for [2-306](#)
 - set drop threshold for [2-309](#)
- CEF
 - displaying next-hop information [2-590](#)
 - displaying VLAN configuration information [2-590](#)
- chassis
 - displaying
 - chassis MAC address ranges [2-657](#)
 - current and peak traffic meter readings [2-657](#)
 - percentage of backplane utilization [2-657](#)
 - switching clock failure recovery mode [2-657](#)
- circuit-id
 - setting for an interface [2-413](#)
- circuit-id, setting for an interface VLAN range [2-414](#)
- cisco-desktop
 - macro apply [2-334](#)
- Cisco Express Forwarding
 - See CEF
- cisco-phone
 - macro apply [2-336](#)
- cisco-router
 - macro apply [2-338](#)
- cisco-switch
 - macro apply [2-340](#)
- class maps
 - creating [2-65](#)
 - defining the match criteria [2-348](#)
- clear commands
 - clearing Gigabit Ethernet interfaces [2-72](#)
 - clearing IGMP group cache entries [2-81](#)
 - clearing interface counters [2-67](#)
 - clearing IP access lists [2-74, 2-75](#)
 - clearing IP ARP inspection statistics VLAN [2-76](#)
 - clearing IP DHCP snooping database statistics [2-80](#)
 - clearing MFIB counters and routes [2-84](#)
 - clearing MFIB fastdrop entries [2-85](#)
 - clearing PAgP channel information [2-91](#)
 - clearing QoS aggregate counters [2-95](#)
 - clearing VLAN interfaces [2-73](#)
- clear energywise neighbors command [2-69](#)
- clear nmsp statistics command [2-90](#)
- CLI string search
 - anchoring [1-10](#)
 - expressions [1-7](#)
 - filtering [1-6](#)
 - multiple-character patterns [1-8](#)
 - multipliers [1-9](#)
 - parentheses for recall [1-11](#)
 - searching outputs [1-6](#)
 - single-character patterns [1-7](#)
 - using [1-6](#)
- command modes
 - accessing privileged EXEC mode [1-5](#)
 - exiting [1-5](#)
 - understanding user EXEC and configuration modes [1-5](#)
- condition interface
 - debugging interface-related activities [2-106](#)
- condition vlan
 - debugging VLAN output [2-109](#)
- configuration, saving [1-11](#)
- configuring
 - root as secondary [2-801](#)
- configuring a SPAN session to monitor
 - limit SPAN source traffic [2-360](#)
- configuring critical recovery [2-25](#)
- configuring forward delay [2-797](#)
- configuring root as primary [2-801](#)
- CoPP
 - attaching
 - policy map to control plane [2-473](#)
 - displaying
 - policy-map class information [2-692](#)
 - entering configuration mode [2-99](#)
 - removing
 - service policy from control plane [2-473](#)

CoS

- assigning to Layer 2 protocol packets [2-308](#)

CoS QoS default

- defining value on an interface [2-439](#)

Cost of Service

- See QoS CoS

counters

- clearing interface counters [2-67](#)

- critical authentication, configure 802.1X parameters [2-25](#)

- critical recovery, configuring 802.1X parameter [2-25](#)

D

DAI

- clear statistics [2-76](#)

DBL

- displaying qos dbl [2-720](#)

- enabling DBL globally on the switch [2-440](#)

debug commands

- debugging backup events [2-105](#)

- debugging DHCP snooping events [2-116](#)

- debugging DHCP snooping messages [2-117](#)

- debugging EtherChannel/PAgP/shim [2-112](#)

- debugging IPC activity [2-115](#)

- debugging IP DHCP snooping security messages [2-118](#)

- debugging NVRAM activities [2-122](#)

- debugging PAgP activities [2-123](#)

- debugging port manager activities [2-126](#)

- debugging spanning tree activities [2-131](#)

- debugging spanning tree backbonefast [2-133](#)

- debugging spanning tree UplinkFast [2-136](#)

- debugging supervisor redundancy [2-130](#)

- debugging VLAN manager activities [2-137](#)

- displaying monitor activity [2-120](#)

- displaying the adjacency table [2-104](#)

- enabling debug dot1x [2-111](#)

- enabling debugging messages for ISL VLAN IDs [2-140](#)

- enabling debugging messages for VTP [2-141](#)

- enabling debugging of UDLD activity [2-142](#)

- enabling switch shim debugging [2-134](#)

- enabling VLAN manager file system error tests [2-138](#)

- limiting debugging output for VLANs [2-109](#)

- limiting interface debugging output [2-106](#)

- limiting output for debugging standby state changes [2-107](#)

- shortcut to the debug condition interface [2-114](#)

debugging

- activity monitoring [2-120](#)

- DHCP snooping events [2-116](#)

- DHCP snooping packets [2-117](#)

- IPC activities [2-115](#)

- IP DHCP snooping security packets [2-118](#)

- NVRAM activities [2-122](#)

- PAgP activities [2-123](#)

- PAgP shim [2-112](#)

- PM activities [2-126](#)

- PPPoE Intermediate Agent [2-128](#)

- spanning tree BackboneFast events [2-133](#)

- spanning tree switch shim [2-134](#)

- spanning tree UplinkFast events [2-136](#)

- VLAN manager activities [2-137](#)

- VLAN manager IOS file system error tests [2-138](#)

- VTP protocol debug messages [2-141](#)

- debug nmsp command [2-121](#)

- debug spanning tree switch [2-134](#)

- debug sw-vlan vtp [2-141](#)

- default CoS value [2-439](#)

- default form of a command, using [1-6](#)

- defining egress DSCP-to-CoS mapping [2-446](#)

DHCP

- clearing database statistics [2-80](#)

DHCP bindings

- configuring bindings [2-238](#)

- deny ARP packet based on matches [2-146](#)

- permit ARP packet based on matches [2-375](#)

DHCP snooping

- clearing binding entries [2-77](#)
- clearing database [2-79](#)
- displaying binding table [2-593](#)
- displaying configuration information [2-591](#)
- displaying status of DHCP database [2-596](#)
- displaying status of error detection [2-544](#)
- enabling DHCP globally [2-237](#)
- enabling IP source guard [2-279](#)
- enabling on a VLAN [2-247](#)
- enabling option 82 [2-242, 2-244](#)
- enabling option-82 [2-249](#)
- enabling rate limiting on an interface [2-245](#)
- enabling trust on an interface [2-246](#)
- establishing binding configuration [2-238](#)
- renew binding database [2-465](#)
- store generated bindings [2-240](#)
- diagnostic fpga soft-error recover command [2-156](#)
- diagnostic test
 - bootup packet memory [2-527](#)
 - displaying attributes [2-521](#)
 - display module-based results [2-523](#)
 - running [2-158](#)
 - show results for TDR [2-509](#)
- displaying error disable recovery [2-545](#)
- displaying inline power status [2-707](#)
- displaying monitoring activity [2-120](#)
- displaying PoE policing and monitoring status [2-715](#)
- displaying SEEPROM information
 - GBIC [2-555](#)
- displaying SPAN session information [2-750, 2-820](#)
- document conventions [1-xx](#)
- document organization [1-xix](#)
- DoS
 - CoPP
 - attaching policy map to control plane [2-473](#)
 - displaying policy-map class information [2-692](#)
 - entering configuration mode [2-99](#)
 - removing service policy from control plane [2-473](#)
 - entering

- CoPP configuration mode [2-99](#)
- DOS attack
 - protecting system's resources [2-223](#)
- drop threshold, Layer 2 protocol tunneling [2-309](#)
- DSCP rewrite for IP packets
 - enable [2-450](#)
- dual-capable port
 - selecting a connector [2-357](#)
- duplex mode
 - configuring autonegotiation on an interface [2-182](#)
 - configuring full duplex on an interface [2-182](#)
 - configuring half duplex on an interface [2-182](#)
- dynamic ARP inspection
 - preventing [2-223](#)
- Dynamic Buffer Limiting
 - See DBL
- Dynamic Host Configuration Protocol
 - See DHCP

E

- EAP
 - restarting authentication process [2-173](#)
- EDCS-587028 [2-500, 2-657](#)
- EIGRP (Enhanced IGRP)
 - filters
 - routing updates, preventing [2-372](#)
- enabling
 - debugging for UDLD [2-142](#)
 - voice VLANs [2-833](#)
- enabling open access [2-31](#)
- EnergyWise
 - display power information through queries [2-191](#)
 - display setting, status of entity and PoE ports [2-537](#)
 - on an entity
 - enable, assign to domain, and set password [2-189](#)
 - on an entity, enable and configure [2-184](#)
 - on a PoE port
 - configuring on PoE port [2-186](#)

energywise (global configuration) command [2-184, 2-186](#)

energywise domain command [2-189](#)

EnergyWise neighbor table, deleting [2-69](#)

energywise query command [2-191](#)

environmental

alarms [2-541](#)

displaying information [2-541](#)

status [2-541](#)

temperature [2-541](#)

erase a file [2-195](#)

error disable detection

clearing error disable on an interface [2-70](#)

enabling error disable detection [2-70, 2-198](#)

enabling per-VLAN on BPDU guard [2-198](#)

error-disabled state

displaying [2-574](#)

error disable recovery

configuring recovery mechanism variables [2-200](#)

displaying recovery timer information [2-545](#)

enabling ARP inspection timeout [2-200](#)

specifying recovery cause [2-200](#)

EtherChannel

assigning interfaces to EtherChannel groups [2-58](#)

debugging EtherChannel [2-112](#)

debugging PAgP shim [2-112](#)

debugging spanning tree activities [2-131](#)

displaying information for a channel [2-547](#)

removing interfaces from EtherChannel groups [2-58](#)

EtherChannel guard

detecting STP misconfiguration [2-787](#)

Explicit Host Tracking

clearing the database [2-83](#)

enabling per-VLAN [2-261](#)

expressions

matching multiple expression occurrences [1-9](#)

multiple-character patterns [1-8](#)

multiplying pattern occurrence [1-11](#)

single-character patterns [1-7](#)

Extensible Authentication Protocol

See EAP

F

fallback profile, specifying [2-28](#)

field replaceable unit (FRU)

displaying status information [2-541](#)

filters

EIGRP

routing updates, preventing [2-372](#)

Flash memory file system

displaying file system information [2-506](#)

verifying checksum [2-887](#)

flow control

configuring a gigabit interface for pause frames [2-203](#)

displaying per-interface statistics for flow control [2-551](#)

G

GBIC

displaying SEEPROM information [2-555](#)

generic-error-message, setting for the switch [2-411](#)

Gigabit Ethernet interface

clearing the hardware logic [2-72](#)

Gigabit Ethernet uplink

selecting [2-211](#)

showing the mode [2-553, 2-554](#)

global configuration mode

using [1-5](#)

H

hardware module

resetting a module by toggling the power [2-208](#)

hardware statistics

disabling [2-206](#)

enabling [2-206](#)

hardware uplink

- selecting the mode [2-211](#)
- showing the mode [2-553, 2-554](#)
- helper addresses, IP [2-611](#)
- hot standby protocol
 - debugging [2-107](#)
 - disabling debugging [2-107](#)
 - limiting output [2-107](#)
- hw-module uplink mode shared-backplane command [2-209](#)

I

- identifier-string, setting for the switch [2-411](#)
- ID mapping, creating an ANCP client [2-16](#)
- IDPROMs
 - displaying SEEPROM information
 - chassis [2-555](#)
 - clock module [2-555](#)
 - fan trays [2-555](#)
 - module [2-555](#)
 - mux buffer [2-555](#)
 - power supplies [2-555](#)
 - supervisor engine [2-555](#)
- ifIndex persistence
 - clearing SNMP ifIndex commands [2-773](#)
 - compress SNMP ifIndex table format [2-780](#)
 - enabling globally [2-779](#)
- IGMP
 - applying filters for host joining on Layer 2 interfaces [2-251](#)
 - clearing IGMP group cache entries [2-81](#)
 - configuring frequency for IGMP host-query messages [2-254](#)
 - creating an IGMP profile [2-253](#)
 - displaying IGMP interface configuration information [2-598](#)
 - displaying profiles [2-600](#)
 - setting maximum group numbers [2-252](#)
- IGMP profiles
 - displaying [2-600](#)

- IGMP snooping
 - clearing the EHT database [2-83](#)
 - configuring a Layer 2 interface as a group member [2-267](#)
 - configuring a Layer 2 interface as a multicast router [2-265](#)
 - configuring a static VLAN interface [2-267](#)
 - displaying multicast information [2-607](#)
 - displaying VLAN information [2-601, 2-605, 2-608](#)
 - enabling [2-256](#)
 - enabling immediate-leave processing [2-263](#)
 - enabling on a VLAN [2-260](#)
 - enabling per-VLAN Explicit Host Tracking [2-261](#)
- informs
 - enabling [2-777](#)
- inline power
 - displaying inline power status [2-707](#)
- In Service Software Upgrade
 - See ISSU
- inspection log
 - clearing log buffer [2-75](#)
- interface
 - displaying suppressed multicast bytes [2-568](#)
- interface capabilities
 - displaying [2-564](#)
- interface configuration mode
 - summary [1-5](#)
- interface link
 - display cable disconnect time [2-571](#)
- interfaces
 - configuring dot1q tunnel ports [2-840](#)
 - creating an interface-range macro [2-145](#)
 - debugging output of interface related activities [2-106](#)
 - displaying description [2-570](#)
 - displaying error-disabled state [2-574](#)
 - displaying information when tunneling is enabled [2-651](#)
 - displaying status [2-570](#)
 - displaying traffic for a specific interface [2-561](#)
 - entering interface configuration mode [2-215](#)

- executing a command on multiple ports in a range [2-218](#)
 - selecting an interface to configure [2-215](#)
 - setting a CoS value for Layer 2 packets [2-308](#)
 - setting drop threshold for Layer 2 packets [2-309](#)
 - setting the interface type [2-840](#)
- interface speed
 - configuring interface speed [2-815](#)
- interface transceiver
 - displaying diagnostic data [2-578](#)
- internal VLAN allocation
 - configuring [2-901](#)
 - default setting [2-901](#)
 - displaying allocation information [2-763](#)
- Internet Group Management Protocol
 - See IGMP
- IP address of remote ANCP server, setting [2-17](#)
- IP ARP
 - applying ARP ACL to VLAN [2-221](#)
 - clearing inspection statistics [2-76](#)
 - clearing status of log buffer [2-75](#)
 - controlling packet logging [2-232](#)
 - enabling dynamic inspection [2-230](#)
 - limit rate of incoming requests [2-223](#)
 - set per-port config trust state [2-227](#)
 - showing status of dynamic ARP inspection [2-585](#)
 - showing status of log buffer [2-588](#)
- IPC
 - debugging IPC activities [2-115](#)
- IP DHCP Snooping
 - See DHCP snooping
- IP header validation
 - disabling [2-278](#)
 - enabling [2-278](#)
- IP interfaces
 - displaying usability status [2-610](#)
- IP multicast
 - displaying multicast routing table information [2-616](#)
- ip multicast multipath command [2-271](#)
- IP packets
 - enable DSCP rewrite [2-450](#)
- IP phone and standard desktop
 - enabling Cisco-recommended features [2-336](#)
- IP Port Security
 - enabling [2-279](#)
- IP source binding
 - adding or deleting [2-275](#)
 - displaying bindingstaggging [2-621](#)
- IP source guard
 - debugging messages [2-118](#)
 - displaying configuration and filters [2-622](#)
 - enabling on DHCP snooping [2-279](#)
- IPv6 MLD
 - configuring queries [2-285, 2-287](#)
 - configuring snooping
 - last-listener-query-intervals [2-287](#)
 - configuring snooping
 - listener-message-suppression [2-289](#)
 - configuring snooping robustness-variables [2-290](#)
 - configuring tcn topology change notifications [2-292](#)
 - counting snooping last-listener-queries [2-285](#)
 - displaying information [2-627](#)
 - displaying ports for a switch or VLAN [2-629](#)
 - displaying querier information [2-630](#)
 - enabling snooping [2-283](#)
 - enabling snooping on a VLAN [2-293](#)
- ISSU
 - canceling process [2-295](#)
 - configuring rollback timer [2-305](#)
 - displaying capability [2-632](#)
 - displaying client information [2-634](#)
 - displaying compatibility matrix [2-636](#)
 - displaying endpoint information [2-641](#)
 - displaying entities [2-642](#)
 - displaying FSM session [2-643](#)
 - displaying messages [2-644](#)
 - displaying negotiated [2-646](#)
 - displaying rollback-timer [2-647](#)

- displaying session information [2-648](#)
- displaying software version [2-649](#)
- displaying state [2-649](#)
- forcing switchover to standby supervisor engine [2-303](#)
- loading new image [2-299](#)
- starting process [2-301](#)
- stopping rollback timer [2-297](#)

J

Jumbo frames

- enabling jumbo frames [2-366](#)

L

LACP

- deselecting channeling protocol [2-60](#)
- enabling LACP on an interface [2-60](#)
- setting channeling protocol [2-60](#)

- lacp port-priority command [2-313](#)

- lacp system-priority command [2-314](#)

Layer 2

- displaying ACL configuration [2-660](#)

Layer 2 interface type

- specifying a nontrunking, nontagged single VLAN interface [2-840](#)
- specifying a trunking VLAN interface [2-840](#)

Layer 2 protocol ports

- displaying [2-651](#)

Layer 2 protocol tunneling error recovery [2-311](#)

Layer 2 switching

- enabling voice VLANs [2-833](#)
- modifying switching characteristics [2-833](#)

Layer 2 traceroute

- IP addresses [2-872](#)

Layer 3 switching

- displaying information about an adjacency table [2-496](#)

- displaying port status [2-576](#)

- displaying status of native VLAN tagging [2-576](#)

link-status event messages

disabling

- globally [2-316, 2-319](#)
- on an interface [2-317, 2-320](#)

enabling

- globally [2-316, 2-319](#)
- on an interface [2-317, 2-320](#)

- lldp run command [2-315](#)

log buffer

- show status [2-588](#)

logging

- controlling IP ARP packets [2-232](#)

M

- MAB, display information [2-657](#)

- MAB, enable and configure [2-322](#)

- mab command [2-322](#)

MAC Access Control Lists

- See MAC ACLs

MAC ACLs

- defining extended MAC access list [2-324](#)
- displaying MAC ACL information [2-760](#)
- naming an ACL [2-324](#)

MAC address filtering

- configuring [2-333](#)
- disabling [2-333](#)
- enabling [2-333](#)

MAC address table

- adding static entries [2-345](#)
- clearing dynamic entries [2-87, 2-89](#)
- configuring aging time [2-327](#)
- displaying dynamic table entry information [2-667](#)
- displaying entry count [2-665](#)
- displaying information [2-661](#)
- displaying interface-based information [2-669](#)
- displaying multicast information [2-671](#)

- displaying notification information [2-673](#)
- displaying protocol-based information [2-675](#)
- displaying static table entry information [2-677](#)
- displaying the MAC address aging time [2-663](#)
- displaying VLAN-based information [2-680](#)
- enabling authentication bypass [2-171](#)
- enabling notifications [2-331](#)
- learning in the protocol buckets [2-328](#)
- removing static entries [2-345](#)
- MAC address tables
 - adding static entries [2-333](#)
 - deleting secure or specific addresses [2-92](#)
 - disabling IGMP snooping on static MAC addresses [2-333](#)
 - removing static entries [2-333](#)
- mac-address-table static [2-333](#)
- MAC address unicast filtering
 - dropping unicast traffic [2-333](#)
- MAC authentication bypass (MAB), display information [2-657](#)
- MAC authorization bypass(MAB), enable and configure [2-322](#)
- macro
 - displaying descriptions [2-344](#)
- macro keywords
 - help strings [2-2](#)
- macros
 - adding a global description [2-344](#)
 - cisco global [2-342](#)
 - system-cpp [2-343](#)
- mapping secondary VLANs to MST instance [2-427](#)
- mapping VLAN(s) to an MST instance [2-213](#)
- match (class-map configuration) command [2-14](#), [2-148](#), [2-150](#), [2-152](#), [2-154](#), [2-348](#), [2-821](#), [2-823](#), [2-825](#), [2-827](#), [2-831](#)
- maximum transmission unit (MTU)
 - displaying the system MTU setting [2-751](#)
 - setting the maximum Layer 2 payload size [2-865](#)
- MFIB
 - clearing ip mfib counters [2-84](#)
 - clearing ip mfib fastdrop [2-85](#)
 - displaying all active MFIB routes [2-613](#)
 - displaying MFIB fastdrop table entries [2-615](#)
 - enabling IP MFIB fastdrops [2-270](#)
- MLD
 - configuring snooping
 - last-listener-query-intervals [2-287](#)
 - configuring snooping
 - listener-message-suppression [2-289](#)
 - configuring snooping robustness-variables [2-290](#)
 - configuring topology change notifications [2-292](#)
 - counting snooping last-listener-queries [2-285](#)
 - enabling snooping [2-283](#)
 - enabling snooping on a VLAN [2-293](#)
- MLD snooping
 - displaying [2-630](#)
- modes
 - access-group [2-6](#)
 - show access-group interface [2-408](#), [2-495](#), [2-718](#)
 - switching between PVST+, MST, and Rapid PVST [2-792](#)
 - See also command modes
- module password clearing [2-71](#)
- module reset
 - resetting a module by toggling the power [2-208](#)
- More-- prompt
 - filter [1-6](#)
 - search [1-7](#)
- MST
 - designating the primary and secondary root [2-801](#)
 - displaying MST protocol information [2-745](#)
 - displaying region configuration information [2-745](#)
 - displaying spanning tree information [2-745](#)
 - entering MST configuration submode [2-795](#)
 - setting configuration revision number [2-467](#)
 - setting path cost and port priority for instances [2-793](#)
 - setting the forward delay timer for all instances [2-797](#)
 - setting the hello-time delay timer for all instances [2-798](#)
 - setting the max-age timer for all instances [2-799](#)
 - setting the MST region name [2-367](#)

- specifying the maximum number of hops [2-800](#)
- switching between PVST+ and Rapid PVST [2-792](#)
- using the MST configuration submode revision command [2-467](#)
- using the submode name command [2-367](#)

MTU

- displaying global MTU settings [2-751](#)

multi-auth, setting [2-29](#)

Multicast Listener Discovery

See MLD

multicast

- counters [2-101](#)
- enabling storm control [2-820](#)
- show ancp [2-498](#)

multicast/unicast packets

- prevent forwarding [2-839](#)

Multicast Forwarding Information Base

See MFIB

multi-domain, setting [2-29](#)

multiple-character patterns [1-8](#)

Multiple Spanning Tree

See MST

N

native VLAN

- controlling tagging of traffic [2-860](#)
- displaying ports eligible for native tagging [2-762](#)
- displaying ports eligible for tagging [2-762](#)
- enabling tagging on 802.1Q trunk ports [2-898](#)

NetFlow

- enabling NetFlow statistics [2-273](#)
- including infer fields in routing statistics [2-273](#)

next-hop

- displaying CEF VLAN information [2-590](#)

nmosp attachment suppress command [2-369](#)

nmosp command [2-368](#)

no form of a command, using [1-6](#)

NVRAM

debugging NVRAM activities [2-122](#)

O

open access on a port, enabling [2-31](#)

output

pattern searches [1-7](#)

P

packet counters (statistics)

clear for PPPoE Intermediate Agent [2-94](#)

packet counters, display for PPPoE Intermediate Agent [2-716](#)

packet forwarding

prevent unknown packets [2-839](#)

packet memory failure

direct switch action upon detection [2-157](#)

packet memory test

- bootup, displaying results [2-527](#), [2-529](#)
- ongoing, displaying results [2-531](#)

PACL

access-group mode [2-6](#)

paging prompt

see --More-- prompt

PAgP

- clearing port channel information [2-91](#)
- debugging PAgP activity [2-123](#)
- deselecting channeling protocol [2-60](#)
- displaying port channel information [2-689](#)
- hot standby mode
 - returning to defaults [2-371](#)
 - selecting ports [2-371](#)
- input interface of incoming packets
 - learning [2-370](#)
 - returning to defaults [2-370](#)
 - setting channeling protocol [2-60](#)

parentheses [1-11](#)

password

- clearing on an intelligent line module [2-71](#)
- setting username [2-885](#)
- PBR
 - displaying route maps [1-xx](#)
 - redistributing route maps [1-xx](#)
- PM activities
 - debugging [2-126](#)
 - disabling debugging [2-126](#)
- PoE policing
 - configure on an interface [2-403](#)
- PoE policing and monitoring
 - displaying status [2-715](#)
- police (percent) command [2-382](#)
- police (two rates) command [2-384](#), [2-386](#)
- police command [2-377](#)
- policing, configure PoE [2-403](#)
- policing and monitoring status
 - displaying PoE [2-715](#)
- Policy Based Routing
 - See PBR
- policy maps
 - creating [2-390](#)
 - marking [2-477](#)
 - See also QoS, hierarchical policies
 - traffic classification
 - defining the class
 - defining trust states [2-875](#)
- port, dual-capable
 - selecting the connector [2-357](#)
- Port Aggregation Protocol
 - See PAgP
- port-based authentication
 - displaying debug messages [2-111](#)
 - displaying statistics and status [2-533](#)
 - enabling 802.1X [2-175](#)
 - host modes [2-168](#)
 - manual control of authorization state [2-175](#)
 - periodic re-authentication
 - enabling [2-178](#)
 - re-authenticating 802.1X-enabled ports [2-177](#)
 - switch-to-client frame-retransmission number [2-173](#)
- port channel
 - accessing [2-217](#)
 - creating [2-217](#)
 - displaying information [2-689](#)
 - load distribution method
 - resetting to defaults [2-392](#)
 - setting [2-392](#)
- port control, changing from unidirectional or bidirectional [2-23](#)
- port-control value, configuring [2-35](#)
- port range
 - executing [2-218](#)
- port security
 - debugging ports security [2-127](#)
 - deleting secure or specific addresses [2-92](#)
 - displaying settings for an interface or switch [2-700](#)
 - enabling [2-845](#)
 - filter source IP and MAC addresses [2-279](#)
 - setting the rate limit for bad packets [2-845](#)
 - sticky port [2-845](#)
- Port Trust Device
 - displaying [2-721](#)
- power status
 - displaying inline power [2-707](#)
 - displaying power status [2-707](#)
- power supply
 - configuring combined and redundant power on the Catalyst 4507R [2-394](#)
 - configuring inline power [2-399](#)
 - configuring power consumption [2-394](#)
 - displaying the SEEPROM [2-555](#)
 - setting inline power state [2-398](#)
- PPPoE Discovery
 - enable vendor-tag stripping on packetsPPPoE Server
 - enable vendor-tag stripping on Discovery packets [2-417](#)
- PPPoE Discovery packets, limit rate arriving on an interface [2-415](#)

PPPoE Intermediate Agent

clear statistics (packet counters) [2-94](#)

debugging [2-128](#)

pppoe intermediate-agent

enable intermediate agent on a switch [2-407](#)

enable on an interface VLAN range [2-410](#)

enable PPPoE Intermediate Agent on an interface [2-408](#)

enable vendor-tag stripping of Discovery packets [2-417](#)

format-type (global) [2-411](#)

limit rate of PPPoE Discovery packets [2-415](#)

set circuit-id or remote-id for an interface [2-413](#)

set circuit-id or remote-id for an interface VLAN range [2-414](#)

set trust configuration on an interface [2-415, 2-416](#)

PPPoE Intermediate Agent, display configuration and statistics (packet counters) [2-716](#)

priority command [2-418](#)

priority-queue command [2-102](#)

Private VLAN

See PVLANS

privileged EXEC mode, summary [1-5](#)

prompts

system [1-5](#)

protocol tunneling

configuring encapsulation rate [2-311](#)

disabling [2-306](#)

displaying port information [2-651](#)

enabling [2-306](#)

setting a CoS value for Layer 2 packets [2-308](#)

setting a drop threshold for Layer 2 packets [2-309](#)

PVLANS

configuring isolated, primary, and community PVLANS [2-420](#)

controlling tagging of native VLAN traffic [2-860](#)

disabling sticky-ARP [2-276](#)

displaying map information for VLAN SVIs [2-573](#)

displaying PVLAN information [2-765](#)

enabling interface configuration mode [2-840](#)

enabling sticky-ARP [2-276](#)

mapping VLANs to the same SVI [2-424](#)

specifying host ports [2-840](#)

specifying promiscuous ports [2-840](#)

Q

QoS

account Layer 2 encapsulation [2-432](#)

attaching a policy-map to an interface [2-468](#)

automatic configuration [2-42](#)

class maps

creating [2-65](#)

defining the match criteria [2-348](#)

clearing aggregate counters [2-95](#)

configuring auto [2-42](#)

defining a named aggregate policer [2-434](#)

defining default CoS value [2-439](#)

defining ingress CoS-to-DSCP mapping [2-444](#)

displaying aggregate policer information [2-719](#)

displaying auto configuration [2-505](#)

displaying class maps information [2-519](#)

displaying configuration information [2-505](#)

displaying configurations of policies [2-695](#)

displaying policy map information [2-691, 2-698](#)

displaying QoS information [2-718](#)

displaying QoS map information [2-723](#)

egress queue-sets

enabling the priority queue [2-102](#)

enabling global configuration mode [2-430](#)

enabling on control packets [2-437](#)

enabling per-VLAN QoS for a Layer 2 interface [2-453](#)

enabling QoS on an interface [2-431](#)

hierarchical policies

average-rate traffic shaping on a class [2-490](#)

bandwidth allocation for a class [2-46, 2-64](#)

creating a service policy [2-471](#)

marking [2-477](#)

- strict priority queueing (LLQ) [2-418](#)
- mapping DSCP values to transmit queues [2-446](#)
- mapping egress DSCP-to-CoS [2-446](#)
- mapping the DSCP-to-CoS value [2-446](#)
- policy maps
 - creating [2-390](#)
 - marking [2-477](#)
 - traffic classifications
 - trust states [2-875](#)
- setting the mapping of policed DSCP values [2-448](#)
- setting the trust state [2-451](#)
- specifying flow-based match criteria [2-351](#)
- Supervisor Engine 6-E
 - setting CoS [2-479](#)
 - setting DSCP [2-482](#)
 - setting precedence values [2-485](#)
 - setting QoS group identifiers [2-488](#)
- QoS CoS
 - configuring for tunneled Layer 2 protocol packets [2-308](#)
 - defining default CoS value [2-439](#)
- qos dbl [2-440](#)
- quality of service
 - See QoS
- question command [1-1](#)
- queueing information
 - displaying [2-721](#)
- queue limiting
 - configuring packet limits [2-455](#)

R

- Rapid PVST
 - switching between PVST and MST [2-792](#)
- re-authenticating 802.1X-enabled ports [2-177](#)
- re-authentication
 - periodic [2-178](#)
 - set the time [2-180](#)
- reauthentication, enabling [2-34](#)
- reboots
 - restoring bindings across [2-238](#)
- redundancy
 - accessing the main CPU [2-457](#)
 - changing from active to standby supervisor engine [2-461](#)
 - displaying information [2-725](#)
 - displaying ISSU config-sync failure information [2-729](#)
 - displaying redundancy facility information [2-725](#)
 - displaying RF client list [2-725](#)
 - displaying RF operational counters [2-725](#)
 - displaying RF states [2-725](#)
 - enabling automatic synchronization [2-45](#)
 - forcing switchover to standby supervisor engine [2-461](#)
 - mismatched command listing [2-459](#)
 - set the mode [2-358](#)
 - synchronizing the route processor configurations [2-345](#)
- related documentation [1-xix](#)
- remote-id, setting for an interface [2-413](#)
- remote-id, setting for an interface VLAN range [2-414](#)
- remote SPAN
 - See RSPAN
- renew commands
 - ip dhcp snooping database [2-465](#)
- resetting PVLAN trunk
 - setting switchport to trunk [2-840](#)
- retry failed authentication, configuring [2-26](#)
- rj45 connector, selecting the connector [2-357](#)
- ROM monitor mode
 - summary [1-6](#)
- Route Processor Redundancy
 - See redundancy
- router, set to become ANCP client [2-18](#)
- RPF
 - disabling IPv4 exists-only checks [2-281](#)
 - enabling IPv4 exists-only checks [2-281](#)
- RPR

set the redundancy mode [2-358](#)

RSPAN

converting VLAN to RSPAN VLAN [2-464](#)

displaying list [2-767](#)

S

saving configuration changes [1-11](#)

secure address, configuring [2-394](#)

secure ports, limitations [2-846](#)

server (AAA) alive actions, configuring [2-26](#)

server (AAA) dead actions, configuring [2-26](#)

service-policy command (policy-map class) [2-471](#)

session classification, defining [2-29](#)

set the redundancy mode [2-358](#)

sfp connector, selecting the connector [2-357](#)

shape command [2-490](#)

show ancp multicast [2-498](#)

show authentication interface command [2-500](#)

show authentication registration command [2-500](#)

show authentication sessions command [2-500](#)

show commands

filtering parameters [1-7](#)

searching and filtering [1-6](#)

show platform commands [1-11](#)

show energywise command [2-537](#)

show mab command [2-657](#)

show nmsp command [2-686](#)

Simple Network Management Protocol

See SNMP

single-character patterns

special characters [1-7](#)

single-host, setting [2-29](#)

slaveslot0

displaying information on the standby
supervisor [2-736](#)

slot0

displaying information about the system [2-738](#)

SNMP

debugging spanning tree activities [2-131](#)

ifIndex persistence

clearing SNMP ifIndex commands [2-773](#)

compress SNMP ifIndex table format [2-780](#)

enabling globally [2-779](#)

informs

enabling [2-777](#)

traps

configuring to send when storm occurs [2-818](#)

enabling [2-777](#)

mac-notification

adding [2-781](#)

removing [2-781](#)

snmp ifindex persist command [2-775](#)

SPAN commands

configuring a SPAN session to monitor [2-360](#)

displaying SPAN session information [2-750, 2-820](#)

SPAN enhancements

displaying status [2-684](#)

Spanning Tree Protocol

See STP

SPAN session

displaying session information [2-684](#)

filter ACLs [2-360](#)

specify encap type [2-360](#)

turn off host learning based on ingress packets [2-360](#)

special characters

anchoring, table [1-10](#)

SSO [2-358](#)

standard desktop

enabling Cisco-recommended features [2-334](#)

standard desktop and Cisco IP phone

enabling Cisco-recommended features [2-336](#)

sticky address, configuring [2-395](#)

sticky-ARP

disabling on PVLANS [2-276](#)

enabling on PVLANS [2-276](#)

sticky port

deleting [2-92](#)

- enabling security [2-845](#)
 - storm control
 - disabling suppression mode [2-544](#)
 - displaying settings [2-748](#)
 - enabling [2-818](#)
 - enabling broadcast [2-818, 2-820](#)
 - enabling multicast [2-818, 2-820](#)
 - enabling suppression mode [2-544](#)
 - enabling timer to recover from error disable [2-200](#)
 - enabling unicast [2-818, 2-820](#)
 - multicast, enabling [2-820](#)
 - setting high and low levels [2-818](#)
 - setting suppression level [2-544](#)
 - STP
 - configuring link type for a port [2-790](#)
 - configuring tunneling encapsulation rate [2-311](#)
 - debugging all activities [2-131](#)
 - debugging spanning tree activities [2-131](#)
 - debugging spanning tree BackboneFast events [2-133](#)
 - debugging spanning tree UplinkFast [2-136](#)
 - detecting misconfiguration [2-787](#)
 - displaying active interfaces only [2-740](#)
 - displaying BackboneFast status [2-740](#)
 - displaying bridge status and configuration [2-740](#)
 - displaying spanning tree debug messages [2-131](#)
 - displaying summary of interface information [2-740](#)
 - enabling BPDU filtering by default on all PortFast ports [2-806](#)
 - enabling BPDU filtering on an interface [2-783](#)
 - enabling BPDU guard by default on all PortFast ports [2-808](#)
 - enabling BPDU guard on an interface [2-785](#)
 - enabling extended system ID [2-788](#)
 - enabling loop guard as a default on all ports [2-791](#)
 - enabling PortFast by default on all access ports [2-809](#)
 - enabling PortFast mode [2-804](#)
 - enabling protocol tunneling for [2-306](#)
 - enabling root guard [2-789](#)
 - enabling spanning tree BackboneFast [2-782](#)
 - enabling spanning tree on a per VLAN basis [2-813](#)
 - enabling spanning tree UplinkFast [2-811](#)
 - setting an interface priority [2-810](#)
 - setting drop threshold for [2-309](#)
 - setting pathcost [2-786](#)
 - setting the default pathcost calculation method [2-803](#)
 - subinterface configuration mode, summary [1-6](#)
 - subscribe-to-alert-group inventory command [2-829](#)
 - SVI
 - creating a Layer 3 interface on a VLAN [2-220](#)
 - switching characteristics
 - excluding from link-up calculation [2-837](#)
 - modifying [2-837](#)
 - returning to interfaces
 - capture function [2-837](#)
 - switchport interfaces
 - displaying status of Layer 3 port [2-576](#)
 - displaying status of native VLAN tagging [2-576](#)
 - switchport private-vlan trunk allowed vlan command [2-857](#)
 - switchport trunk command [2-861](#)
 - switch shim
 - debugging [2-134](#)
 - disabling debugging [2-134](#)
 - switch to router connection
 - enabling Cisco-recommended features [2-338](#)
 - switch to switch connection
 - enabling Cisco-recommended features [2-340](#)
 - switch virtual interface
 - See SVI
 - sw-vlan [2-137](#)
 - system prompts [1-5](#)
-
- ## T
- Tab key
 - command completion [1-1](#)
 - tables
 - characters with special meaning [1-7](#)

- mac access-list extended subcommands [2-324](#)
- multipliers [1-9](#)
- relationship between duplex and speed commands [2-816](#)
- show cable-diagnostics tdr command output fields [2-510](#)
- show cdp neighbors detail field descriptions [2-518](#)
- show cdp neighbors field descriptions [2-517](#)
- show ip dhcp snooping command output [2-501, 2-657](#)
- show ip interface field descriptions [2-611](#)
- show policy-map control-plane field descriptions [2-694](#)
- show vlan command output fields [2-766](#)
- show vtp command output fields [2-771](#)
- special characters [1-9](#)
- special characters used for anchoring [1-10](#)
- speed command options [2-351, 2-816](#)
- valid interface types [2-215](#)

TAC

- displaying information useful to TAC [2-752](#)

TCAM

- debugging spanning tree activities [2-131](#)

TDR

- displaying cable diagnostic test results [2-509](#)
- test condition of copper cables [2-867](#)

temperature readings

- displaying information [2-541](#)

timer information [2-545](#)

traceroute mac command [2-869](#)

traffic monitor

- display status [2-657](#)

traffic shaping

- enable on an interface [2-492](#)

traps, enabling [2-777](#)

trunk interfaces

- displaying trunk interfaces information [2-583](#)

trust configuration, setting on an interface [2-415, 2-416](#)

trust state

- setting [2-227](#)

tunnel ports

- displaying information about Layer 2 protocol [2-651](#)

TX queues

- allocating bandwidth [2-877](#)
- returning to default values [2-877](#)
- setting priority to high [2-877](#)
- specifying traffic rate [2-877](#)

U

UDLD

- displaying administrative and operational status [2-754](#)
- enabling by default on all fiber interfaces [2-879](#)
- enabling on an individual interface [2-881](#)
- preventing a fiber interface from being enabled [2-881](#)
- resetting all shutdown ports [2-883](#)
- setting the message timer [2-879](#)

unicast

- counters [2-101](#)

Unidirectional Link Detection

- See UDLD

- unidirection port control, changing from bidirectional [2-23](#)

- unknown multicast traffic, preventing [2-839](#)

- unknown unicast traffic, preventing [2-839](#)

- user EXEC mode, summary [1-5](#)

username

- setting password and privilege level [2-885](#)

V

VACLs

- access-group mode [2-6](#)
- applying VLAN access maps [2-900](#)
- displaying VLAN access map information [2-760](#)
- specifying an action in a VLAN access map [2-13](#)
- specifying the match clause for a VLAN access-map sequence [2-346](#)
- using a VLAN filter [2-900](#)

VLAN

- applying an ARP ACL [2-221](#)
- configuring [2-889](#)
- configuring service policies [2-894](#)
- converting to RSPAN VLAN [2-464](#)
- displaying CEF information [2-590](#)
- displaying CEF next-hop information [2-590](#)
- displaying information on switch interfaces [2-601, 2-605](#)
- displaying information on VLAN switch interfaces [2-608](#)
- displaying information sorted by group IP address [2-601, 2-605](#)
- displaying IP address and version information [2-601, 2-605](#)
- displaying Layer 2 VLAN information [2-756](#)
- displaying statistical information [2-682](#)
- displaying VLAN information [2-758](#)
- enabling dynamic ARP inspection [2-230](#)
- enabling Explicit Host Tracking [2-261](#)
- enabling guest per-port [2-166](#)
- enabling guest VLAN supplicant [2-159, 2-167](#)
- entering VLAN configuration mode [2-894, 2-896](#)
- native frames
 - enabling tagging on all 802.1Q trunk ports [2-898](#)

VLAN Access Control Lists

See VACLs

VLAN access map

See VACLs

vlan access-map command [2-892](#)

VLAN database

- resetting [2-466](#)

VLAN debugging

- limiting output [2-109](#)

VLAN link-up calculation

- excluding a switch port [2-837](#)

VLAN manager

- debugging [2-137](#)
- disabling debugging [2-137](#)
- IOS file system error tests

- debugging [2-138](#)

- disabling debugging [2-138](#)

VLAN Query Protocol

See VQP

VLAN query protocol (VQPC)

- debugging [2-144](#)

VLANs

- clearing
 - counters [2-97](#)
- clearing hardware logic [2-73](#)
- configuring
 - internal allocation scheme [2-901](#)
- displaying
 - internal VLAN allocation information [2-763](#)
 - RSPAN VLANs [2-767](#)
- entering VLAN configuration mode [2-896](#)

VMPS

- configuring servers [2-905](#)
- reconfirming dynamic VLAN assignments [2-144, 2-903](#)

vmps reconfirm (privileged EXEC) command [2-903](#)

voice VLANs

- enabling [2-833](#)

VoIP

- configuring auto-QoS [2-42](#)

VQP

- per-server retry count [2-904](#)
- reconfirming dynamic VLAN assignments [2-144, 2-903](#)

VTP

- configuring the administrative domain name [2-909](#)
- configuring the device in VTP client mode [2-908](#)
- configuring the device in VTP server mode [2-912](#)
- configuring the device in VTP transparent mode [2-913](#)
- configuring tunnel encapsulation rate [2-311](#)
- creating a VTP domain password [2-910](#)
- displaying domain information [2-770](#)
- displaying statistics information [2-770](#)
- enabling protocol tunneling for [2-306](#)

enabling pruning in the VLAN database [2-911](#)

enabling VTP version 2 mode [2-914](#)

modifying the VTP configuration storage file
name [2-907](#)

set drop threshold for [2-309](#)

VTP protocol code

activating debug messages [2-141](#)

deactivating debug messages [2-141](#)

W

Webauth fallback, enabling [2-28](#)