



INDEX

Symbols

- \$ matches the end of a string [1-7](#)
- () in commands [1-11](#)
- * matches 0 or more sequences of a pattern [1-7](#)
- + matches 1 or more sequences of a pattern [1-7](#)
- . matches any single character [1-7](#)
- ? command [1-1](#)
- ? matches 0 or 1 occurrence of a pattern [1-7](#)
- ^ matches the beginning of a string [1-7](#)
- _ matches a comma (,), left brace ({), left parenthesis [1-7](#)
- “ [1-10](#)

Numerics

- 10-Gigabit Ethernet uplink
 - selecting [2-263](#)
 - showing the mode [2-667, 2-668](#)
- 802.1Q trunk ports and native VLANs [2-1063](#)
- 802.1Q tunnel ports
 - configuring [2-995](#)
- 802.1S Multiple Spanning Tree
 - see MST
- 802.1X
 - configuring for multiple hosts [2-207](#)
 - configuring for single host [2-207](#)
 - configuring multiple domains [2-207](#)
 - disabling port control [2-199](#)
 - enabling port control [2-199](#)
- 802.1X Critical Authentication
 - disabling on a port [2-201](#)
 - disabling on a VLAN [2-204](#)
- EAPOL

- disabling send success packets [2-202](#)
- enabling send success packets [2-202](#)
- enabling on a port [2-201](#)
- enabling on a VLAN [2-204](#)
- returning delay time to default setting [2-203](#)
- setting delay time on a port [2-203](#)
- 802.1X critical authentication
 - configure parameters [2-25](#)
- 802.1X critical recovery delay, configuring [2-25](#)
- 802.1X Port Based Authentication
 - debugging 802.1X Port Based Authentication [2-147](#)
 - displaying port based authentication [2-647](#)
 - enabling accounting for authentication sessions [2-4](#)
 - enabling authentication on the system [2-218](#)
 - enabling guest VLAN [2-205](#)
 - enabling guest VLAN supplicant [2-198, 2-206](#)
 - enabling manual control of auth state [2-214](#)
 - enabling periodic re-authentication of the client [2-217](#)
 - initializing re-authentication of dot1x ports [2-216](#)
 - initializing state machines [2-209](#)
 - receive session termination message upon reboot [2-5](#)
 - setting maximum number for EAP requests [2-212](#)
 - setting the reauthentication timer [2-219](#)

A

- aaa authorization network command [2-200](#)
- abbreviating commands
 - context-sensitive help [1-1](#)
- Access Gateway Module
 - connecting to a module [2-22](#)
 - connecting to a remote module [2-559](#)
 - connecting to a specific remote module [2-588](#)

- access-group
 - displaying mac interface [2-782](#)
 - show mode interface [2-524, 2-609, 2-862](#)
- access groups
 - IP [2-6, 2-194](#)
- access lists
 - clearing an access template [2-104](#)
 - defining ARP [2-21](#)
 - displaying ARP information [2-613](#)
 - See also ACLs, MAC ACLs, and VACLs
- access maps
 - applying with VLAN filter [2-1065](#)
- access-node-identifier, setting for the switch [2-527](#)
- access-policies, applying using host-mode [2-30](#)
- ACLs
 - access-group mode [2-6](#)
 - balancing hardware regions [2-12](#)
 - capturing control packets [2-8](#)
 - determining ACL hardware programming [2-10](#)
 - disabling hardware statistics [2-252](#)
 - displaying mac access-group interface [2-782](#)
 - enabling hardware statistics [2-252](#)
 - using ACL naming conventions for MAC ACLs [2-390](#)
- action clause
 - specifying drop or forward action in a VACL [2-13](#)
- addresses, configuring a maximum [2-508](#)
- adjacency
 - debugging the adjacency table [2-140](#)
 - disabling the debug facility [2-140](#)
 - displaying information about the adjacency table [2-610](#)
 - displaying IPC table entries [2-140](#)
- aggregate policer
 - displaying information [2-863](#)
- aging time
 - displaying MAC address aging time [2-785](#)
 - MAC address table [2-393](#)
- alarms
 - displaying operational status [2-655](#)
- alternation
 - description [1-10](#)
- anchoring
 - description [1-10](#)
- anycp, show multicast [2-612](#)
- ANCP client
 - port identifier [2-16](#)
 - remote server [2-17](#)
 - set router to become [2-18](#)
- ARP
 - access list, displaying detailed information [2-613](#)
 - defining access-lists [2-21](#)
- ARP inspection
 - enforce certain types of checking [2-283](#)
- ARP packet
 - deny based on DHCP bindings [2-182](#)
 - permit based on DHCP bindings [2-486](#)
- authentication [2-25, 2-32](#)
 - changing the control-direction [2-23](#)
 - configure actions for events
 - configuring the actions [2-26](#)
 - configuring port-control [2-36](#)
 - enabling reauthentication [2-35](#)
 - enabling Webauth fallback [2-29](#)
 - host-mode configuration [2-30](#)
 - setting priority of methods [2-38](#)
 - setting the timer [2-40](#)
 - setting username [2-1050](#)
 - specifying the order of methods [2-33](#)
 - using an MD5-type encryption method [2-1050](#)
 - verifying MD5 signature\$nopage>message digest 5
 - See MD5 [2-1052](#)
- authentication control-direction command [2-23](#)
- authentication critical recovery delay command [2-25](#)
- authentication event command [2-26](#)
- authentication fallback command [2-29](#)
- authentication host-mode [2-30](#)
- authentication methods, setting priority [2-38](#)

authentication methods, specifying the order of attempts [2-33](#)
 authentication open command [2-32](#)
 authentication order command [2-33](#)
 authentication periodic command [2-35](#)
 authentication port-control command [2-36](#)
 authentication priority command [2-38](#)
 authentication timer, setting [2-40](#)
 authentication timer command [2-40](#)
 authentication violation command [2-42](#)
 auth fail VLAN
 enable on a port [2-198](#)
 set max number of attempts [2-197](#)
 Auth Manager
 configuring
 authentication timer [2-40](#)
 authorization state
 enabling manual control [2-214](#)
 authorization state of a controlled port [2-214](#)
 automatic installation
 displaying status [2-618](#)
 automatic medium-dependent interface crossover
 See Auto-MDIX
 Auto-MDIX
 disabling [2-439](#)
 enabling [2-439](#)
 auto-negotiate interface speed
 example [2-971](#)
 auto-QoS
 configuring for VoIP [2-64](#)
 displaying configuration [2-619](#)
 auto qos srnd4 command [2-52](#)
 average-packet-size (netflow-lite monitor submode) command [2-73](#)

B

baby giants
 displaying the system MTU setting [2-897](#)

 setting the maximum Layer 2 payload size [2-1022](#)
 BackboneFast
 displaying debugging messages [2-169](#)
 displaying spanning tree status [2-886](#)
 enabling debugging [2-169](#)
 bandwidth command [2-75](#)
 bindings
 store for DHCP snooping [2-295](#)
 BOOT environment variable
 displaying information [2-622](#)
 bootflash
 displaying information [2-620](#)
 BPDUs
 debugging spanning tree activities [2-167](#)
 bridge protocol data units
 See BPDUs
 broadcast suppression level
 configuring [2-972, 2-974](#)
 enabling [2-972, 2-974](#)

C

cable diagnostics
 TDR
 displaying test results [2-623](#)
 testing conditions of copper cables [2-1026](#)
 call home
 displaying information [2-625](#)
 e-mailing output [2-83](#)
 entering configuration submode [2-78](#)
 executing [2-83](#)
 manually send test message [2-86](#)
 receiving information [2-81](#)
 sending alert group message [2-84](#)
 submitting information [2-81](#)
 call home destination profiles
 displaying [2-627](#)
 Catalyst 4507R [2-506](#)
 CDP

- configuring tunneling encapsulation rate [2-377](#)
 - displaying
 - neighbor information [2-630](#)
 - enabling protocol tunneling for [2-372](#)
 - set drop threshold for [2-375](#)
- CEF
 - displaying next-hop information [2-704](#)
 - displaying VLAN configuration information [2-704](#)
- chassis
 - displaying
 - chassis MAC address ranges [2-779](#)
 - current and peak traffic meter readings [2-779](#)
 - percentage of backplane utilization [2-779](#)
 - switching clock failure recovery mode [2-779](#)
- circuit-id
 - setting for an interface [2-529](#)
- circuit-id, setting for an interface VLAN range [2-530](#)
- cisco-desktop
 - macro apply [2-402](#)
- Cisco Express Forwarding
 - See CEF
- cisco-phone
 - macro apply [2-404](#)
- cisco-router
 - macro apply [2-406](#)
- cisco-switch
 - macro apply [2-408](#)
- CISP
 - See Client Information Signalling Protocol
- cisp enable command [2-91](#)
- class maps
 - creating [2-95](#)
 - defining the match criteria [2-432](#)
- monitor capture [2-445](#)
- clear commands
 - clearing Gigabit Ethernet interfaces [2-102](#)
 - clearing IGMP group cache entries [2-111](#)
 - clearing interface counters [2-97](#)
 - clearing IP access lists [2-104, 2-105](#)
 - clearing IP ARP inspection statistics VLAN [2-106](#)
 - clearing IP DHCP snooping database statistics [2-110](#)
 - clearing MFIB counters and routes [2-114](#)
 - clearing MFIB fastdrop entries [2-115](#)
 - clearing PAgP channel information [2-124](#)
 - clearing QoS aggregate counters [2-128](#)
 - clearing VLAN interfaces [2-103](#)
- clear energywise neighbors command [2-99](#)
- clear ip wccp command [2-116](#)
- clear netflow-lite exporter statistics command [2-121](#)
- clear netflow-lite monitor statistics interface command [2-122](#)
- clear nmsp statistics command [2-123](#)
- Client Information Signalling Protocol [2-200](#)
- Client Information Signalling Protocol, enabling [2-91](#)
- CLI string search
 - anchoring [1-10](#)
 - expressions [1-7](#)
 - filtering [1-6](#)
 - multiple-character patterns [1-8](#)
 - multipliers [1-9](#)
 - parentheses for recall [1-11](#)
 - searching outputs [1-6](#)
 - single-character patterns [1-7](#)
 - using [1-6](#)
- command [2-445](#)
- command modes
 - accessing privileged EXEC mode [1-5](#)
 - exiting [1-5](#)
 - understanding user EXEC and configuration modes [1-5](#)
- condition interface
 - debugging interface-related activities [2-142](#)
- condition vlan
 - debugging VLAN output [2-145](#)
- configuration, saving [1-11](#)
- configuring
 - root as secondary [2-955](#)
- configuring a SPAN session to monitor

- limit SPAN source traffic [2-458](#)
- configuring critical recovery [2-25](#)
- configuring forward delay [2-951](#)
- configuring root as primary [2-955](#)
- CoPP
 - attaching
 - policy map to control plane [2-586](#)
 - displaying
 - policy-map class information [2-836](#)
 - entering configuration mode [2-132](#)
 - removing
 - service policy from control plane [2-586](#)
- CoS
 - assigning to Layer 2 protocol packets [2-374](#)
- cos (netflow-lite exporter submode) command [2-134](#)
- counter command [2-136](#)
- counters
 - clearing interface counters [2-97](#)
- critical authentication, configure 802.1X parameters [2-25](#)
- critical recovery, configuring 802.1X parameter [2-25](#)

D

- DAI
 - clear statistics [2-106](#)
- DBL
 - displaying qos dbl [2-864](#)
- debug commands
 - debugging backup events [2-141](#)
 - debugging DHCP snooping events [2-152](#)
 - debugging DHCP snooping messages [2-153](#)
 - debugging EtherChannel/PAgP/shim [2-148](#)
 - debugging IPC activity [2-151](#)
 - debugging IP DHCP snooping security messages [2-154](#)
 - debugging NVRAM activities [2-158](#)
 - debugging PAgP activities [2-159](#)
 - debugging port manager activities [2-162](#)
 - debugging spanning tree activities [2-167](#)
 - debugging spanning tree backbonefast [2-169](#)
 - debugging spanning tree UplinkFast [2-172](#)
 - debugging supervisor redundancy [2-166](#)
 - debugging VLAN manager activities [2-173](#)
 - displaying monitor activity [2-156](#)
 - displaying the adjacency table [2-140](#)
 - enabling debug dot1x [2-147](#)
 - enabling debugging messages for ISL VLAN IDs [2-176](#)
 - enabling debugging messages for VTP [2-177](#)
 - enabling debugging of UDLD activity [2-178](#)
 - enabling switch shim debugging [2-170](#)
 - enabling VLAN manager file system error tests [2-174](#)
 - limiting debugging output for VLANs [2-145](#)
 - limiting interface debugging output [2-142](#)
 - limiting output for debugging standby state changes [2-143](#)
 - shortcut to the debug condition interface [2-150](#)
- debugging
 - activity monitoring [2-156](#)
 - DHCP snooping events [2-152](#)
 - DHCP snooping packets [2-153](#)
 - IPC activities [2-151](#)
 - IP DHCP snooping security packets [2-154](#)
 - NVRAM activities [2-158](#)
 - PAgP activities [2-159](#)
 - PAgP shim [2-148](#)
 - PM activities [2-162](#)
 - PPPoE Intermediate Agent [2-164](#)
 - spanning tree BackboneFast events [2-169](#)
 - spanning tree switch shim [2-170](#)
 - spanning tree UplinkFast events [2-172](#)
 - VLAN manager activities [2-173](#)
 - VLAN manager IOS file system error tests [2-174](#)
 - VTP protocol debug messages [2-177](#)
- debug nmsp command [2-157](#)
- debug spanning tree switch [2-170](#)
- debug sw-vlan vtp [2-177](#)
- default form of a command, using [1-6](#)

destination (netflow-lite exporter submode)
command [2-184](#)

DHCP

clearing database statistics [2-110](#)

DHCP bindings

configuring bindings [2-293](#)
deny ARP packet based on matches [2-182](#)
permit ARP packet based on matches [2-486](#)

DHCP snooping

clearing binding entries [2-107](#)
clearing database [2-109](#)
displaying binding table [2-707](#)
displaying configuration information [2-705](#)
displaying status of DHCP database [2-710](#)
displaying status of error detection [2-658](#)
enabling DHCP globally [2-292](#)
enabling IP source guard [2-334](#)
enabling on a VLAN [2-302](#)
enabling option 82 [2-297, 2-299](#)
enabling option-82 [2-304](#)
enabling rate limiting on an interface [2-300](#)
enabling trust on an interface [2-301](#)
establishing binding configuration [2-293](#)
renew binding database [2-561](#)
store generated bindings [2-295](#)

diagnostic fpga soft-error recover command [2-194](#)

diagnostic test

bootup packet memory [2-641](#)
displaying attributes [2-635](#)
display module-based results [2-637](#)
running [2-196](#)
show results for TDR [2-623](#)

displaying error disable recovery [2-659](#)

displaying inline power status [2-851](#)

displaying monitoring activity [2-156](#)

displaying PoE policing and monitoring status [2-859](#)

displaying SEEPROM information

GBIC [2-669](#)

displaying SPAN session information [2-897, 2-974](#)

document conventions [1-xxiv](#)

document organization [1-xxiii](#)

DoS

CoPP

attaching policy map to control plane [2-586](#)
displaying policy-map class information [2-836](#)
entering configuration mode [2-132](#)
removing service policy from control plane [2-586](#)

entering

CoPP configuration mode [2-132](#)

DOS attack

protecting system's resources [2-278](#)

dot1x credentials (global configuration) command [2-200](#)

drop threshold, Layer 2 protocol tunneling [2-375](#)

dscp (netflow-lite exporter submode command [2-221](#)

DSCP rewrite for IP packets

enable [2-549](#)

dual-capable port

selecting a connector [2-441](#)

duplex mode

configuring autonegotiation on an interface [2-223](#)
configuring full duplex on an interface [2-223](#)
configuring half duplex on an interface [2-223](#)

dynamic ARP inspection

preventing [2-278](#)

Dynamic Host Configuration Protocol

See DHCP

E

EAP

restarting authentication process [2-212](#)

EDCS-587028 [2-614, 2-779](#)

EIGRP (Enhanced IGRP)

filters

routing updates, preventing [2-483](#)

enabling

debugging for UDLD [2-178](#)

voice VLANs [2-988](#)

enabling open access [2-32](#)

EnergyWise

display power information through queries [2-232](#)

display setting, status of entity and PoE ports [2-651](#)

on an entity

enable, assign to domain, and set password [2-230](#)

on an entity, enable and configure [2-225](#)

on a PoE port

configuring on PoE port [2-227](#)

energywise (global configuration) command [2-225, 2-227](#)

energywise domain command [2-230](#)

EnergyWise neighbor table, deleting [2-99](#)

energywise query command [2-232](#)

environmental

alarms [2-655](#)

displaying information [2-655](#)

status [2-655](#)

temperature [2-655](#)

epm access control command [2-236](#)

erase a file [2-237](#)

error disable detection

clearing error disable on an interface [2-100](#)

enabling error disable detection [2-100, 2-240](#)

enabling per-VLAN on BPDU guard [2-240](#)

error-disabled state

displaying [2-688](#)

error disable recovery

configuring recovery mechanism variables [2-242](#)

displaying recovery timer information [2-659](#)

enabling ARP inspection timeout [2-242](#)

specifying recovery cause [2-242](#)

EtherChannel

assigning interfaces to EtherChannel groups [2-87](#)

debugging EtherChannel [2-148](#)

debugging PAgP shim [2-148](#)

debugging spanning tree activities [2-167](#)

displaying information for a channel [2-661](#)

removing interfaces from EtherChannel groups [2-87](#)

EtherChannel guard

detecting STP misconfiguration [2-941](#)

Explicit Host Tracking

clearing the database [2-113](#)

enabling per-VLAN [2-316](#)

exporter (netflow-lite monitor submode) command [2-247](#)

expressions

matching multiple expression occurrences [1-9](#)

multiple-character patterns [1-8](#)

multiplying pattern occurrence [1-11](#)

single-character patterns [1-7](#)

Extensible Authentication Protocol

See EAP

F

fallback profile, specifying [2-29](#)

field replaceable unit (FRU)

displaying status information [2-655](#)

filters

EIGRP

routing updates, preventing [2-483](#)

Flash memory file system

displaying file system information [2-620](#)

verifying checksum [2-1052](#)

flow control

configuring a gigabit interface for pause frames [2-249](#)

displaying per-interface statistics for flow control [2-665](#)

G

GBIC

displaying SEEPROM information [2-669](#)

generic-error-message, setting for the switch [2-527](#)

Gigabit Ethernet interface

clearing the hardware logic [2-102](#)

Gigabit Ethernet uplink

selecting [2-263](#)

showing the mode [2-667, 2-668](#)

global configuration mode

using [1-5](#)

H

hardware module

resetting a module by toggling the power [2-259](#)

hardware statistics

disabling [2-252](#)

enabling [2-252](#)

hardware uplink

selecting the mode [2-263](#)

showing the mode [2-667, 2-668](#)

helper addresses, IP [2-725](#)

hot standby protocol

debugging [2-143](#)

disabling debugging [2-143](#)

limiting output [2-143](#)

hw-module beacon command [2-253](#)

hw-module module start command [2-254](#)

hw-module module stop command [2-256](#)

hw-module uplink mode command [2-261](#)

I

identifier-string, setting for the switch [2-527](#)

ID mapping, creating an ANCP client [2-16](#)

IDPROMs

displaying SEEPROM information

chassis [2-669](#)

clock module [2-669](#)

fan trays [2-669](#)

module [2-669](#)

mux buffer [2-669](#)

power supplies [2-669](#)

supervisor engine [2-669](#)

ifindex persist, snmp [2-925](#)

ifIndex persistence

compress SNMP ifIndex table format [2-930](#)

enabling globally [2-929](#)

IGMP

applying filters for host joining on Layer 2 interfaces [2-306](#)

clearing IGMP group cache entries [2-111](#)

configuring frequency for IGMP host-query messages [2-309](#)

creating an IGMP profile [2-308](#)

displaying IGMP interface configuration information [2-712](#)

displaying profiles [2-714](#)

setting maximum group numbers [2-307](#)

IGMP profiles

displaying [2-714](#)

IGMP snooping

clearing the EHT database [2-113](#)

configuring a Layer 2 interface as a group member [2-322](#)

configuring a Layer 2 interface as a multicast router [2-320](#)

configuring a static VLAN interface [2-322](#)

displaying multicast information [2-721](#)

displaying VLAN information [2-715, 2-719, 2-722](#)

enabling [2-311](#)

enabling immediate-leave processing [2-318](#)

enabling on a VLAN [2-315](#)

enabling per-VLAN Explicit Host Tracking [2-316](#)

informs

enabling [2-927](#)

inline power

displaying inline power status [2-851](#)

In Service Software Upgrade

See ISSU

inspection log

clearing log buffer [2-105](#)

interface

displaying suppressed multicast bytes [2-682](#)

interface capabilities

displaying [2-678](#)

- interface configuration mode
 - summary [1-5](#)
- interface link
 - display cable disconnect time [2-685](#)
- interfaces
 - configuring dot1q tunnel ports [2-995](#)
 - creating an interface-range macro [2-181](#)
 - debugging output of interface related activities [2-142](#)
 - displaying description [2-684](#)
 - displaying error-disabled state [2-688](#)
 - displaying information when tunneling is enabled [2-773](#)
 - displaying status [2-684](#)
 - displaying traffic for a specific interface [2-675](#)
 - entering interface configuration mode [2-269](#)
 - executing a command on multiple ports in a range [2-272](#)
 - selecting an interface to configure [2-269](#)
 - setting a CoS value for Layer 2 packets [2-374](#)
 - setting drop threshold for Layer 2 packets [2-375](#)
 - setting the interface type [2-995](#)
- interface speed
 - configuring interface speed [2-969](#)
- interface transceiver
 - displaying diagnostic data [2-692](#)
- internal VLAN allocation
 - configuring [2-1068](#)
 - displaying allocation information [2-911](#)
- Internet Group Management Protocol
 - See IGMP
- IP address of remote ANCP server, setting [2-17](#)
- IP ARP
 - applying ARP ACL to VLAN [2-276](#)
 - clearing inspection statistics [2-106](#)
 - clearing status of log buffer [2-105](#)
 - controlling packet logging [2-287](#)
 - enabling dynamic inspection [2-285](#)
 - limit rate of incoming requests [2-278](#)
 - set per-port config trust state [2-282](#)
 - showing status of dynamic ARP inspection [2-699](#)
 - showing status of log buffer [2-702](#)
- IPC
 - debugging IPC activities [2-151](#)
- IP DHCP Snooping
 - See DHCP snooping
- IP header validation
 - disabling [2-333](#)
 - enabling [2-333](#)
- IP interfaces
 - displaying usability status [2-724](#)
- IP multicast
 - displaying multicast routing table information [2-730](#)
- ip multicast multipath command [2-326](#)
- IP packets
 - enable DSCP rewrite [2-549](#)
- IP phone and standard desktop
 - enabling Cisco-recommended features [2-404](#)
- IP Port Security
 - enabling [2-334](#)
- IP source binding
 - adding or deleting [2-330](#)
 - displaying bindingstaggering [2-735](#)
- IP source guard
 - debugging messages [2-154](#)
 - displaying configuration and filters [2-736](#)
 - enabling on DHCP snooping [2-334](#)
- IPv4 statistics, enabling collection [2-136](#)
- IPv6 MLD
 - configuring queries [2-351](#), [2-353](#)
 - configuring snooping
 - last-listener-query-intervals [2-353](#)
 - configuring snooping
 - listener-message-suppression [2-355](#)
 - configuring snooping robustness-variables [2-356](#)
 - configuring ten topology change notifications [2-358](#)
 - counting snooping last-listener-queries [2-351](#)
 - displaying information [2-749](#)
 - displaying ports for a switch or VLAN [2-751](#)

displaying querier information [2-752](#)
 enabling snooping [2-349](#)
 enabling snooping on a VLAN [2-359](#)
 IPv6 statistics, enabling collection [2-136](#)
 ip wccp check services all command [2-341](#)
 ip wccp command [2-338](#)
 ip wccp group-address command [2-338](#)
 ip wccp group-list command [2-338](#)
 ip wccp group-listen command [2-343](#)
 ip wccp password command [2-338, 2-340](#)
 ip wccp redirect command [2-345](#)
 ip wccp redirect exclude in command [2-347](#)
 ip wccp redirect-list command [2-338](#)
 ISSU
 canceling process [2-361](#)
 configuring rollback timer [2-371](#)
 displaying capability [2-754](#)
 displaying client information [2-756](#)
 displaying compatibility matrix [2-758](#)
 displaying endpoint information [2-763](#)
 displaying entities [2-764](#)
 displaying FSM session [2-765](#)
 displaying messages [2-766](#)
 displaying negotiated [2-768](#)
 displaying rollback-timer [2-769](#)
 displaying session information [2-770](#)
 displaying software version [2-771](#)
 displaying state [2-771](#)
 forcing switchover to standby supervisor engine [2-369](#)
 loading new image [2-365](#)
 starting process [2-367](#)
 stopping rollback timer [2-363](#)

J

Jumbo frames
 enabling jumbo frames [2-463](#)

L

LACP

 deselecting channeling protocol [2-89](#)
 enabling LACP on an interface [2-89](#)
 setting channeling protocol [2-89](#)

lacp port-priority command [2-379](#)

lacp system-priority command [2-380](#)

Layer 2

 displaying ACL configuration [2-782](#)

Layer 2 interface type

 specifying a nontrunking, nontagged single VLAN interface [2-995](#)

Layer 2 protocol ports

 displaying [2-773](#)

Layer 2 protocol tunneling error recovery [2-377](#)

Layer 2 switching

 enabling voice VLANs [2-988](#)
 modifying switching characteristics [2-988](#)

Layer 2 traceroute

 IP addresses [2-1031](#)

Layer 3 interface, assign counters [2-136](#)

Layer 3 switching

 displaying information about an adjacency table [2-610](#)
 displaying port status [2-690](#)
 displaying status of native VLAN tagging [2-690](#)

link-status event messages

 disabling
 globally [2-382, 2-385](#)
 on an interface [2-383, 2-386](#)
 enabling
 globally [2-382, 2-385](#)
 on an interface [2-383, 2-386](#)

LLDP

 enabling power negotiation [2-381](#)

lldp tlv-select power-management command [2-381](#)

log buffer

 show status [2-702](#)

logging

- controlling IP ARP packets [2-287](#)

M

MAB, display information [2-779](#)

MAB, enable and configure [2-388](#)

mab command [2-388](#)

MAC Access Control Lists

- See MAC ACLs

MAC ACLs

- defining extended MAC access list [2-390](#)

- displaying MAC ACL information [2-907](#)

- naming an ACL [2-390](#)

MAC addresses

- disabling MAC address learning per VLAN [2-397](#)

- displaying

- notification settings [2-236, 2-748, 2-793](#)

MAC address filtering

- configuring [2-401](#)

- disabling [2-401](#)

- enabling [2-401](#)

MAC address learning on a VLAN, enabling [2-397](#)

MAC address table

- adding static entries [2-429](#)

- clearing dynamic entries [2-118, 2-120](#)

- configuring aging time [2-393](#)

- displaying dynamic table entry information [2-789](#)

- displaying entry count [2-787](#)

- displaying information [2-783](#)

- displaying interface-based information [2-791](#)

- displaying multicast information [2-794](#)

- displaying notification information [2-796](#)

- displaying protocol-based information [2-798](#)

- displaying static table entry information [2-800](#)

- displaying the MAC address aging time [2-785](#)

- displaying VLAN-based information [2-803](#)

- enabling authentication bypass [2-210](#)

- enabling notifications [2-399](#)

- learning in the protocol buckets [2-394](#)

- removing static entries [2-429](#)

mac address-table learning vlan command [2-397](#)

MAC address tables

- adding static entries [2-401](#)

- deleting secure or specific addresses [2-125](#)

- disabling IGMP snooping on static MAC addresses [2-401](#)

- removing static entries [2-401](#)

mac-address-table static [2-401](#)

MAC address unicast filtering

- dropping unicast traffic [2-401](#)

MAC authentication bypass (MAB), display information [2-779](#)

MAC authorization bypass(MAB), enable and configure [2-388](#)

macro

- displaying descriptions [2-428](#)

macro auto global processing command [2-410, 2-412, 2-415, 2-417, 2-419, 2-421, 2-423, 2-425, 2-805](#)

macro auto monitor command [2-422](#)

macro keywords

- help strings [2-2](#)

macros

- adding a global description [2-428](#)

- cisco global [2-426](#)

- system-cpp [2-427](#)

mapping secondary VLANs to MST instance [2-543](#)

mapping VLAN(s) to an MST instance [2-267](#)

match (class-map configuration) command [2-14, 2-186, 2-188, 2-190, 2-192, 2-432, 2-976, 2-978, 2-980, 2-982, 2-986](#)

maximum transmission unit (MTU)

- displaying the system MTU setting [2-897](#)

- setting the maximum Layer 2 payload size [2-1022](#)

MFIB

- clearing ip mfib counters [2-114](#)

- clearing ip mfib fastdrop [2-115](#)

- displaying all active MFIB routes [2-727](#)

- displaying MFIB fastdrop table entries [2-729](#)

- enabling IP MFIB fastdrops [2-325](#)

MLD

- configuring snooping
- last-listener-query-intervals [2-353](#)
- configuring snooping
- listener-message-suppression [2-355](#)
- configuring snooping robustness-variables [2-356](#)
- configuring topology change notifications [2-358](#)
- counting snooping last-listener-queries [2-351](#)
- enabling snooping [2-349](#)
- enabling snooping on a VLAN [2-359](#)

MLD snooping

- displaying [2-752](#)

modes

- access-group [2-6](#)
- show access-group interface [2-524](#), [2-609](#), [2-862](#)
- switching between PVST+, MST, and Rapid PVST [2-946](#)
- See also command modes

module password clearing [2-101](#)

module reset

- resetting a module by toggling the power [2-259](#)

monitor capture {access-list | class-map} command [2-444](#)monitor capture mycap match command [2-451](#)monitor capture start command [2-453](#)

--More-- prompt

- filter [1-6](#)
- search [1-7](#)

MST

- designating the primary and secondary root [2-955](#)
- displaying MST protocol information [2-891](#)
- displaying region configuration information [2-891](#)
- displaying spanning tree information [2-891](#)
- entering MST configuration submode [2-949](#)
- setting configuration revision number [2-578](#)
- setting path cost and port priority for instances [2-947](#)
- setting the forward delay timer for all instances [2-951](#)
- setting the hello-time delay timer for all instances [2-952](#)
- setting the max-age timer for all instances [2-953](#)
- setting the MST region name [2-464](#)

specifying the maximum number of hops [2-954](#)

switching between PVST+ and Rapid PVST [2-946](#)

using the MST configuration submode revision command [2-578](#)

using the submode name command [2-464](#)

MTU

displaying global MTU settings [2-897](#)

multi-auth, setting [2-30](#)

Multicast Listener Discovery

See MLD

multicast

enabling storm control [2-974](#)

show ancp [2-612](#)

multicast/unicast packets

prevent forwarding [2-994](#)

Multicast Forwarding Information Base

See MFIB

multi-domain, setting [2-30](#)

multiple-character patterns [1-8](#)

Multiple Spanning Tree

See MST

N

native VLAN

controlling tagging of traffic [2-1015](#)

displaying ports eligible for native tagging [2-909](#)

displaying ports eligible for tagging [2-909](#)

enabling tagging on 802.1Q trunk ports [2-1063](#)

NetFlow

enabling NetFlow statistics [2-328](#)

including infer fields in routing statistics [2-328](#)

netflow-lite exporter command [2-465](#)

netflow-lite monitor command [2-467](#)

netflow-lite sampler command [2-469](#)

next-hop

displaying CEF VLAN information [2-704](#)

nmosp attachment suppress command [2-472](#)

nmosp command [2-471](#)

no form of a command, using [1-6](#)

NVRAM

debugging NVRAM activities [2-158](#)

O

open access on a port, enabling [2-32](#)

options timeout (netflow-lite exporter submode)
command [2-245, 2-473](#)

output

pattern searches [1-7](#)

P

packet counters (statistics)

clear for PPPoE Intermediate Agent [2-127](#)

packet counters, display for PPPoE Intermediate Agent [2-860](#)

packet forwarding

prevent unknown packets [2-994](#)

packet memory failure

direct switch action upon detection [2-195](#)

packet memory test

bootup, displaying results [2-641, 2-643](#)

ongoing, displaying results [2-645](#)

packet-offset (netflow-lite sampler submode)

command [2-475](#)

packet rate (netflow-lite sampler submode)

command [2-477](#)

packet-section size (netflow-lite sampler submode)

command [2-479](#)

PACL

access-group mode [2-6](#)

paging prompt

see --More-- prompt

PAgP

clearing port channel information [2-124](#)

debugging PAgP activity [2-159](#)

deselecting channeling protocol [2-89](#)

displaying port channel information [2-833](#)

hot standby mode

returning to defaults [2-482](#)

selecting ports [2-482](#)

input interface of incoming packets

learning [2-481](#)

returning to defaults [2-481](#)

setting channeling protocol [2-89](#)

parentheses [1-11](#)

password

clearing on an intelligent line module [2-101](#)

setting username [2-1050](#)

PBR

displaying route maps [1-xxiv](#)

redistributing route maps [1-xxiv](#)

PM activities

debugging [2-162](#)

disabling debugging [2-162](#)

PoE policing

configure on an interface [2-519](#)

PoE policing and monitoring

displaying status [2-859](#)

police (percent) command [2-493](#)

police (two rates) command [2-495, 2-497](#)

police command [2-488](#)

policing, configure PoE [2-519](#)

policing and monitoring status

displaying PoE [2-859](#)

Policy Based Routing

See PBR

policy maps

creating [2-501](#)

marking [2-590](#)

See also QoS, hierarchical policies

traffic classification

defining the class

defining trust states [2-1038](#)

port, dual-capable

selecting the connector [2-441](#)

Port Aggregation Protocol

- See PAgP
- port-based authentication
 - displaying debug messages [2-147](#)
 - displaying statistics and status [2-647](#)
 - enabling 802.1X [2-214](#)
 - host modes [2-207](#)
 - manual control of authorization state [2-214](#)
 - periodic re-authentication
 - enabling [2-217](#)
 - re-authenticating 802.1X-enabled ports [2-216](#)
 - switch-to-client frame-retransmission number [2-212](#)
- port channel
 - accessing [2-271](#)
 - creating [2-271](#)
 - displaying information [2-833](#)
 - load distribution method
 - resetting to defaults [2-503](#)
 - setting [2-503](#)
- port-channel standalone-disable command [2-505](#)
- port control, changing from unidirectional or bidirectional [2-23](#)
- port-control value, configuring [2-36](#)
- port range
 - executing [2-272](#)
- port security
 - debugging ports security [2-163](#)
 - deleting secure or specific addresses [2-125](#)
 - displaying settings for an interface or switch [2-844](#)
 - enabling [2-1000](#)
 - filter source IP and MAC addresses [2-334](#)
 - setting the rate limit for bad packets [2-1000](#)
 - sticky port [2-1000](#)
- Port Trust Device
 - displaying [2-865](#)
- power efficient-ethernet auto command [2-511](#)
- power inline four-pair forced command [2-516](#)
- power inline logging global command [2-518](#)
- power negotiation through LLDP, enabling [2-381](#)
- power status
 - displaying inline power [2-851](#)
 - displaying power status [2-851](#)
- power supply
 - configuring combined and redundant power on the Catalyst 4507R [2-506](#)
 - configuring inline power [2-512](#)
 - configuring power consumption [2-506](#)
 - displaying the SEEPROM [2-669](#)
 - setting inline power state [2-510](#)
- PPPoE Discovery
 - enable vendor-tag stripping on packetsPPPoE Server
 - enable vendor-tag stripping on Discovery packets [2-533](#)
- PPPoE Discovery packets, limit rate arriving on an interface [2-531](#)
- PPPoE Intermediate Agent
 - clear statistics (packet counters) [2-127](#)
 - debugging [2-164](#)
- pppoe intermediate-agent
 - enable intermediate agent on a switch [2-523](#)
 - enable on an interface VLAN range [2-526](#)
 - enable PPPoE Intermediate Agent on an interface [2-524](#)
 - enable vendor-tag stripping of Discovery packets [2-533](#)
 - format-type (global) [2-527](#)
 - limit rate of PPPoE Discovery packets [2-531](#)
 - set circuit-id or remote-id for an interface [2-529](#)
 - set circuit-id or remote-id for an interface VLAN range [2-530](#)
 - set trust configuration on an interface [2-531, 2-532](#)
- PPPoE Intermediate Agent, display configuration and statistics (packet counters) [2-860](#)
- priority command [2-534](#)
- priority-queue command [2-138](#)
- Private VLAN
 - See PVLANS
- privileged EXEC mode, summary [1-5](#)
- prompts
 - system [1-5](#)
- protocol tunneling

- configuring encapsulation rate [2-377](#)
- disabling [2-372](#)
- displaying port information [2-773](#)
- enabling [2-372](#)
- setting a CoS value for Layer 2 packets [2-374](#)
- setting a drop threshold for Layer 2 packets [2-375](#)

PVLANs

- configuring isolated, primary, and community PVLANs [2-536](#)
- controlling tagging of native VLAN traffic [2-1015](#)
- disabling sticky-ARP [2-331](#)
- displaying map information for VLAN SVIs [2-687](#)
- displaying PVLAN information [2-915](#)
- enabling interface configuration mode [2-995](#)
- enabling sticky-ARP [2-331](#)
- mapping VLANs to the same SVI [2-540](#)
- specifying host ports [2-995](#)
- specifying promiscuous ports [2-995](#)

Q

QoS

- account Layer 2 encapsulation [2-547](#)
- attaching a policy-map to an interface [2-581](#)
- automatic configuration [2-44, 2-48, 2-52, 2-56, 2-60, 2-64, 2-67](#)
- class maps
 - creating [2-95](#)
 - defining the match criteria [2-432](#)
- clearing aggregate counters [2-128](#)
- configuring auto [2-64](#)
- defining a named aggregate policer [2-549](#)
- displaying aggregate policer information [2-863](#)
- displaying auto configuration [2-619](#)
- displaying class maps information [2-633](#)
- displaying configuration information [2-619](#)
- displaying configurations of policies [2-839](#)
- displaying policy map information [2-835, 2-842](#)
- displaying QoS information [2-862](#)

- displaying QoS map information [2-867](#)

egress queue-sets

- enabling the priority queue [2-138](#)
- enabling global configuration mode [2-56, 2-546](#)
- enabling per-VLAN QoS for a Layer 2 interface [2-551](#)
- hierarchical policies

- average-rate traffic shaping on a class [2-603](#)
- bandwidth allocation for a class [2-75, 2-94](#)
- creating a service policy [2-584](#)
- marking [2-590](#)
- strict priority queueing (LLQ) [2-534](#)

policy maps

- creating [2-501](#)
- marking [2-590](#)
- traffic classifications
- trust states [2-1038](#)

- setting the trust state [2-549](#)

- specifying flow-based match criteria [2-435](#)

Supervisor Engine 6-E

- setting CoS [2-592](#)
- setting DSCP [2-595](#)
- setting precedence values [2-598](#)
- setting QoS group identifiers [2-601](#)

QoS CoS

- configuring for tunneled Layer 2 protocol packets [2-374](#)

quality of service

- See QoS

- question command [1-1](#)

queueing information

- displaying [2-865](#)

queue limiting

- configuring packet limits [2-551](#)

R

- re-authenticating 802.1X-enabled ports [2-216](#)

- re-authentication

periodic [2-217](#)
 set the time [2-219](#)
 reauthentication, enabling [2-35](#)
 reboots
 restoring bindings across [2-293](#)
 redundancy
 accessing the main CPU [2-553](#)
 changing from active to standby supervisor engine [2-557](#)
 displaying information [2-869](#)
 displaying ISSU config-sync failure information [2-873](#)
 displaying redundancy facility information [2-869](#)
 displaying RF client list [2-869](#)
 displaying RF operational counters [2-869](#)
 displaying RF states [2-869](#)
 enabling automatic synchronization [2-72](#)
 forcing switchover to standby supervisor engine [2-557](#)
 mismatched command listing [2-555](#)
 set the mode [2-442](#)
 synchronizing the route processor configurations [2-429](#)
 related documentation [1-xxiii](#)
 remote-id, setting for an interface [2-529](#)
 remote-id, setting for an interface VLAN range [2-530](#)
 remote SPAN
 See RSPAN
 renew commands
 ip dhcp snooping database [2-561](#)
 rep admin vlan command [2-562](#)
 rep block port command [2-563](#)
 rep lsl-age-timer command [2-567](#)
 rep preempt delay command [2-569](#)
 rep preempt segment command [2-571](#)
 rep segment command [2-572](#)
 rep stcn command [2-575](#)
 resetting PVLAN trunk
 setting switchport to trunk [2-995](#)
 retry failed authentication, configuring [2-26](#)

rj45 connector, selecting the connector [2-441](#)
 ROM monitor mode
 summary [1-6](#)
 Route Processor Redundancy
 See redundancy
 router, set to become ANCP client [2-18](#)
 RPF
 disabling IPv4 exists-only checks [2-336](#)
 enabling IPv4 exists-only checks [2-336](#)
 RPR
 set the redundancy mode [2-442](#)
 RSPAN
 converting VLAN to RSPAN VLAN [2-560](#)
 displaying list [2-917](#)

S

sampler (netflow-lite monitor submode) command [2-579](#)
 saving configuration changes [1-11](#)
 secure address, configuring [2-506](#)
 secure ports, limitations [2-1001](#)
 server (AAA) alive actions, configuring [2-26](#)
 server (AAA) dead actions, configuring [2-26](#)
 service-policy command (policy-map class) [2-584](#)
 session classification, defining [2-30](#)
 set the redundancy mode [2-442](#)
 sfp connector, selecting the connector [2-441](#)
 shape command [2-603](#)
 shell trigger command [2-607, 2-879](#)
 show ancp multicast [2-612](#)
 show authentication interface command [2-614](#)
 show authentication registration command [2-614](#)
 show authentication sessions command [2-614](#)
 show capture command [2-817](#)
 show commands
 filtering parameters [1-7](#)
 searching and filtering [1-6](#)
 show platform commands [1-11](#)
 show energywise command [2-651](#)

- show ipv6 snooping counters command [2-748](#)
- show ip wccp command [2-739](#)
- show ip wccp detail command [2-739](#)
- show ip wccp view command [2-739](#)
- show mab command [2-779](#)
- show mac address-table learning command [2-236](#), [2-793](#)
- show macro auto monitor device command [2-808](#), [2-810](#), [2-812](#)
- show monitor capture command [2-819](#), [2-821](#)
- show monitor capture file command [2-821](#)
- show netflow-lite exporter command [2-825](#)
- show netflow-lite monitor command [2-827](#)
- show netflow-lite sampler command [2-829](#)
- show nmsp command [2-830](#)
- show vlan group command [2-910](#)
- show vlan mapping command [2-912](#)
- Simple Network Management Protocol
 - See SNMP
- single-character patterns
 - special characters [1-7](#)
- single-host, setting [2-30](#)
- slaveslot0
 - displaying information on the standby supervisor [2-882](#)
- slot0
 - displaying information about the system [2-884](#)
- SNMP
 - debugging spanning tree activities [2-167](#)
 - ifindex persist [2-925](#)
 - ifIndex persistence
 - clearing SNMP ifIndex commands [2-923](#)
 - compress SNMP ifIndex table format [2-930](#)
 - enabling globally [2-929](#)
 - informs
 - enabling [2-927](#)
 - traps
 - configuring to send when storm occurs [2-972](#)
 - disabling [2-927](#)
 - enabling [2-927](#)
 - mac-notification
 - adding [2-931](#)
 - removing [2-931](#)
 - source (netflow-lite exporter submode) command [2-932](#)
- SPAN commands
 - configuring a SPAN session to monitor [2-458](#)
 - displaying SPAN session information [2-897](#), [2-974](#)
- SPAN enhancements
 - displaying status [2-817](#)
- Spanning Tree Protocol
 - See STP
- SPAN session
 - displaying session information [2-817](#)
 - filter ACLs [2-458](#)
 - specify encap type [2-458](#)
 - turn off host learning based on ingress packets [2-458](#)
- special characters
 - anchoring, table [1-10](#)
- SSO [2-442](#)
- standard desktop
 - enabling Cisco-recommended features [2-402](#)
- standard desktop and Cisco IP phone
 - enabling Cisco-recommended features [2-404](#)
- sticky address, configuring [2-507](#)
- sticky-ARP
 - disabling on PVLANS [2-331](#)
 - enabling on PVLANS [2-331](#)
- sticky port
 - deleting [2-125](#)
 - enabling security [2-1000](#)
- storm control
 - disabling suppression mode [2-658](#)
 - displaying settings [2-894](#)
 - enabling [2-972](#)
 - enabling broadcast [2-972](#), [2-974](#)
 - enabling multicast [2-972](#), [2-974](#)
 - enabling suppression mode [2-658](#)
 - enabling timer to recover from error disable [2-242](#)
 - enabling unicast [2-972](#), [2-974](#)

multicast, enabling [2-974](#)

setting high and low levels [2-972](#)

setting suppression level [2-658](#)

STP

configuring link type for a port [2-944](#)

configuring tunneling encapsulation rate [2-377](#)

debugging all activities [2-167](#)

debugging spanning tree activities [2-167](#)

debugging spanning tree BackboneFast events [2-169](#)

debugging spanning tree UplinkFast [2-172](#)

detecting misconfiguration [2-941](#)

displaying active interfaces only [2-886](#)

displaying BackboneFast status [2-886](#)

displaying bridge status and configuration [2-886](#)

displaying spanning tree debug messages [2-167](#)

displaying summary of interface information [2-886](#)

enabling BPDU filtering by default on all PortFast ports [2-960](#)

enabling BPDU filtering on an interface [2-937](#)

enabling BPDU guard by default on all PortFast ports [2-962](#)

enabling BPDU guard on an interface [2-939](#)

enabling extended system ID [2-942](#)

enabling loop guard as a default on all ports [2-945](#)

enabling PortFast by default on all access ports [2-963](#)

enabling PortFast mode [2-958](#)

enabling protocol tunneling for [2-372](#)

enabling root guard [2-943](#)

enabling spanning tree BackboneFast [2-936](#)

enabling spanning tree on a per VLAN basis [2-967](#)

enabling spanning tree UplinkFast [2-965](#)

setting an interface priority [2-964](#)

setting drop threshold for [2-375](#)

setting pathcost [2-940](#)

setting the default pathcost calculation method [2-957](#)

subinterface configuration mode, summary [1-6](#)

SVI

creating a Layer 3 interface on a VLAN [2-274](#)

switching characteristics

excluding from link-up calculation [2-992](#)

modifying [2-992](#)

returning to interfaces

capture function [2-992](#)

switchport interfaces

displaying status of Layer 3 port [2-690](#)

displaying status of native VLAN tagging [2-690](#)

switchport trunk command [2-1016](#)

switchport vlan mapping command [2-1020](#)

switch shim

debugging [2-170](#)

disabling debugging [2-170](#)

switch to router connection

enabling Cisco-recommended features [2-406](#)

switch to switch connection

enabling Cisco-recommended features [2-408](#)

switch virtual interface

See SVI

sw-vlan [2-173](#)

system prompts [1-5](#)

T

Tab key

command completion [1-1](#)

tables

characters with special meaning [1-7](#)

mac access-list extended subcommands [2-390](#)

multipliers [1-9](#)

relationship between duplex and speed commands [2-970](#)

show cable-diagnostics tdr command output fields [2-624](#)

show cdp neighbors detail field descriptions [2-632](#)

show cdp neighbors field descriptions [2-631](#)

show ip dhcp snooping command output [2-615, 2-779](#)

show ip interface field descriptions [2-725](#)

show policy-map control-plane field descriptions [2-838](#)

- show vlan command output fields [2-916](#)
- show vtp command output fields [2-921](#)
- special characters [1-9](#)
- special characters used for anchoring [1-10](#)
- speed command options [2-435, 2-970](#)
- valid interface types [2-269](#)
- TAC
 - displaying information useful to TAC [2-898](#)
- TCAM
 - debugging spanning tree activities [2-167](#)
- TDR
 - displaying cable diagnostic test results [2-623](#)
 - test condition of copper cables [2-1026](#)
- temperature readings
 - displaying information [2-655](#)
- template data timeout (netflow-lite exporter submode) command [2-1024](#)
- timer information [2-659](#)
- traffic monitor
 - display status [2-779](#)
- traffic shaping
 - enable on an interface [2-605](#)
- transport udp (netflow-lite exporter submode) command [2-1034](#)
- transport udp load-share (netflow-lite exporter submode) command [2-1036](#)
- traps, enabling [2-927](#)
- trunk interfaces
 - displaying trunk interfaces information [2-697](#)
- trunk port, configuring VLAN mapping [2-1020](#)
- trunk ports, display VLAN mapping information [2-912](#)
- trust configuration, setting on an interface [2-531, 2-532](#)
- trust state
 - setting [2-282](#)
- ttl (netflow-lite exporter submode) command [2-1040](#)
- tunnel ports
 - displaying information about Layer 2 protocol [2-773](#)
- TX queues
 - allocating bandwidth [2-1042](#)
 - returning to default values [2-1042](#)

- setting priority to high [2-1042](#)

U

UDLD

- displaying administrative and operational status [2-900](#)
- enabling by default on all fiber interfaces [2-1044](#)
- enabling on an individual interface [2-1046](#)
- preventing a fiber interface from being enabled [2-1046](#)
- resetting all shutdown ports [2-1048](#)
- setting the message timer [2-1044](#)

Unidirectional Link Detection

See UDLD

- unidirection port control, changing from bidirectional [2-23](#)

- unknown multicast traffic, preventing [2-994](#)

- unknown unicast traffic, preventing [2-994](#)

- user EXEC mode, summary [1-5](#)

V

VACLs

- access-group mode [2-6](#)
- applying VLAN access maps [2-1065](#)
- displaying VLAN access map information [2-907](#)
- specifying an action in a VLAN access map [2-13](#)
- specifying the match clause for a VLAN access-map sequence [2-430](#)
- using a VLAN filter [2-1065](#)

VLAN

- applying an ARP ACL [2-276](#)
- configuring [2-1054](#)
- configuring service policies [2-1059](#)
- converting to RSPAN VLAN [2-560](#)
- displaying CEF information [2-704](#)
- displaying CEF next-hop information [2-704](#)
- displaying information on switch interfaces [2-715, 2-719](#)

- displaying information on VLAN switch interfaces [2-722](#)
- displaying information sorted by group IP address [2-715, 2-719](#)
- displaying IP address and version information [2-715, 2-719](#)
- displaying Layer 2 VLAN information [2-903](#)
- displaying statistical information [2-815](#)
- displaying VLAN information [2-905](#)
- enabling dynamic ARP inspection [2-285](#)
- enabling Explicit Host Tracking [2-316](#)
- enabling guest per-port [2-205](#)
- enabling guest VLAN supplicant [2-198, 2-206](#)
- entering VLAN configuration mode [2-1059, 2-1061](#)
- native frames
 - enabling tagging on all 802.1Q trunk ports [2-1063](#)
- VLAN, create or modify a group [2-1066](#)
- VLAN Access Control Lists
 - See VACLs
- VLAN access map
 - See VACLs
- VLAN database
 - resetting [2-577](#)
- VLAN debugging
 - limiting output [2-145](#)
- vlan group command [2-1066](#)
- VLAN groups, display VLANs mapped [2-910](#)
- VLAN link-up calculation
 - excluding a switch port [2-992](#)
- VLAN manager
 - debugging [2-173](#)
 - disabling debugging [2-173](#)
 - IOS file system error tests
 - debugging [2-174](#)
 - disabling debugging [2-174](#)
- VLAN mapping
 - configuring [2-1020](#)
 - displaying [2-912](#)
- VLAN mapping, configure on trunk port [2-1020](#)
- VLAN mapping on trunk ports, display information [2-912](#)
- VLAN Query Protocol
 - See VQP
- VLAN query protocol (VQPC)
 - debugging [2-180](#)
- VLANs
 - clearing
 - counters [2-130](#)
 - clearing hardware logic [2-103](#)
 - configuring
 - internal allocation scheme [2-1068](#)
 - displaying
 - internal VLAN allocation information [2-911](#)
 - RSPAN VLANs [2-917](#)
 - entering VLAN configuration mode [2-1061](#)
- VMPS
 - configuring servers [2-1072](#)
 - reconfirming dynamic VLAN assignments [2-180, 2-1070](#)
- voice VLANs
 - enabling [2-988](#)
- VoIP
 - configuring auto-QoS [2-64](#)
- VQP
 - per-server retry count [2-1071](#)
 - reconfirming dynamic VLAN assignments [2-180, 2-1070](#)
- vrf (netflow-lite exporter submode) command [2-1074](#)
- VTP
 - configuring the administrative domain name [2-1078](#)
 - configuring the device in VTP client mode [2-1077](#)
 - configuring the device in VTP server mode [2-1081](#)
 - configuring the device in VTP transparent mode [2-1082](#)
 - configuring tunnel encapsulation rate [2-377](#)
 - creating a VTP domain password [2-1079](#)
 - displaying domain information [2-920](#)
 - displaying statistics information [2-920](#)
 - enabling protocol tunneling for [2-372](#)
 - enabling pruning in the VLAN database [2-1080](#)
 - enabling VTP version 2 mode [2-1083](#)

modifying the VTP configuration storage file
name [2-1076](#)

set drop threshold for [2-375](#)

VTP protocol code

activating debug messages [2-177](#)

deactivating debug messages [2-177](#)

W

Webauth fallback, enabling [2-29](#)

