



A

aaa accounting dot1x command [2-1](#)
aaa authentication dot1x command [2-3](#)
AAA methods [2-3](#)
access control entries
 See ACEs
access control lists
 See ACLs
access groups
 IP [2-83](#)
 MAC, displaying [2-293](#)
 matching for QoS classification [2-148](#)
access mode [2-427](#)
access ports [2-427](#)
ACEs [2-54, 2-175](#)
ACLs
 as match criteria for QoS classes [2-148](#)
 deny [2-52](#)
 displaying [2-225](#)
 for non-IP protocols [2-130](#)
 IP [2-83](#)
 on Layer 2 interfaces [2-83](#)
 permit [2-173](#)
action command [2-5](#)
address aliasing [2-164](#)
aggregate policers
 applying [2-179](#)
 creating [2-181](#)
 displaying [2-325](#)
 QoS [2-182](#)
aggregate-port learner [2-169](#)
allowed VLANs [2-442](#)

archive download-sw command [2-7](#)
archive tar command [2-10](#)
archive upload-sw command [2-13](#)
attaching policy maps to interfaces [2-208](#)
audience [xv](#)
authorization state of controlled port [2-60](#)
autonegotiation of duplex mode [2-68](#)

B

bandwidth, configuring for QoS [2-15](#)
bandwidth command [2-15](#)
boot (boot loader) command [A-2](#)
boot bootlpr command [2-18](#)
boot config-file command [2-19](#)
boot enable-break command [2-20](#)
boot helper command [2-21](#)
boot helper-config file command [2-22](#)
booting
 Cisco IOS image [2-25](#)
 displaying environment variables [2-229](#)
 interrupting [2-20](#)
 manually [2-23](#)
boot loader
 accessing [A-1](#)
 booting
 Cisco IOS image [A-2](#)
 helper image [2-21](#)
directories
 creating [A-15](#)
 displaying a list of [A-7](#)
 removing [A-19](#)

- boot loader (continued)
 - displaying
 - available commands [A-12](#)
 - memory heap utilization [A-14](#)
 - version [A-26](#)
 - environment variables
 - described [A-20](#)
 - displaying settings [A-20](#)
 - location of [A-21](#)
 - setting [A-20](#)
 - unsetting [A-24](#)
 - files
 - copying [A-5](#)
 - deleting [A-6](#)
 - displaying a list of [A-7](#)
 - displaying the contents of [A-4, A-16, A-23](#)
 - renaming [A-17](#)
 - file system
 - formatting [A-10](#)
 - initializing flash [A-9](#)
 - running a consistency check [A-11](#)
 - loading helper images [A-13](#)
 - prompt [A-1](#)
 - resetting the system [A-18](#)
- boot manual command [2-23](#)
- boot private-config-file command [2-24](#)
- boot system command [2-25](#)
- BPDU filtering, for spanning tree [2-372, 2-408](#)
- BPDU guard, for spanning tree [2-374, 2-408](#)
- broadcast storm control [2-417](#)
- burst bytes, in QoS policers [2-176, 2-181](#)
- child policy maps [2-210](#)
- class-based traffic shaping [2-223](#)
- class-based weighted fair queuing
 - See CBWFQ
- class command [2-32](#)
- class-map command [2-34](#)
- class-map configuration mode [2-34](#)
- class maps
 - creating [2-34](#)
 - defining the match criteria [2-149](#)
 - displaying [2-233](#)
 - matching in [2-34](#)
- class of service
 - See CoS
- clear ip dhcp snooping database statistics command [2-36](#)
- clear lacp command [2-37](#)
- clear mac address-table command [2-38](#)
- clear pagp command [2-39](#)
- clear policer cpu uni counters command [2-40](#)
- clear port-security command [2-41](#)
- clear spanning-tree counters command [2-43](#)
- clear spanning-tree detected-protocols command [2-44](#)
- clear vmps statistics command [2-46](#)
- command modes defined [1-1](#)
- committed information rate in QoS policers [2-176, 2-181](#)
- configuration, initial
 - See also getting started guide and hardware installation guide
- configuration files
 - password recovery disable considerations [A-1](#)
 - specifying the name [2-19, 2-24](#)
- configuring multiple interfaces [2-79](#)
- conform-action command [2-47](#)
- control-plane policer [2-40](#)
- control-plane policer information, displaying [2-326](#)
- control-plane security [2-184](#)
- control plane statistics, clearing [2-40](#)

C

- cat (boot loader) command [A-4](#)
- caution, description [xvi](#)
- CBWFQ, configuring [2-15](#)
- channel-group command [2-26](#)
- channel-protocol command [2-30](#)

conventions

- command [xvi](#)
- for examples [xvi](#)
- publication [xvi](#)
- text [xvi](#)

copy (boot loader) command [A-5](#)

CoS

- as match criteria for QoS groups [2-149](#)
- for QoS classification [2-212](#)
- setting value in policy maps [2-212](#)

CPU ASIC statistics, displaying [2-234](#)

CPU protection policers, displaying [C-14](#)

D

debug dot1x command [B-2](#)

debug etherchannel command [B-3](#)

debug interface command [B-6](#)

debug ip dhcp snooping command [B-5](#)

debug ip igmp filter command [B-7](#)

debug ip igmp max-groups command [B-8](#)

debug ip igmp snooping command [B-9](#)

debug lacp command [B-10](#)

debug mac-notification command [B-11](#)

debug matm command [B-12](#)

debug monitor command [B-13](#)

debug mvrdbg command [B-14](#)

debug nvram command [B-15](#)

debug pagp command [B-16](#)

debug platform acl command [B-17](#)

debug platform cpu-queues command [B-18](#)

debug platform dot1x command [B-20](#)

debug platform etherchannel command [B-21](#)

debug platform forw-tcam command [B-22](#)

debug platform ip dhcp command [B-23](#)

debug platform ip igmp snooping command [B-24](#)

debug platform led command [B-26](#)

debug platform matm command [B-27](#)

debug platform messaging application command [B-28](#)

debug platform phy command [B-29](#)

debug platform pm command [B-31](#)

debug platform policer cpu uni command [B-33](#)

debug platform port-asic command [B-34](#)

debug platform port-security command [B-35](#)

debug platform qos-acl-tcam command [B-36](#)

debug platform remote-commands command [B-37](#)

debug platform resource-manager command [B-38](#)

debug platform snmp command [B-39](#)

debug platform span command [B-40](#)

debug platform supervisor-asic command [B-41](#)

debug platform sw-bridge command [B-42](#)

debug platform tcam command [B-43](#)

debug platform udd command [B-45](#)

debug platform vlan command [B-46](#)

debug pm command [B-47](#)

debug port-security command [B-49](#)

debug qos-manager command [B-50](#)

debug spanning-tree bpdu command [B-53](#)

debug spanning-tree bpdu-opt command [B-54](#)

debug spanning-tree command [B-51](#)

debug spanning-tree mstp command [B-55](#)

debug spanning-tree switch command [B-57](#)

debug sw-vlan command [B-59](#)

debug sw-vlan ifs command [B-61](#)

debug sw-vlan notification command [B-62](#)

debug udd command [B-64](#)

debug vqpc command [B-66](#)

define interface-range command [2-49](#)

delete (boot loader) command [A-6](#)

delete command [2-51](#)

deny command [2-52](#)

detect mechanism, causes [2-69](#)

DHCP snooping

- accepting untrusted packets from edge switch [2-94](#)
- enabling
 - on a VLAN [2-99](#)
 - option 82 [2-92, 2-94](#)
 - trust on an interface [2-97](#)
- error recovery timer [2-71](#)
- rate limiting [2-96](#)

DHCP snooping binding database

- binding file, configuring [2-90](#)
- bindings
 - adding [2-88](#)
 - deleting [2-88](#)
 - displaying [2-276](#)
- clearing database agent statistics [2-36](#)
- database agent, configuring [2-90](#)
- displaying
 - binding entries [2-276](#)
 - database agent status [2-278](#)
- renewing [2-203](#)

differentiated service code point

See DSCP

dir (boot loader) command [A-7](#)

- directories, deleting [2-51](#)
- documentation, related [xvi](#)
- document conventions [xvi](#)
- dot1x default command [2-55](#)
- dot1x host-mode command [2-56](#)
- dot1x initialize command [2-57](#)
- dot1x max-req command [2-58, 2-59](#)
- dot1x port-control command [2-60](#)
- dot1x re-authenticate command [2-62](#)
- dot1x reauthentication command [2-63](#)
- dot1x system-auth-control command [2-64](#)
- dot1x timeout command [2-65](#)
- dropping packets, with ACL matches [2-5](#)

DSCP

- as match criteria for QoS groups [2-150](#)
- for QoS traffic marking [2-214](#)
- setting in policy maps [2-214](#)

duplex command [2-67](#)

dynamic-access ports

- configuring [2-422](#)
- restrictions [2-423](#)

Dynamic Host Configuration Protocol (DHCP)

See DHCP snooping

E

EAP-request/identity frame

- maximum number to send [2-59](#)
- response time before retransmitting [2-65](#)

environment variables, displaying [2-229](#)errdisable detect cause command [2-69](#)errdisable recovery command [2-71](#)error conditions, displaying [2-253](#)error disable detection [2-69](#)error-disabled interfaces, displaying [2-264](#)

EtherChannel

- assigning Ethernet interface to channel group [2-26](#)

creating port-channel logical interface [2-77](#)debug EtherChannel/PAgP, display [B-3](#)debug platform-specific events, display [B-21](#)displaying [2-257](#)interface information, displaying [2-264](#)

LACP

- clearing channel-group information [2-37](#)

debug messages, display [B-10](#)displaying [2-289](#)modes [2-26](#)port priority for hot-standby ports [2-122](#)restricting a protocol [2-30](#)system priority [2-124](#)load-distribution methods [2-188](#)

EtherChannel (continued)

PAgP

- aggregate-port learner [2-169](#)
- clearing channel-group information [2-39](#)
- debug messages, display [B-16](#)
- displaying [2-321](#)
- error detection for [2-69](#)
- error recovery timer [2-71](#)
- learn method [2-169](#)
- modes [2-26](#)
- physical-port learner [2-169](#)
- priority of interface for transmitted traffic [2-171](#)

Ethernet controller, internal register display [2-236](#)

Ethernet statistics, collecting [2-205](#)

examples, conventions for [xvi](#)

exceed-action command [2-73](#)

extended-range VLANs

- and allowed VLAN list [2-442](#)

- configuring [2-463](#)

extended system ID for STP [2-380](#)

F

fan information, displaying [2-250](#)

files, deleting [2-51](#)

flash_init (boot loader) command [A-9](#)

flowcontrol command [2-75](#)

format (boot loader) command [A-10](#)

forwarding packets, with ACL matches [2-5](#)

forwarding results, display [C-5](#)

frame forwarding information, displaying [C-5](#)

fsck (boot loader) command [A-11](#)

G

global configuration mode [1-2, 1-3](#)

H

hardware ACL statistics [2-225](#)

help (boot loader) command [A-12](#)

host connection, port configuration [2-426](#)

host ports, private VLANs [2-429](#)

I

IEEE 802.1x

- and switchport modes [2-427](#)

- violation error recovery [2-71](#)

See also port-based authentication

IGMP filters

- applying [2-100](#)

- debug messages, display [B-7](#)

IGMP groups, setting maximum [2-101](#)

IGMP maximum groups, debugging [B-8](#)

IGMP profiles

- creating [2-103](#)

- displaying [2-280](#)

IGMP snooping

- adding ports as a static member of a group [2-118](#)

- displaying [2-281, 2-285, 2-287](#)

- enabling [2-105](#)

- enabling the configurable-leave timer [2-107](#)

- enabling the Immediate-Leave feature [2-115](#)

- flooding query count [2-113](#)

- interface topology change notification behavior [2-114](#)

- multicast table [2-283](#)

- querier [2-109](#)

- query solicitation [2-113](#)

- report suppression [2-111](#)

- switch topology change notification behavior [2-113](#)

images

- See software images

Immediate-Leave feature, MVR [2-166](#)

immediate-leave processing [2-115](#)

initial configuration

See also getting started guide and hardware installation guide

input policy maps

and ACL classification [2-148](#)
 and aggregate policers [2-182](#)
 commands not supported in [2-186](#)
 configuration guidelines [2-186](#)

interface command [2-82](#)interface configuration mode [1-2, 1-4](#)interface port-channel command [2-77](#)interface range command [2-79](#)interface-range macros [2-49](#)

interfaces

assigning Ethernet interface to channel group [2-26](#)
 configuring [2-67](#)
 configuring multiple [2-79](#)
 creating port-channel logical [2-77](#)
 debug messages, display [B-6](#)
 disabling [2-361](#)
 displaying the MAC address table [2-305](#)
 restarting [2-361](#)

interface speed, configuring [2-415](#)internal registers, displaying [2-236, 2-243](#)

Internet Group Management Protocol

See IGMP

invalid GBIC

error detection for [2-69](#)
 error recovery timer [2-71](#)

ip address command [2-85](#)IP addresses, setting [2-85](#)IP address matching [2-146](#)

IP DHCP snooping

See DHCP snooping

ip dhcp snooping binding command [2-88](#)ip dhcp snooping command [2-87](#)ip dhcp snooping database command [2-90](#)ip dhcp snooping information option allow-untrusted command [2-94](#)ip dhcp snooping information option command [2-92](#)ip dhcp snooping limit rate command [2-96](#)ip dhcp snooping trust command [2-97](#)ip dhcp snooping verify command [2-98](#)ip dhcp snooping vlan command [2-99](#)ip igmp filter command [2-100](#)ip igmp max-groups command [2-101](#)ip igmp profile command [2-103](#)ip igmp snooping command [2-105](#)ip igmp snooping last-member-query-interval command [2-107](#)ip igmp snooping querier command [2-109](#)ip igmp snooping report-suppression command [2-111](#)ip igmp snooping tcn command [2-113](#)ip igmp snooping tcn flood command [2-114](#)ip igmp snooping vlan immediate-leave command [2-115](#)ip igmp snooping vlan mrouter command [2-116](#)ip igmp snooping vlan static command [2-118](#)IP multicast addresses [2-163](#)IP precedence, as match criteria for QoS groups [2-152](#)

IP source guard, displaying

dynamic binding entries [2-276](#)

ip ssh command [2-120](#)

J

jumbo frames

See MTU

L

LACP

See EtherChannel

lacp port-priority command [2-122](#)lacp system-priority command [2-124](#)

Layer 2 traceroute

IP addresses [2-453](#)

MAC addresses [2-450](#)

line configuration mode [1-2, 1-4](#)

Link Aggregation Control Protocol

See EtherChannel

link flap

error detection for [2-69](#)error recovery timer [2-71](#)load_helper (boot loader) command [A-13](#)load-distribution methods for EtherChannel [2-188](#)logging file command [2-126](#)logical interface [2-77](#)

loopback error

detection for [2-69](#)recovery timer [2-71](#)loop guard, for spanning tree [2-382, 2-386](#)

Mmac access-group command [2-128](#)MAC access-groups, displaying [2-293](#)MAC access list configuration mode [2-130](#)mac access-list extended command [2-130](#)MAC access lists [2-52](#)

MAC addresses

displaying

aging time [2-299](#)all [2-297](#)dynamic [2-303](#)notification settings [2-307](#)number of addresses in a VLAN [2-301](#)per interface [2-305](#)per VLAN [2-311](#)static [2-309](#)static and dynamic entries [2-295](#)

dynamic

aging time [2-132](#)deleting [2-38](#)displaying [2-303](#)enabling MAC address notification [2-133](#)matching [2-146](#)

MAC addresses (continued)

static

adding and removing [2-135](#)displaying [2-309](#)dropping on an interface [2-136](#)tables [2-297](#)MAC address notification, debugging [B-11](#)mac address-table aging-time [2-128, 2-146](#)mac address-table aging-time command [2-132](#)mac address-table notification command [2-133](#)mac address-table static command [2-135](#)mac address-table static drop command [2-136](#)macro description command [2-140](#)macro global command [2-141](#)macro global description command [2-143](#)macro name command [2-144](#)

macros

adding a description [2-140](#)adding a global description [2-143](#)applying [2-141](#)creating [2-144](#)displaying [2-323](#)interface range [2-49, 2-79](#)specifying parameter values [2-141](#)tracing [2-141](#)

manual

audience [xv](#)purpose of [xv](#)mapping tables, QoS [2-447](#)

maps

VLAN

creating [2-466](#)defining [2-146](#)displaying [2-357](#)match access-group command [2-148](#)match cos command [2-149](#)match ip dscp command [2-150](#)match ip precedence command [2-152](#)match qos-group command [2-154](#)

maximum transmission unit

See MTU

mdix auto command [2-156](#)

memory (boot loader) command [A-14](#)

mkdir (boot loader) command [A-15](#)

mode, MVR [2-163](#)

modes, commands [1-1](#)

monitor session command [2-158](#)

more (boot loader) command [A-16](#)

MSTP

displaying [2-339](#)

interoperability [2-44](#)

link type [2-384](#)

MST region

aborting changes [2-390](#)

applying changes [2-390](#)

configuration name [2-390](#)

configuration revision number [2-390](#)

current or pending display [2-390](#)

displaying [2-339](#)

MST configuration mode [2-390](#)

VLANs-to-instance mapping [2-390](#)

path cost [2-392](#)

protocol mode [2-388](#)

restart protocol migration process [2-44](#)

root port

loop guard [2-382](#)

preventing from becoming designated [2-382](#)

restricting which can be root [2-382](#)

root guard [2-382](#)

MSTP (continued)

root switch

affects of extended system ID [2-380](#)

hello-time [2-395, 2-404](#)

interval between BPDU messages [2-397](#)

interval between hello BPDU messages [2-395, 2-404](#)

max-age [2-397](#)

maximum hop count before discarding BPDU [2-399](#)

port priority for selection of [2-401](#)

primary or secondary [2-404](#)

switch priority [2-403](#)

state changes

blocking to forwarding state [2-410](#)

enabling BPDU filtering [2-372, 2-408](#)

enabling BPDU guard [2-374, 2-408](#)

enabling Port Fast [2-408, 2-410](#)

forward-delay time [2-394](#)

length of listening and learning states [2-394](#)

rapid transition to forwarding [2-384](#)

shutting down Port Fast-enabled ports [2-408](#)

state information display [2-338](#)

MTU

configuring size [2-445](#)

displaying global setting [2-345](#)

multicast group address, MVR [2-166](#)

multicast groups, MVR [2-164](#)

multicast router learning method [2-116](#)

multicast router ports, configuring [2-116](#)

multicast storm control [2-417](#)

multicast VLAN, MVR [2-163](#)

multicast VLAN registration

See MVR

multiple hosts on authorized port [2-56](#)

Multiple Spanning Tree Protocol

See MSTP

MVR

- and address aliasing [2-164](#)
- configuring [2-163](#)
- configuring interfaces [2-166](#)
- debug messages, display [B-14](#)
- displaying [2-315](#)
- displaying interface information [2-317](#)
- members, displaying [2-319](#)
- mvr (global configuration) command [2-163](#)
- mvr (interface configuration) command [2-166](#)
- mvr vlan group command [2-167](#)

N

- native VLANs [2-442](#)
- network node interface [2-190](#)
- nonegotiate, speed [2-415](#), [2-416](#)
- non-IP protocols
 - denying [2-52](#)
 - forwarding [2-173](#)
- non-IP traffic access lists [2-130](#)
- non-IP traffic forwarding
 - denying [2-52](#)
 - permitting [2-173](#)
- normal-range VLANs [2-463](#)
- note, description [xvi](#)
- no vlan command [2-463](#)

O

- output policy maps
 - and QoS group classification [2-154](#)
 - and traffic shaping [2-223](#)
 - commands not supported in [2-186](#)
 - configuration guidelines [2-186](#)
 - priority in [2-193](#)
 - queue limit in [2-198](#)

P

PAgP

See EtherChannel

- pagp learn-method command [2-169](#)
- pagp port-priority command [2-171](#)
- parent policy maps [2-210](#)
- password-recovery mechanism, enabling and disabling [2-206](#)
- permit command [2-173](#)
- per-VLAN spanning-tree plus
 - See STP
- physical-port learner [2-169](#)
- PID, displaying [2-274](#)
- PIM-DVMRP, as multicast router learning method [2-116](#)
- police
 - multiple conform actions for a class [2-47](#)
 - multiple exceed actions for a class [2-73](#)
 - with priority [2-176](#)
- police aggregate command [2-179](#)
- police command [2-176](#)
- policer aggregate command [2-181](#)
- policer cpu uni command [2-184](#)
- policers
 - aggregate [2-179](#), [2-181](#)
 - for CPU protection [2-184](#)
 - individual [2-176](#)
- policy-map class, configuring multiple actions [2-47](#), [2-73](#)
- policy-map class configuration mode [2-32](#)
- policy-map class police configuration mode [2-47](#), [2-178](#)
- policy-map command [2-185](#)
- policy-map configuration mode [2-185](#)
- policy maps
 - and CoS classification [2-149](#)
 - and DSCP classification [2-150](#)
 - and IP precedence classification [2-152](#)
 - and policing [2-177](#)
 - applying [2-208](#)
 - applying to an interface [2-186](#), [2-208](#), [2-220](#)

policy maps (continued)

- child [2-210](#)
- creating [2-185](#)
- displaying [2-328](#)
- hierarchical [2-210](#)
- parent [2-210](#)
- policers
 - for a single class [2-176](#)
 - for multiple classes [2-179, 2-181, 2-184, 2-210](#)
- setting priority [2-192](#)
- setting QoS group identifier [2-218](#)
- traffic classification, defining [2-32](#)
- traffic marking
 - setting CoS values [2-212](#)
 - setting DSCP values [2-214](#)
 - setting IP precedence values [2-216](#)

Port Aggregation Protocol

See EtherChannel

port-based authentication

- AAA method list [2-3](#)
- debug messages, display [B-2](#)
- enabling 802.1x
 - globally [2-64](#)
 - per interface [2-60](#)
- host modes [2-56](#)
- IEEE 802.1x AAA accounting methods [2-1](#)
- initialize an interface [2-57](#)
- manual control of authorization state [2-60](#)
- multiple hosts on authorized port [2-56](#)
- periodic re-authentication
 - enabling [2-63](#)
 - time between attempts [2-65](#)
- quiet period between failed authentication exchanges [2-65](#)
- re-authenticating 802.1x-enabled ports [2-62](#)
- resetting configurable 802.1x parameters [2-55](#)
- switch-to-authentication server retransmission time [2-65](#)

port-based authentication (continued)

- switch-to-client frame-retransmission number [2-58 to 2-59](#)
- switch-to-client retransmission time [2-65](#)
- port-channel load-balance command [2-188](#)
- Port Fast, for spanning tree [2-410](#)
- port ranges, defining [2-49](#)
- ports, debugging [B-47](#)
- ports, protected [2-440](#)
- port security
 - aging [2-436](#)
 - debug messages, display [B-49](#)
 - enabling [2-432](#)
 - violation error recovery [2-71](#)
- port shaping [2-224](#)
- port-type command [2-190](#)
- port types, MVR [2-166](#)
- power information, displaying [2-250](#)
- precedence
 - for QoS traffic marking [2-216](#)
 - setting in policy maps [2-216](#)
- priority command [2-192](#)
- priority queuing, QoS [2-192](#)
- priority with police, QoS [2-192](#)
- private-vlan command [2-195](#)
- private VLANs
 - association [2-438](#)
 - configuring [2-195](#)
 - configuring ports [2-429](#)
 - displaying [2-353](#)
 - host ports [2-429](#)
 - mapping
 - configuring [2-438](#)
 - promiscuous ports [2-429](#)
- privileged EXEC mode [1-2, 1-3](#)
- product identification information, displaying [2-274](#)
- promiscuous ports, private VLANs [2-429](#)
- PVST+
 - See STP

Q

QoS

aggregate policers

- applying [2-179](#)
- creating [2-181](#)
- displaying [2-325](#)

class maps

- creating [2-34](#)
- defining the match criteria [2-149](#)
- displaying [2-233](#)

displaying statistics for [2-328, C-24](#)

policy maps

- applying an aggregate policer [2-179, 2-181, 2-184, 2-210](#)
- applying to an interface [2-208, 2-220](#)
- creating [2-185](#)
- defining policers [2-176](#)
- displaying policy maps [2-328](#)
- setting CoS values [2-212](#)
- setting DSCP values [2-214](#)
- setting IP precedence values [2-216](#)
- setting QoS group identifier [2-218](#)
- traffic classifications [2-32](#)

table maps

- configuring [2-447](#)
- displaying [2-346](#)

QoS groups

- as match criteria [2-154](#)
- for QoS traffic classification [2-218](#)
- setting in policy maps [2-218](#)

QoS match criteria

- ACLs [2-148](#)
- CoS value [2-149](#)
- DSCP value [2-150](#)
- precedence value [2-152](#)
- QoS group number [2-154](#)

quality of service

See QoS

querytime, MVR [2-163](#)

queue-limit command [2-198](#)

R

rapid per-VLAN spanning-tree plus

See STP

rapid PVST+

See STP

re-authenticating 802.1x-enabled ports [2-62](#)

re-authentication

- periodic [2-63](#)
- time between attempts [2-65](#)

receiver ports, MVR [2-166](#)

receiving flow-control packets [2-75](#)

recovery mechanism

- causes [2-71](#)
- display [2-231, 2-251, 2-255](#)
- timer interval [2-71](#)

remote-span command [2-201](#)

Remote Switched Port Analyzer

See RSPAN

rename (boot loader) command [A-17](#)

renew ip dhcp snooping database command [2-203](#)

reset (boot loader) command [A-18](#)

rmdir (boot loader) command [A-19](#)

rmon collection stats command [2-205](#)

root guard, for spanning tree [2-382](#)

RSPAN

- configuring [2-158](#)
- displaying [2-313](#)
- filter RSPAN traffic [2-158](#)
- remote-span command [2-201](#)
- sessions
 - add interfaces to [2-158](#)
 - displaying [2-313](#)
 - start new [2-158](#)

S

- SDM templates, displaying [2-337](#)
- secure ports, limitations [2-433](#)
- sending flow-control packets [2-75](#)
- service password-recovery command [2-206](#)
- service policy (policy-map class configuration) command [2-210](#)
- service-policy interface configuration command [2-208](#)
- service-policy policy-map class configuration command [2-210](#)
- set (boot loader) command [A-20](#)
- set cos command [2-212](#)
- set dscp command [2-214](#)
- set precedence command [2-216](#)
- set qos-group command [2-218](#)
- setup command [2-220](#)
- SFPs, displaying information about [2-274](#)
- shape average command [2-223](#)
- show access-lists command [2-225](#)
- show aggregate-policer command [2-346](#)
- show archive status command [2-228](#)
- show boot command [2-229](#)
- show class-map command [2-233](#)
- show controllers cpu-interface command [2-234](#)
- show controllers ethernet-controller command [2-236](#)
- show controllers team command [2-243](#)
- show controllers utilization command [2-245](#)
- show controller utilization command [2-245](#)
- show dot1x command [2-247](#)
- show env command [2-250](#)
- show errdisable detect command [2-251](#)
- show errdisable flap-values command [2-253](#)
- show errdisable recovery command [2-255](#)
- show etherchannel command [2-257](#)
- show flowcontrol command [2-260](#)
- show idprom command [2-262](#)
- show interfaces command [2-264](#)
- show interfaces counters command [2-272](#)
- show inventory command [2-274](#)
- show ip dhcp snooping binding command [2-276](#)
- show ip dhcp snooping command [2-275](#)
- show ip dhcp snooping database command [2-278](#)
- show ip igmp profile command [2-280](#)
- show ip igmp snooping command [2-281](#)
- show ip igmp snooping command querier detail [2-287](#)
- show ip igmp snooping groups command [2-283](#)
- show ip igmp snooping mrouter command [2-285](#)
- show ip igmp snooping querier command [2-287](#)
- show ip igmp snooping querier detail command [2-287](#)
- show lacp command [2-289](#)
- show mac access-group command [2-293](#)
- show mac address-table address command [2-297](#)
- show mac address-table aging time command [2-299](#)
- show mac address-table command [2-295](#)
- show mac address-table count command [2-301](#)
- show mac address-table dynamic command [2-303](#)
- show mac address-table interface command [2-305](#)
- show mac address-table notification command [2-307](#)
- show mac address-table static command [2-309](#)
- show mac address-table vlan command [2-311](#)
- show monitor command [2-313](#)
- show mvr command [2-315](#)
- show mvr interface command [2-317](#)
- show mvr members command [2-319](#)
- show pagp command [2-321](#)
- show parser macro command [2-323](#)
- show platform acl command [C-2](#)
- show platform configuration command [C-3](#)
- show platform etherchannel command [C-4](#)
- show platform forward command [C-5](#)
- show platform igmp snooping command [C-7](#)
- show platform layer4op command [C-9](#)
- show platform mac-address-table command [C-10](#)
- show platform messaging command [C-11](#)
- show platform monitor command [C-12](#)
- show platform mvr table command [C-13](#)
- show platform pm command [C-17](#)

- show platform policer cpu command [C-14](#)
- show platform port-asic command [C-19](#)
- show platform port-security command [C-23](#)
- show platform qos command [C-24](#)
- show platform resource-manager command [C-27](#)
- show platform snmp counters command [C-29](#)
- show platform spanning-tree synchronization command [C-30](#)
- show platform stp-instance command [C-31](#)
- show platform team command [C-32](#)
- show platform vlan command [C-34](#)
- show policer aggregate command [2-325](#)
- show policer cpu uni command [2-326](#)
- show policy-map command [2-328](#)
- show policy-map interface output fields [2-331](#)
- show port security command [2-332](#)
- show sdm prefer command [2-337](#)
- show spanning-tree command [2-338](#)
- show storm-control command [2-343](#)
- show system mtu command [2-345](#)
- show udld command [2-348](#)
- show version command [2-351](#)
- show vlan access-map command [2-357](#)
- show vlan command [2-353](#)
- show vlan command, fields [2-355](#)
- show vlan filter command [2-358](#)
- show vmps command [2-359](#)
- shutdown command [2-361](#)
- shutdown vlan command [2-362](#)
- SNMP host, specifying [2-366](#)
- SNMP informs, enabling the sending of [2-363](#)
- snmp-server enable traps command [2-363](#)
- snmp-server host command [2-366](#)
- snmp trap mac-notification command [2-370](#)
- SNMP traps
 - enabling MAC address notification trap [2-370](#)
 - enabling the MAC address notification feature [2-133](#)
 - enabling the sending of [2-363](#)
- software images
 - deleting [2-51](#)
 - downloading [2-7](#)
 - upgrading [2-7](#)
 - uploading [2-13](#)
- software version, displaying [2-351](#)
- source ports, MVR [2-166](#)
- SPAN
 - configuring [2-158](#)
 - debug messages, display [B-13](#)
 - displaying [2-313](#)
 - filter SPAN traffic [2-158](#)
 - sessions
 - add interfaces to [2-158](#)
 - displaying [2-313](#)
 - start new [2-158](#)
- spanning-tree bpduguard command [2-372](#)
- spanning-tree bpduguard command [2-374](#)
- spanning-tree cost command [2-376](#)
- spanning-tree etherchannel command [2-378](#)
- spanning-tree extend system-id command [2-380](#)
- spanning-tree guard command [2-382](#)
- spanning-tree link-type command [2-384](#)
- spanning-tree loopguard default command [2-386](#)
- spanning-tree mode command [2-388](#)
- spanning-tree mst configuration command [2-390](#)
- spanning-tree mst cost command [2-392](#)
- spanning-tree mst forward-time command [2-394](#)
- spanning-tree mst hello-time command [2-395](#)
- spanning-tree mst max-age command [2-397](#)
- spanning-tree mst max-hops command [2-399](#)
- spanning-tree mst port-priority command [2-401](#)
- spanning-tree mst priority command [2-403](#)
- spanning-tree mst root command [2-404](#)
- spanning-tree portfast (global configuration) command [2-408](#)
- spanning-tree portfast (interface configuration) command [2-410](#)
- spanning-tree port-priority command [2-406](#)

Spanning Tree Protocol

See STP

spanning-tree vlan command [2-412](#)speed command [2-415](#)SSH, configuring version [2-120](#)static-access ports, configuring [2-422](#)statistics, Ethernet group [2-205](#)sticky learning, enabling [2-432](#)storm-control command [2-417](#)

STP

counters, clearing [2-43](#)

debug messages, display

MSTP [B-55](#)optimized BPDUs handling [B-54](#)spanning-tree activity [B-51](#)switch shim [B-57](#)transmitted and received BPDUs [B-53](#)EtherChannel misconfiguration [2-378](#)extended system ID [2-380](#)path cost [2-376](#)protocol modes [2-388](#)

root port

loop guard [2-382](#)preventing from becoming designated [2-382](#)restricting which can be root [2-382](#)root guard [2-382](#)

root switch

affects of extended system ID [2-380, 2-413](#)hello-time [2-412](#)interval between BDPUs messages [2-412](#)interval between hello BDPUs messages [2-412](#)max-age [2-412](#)port priority for selection of [2-406](#)primary or secondary [2-412](#)switch priority [2-412](#)

STP (continued)

state changes

blocking to forwarding state [2-410](#)enabling BPDU filtering [2-372, 2-408](#)enabling BPDU guard [2-374, 2-408](#)enabling Port Fast [2-408, 2-410](#)enabling timer to recover from error state [2-71](#)forward-delay time [2-412](#)length of listening and learning states [2-412](#)shutting down Port Fast-enabled ports [2-408](#)state information display [2-338](#)VLAN options [2-403, 2-412](#)

Switched Port Analyzer

See SPAN

switching characteristics

modifying [2-420](#)returning to interfaces [2-420](#)switchport access command [2-422](#)switchport block command [2-424](#)switchport command [2-420](#)switchport host command [2-426](#)switchport mode command [2-427](#)switchport mode private-vlan command [2-429](#)switchport port-security aging command [2-436](#)switchport port-security command [2-432](#)switchport private-vlan command [2-438](#)switchport protected command [2-440](#)switchports, displaying [2-264](#)switchport trunk command [2-442](#)system env temperature threshold yellow command [2-444](#)system message logging, save message to flash [2-126](#)system mtu command [2-445](#)

Ttable-map command [2-447](#)table-map configuration mode [2-447](#)

table maps

- configuring [2-447](#)
- displaying [2-346](#)
- QoS [2-447](#)

tar files, creating, listing, and extracting [2-10](#)

TDR, running [2-449](#)

temperature information, displaying [2-250](#)

test cable-diagnostics tdr command [2-449](#)

traceroute mac command [2-450](#)

traceroute mac ip command [2-453](#)

traffic shaping, QoS [2-223](#)

trunking, VLAN mode [2-427](#)

trunk mode [2-427](#)

trunk ports [2-427](#)

type (boot loader) command [A-23](#)

U

UDLD

- aggressive mode [2-456, 2-458](#)
- debug messages, display [B-64](#)
- enable globally [2-456](#)
- enable per interface [2-458](#)
- error recovery timer [2-71](#)
- message timer [2-456](#)
- normal mode [2-456, 2-458](#)
- reset a shutdown interface [2-460](#)
- status [2-348](#)

udld command [2-456](#)

udld port command [2-458](#)

udld reset command [2-460](#)

unicast storm control [2-417](#)

UniDirectional Link Detection

- See UDLD

uni-vlan command [2-461](#)

unknown multicast traffic, preventing [2-424](#)

unknown unicast traffic, preventing [2-424](#)

unset (boot loader) command [A-24](#)

upgrading

- software images [2-7](#)
 - monitoring status of [2-228](#)

upgrading information

- See release notes

user EXEC mode [1-2](#)

user network interface [2-190](#)

V

version (boot loader) command [A-26](#)

vlan access-map command [2-466](#)

VLAN access map configuration mode [2-466](#)

VLAN access maps

- actions [2-5](#)
- displaying [2-357](#)

vlan command [2-463](#)

VLAN configuration mode

- commands [2-463](#)
- description [1-4](#)
- entering [2-463](#)
- summary [1-2](#)

vlan filter command [2-468](#)

VLAN filters, displaying [2-358](#)

VLAN ID range [2-463](#)

VLAN maps

- applying [2-468](#)
- creating [2-466](#)
- defining [2-146](#)
- displaying [2-357](#)

VLAN Query Protocol

- See VQP

VLANs

- adding [2-463](#)
- configuring [2-463](#)
- debug messages, display
 - activation of [B-62](#)
 - VLAN IOS file system error tests [B-61](#)
 - VLAN manager activity [B-59](#)

VLANs (continued)

displaying configurations [2-353](#)

extended-range [2-463](#)

MAC addresses

displaying [2-311](#)

number of [2-301](#)

normal-range [2-463](#)

private [2-429](#)

configuring [2-195](#)

displaying [2-353](#)

See also private VLANs

restarting [2-362](#)

saving the configuration [2-463](#)

shutting down [2-362](#)

suspending [2-362](#)

VMPS

configuring servers [2-473](#)

displaying [2-359](#)

error recovery timer [2-71](#)

reconfirming dynamic VLAN assignments [2-470](#)

vmmps reconfirm (global configuration) command [2-471](#)

vmmps reconfirm (privileged EXEC) command [2-470](#)

vmmps retry command [2-472](#)

vmmps server command [2-473](#)

VQP

and dynamic-access ports [2-423](#)

clearing client statistics [2-46](#)

displaying information [2-359](#)

per-server retry count [2-472](#)

reconfirmation interval [2-471](#)

reconfirming dynamic VLAN assignments [2-470](#)

W

Weighted Tail Drop

See WTD

WTD, queue-limit command [2-198](#)