



INDEX

A

aaa accounting dot1x command [2-1](#)
aaa authentication dot1x command [2-3](#)
AAA methods [2-3](#)
access control entries
 See ACEs
access control lists
 See ACLs
access groups
 IP [2-84](#)
 MAC, displaying [2-303](#)
 matching for QoS classification [2-154](#)
access mode [2-441](#)
access ports [2-441](#)
ACEs [2-55, 2-181](#)
ACLs
 as match criteria for QoS classes [2-154](#)
 deny [2-53](#)
 displaying [2-231](#)
 for non-IP protocols [2-136](#)
 IP [2-84](#)
 on Layer 2 interfaces [2-84](#)
 permit [2-179](#)
action command [2-5](#)
address aliasing [2-170](#)
aggregate policers
 applying [2-186](#)
 creating [2-188](#)
 displaying [2-335](#)
 QoS [2-189](#)
aggregate-port learner [2-175](#)
allowed VLANs [2-456](#)

archive download-sw command [2-7](#)
archive tar command [2-10](#)
archive upload-sw command [2-13](#)
attaching policy maps to interfaces [2-214](#)
audience [xv](#)
authorization state of controlled port [2-61](#)
autonegotiation of duplex mode [2-69](#)

B

bandwidth, configuring for QoS [2-15](#)
bandwidth command [2-15](#)
boot (boot loader) command [A-2](#)
boot bootlpr command [2-18](#)
boot config-file command [2-19](#)
boot enable-break command [2-20](#)
boot helper command [2-21](#)
boot helper-config file command [2-22](#)
booting
 Cisco IOS image [2-25](#)
 displaying environment variables [2-235](#)
 interrupting [2-20](#)
 manually [2-23](#)
boot loader
 accessing [A-1](#)
 booting
 Cisco IOS image [A-2](#)
 helper image [2-21](#)
 directories
 creating [A-15](#)
 displaying a list of [A-7](#)
 removing [A-19](#)

boot loader (continued)

displaying

- available commands [A-12](#)
- memory heap utilization [A-14](#)
- version [A-26](#)

environment variables

- described [A-20](#)
- displaying settings [A-20](#)
- location of [A-21](#)
- setting [A-20](#)
- unsetting [A-24](#)

files

- copying [A-5](#)
- deleting [A-6](#)
- displaying a list of [A-7](#)
- displaying the contents of [A-4, A-16, A-23](#)
- renaming [A-17](#)

file system

- formatting [A-10](#)
- initializing flash [A-9](#)
- running a consistency check [A-11](#)

loading helper images [A-13](#)prompt [A-1](#)resetting the system [A-18](#)boot manual command [2-23](#)boot private-config-file command [2-24](#)boot system command [2-25](#)BPDU filtering, for spanning tree [2-384, 2-422](#)BPDU guard, for spanning tree [2-386, 2-422](#)broadcast storm control [2-431](#)burst bytes, in QoS policers [2-182, 2-188](#)child policy maps [2-216](#)class-based traffic shaping [2-229](#)

class-based weighted fair queuing

See CBWFQ

class command [2-32](#)class-map command [2-34](#)class-map configuration mode [2-35](#)

class maps

- creating [2-34](#)
- defining the match criteria [2-155](#)
- displaying [2-239](#)
- matching in [2-34](#)

class of service

See CoS

clear lacp command [2-38](#)clear mac address-table command [2-39](#)clear pagp command [2-40](#)clear policer cpu uni counters command [2-41](#)clear port-security command [2-42](#)clear spanning-tree counters command [2-44](#)clear spanning-tree detected-protocols command [2-45](#)clear vmps statistics command [2-47](#)command modes defined [1-1](#)committed information rate in QoS policers [2-182, 2-188](#)

configuration, initial

See also getting started guide and hardware installation guide

configuration files

- password recovery disable considerations [A-1](#)
- specifying the name [2-19, 2-24](#)

configuring multiple interfaces [2-80](#)conform-action command [2-48](#)control-plane policer [2-41](#)control-plane policer information, displaying [2-336](#)control-plane security [2-191](#)control plane statistics, clearing [2-41](#)

Ccat (boot loader) command [A-4](#)caution, description [xvi](#)CBWFQ, configuring [2-15](#)channel-group command [2-26](#)channel-protocol command [2-30](#)

conventions

- command [xv](#)
- for examples [xvi](#)
- publication [xv](#)
- text [xv](#)

copy (boot loader) command [A-5](#)

CoS

- as match criteria for QoS groups [2-155](#)
- for QoS classification [2-218](#)
- setting value in policy maps [2-218](#)

CPU ASIC statistics, displaying [2-240](#)

CPU protection policers, displaying [C-16](#)

D

debug dot1x command [B-2](#)

debug etherchannel command [B-3](#)

debug interface command [B-5](#)

debug ip dhcp snooping command [B-4](#)

debug ip igmp filter command [B-6](#)

debug ip igmp max-groups command [B-7](#)

debug ip igmp snooping command [B-8](#)

debug lacp command [B-9](#)

debug mac-notification command [B-10](#)

debug matm command [B-11](#)

debug monitor command [B-12](#)

debug mvrdbg command [B-13](#)

debug nvram command [B-14](#)

debug pagp command [B-15](#)

debug platform acl command [B-16](#)

debug platform cpu-queues command [B-17](#)

debug platform dot1x command [B-19](#)

debug platform etherchannel command [B-20](#)

debug platform forw-tcam command [B-21](#)

debug platform ip dhcp command [B-22](#)

debug platform ip igmp snooping command [B-23](#)

debug platform led command [B-25](#)

debug platform matm command [B-26](#)

debug platform messaging application command [B-27](#)

debug platform phy command [B-28](#)

debug platform pm command [B-30](#)

debug platform policer cpu uni command [B-32](#)

debug platform port-asic command [B-33](#)

debug platform port-security command [B-34](#)

debug platform qos-acl-tcam command [B-35](#)

debug platform remote-commands command [B-36](#)

debug platform resource-manager command [B-37](#)

debug platform snmp command [B-38](#)

debug platform span command [B-39](#)

debug platform supervisor-asic command [B-40](#)

debug platform sw-bridge command [B-41](#)

debug platform tcam command [B-42](#)

debug platform udd command [B-44](#)

debug platform vlan command [B-45](#)

debug pm command [B-46](#)

debug port-security command [B-48](#)

debug qos-manager command [B-49](#)

debug spanning-tree bpdu command [B-52](#)

debug spanning-tree bpdu-opt command [B-53](#)

debug spanning-tree command [B-50](#)

debug spanning-tree mstp command [B-54](#)

debug spanning-tree switch command [B-56](#)

debug sw-vlan command [B-58](#)

debug sw-vlan ifs command [B-60](#)

debug sw-vlan notification command [B-61](#)

debug udd command [B-63](#)

debug vqpc command [B-65](#)

default policer configuration

NNIs [C-18](#)

UNIs [C-17](#)

define interface-range command [2-50](#)

delete (boot loader) command [A-6](#)

delete command [2-52](#)

deny command [2-53](#)

detect mechanism, causes [2-70](#)

DHCP snooping

- accepting untrusted packets from edge switch [2-95](#)
- enabling
 - on a VLAN [2-101](#)
 - option 82 [2-93, 2-95](#)
 - trust on an interface [2-99](#)
- error recovery timer [2-72](#)
- rate limiting [2-98](#)

DHCP snooping binding database

- binding file, configuring [2-91](#)
- bindings
 - adding [2-89](#)
 - deleting [2-89](#)
 - displaying [2-283](#)
- clearing database agent statistics [2-36](#)
- database agent, configuring [2-91](#)
- displaying
 - binding entries [2-283](#)
 - database agent status [2-285, 2-287](#)
- renewing [2-210](#)

differentiated service code point

See DSCP

- dir (boot loader) command [A-7](#)
- directories, deleting [2-52](#)
- documentation, related [xvi](#)
- document conventions [xv](#)
- dot1x default command [2-56](#)
- dot1x host-mode command [2-57](#)
- dot1x initialize command [2-58](#)
- dot1x max-req command [2-59, 2-60](#)
- dot1x port-control command [2-61](#)
- dot1x re-authenticate command [2-63](#)
- dot1x reauthentication command [2-64](#)
- dot1x system-auth-control command [2-65](#)
- dot1x timeout command [2-66](#)
- dropping packets, with ACL matches [2-5](#)

DSCP

- as match criteria for QoS groups [2-156](#)
- for QoS traffic marking [2-220](#)
- setting in policy maps [2-220](#)

duplex command [2-68](#)

dynamic-access ports

- configuring [2-436](#)
- restrictions [2-437](#)

Dynamic Host Configuration Protocol (DHCP)

See DHCP snooping

E

EAP-request/identity frame

- maximum number to send [2-60](#)
- response time before retransmitting [2-66](#)

environment variables, displaying [2-235](#)errdisable detect cause command [2-70](#)errdisable recovery command [2-72](#)error conditions, displaying [2-259](#)error disable detection [2-70](#)error-disabled interfaces, displaying [2-270](#)

EtherChannel

- assigning Ethernet interface to channel group [2-26](#)
- creating port-channel logical interface [2-78](#)
- debug EtherChannel/PAgP, display [B-3](#)
- debug platform-specific events, display [B-20](#)
- displaying [2-263](#)
- interface information, displaying [2-270](#)

LACP

- clearing channel-group information [2-38](#)
- debug messages, display [B-9](#)
- displaying [2-299](#)
- modes [2-26](#)
- port priority for hot-standby ports [2-127](#)
- restricting a protocol [2-30](#)
- system priority [2-129](#)
- load-distribution methods [2-195](#)

EtherChannel (continued)

PAgP

- aggregate-port learner [2-175](#)
- clearing channel-group information [2-40](#)
- debug messages, display [B-15](#)
- displaying [2-331](#)
- error detection for [2-70](#)
- error recovery timer [2-72](#)
- learn method [2-175](#)
- modes [2-26](#)
- physical-port learner [2-175](#)
- priority of interface for transmitted traffic [2-177](#)

Ethernet controller, internal register display [2-242](#)

Ethernet statistics, collecting [2-211](#)

examples, conventions for [xvi](#)

exceed-action command [2-74](#)

extended-range VLANs

- and allowed VLAN list [2-456](#)

- configuring [2-475](#)

extended system ID for STP [2-392](#)

F

fan information, displaying [2-256](#)

files, deleting [2-52](#)

flash_init (boot loader) command [A-9](#)

flowcontrol command [2-76](#)

format (boot loader) command [A-10](#)

forwarding packets, with ACL matches [2-5](#)

forwarding results, display [C-5](#)

frame forwarding information, displaying [C-5](#)

fsck (boot loader) command [A-11](#)

G

global configuration mode [1-2, 1-3](#)

H

hardware ACL statistics [2-231](#)

help (boot loader) command [A-12](#)

host connection, port configuration [2-440](#)

host ports, private VLANs [2-443](#)

I

IEEE 802.1x

- and switchport modes [2-441](#)

- violation error recovery [2-72](#)

See also port-based authentication

IGMP filters

- applying [2-104](#)

- debug messages, display [B-6](#)

IGMP groups, setting maximum [2-106](#)

IGMP maximum groups, debugging [B-7](#)

IGMP profiles

- creating [2-108](#)

- displaying [2-290](#)

IGMP snooping

- adding ports as a static member of a group [2-123](#)

- displaying [2-291, 2-295, 2-297](#)

- enabling [2-110](#)

- enabling the configurable-leave timer [2-112](#)

- enabling the Immediate-Leave feature [2-120](#)

- flooding query count [2-118](#)

- interface topology change notification behavior [2-119](#)

- multicast table [2-293](#)

- querier [2-114](#)

- query solicitation [2-118](#)

- report suppression [2-116](#)

- switch topology change notification behavior [2-118](#)

images

- See software images

Immediate-Leave feature, MVR [2-172](#)

immediate-leave processing [2-120](#)

initial configuration

See also getting started guide and hardware installation guide

input policy maps

and ACL classification [2-154](#)
 and aggregate policers [2-189](#)
 commands not supported in [2-193](#)
 configuration guidelines [2-193](#)

interface command [2-83](#)interface configuration mode [1-2, 1-4](#)interface port-channel command [2-78](#)interface range command [2-80](#)interface-range macros [2-50](#)

interfaces

assigning Ethernet interface to channel group [2-26](#)
 configuring [2-68](#)
 configuring multiple [2-80](#)
 creating port-channel logical [2-78](#)
 debug messages, display [B-5](#)
 disabling [2-373](#)
 displaying the MAC address table [2-315](#)
 restarting [2-373](#)

interface speed, configuring [2-429](#)internal registers, displaying [2-242, 2-249](#)

Internet Group Management Protocol

See IGMP

invalid GBIC

error detection for [2-70](#)
 error recovery timer [2-72](#)

ip address command [2-86](#)IP addresses, setting [2-86](#)IP address matching [2-152](#)

IP DHCP snooping

See DHCP snooping

ip dhcp snooping binding command [2-89](#)ip dhcp snooping command [2-88](#)ip dhcp snooping database command [2-91](#)ip dhcp snooping information option allow-untrusted command [2-95](#)ip dhcp snooping information option command [2-93](#)ip dhcp snooping information option format remote-id command [2-97](#)ip dhcp snooping limit rate command [2-98](#)ip dhcp snooping trust command [2-99](#)ip dhcp snooping verify command [2-100](#)ip dhcp snooping vlan command [2-101](#)ip dhcp snooping vlan information option format-type circuit-id string command [2-102](#)ip igmp filter command [2-104](#)ip igmp max-groups command [2-106](#)ip igmp profile command [2-108](#)ip igmp snooping command [2-110](#)ip igmp snooping last-member-query-interval command [2-112](#)ip igmp snooping querier command [2-114](#)ip igmp snooping report-suppression command [2-116](#)ip igmp snooping tcn command [2-118](#)ip igmp snooping tcn flood command [2-119](#)ip igmp snooping vlan immediate-leave command [2-120](#)ip igmp snooping vlan mrouter command [2-121](#)ip igmp snooping vlan static command [2-123](#)IP multicast addresses [2-169](#)IP precedence, as match criteria for QoS groups [2-158](#)IP source guard, displaying dynamic binding entries [2-283](#)ip ssh command [2-125](#)

J

jumbo frames

See MTU

L

LACP

See EtherChannel

lacp port-priority command [2-127](#)lacp system-priority command [2-129](#)

Layer 2 traceroute

IP addresses [2-466](#)

MAC addresses [2-463](#)

line configuration mode [1-2, 1-4](#)

Link Aggregation Control Protocol

See EtherChannel

link flap

error detection for [2-70](#)

error recovery timer [2-72](#)

load_helper (boot loader) command [A-13](#)

load-distribution methods for EtherChannel [2-195](#)

logging event command [2-131](#)

logging file command [2-132](#)

logical interface [2-78](#)

loopback error

detection for [2-70](#)

recovery timer [2-72](#)

loop guard, for spanning tree [2-394, 2-398](#)

M

mac access-group command [2-134](#)

MAC access-groups, displaying [2-303](#)

MAC access list configuration mode [2-136](#)

mac access-list extended command [2-136](#)

MAC access lists [2-53](#)

MAC addresses

displaying

aging time [2-309](#)

all [2-307](#)

dynamic [2-313](#)

notification settings [2-317](#)

number of addresses in a VLAN [2-311](#)

per interface [2-315](#)

per VLAN [2-321](#)

static [2-319](#)

static and dynamic entries [2-305](#)

MAC addresses (continued)

dynamic

aging time [2-138](#)

deleting [2-39](#)

displaying [2-313](#)

enabling MAC address notification [2-139](#)

matching [2-152](#)

static

adding and removing [2-141](#)

displaying [2-319](#)

dropping on an interface [2-142](#)

tables [2-307](#)

MAC address notification, debugging [B-10](#)

mac address-table aging-time [2-134, 2-152](#)

mac address-table aging-time command [2-138](#)

mac address-table notification command [2-139](#)

mac address-table static command [2-141](#)

mac address-table static drop command [2-142](#)

macro description command [2-146](#)

macro global command [2-147](#)

macro global description command [2-149](#)

macro name command [2-150](#)

macros

adding a description [2-146](#)

adding a global description [2-149](#)

applying [2-147](#)

creating [2-150](#)

displaying [2-333](#)

interface range [2-50, 2-80](#)

specifying parameter values [2-147](#)

tracing [2-147](#)

manual

audience [xv](#)

purpose of [xv](#)

mapping tables, QoS [2-460](#)

maps

class

creating [2-34](#)

VLAN

creating [2-478](#)

defining [2-152](#)

displaying [2-369](#)

match access-group command [2-154](#)

match cos command [2-155](#)

match ip dscp command [2-156](#)

match ip precedence command [2-158](#)

match qos-group command [2-160](#)

maximum transmission unit

See MTU

mdix auto command [2-162](#)

memory (boot loader) command [A-14](#)

mkdir (boot loader) command [A-15](#)

mode, MVR [2-169](#)

modes, commands [1-1](#)

monitor session command [2-164](#)

more (boot loader) command [A-16](#)

MSTP

displaying [2-350](#)

interoperability [2-45](#)

link type [2-396](#)

MST region

aborting changes [2-402](#)

applying changes [2-402](#)

configuration name [2-402](#)

configuration revision number [2-402](#)

current or pending display [2-402](#)

displaying [2-350](#)

MST configuration mode [2-402](#)

VLANs-to-instance mapping [2-402](#)

path cost [2-404](#)

protocol mode [2-400](#)

restart protocol migration process [2-45](#)

MSTP (continued)

root port

loop guard [2-394](#)

preventing from becoming designated [2-394](#)

restricting which can be root [2-394](#)

root guard [2-394](#)

root switch

affects of extended system ID [2-392](#)

hello-time [2-407, 2-418](#)

interval between BDPU messages [2-409](#)

interval between hello BPDU messages [2-407, 2-418](#)

max-age [2-409](#)

maximum hop count before discarding BPDU [2-411](#)

port priority for selection of [2-413](#)

primary or secondary [2-418](#)

switch priority [2-416](#)

state changes

blocking to forwarding state [2-424](#)

enabling BPDU filtering [2-384, 2-422](#)

enabling BPDU guard [2-386, 2-422](#)

enabling Port Fast [2-422, 2-424](#)

forward-delay time [2-406](#)

length of listening and learning states [2-406](#)

rapid transition to forwarding [2-396](#)

shutting down Port Fast-enabled ports [2-422](#)

state information display [2-349](#)

MTU

configuring size [2-458](#)

displaying global setting [2-357](#)

multicast group address, MVR [2-172](#)

multicast groups, MVR [2-170](#)

multicast router learning method [2-121](#)

multicast router ports, configuring [2-121](#)

multicast storm control [2-431](#)

multicast VLAN, MVR [2-169](#)

multicast VLAN registration

See MVR

multiple hosts on authorized port [2-57](#)

Multiple Spanning Tree Protocol

See MSTP

MVR

and address aliasing [2-170](#)

configuring [2-169](#)

configuring interfaces [2-172](#)

debug messages, display [B-13](#)

displaying [2-325](#)

displaying interface information [2-327](#)

members, displaying [2-329](#)

mvr (global configuration) command [2-169](#)

mvr (interface configuration) command [2-172](#)

mvr vlan group command [2-173](#)

N

native VLANs [2-456](#)

network node interface [2-197](#)

nonegotiate, speed [2-429](#), [2-430](#)

non-IP protocols

denying [2-53](#)

forwarding [2-179](#)

non-IP traffic access lists [2-136](#)

non-IP traffic forwarding

denying [2-53](#)

permitting [2-179](#)

normal-range VLANs [2-475](#)

note, description [xvi](#)

no vlan command [2-475](#)

O

output policy maps

and QoS group classification [2-160](#)

and traffic shaping [2-229](#)

commands not supported in [2-193](#)

configuration guidelines [2-193](#)

output policy maps (continued)

priority in [2-200](#)

queue limit in [2-205](#)

P

PAGP

See EtherChannel

pagp learn-method command [2-175](#)

pagp port-priority command [2-177](#)

parent policy maps [2-216](#)

password-recovery mechanism, enabling and disabling [2-212](#)

permit command [2-179](#)

per-VLAN spanning-tree plus

See STP

physical-port learner [2-175](#)

PID, displaying [2-280](#)

PIM-DVMRP, as multicast router learning method [2-121](#)

police

multiple conform actions for a class [2-48](#)

multiple exceed actions for a class [2-74](#)

with priority [2-182](#)

police aggregate command [2-186](#)

police command [2-182](#)

policer aggregate command [2-188](#)

policer configuration

default for NNIs [C-18](#)

default for UNIs [C-17](#)

policer cpu uni command [2-191](#)

policers

aggregate [2-186](#), [2-188](#)

for CPU protection [2-191](#)

individual [2-182](#)

policy-map class, configuring multiple actions [2-48](#), [2-74](#)

policy-map class configuration mode [2-32](#)

policy-map class police configuration mode [2-48](#), [2-184](#)

policy-map command [2-192](#)

policy-map configuration mode [2-192](#)

policy maps

- and CoS classification [2-155](#)
- and DSCP classification [2-156](#)
- and IP precedence classification [2-158](#)
- and policing [2-184](#)
- applying [2-214](#)
- applying to an interface [2-193, 2-214, 2-226](#)
- child [2-216](#)
- creating [2-192](#)
- displaying [2-338](#)
- hierarchical [2-216](#)
- parent [2-216](#)
- policers
 - for a single class [2-182](#)
 - for multiple classes [2-186, 2-188, 2-191, 2-216](#)
- setting priority [2-199](#)
- setting QoS group identifier [2-224](#)
- traffic classification, defining [2-32](#)
- traffic marking
 - setting CoS values [2-218](#)
 - setting DSCP values [2-220](#)
 - setting IP precedence values [2-222](#)

Port Aggregation Protocol

See EtherChannel

port-based authentication

- AAA method list [2-3](#)
- debug messages, display [B-2](#)
- enabling 802.1x
 - globally [2-65](#)
 - per interface [2-61](#)
- host modes [2-57](#)
- IEEE 802.1x AAA accounting methods [2-1](#)
- initialize an interface [2-58](#)
- manual control of authorization state [2-61](#)
- multiple hosts on authorized port [2-57](#)
- periodic re-authentication
 - enabling [2-64](#)
 - time between attempts [2-66](#)

port-based authentication (continued)

- quiet period between failed authentication exchanges [2-66](#)
- re-authenticating 802.1x-enabled ports [2-63](#)
- resetting configurable 802.1x parameters [2-56](#)
- switch-to-authentication server retransmission time [2-66](#)
- switch-to-client frame-retransmission number [2-59 to 2-60](#)
- switch-to-client retransmission time [2-66](#)
- port-channel load-balance command [2-195](#)
- Port Fast, for spanning tree [2-424](#)
- port ranges, defining [2-50](#)
- ports, debugging [B-46](#)
- ports, protected [2-454](#)
- port security
 - aging [2-450](#)
 - debug messages, display [B-48](#)
 - enabling [2-446](#)
 - violation error recovery [2-72](#)
- port shaping [2-230](#)
- port-type command [2-197](#)
- port types, MVR [2-172](#)
- power information, displaying [2-256](#)
- precedence
 - for QoS traffic marking [2-222](#)
 - setting in policy maps [2-222](#)
- priority command [2-199](#)
- priority queuing, QoS [2-199](#)
- priority with police, QoS [2-199](#)
- private-vlan command [2-202](#)
- private VLANs
 - association [2-452](#)
 - configuring [2-202](#)
 - configuring ports [2-443](#)
 - displaying [2-364](#)
 - host ports [2-443](#)
 - mapping
 - configuring [2-452](#)
 - promiscuous ports [2-443](#)

privileged EXEC mode [1-2, 1-3](#)
 product identification information, displaying [2-280](#)
 promiscuous ports, private VLANs [2-443](#)
 PVST+
 See STP

Q

QoS

aggregate policers
 applying [2-186](#)
 creating [2-188](#)
 displaying [2-335](#)
 class maps
 creating [2-34](#)
 defining the match criteria [2-155](#)
 displaying [2-239](#)
 displaying statistics for [2-338, C-24](#)
 policy maps
 applying an aggregate policer [2-186, 2-188, 2-191, 2-216](#)
 applying to an interface [2-214, 2-226](#)
 creating [2-192](#)
 defining policers [2-182](#)
 displaying policy maps [2-338](#)
 setting CoS values [2-218](#)
 setting DSCP values [2-220](#)
 setting IP precedence values [2-222](#)
 setting QoS group identifier [2-224](#)
 traffic classifications [2-32](#)
 table maps
 configuring [2-460](#)
 displaying [2-358](#)
 QoS groups
 as match criteria [2-160](#)
 for QoS traffic classification [2-224](#)
 setting in policy maps [2-224](#)

QoS match criteria
 ACLs [2-154](#)
 CoS value [2-155](#)
 DSCP value [2-156](#)
 precedence value [2-158](#)
 QoS group number [2-160](#)
 quality of service
 See QoS
 querytime, MVR [2-169](#)
 queue-limit command [2-205](#)

R

rapid per-VLAN spanning-tree plus
 See STP
 rapid PVST+
 See STP
 re-authenticating 802.1x-enabled ports [2-63](#)
 re-authentication
 periodic [2-64](#)
 time between attempts [2-66](#)
 receiver ports, MVR [2-172](#)
 receiving flow-control packets [2-76](#)
 recovery mechanism
 causes [2-72](#)
 display [2-237, 2-257, 2-261](#)
 timer interval [2-72](#)
 remote-span command [2-208](#)
 Remote Switched Port Analyzer
 See RSPAN
 rename (boot loader) command [A-17](#)
 renew ip dhcp snooping database command [2-210](#)
 reset (boot loader) command [A-18](#)
 rmdir (boot loader) command [A-19](#)
 rmon collection stats command [2-211](#)
 root guard, for spanning tree [2-394](#)

RSPAN

- configuring [2-164](#)
- displaying [2-323](#)
- filter RSPAN traffic [2-164](#)
- remote-span command [2-208](#)
- sessions
 - add interfaces to [2-164](#)
 - displaying [2-323](#)
 - start new [2-164](#)

S

SDM templates

- displaying [2-347](#)
- secure ports, limitations [2-448](#)
- sending flow-control packets [2-76](#)
- service password-recovery command [2-212](#)
- service policy (policy-map class configuration) command [2-216](#)
- service-policy interface configuration command [2-214](#)
- service-policy policy-map class configuration command [2-216](#)
- set (boot loader) command [A-20](#)
- set cos command [2-218](#)
- set dscp command [2-220](#)
- set precedence command [2-222](#)
- set qos-group command [2-224](#)
- setup command [2-226](#)
- SFPs, displaying information about [2-280](#)
- shape average command [2-229](#)
- show access-lists command [2-231](#)
- show aggregate-policer command [2-358](#)
- show archive status command [2-234](#)
- show boot command [2-235](#)
- show class-map command [2-239](#)
- show controllers cpu-interface command [2-240](#)
- show controllers ethernet-controller command [2-242](#)
- show controllers tcam command [2-249](#)
- show controllers utilization command [2-251](#)

- show controller utilization command [2-251](#)
- show dot1x command [2-253](#)
- show env command [2-256](#)
- show errdisable detect command [2-257](#)
- show errdisable flap-values command [2-259](#)
- show errdisable recovery command [2-261](#)
- show etherchannel command [2-263](#)
- show flowcontrol command [2-266](#)
- show idprom command [2-268](#)
- show interfaces command [2-270](#)
- show interfaces counters command [2-278](#)
- show inventory command [2-280](#)
- show ip dhcp snooping binding command [2-283](#)
- show ip dhcp snooping command [2-282](#)
- show ip dhcp snooping database command [2-285, 2-287](#)
- show ip igmp profile command [2-290](#)
- show ip igmp snooping command [2-291](#)
- show ip igmp snooping command querier detail [2-297](#)
- show ip igmp snooping groups command [2-293](#)
- show ip igmp snooping mrouter command [2-295](#)
- show ip igmp snooping querier command [2-297](#)
- show ip igmp snooping querier detail command [2-297](#)
- show lacp command [2-299](#)
- show mac access-group command [2-303](#)
- show mac address-table address command [2-307](#)
- show mac address-table aging time command [2-309](#)
- show mac address-table command [2-305](#)
- show mac address-table count command [2-311](#)
- show mac address-table dynamic command [2-313](#)
- show mac address-table interface command [2-315](#)
- show mac address-table notification command [2-317](#)
- show mac address-table static command [2-319](#)
- show mac address-table vlan command [2-321](#)
- show monitor command [2-323](#)
- show mvr command [2-325](#)
- show mvr interface command [2-327](#)
- show mvr members command [2-329](#)
- show pagp command [2-331](#)
- show parser macro command [2-333](#)

- show platform acl command [C-2](#)
- show platform configuration command [C-3](#)
- show platform etherchannel command [C-4](#)
- show platform forward command [C-5](#)
- show platform igmp snooping command [C-7](#)
- show platform layer4op command [C-9](#)
- show platform mac-address-table command [C-10](#)
- show platform messaging command [C-11](#)
- show platform monitor command [C-12](#)
- show platform mvr table command [C-13](#)
- show platform pm command [C-14](#)
- show platform policer cpu command [C-16](#)
- show platform port-asic command [C-19](#)
- show platform port-security command [C-23](#)
- show platform qos command [C-24](#)
- show platform resource-manager command [C-27](#)
- show platform snmp counters command [C-29](#)
- show platform spanning-tree synchronization command [C-30](#)
- show platform stp-instance command [C-31](#)
- show platform team command [C-32](#)
- show platform vlan command [C-35](#)
- show policer aggregate command [2-335](#)
- show policer cpu uni command [2-336](#)
- show policy-map command [2-338](#)
- show policy-map interface output fields [2-341](#)
- show port security command [2-342](#)
- show port-type command [2-345](#)
- show sdm prefer command [2-347](#)
- show spanning-tree command [2-349](#)
- show storm-control command [2-355](#)
- show system mtu command [2-357](#)
- show udld command [2-360](#)
- show version command [2-362](#)
- show vlan access-map command [2-369](#)
- show vlan command [2-364](#)
- show vlan command, fields [2-366](#)
- show vlan filter command [2-370](#)
- show vmps command [2-371](#)
- shutdown command [2-373](#)
- shutdown vlan command [2-374](#)
- SNMP host, specifying [2-378](#)
- SNMP informs, enabling the sending of [2-375](#)
- snmp-server enable traps command [2-375](#)
- snmp-server host command [2-378](#)
- snmp trap mac-notification command [2-382](#)
- SNMP traps
 - enabling MAC address notification trap [2-382](#)
 - enabling the MAC address notification feature [2-139](#)
 - enabling the sending of [2-375](#)
- software images
 - deleting [2-52](#)
 - downloading [2-7](#)
 - upgrading [2-7](#)
 - uploading [2-13](#)
- software version, displaying [2-362](#)
- source ports, MVR [2-172](#)
- SPAN
 - configuring [2-164](#)
 - debug messages, display [B-12](#)
 - displaying [2-323](#)
 - filter SPAN traffic [2-164](#)
 - sessions
 - add interfaces to [2-164](#)
 - displaying [2-323](#)
 - start new [2-164](#)
- spanning-tree bpdupfilter command [2-384](#)
- spanning-tree bpduguard command [2-386](#)
- spanning-tree cost command [2-388](#)
- spanning-tree etherchannel command [2-390](#)
- spanning-tree extend system-id command [2-392](#)
- spanning-tree guard command [2-394](#)
- spanning-tree link-type command [2-396](#)
- spanning-tree loopguard default command [2-398](#)
- spanning-tree mode command [2-400](#)
- spanning-tree mst configuration command [2-402](#)
- spanning-tree mst cost command [2-404](#)
- spanning-tree mst forward-time command [2-406](#)

- spanning-tree mst hello-time command [2-407](#)
- spanning-tree mst max-age command [2-409](#)
- spanning-tree mst max-hops command [2-411](#)
- spanning-tree mst port-priority command [2-413](#)
- spanning-tree mst pre-standard command [2-415](#)
- spanning-tree mst priority command [2-416](#)
- spanning-tree mst root command [2-418](#)
- spanning-tree portfast (global configuration) command [2-422](#)
- spanning-tree portfast (interface configuration) command [2-424](#)
- spanning-tree port-priority command [2-420](#)
- Spanning Tree Protocol
 - See STP
- spanning-tree vlan command [2-426](#)
- speed command [2-429](#)
- SSH, configuring version [2-125](#)
- static-access ports, configuring [2-436](#)
- statistics, Ethernet group [2-211](#)
- sticky learning, enabling [2-446](#)
- storm-control command [2-431](#)
- STP
 - counters, clearing [2-44](#)
 - debug messages, display
 - MSTP [B-54](#)
 - optimized BPDUs handling [B-53](#)
 - spanning-tree activity [B-50](#)
 - switch shim [B-56](#)
 - transmitted and received BPDUs [B-52](#)
 - EtherChannel misconfiguration [2-390](#)
 - extended system ID [2-392](#)
 - path cost [2-388](#)
 - protocol modes [2-400](#)
 - root port
 - loop guard [2-394](#)
 - preventing from becoming designated [2-394](#)
 - restricting which can be root [2-394](#)
 - root guard [2-394](#)

STP (continued)

- root switch
 - affects of extended system ID [2-392, 2-427](#)
 - hello-time [2-426](#)
 - interval between BDPU messages [2-426](#)
 - interval between hello BPDU messages [2-426](#)
 - max-age [2-426](#)
 - port priority for selection of [2-420](#)
 - primary or secondary [2-426](#)
 - switch priority [2-426](#)
- state changes
 - blocking to forwarding state [2-424](#)
 - enabling BPDU filtering [2-384, 2-422](#)
 - enabling BPDU guard [2-386, 2-422](#)
 - enabling Port Fast [2-422, 2-424](#)
 - enabling timer to recover from error state [2-72](#)
 - forward-delay time [2-426](#)
 - length of listening and learning states [2-426](#)
 - shutting down Port Fast-enabled ports [2-422](#)
- state information display [2-349](#)
- VLAN options [2-416, 2-426](#)
- Switched Port Analyzer
 - See SPAN
- switching characteristics
 - modifying [2-434](#)
 - returning to interfaces [2-434](#)
- switchport access command [2-436](#)
- switchport block command [2-438](#)
- switchport command [2-434](#)
- switchport host command [2-440](#)
- switchport mode command [2-441](#)
- switchport mode private-vlan command [2-443](#)
- switchport port-security aging command [2-450](#)
- switchport port-security command [2-446](#)
- switchport private-vlan command [2-452](#)
- switchport protected command [2-454](#)
- switchports, displaying [2-270](#)
- switchport trunk command [2-456](#)

system message logging, save message to flash [2-132](#)
 system mtu command [2-458](#)

T

table-map command [2-460](#)
 table-map configuration mode [2-460](#)
 table maps
 configuring [2-460](#)
 displaying [2-358](#)
 QoS [2-460](#)
 tar files, creating, listing, and extracting [2-10](#)
 TDR, running [2-462](#)
 temperature information, displaying [2-256](#)
 test cable-diagnostics tdr command [2-462](#)
 traceroute mac command [2-463](#)
 traceroute mac ip command [2-466](#)
 traffic shaping, QoS [2-229](#)
 trunking, VLAN mode [2-441](#)
 trunk mode [2-441](#)
 trunk ports [2-441](#)
 type (boot loader) command [A-23](#)

U

UDLD
 aggressive mode [2-468, 2-470](#)
 debug messages, display [B-63](#)
 enable globally [2-468](#)
 enable per interface [2-470](#)
 error recovery timer [2-72](#)
 message timer [2-468](#)
 normal mode [2-468, 2-470](#)
 reset a shutdown interface [2-472](#)
 status [2-360](#)
 udd command [2-468](#)
 udd port command [2-470](#)
 udd reset command [2-472](#)

unicast storm control [2-431](#)
 UniDirectional Link Detection
 See UDLD
 uni-vlan command [2-473](#)
 unknown multicast traffic, preventing [2-438](#)
 unknown unicast traffic, preventing [2-438](#)
 unset (boot loader) command [A-24](#)
 upgrading
 software images [2-7](#)
 monitoring status of [2-234](#)
 upgrading information
 See release notes
 user EXEC mode [1-2](#)
 user network interface [2-197](#)

V

version (boot loader) command [A-26](#)
 vlan access-map command [2-478](#)
 VLAN access map configuration mode [2-478](#)
 VLAN access maps
 actions [2-5](#)
 displaying [2-369](#)
 vlan command [2-475](#)
 VLAN configuration mode
 commands [2-475](#)
 description [1-4](#)
 entering [2-475](#)
 summary [1-2](#)
 vlan filter command [2-480](#)
 VLAN filters, displaying [2-370](#)
 VLAN ID range [2-475](#)
 VLAN maps
 applying [2-480](#)
 creating [2-478](#)
 defining [2-152](#)
 displaying [2-369](#)
 VLAN Query Protocol
 See VQP

VLANs

- adding [2-475](#)
- configuring [2-475](#)
- debug messages, display
 - activation of [B-61](#)
 - VLAN IOS file system error tests [B-60](#)
 - VLAN manager activity [B-58](#)
- displaying configurations [2-364](#)
- extended-range [2-475](#)
- MAC addresses
 - displaying [2-321](#)
 - number of [2-311](#)
- normal-range [2-475](#)
- private [2-443](#)
 - configuring [2-202](#)
 - displaying [2-364](#)
 - See also private VLANs
- restarting [2-374](#)
- saving the configuration [2-475](#)
- shutting down [2-374](#)
- suspending [2-374](#)

VMPS

- configuring servers [2-485](#)
- displaying [2-371](#)
- error recovery timer [2-72](#)
- reconfirming dynamic VLAN assignments [2-482](#)
- vmmps reconfirm (global configuration) command [2-483](#)
- vmmps reconfirm (privileged EXEC) command [2-482](#)
- vmmps retry command [2-484](#)
- vmmps server command [2-485](#)

VQP

- and dynamic-access ports [2-437](#)
- clearing client statistics [2-47](#)
- displaying information [2-371](#)
- per-server retry count [2-484](#)
- reconfirmation interval [2-483](#)
- reconfirming dynamic VLAN assignments [2-482](#)

W

Weighted Tail Drop

See WTD

WTD, queue-limit command [2-205](#)