



INDEX

A

aaa accounting dot1x command [2-1](#)
aaa authentication dot1x command [2-3](#)
AAA methods [2-3](#)
access control entries
 See ACEs
access control lists
 See ACLs
access groups
 IP [2-89](#)
 MAC, displaying [2-309](#)
 matching for QoS classification [2-159](#)
access mode [2-452](#)
access ports [2-452](#)
ACEs [2-55, 2-186](#)
ACLs
 as match criteria for QoS classes [2-159](#)
 deny [2-53](#)
 displaying [2-237](#)
 for non-IP protocols [2-141](#)
 IP [2-89](#)
 on Layer 2 interfaces [2-89](#)
 permit [2-184](#)
action command [2-5](#)
address aliasing [2-175](#)
aggregate policers
 applying [2-191](#)
 creating [2-193](#)
 displaying [2-341](#)
 QoS [2-194](#)
aggregate-port learner [2-180](#)
allowed VLANs [2-467](#)

archive download-sw command [2-7](#)
archive tar command [2-10](#)
archive upload-sw command [2-13](#)
attaching policy maps to interfaces [2-220](#)
audience [xv](#)
authorization state of controlled port [2-61](#)
autonegotiation of duplex mode [2-71](#)

B

bandwidth, configuring for QoS [2-15](#)
bandwidth command [2-15](#)
boot (boot loader) command [A-2](#)
boot bootlpr command [2-18](#)
boot config-file command [2-19](#)
boot enable-break command [2-20](#)
boot helper command [2-21](#)
boot helper-config file command [2-22](#)
booting
 Cisco IOS image [2-25](#)
 displaying environment variables [2-241](#)
 interrupting [2-20](#)
 manually [2-23](#)
boot loader
 accessing [A-1](#)
 booting
 Cisco IOS image [A-2](#)
 helper image [2-21](#)
 directories
 creating [A-14](#)
 displaying a list of [A-7](#)
 removing [A-18](#)

boot loader (continued)

displaying

- available commands [A-12](#)
- memory heap utilization [A-13](#)
- version [A-25](#)

environment variables

- described [A-19](#)
- displaying settings [A-19](#)
- location of [A-20](#)
- setting [A-19](#)
- unsetting [A-23](#)

files

- copying [A-5](#)
- deleting [A-6](#)
- displaying a list of [A-7](#)
- displaying the contents of [A-4, A-15, A-22](#)
- renaming [A-16](#)

file system

- formatting [A-10](#)
- initializing flash [A-9](#)
- running a consistency check [A-11](#)

prompt [A-1](#)resetting the system [A-17](#)boot manual command [2-23](#)boot private-config-file command [2-24](#)boot system command [2-25](#)BPDU filtering, for spanning tree [2-394, 2-432](#)BPDU guard, for spanning tree [2-396, 2-432](#)broadcast storm control [2-442](#)burst bytes, in QoS policers [2-187, 2-193](#)

Ccat (boot loader) command [A-4](#)caution, description [xvi](#)CBWFQ, configuring [2-15](#)channel-group command [2-26](#)channel-protocol command [2-30](#)child policy maps [2-222](#)class-based traffic shaping [2-235](#)

class-based weighted fair queuing

See CBWFQ

class command [2-32](#)class-map command [2-34](#)class-map configuration mode [2-35](#)

class maps

- creating [2-34](#)
- defining the match criteria [2-160](#)
- displaying [2-245](#)
- matching in [2-34](#)

class of service

See CoS

clear lacp command [2-38](#)clear mac address-table command [2-39](#)clear pagp command [2-40](#)clear policer cpu uni-eni counters command [2-41](#)clear port-security command [2-42](#)clear spanning-tree counters command [2-44](#)clear spanning-tree detected-protocols command [2-45](#)clear vmps statistics command [2-47](#)command modes defined [1-1](#)committed information rate in QoS policers [2-187, 2-193](#)

configuration, initial

See also getting started guide and hardware installation guide

configuration files

- password recovery disable considerations [A-1](#)
- specifying the name [2-19, 2-24](#)

configuring multiple interfaces [2-85](#)conform-action command [2-48](#)control-plane policer [2-41](#)control-plane policer information, displaying [2-342](#)control-plane security [2-196](#)control plane statistics, clearing [2-41](#)

conventions

- command [xvi](#)
- for examples [xvi](#)
- publication [xvi](#)
- text [xvi](#)

copy (boot loader) command [A-5](#)

CoS

- as match criteria for QoS groups [2-160](#)
- for QoS classification [2-224](#)
- setting value in policy maps [2-224](#)

CPU ASIC statistics, displaying [2-246](#)

CPU protection policers, displaying [C-16](#)

D

debug dot1x command [B-2](#)

debug etherchannel command [B-3](#)

debug interface command [B-4](#)

debug ip igmp filter command [B-5](#)

debug ip igmp max-groups command [B-6](#)

debug ip igmp snooping command [B-7](#)

debug lacp command [B-8](#)

debug mac-notification command [B-9](#)

debug matm command [B-10](#)

debug monitor command [B-11](#)

debug mvrdbg command [B-12](#)

debug nvram command [B-13](#)

debug pagp command [B-14](#)

debug platform acl command [B-15](#)

debug platform cpu-queues command [B-16](#)

debug platform dot1x command [B-18](#)

debug platform etherchannel command [B-19](#)

debug platform forw-tcam command [B-20](#)

debug platform ip dhcp command [B-21](#)

debug platform ip igmp snooping command [B-22](#)

debug platform led command [B-24](#)

debug platform matm command [B-25](#)

debug platform messaging application command [B-26](#)

debug platform phy command [B-27](#)

debug platform pm command [B-29](#)

debug platform policer cpu uni-eni command [B-31](#)

debug platform port-asic command [B-32](#)

debug platform port-security command [B-33](#)

debug platform qos-acl-tcam command [B-34](#)

debug platform remote-commands command [B-35](#)

debug platform resource-manager command [B-36](#)

debug platform snmp command [B-37](#)

debug platform span command [B-38](#)

debug platform supervisor-asic command [B-39](#)

debug platform sw-bridge command [B-40](#)

debug platform tcam command [B-41](#)

debug platform udd command [B-43](#)

debug platform vlan command [B-44](#)

debug pm command [B-45](#)

debug port-security command [B-47](#)

debug qos-manager command [B-48](#)

debug spanning-tree bpdu command [B-51](#)

debug spanning-tree bpdu-opt command [B-52](#)

debug spanning-tree command [B-49](#)

debug spanning-tree mstp command [B-53](#)

debug spanning-tree switch command [B-55](#)

debug sw-vlan command [B-57](#)

debug sw-vlan ifs command [B-58](#)

debug sw-vlan notification command [B-59](#)

debug udd command [B-61](#)

debug vqpc command [B-63](#)

default

policer configuration

NNIs [C-18](#)

UNIs [C-17](#)

define interface-range command [2-50](#)

delete (boot loader) command [A-6](#)

delete command [2-52](#)

deny command [2-53](#)

detect mechanism, causes [2-72](#)

DHCP snooping

- accepting untrusted packets from edge switch [2-100](#)
- enabling
 - on a VLAN [2-106](#)
 - option 82 [2-98, 2-100](#)
 - trust on an interface [2-104](#)
- error recovery timer [2-77](#)
- rate limiting [2-103](#)

DHCP snooping binding database

- binding file, configuring [2-96](#)
- bindings
 - adding [2-94](#)
 - deleting [2-94](#)
 - displaying [2-289](#)
- clearing database agent statistics [2-36](#)
- database agent, configuring [2-96](#)
- displaying
 - binding entries [2-289](#)
 - database agent status [2-291, 2-293](#)
- renewing [2-215](#)

differentiated service code point

- See DSCP

dir (boot loader) command [A-7](#)

directories, deleting [2-52](#)

documentation, related [xvi](#)

document conventions [xvi](#)

dot1x default command [2-56](#)

dot1x host-mode command [2-57](#)

dot1x initialize command [2-58](#)

dot1x max-req command [2-59, 2-60](#)

dot1x port-control command [2-61](#)

dot1x re-authenticate command [2-63](#)

dot1x reauthentication command [2-64](#)

dot1x system-auth-control command [2-65](#)

dot1x test eapol-capable command [2-66](#)

dot1x test timeout command [2-67](#)

dot1x timeout command [2-68](#)

dropping packets, with ACL matches [2-5](#)

DSCP

- as match criteria for QoS groups [2-161](#)
- for QoS traffic marking [2-226](#)
- setting in policy maps [2-226](#)

duplex command [2-70](#)

dynamic-access ports

- configuring [2-447](#)
- restrictions [2-448](#)

Dynamic Host Configuration Protocol (DHCP)

- See DHCP snooping

E

EAP-request/identity frame

- maximum number to send [2-60](#)
- response time before retransmitting [2-68](#)

environment variables, displaying [2-241](#)

errdisable detect cause command [2-72](#)

errdisable detect cause small-frame comand [2-74](#)

errdisable recovery cause small-frame [2-76](#)

errdisable recovery command [2-77](#)

error conditions, displaying [2-265](#)

error disable detection [2-72](#)

error-disabled interfaces, displaying [2-276](#)

EtherChannel

- assigning Ethernet interface to channel group [2-26](#)
- creating port-channel logical interface [2-83](#)
- debug EtherChannel/PAGP, display [B-3](#)
- debug platform-specific events, display [B-19](#)
- displaying [2-269](#)
- interface information, displaying [2-276](#)

LACP

- clearing channel-group information [2-38](#)
- debug messages, display [B-8](#)
- displaying [2-305](#)
- modes [2-26](#)
- port priority for hot-standby ports [2-132](#)
- restricting a protocol [2-30](#)
- system priority [2-134](#)

EtherChannel (continued)

load-distribution methods [2-200](#)

PAgP

aggregate-port learner [2-180](#)

clearing channel-group information [2-40](#)

debug messages, display [B-14](#)

displaying [2-337](#)

error detection for [2-72](#)

error recovery timer [2-77](#)

learn method [2-180](#)

modes [2-26](#)

physical-port learner [2-180](#)

priority of interface for transmitted traffic [2-182](#)

Ethernet controller, internal register display [2-248](#)

Ethernet statistics, collecting [2-217](#)

examples, conventions for [xvi](#)

exceed-action command [2-79](#)

extended-range VLANs

and allowed VLAN list [2-467](#)

configuring [2-486](#)

extended system ID for STP [2-402](#)

F

fan information, displaying [2-262](#)

files, deleting [2-52](#)

flash_init (boot loader) command [A-9](#)

flowcontrol command [2-81](#)

format (boot loader) command [A-10](#)

forwarding packets, with ACL matches [2-5](#)

forwarding results, display [C-5](#)

frame forwarding information, displaying [C-5](#)

fsck (boot loader) command [A-11](#)

G

global configuration mode [1-2, 1-3](#)

H

hardware ACL statistics [2-237](#)

help (boot loader) command [A-12](#)

host connection, port configuration [2-451](#)

host ports, private VLANs [2-454](#)

I

IEEE 802.1x

and switchport modes [2-453](#)

violation error recovery [2-77](#)

See also port-based authentication

IGMP filters

applying [2-109](#)

debug messages, display [B-5](#)

IGMP groups, setting maximum [2-111](#)

IGMP maximum groups, debugging [B-6](#)

IGMP profiles

creating [2-113](#)

displaying [2-296](#)

IGMP snooping

adding ports as a static member of a group [2-128](#)

displaying [2-297, 2-301, 2-303](#)

enabling [2-115](#)

enabling the configurable-leave timer [2-117](#)

enabling the Immediate-Leave feature [2-125](#)

flooding query count [2-123](#)

interface topology change notification behavior [2-124](#)

multicast table [2-299](#)

querier [2-119](#)

query solicitation [2-123](#)

report suppression [2-121](#)

switch topology change notification behavior [2-123](#)

images

See software images

Immediate-Leave feature, MVR [2-177](#)

immediate-leave processing [2-125](#)

initial configuration

See also getting started guide and hardware installation guide

input policy maps

and ACL classification [2-159](#)
 and aggregate policers [2-194](#)
 commands not supported in [2-198](#)
 configuration guidelines [2-198](#)

interface command [2-88](#)interface configuration mode [1-2, 1-4](#)interface port-channel command [2-83](#)interface range command [2-85](#)interface-range macros [2-50](#)

interfaces

assigning Ethernet interface to channel group [2-26](#)
 configuring [2-70](#)
 configuring multiple [2-85](#)
 creating port-channel logical [2-83](#)
 debug messages, display [B-4](#)
 disabling [2-379](#)
 displaying the MAC address table [2-321](#)
 restarting [2-379](#)

interface speed, configuring [2-440](#)internal registers, displaying [2-248, 2-255](#)

Internet Group Management Protocol

See IGMP

invalid GBIC

error detection for [2-72](#)
 error recovery timer [2-77](#)

ip address command [2-91](#)IP addresses, setting [2-91](#)IP address matching [2-157](#)

IP DHCP snooping

See DHCP snooping

ip dhcp snooping binding command [2-94](#)ip dhcp snooping command [2-93](#)ip dhcp snooping database command [2-96](#)ip dhcp snooping information option allow-untrusted command [2-100](#)ip dhcp snooping information option command [2-98](#)ip dhcp snooping information option format remote-id command [2-102](#)ip dhcp snooping limit rate command [2-103](#)ip dhcp snooping trust command [2-104](#)ip dhcp snooping verify command [2-105](#)ip dhcp snooping vlan command [2-106](#)ip dhcp snooping vlan information option format-type circuit-id string command [2-107](#)ip igmp filter command [2-109](#)ip igmp max-groups command [2-111](#)ip igmp profile command [2-113](#)ip igmp snooping command [2-115](#)ip igmp snooping last-member-query-interval command [2-117](#)ip igmp snooping querier command [2-119](#)ip igmp snooping report-suppression command [2-121](#)ip igmp snooping tcn command [2-123](#)ip igmp snooping tcn flood command [2-124](#)ip igmp snooping vlan immediate-leave command [2-125](#)ip igmp snooping vlan mrouter command [2-126](#)ip igmp snooping vlan static command [2-128](#)IP multicast addresses [2-174](#)IP precedence, as match criteria for QoS groups [2-163](#)IP source guard, displaying dynamic binding entries [2-289](#)ip ssh command [2-130](#)

J

jumbo frames

See MTU

L

LACP

See EtherChannel

lacp port-priority command [2-132](#)lacp system-priority command [2-134](#)

Layer 2 traceroute

- IP addresses [2-477](#)
- MAC addresses [2-474](#)

line configuration mode [1-2, 1-4](#)

Link Aggregation Control Protocol

- See EtherChannel

link flap

- error detection for [2-72](#)
- error recovery timer [2-77](#)

load-distribution methods for EtherChannel [2-200](#)

logging event command [2-136](#)

logging file command [2-137](#)

logical interface [2-83](#)

loopback error

- detection for [2-72](#)
- recovery timer [2-77](#)

loop guard, for spanning tree [2-404, 2-408](#)

M

mac access-group command [2-139](#)

MAC access-groups, displaying [2-309](#)

MAC access list configuration mode [2-141](#)

mac access-list extended command [2-141](#)

MAC access lists [2-53](#)

MAC addresses

- displaying
 - aging time [2-315](#)
 - all [2-313](#)
 - dynamic [2-319](#)
 - notification settings [2-323](#)
 - number of addresses in a VLAN [2-317](#)
 - per interface [2-321](#)
 - per VLAN [2-327](#)
 - static [2-325](#)
 - static and dynamic entries [2-311](#)

MAC addresses (continued)

- dynamic
 - aging time [2-143](#)
 - deleting [2-39](#)
 - displaying [2-319](#)
 - enabling MAC address notification [2-144](#)
 - matching [2-157](#)
- static
 - adding and removing [2-146](#)
 - displaying [2-325](#)
 - dropping on an interface [2-147](#)
- tables [2-313](#)

MAC address notification, debugging [B-9](#)

mac address-table aging-time [2-139, 2-157](#)

mac address-table aging-time command [2-143](#)

mac address-table notification command [2-144](#)

mac address-table static command [2-146](#)

mac address-table static drop command [2-147](#)

macro description command [2-151](#)

macro global command [2-152](#)

macro global description command [2-154](#)

macro name command [2-155](#)

macros

- adding a description [2-151](#)
- adding a global description [2-154](#)
- applying [2-152](#)
- creating [2-155](#)
- displaying [2-339](#)
- interface range [2-50, 2-85](#)
- specifying parameter values [2-152](#)
- tracing [2-152](#)

manual

- audience [xv](#)
- purpose of [xv](#)

mapping tables, QoS [2-471](#)

maps

class

- creating [2-34](#)

VLAN

- creating [2-489](#)

- defining [2-157](#)

- displaying [2-374](#)

match access-group command [2-159](#)

match cos command [2-160](#)

match ip dscp command [2-161](#)

match ip precedence command [2-163](#)

match qos-group command [2-165](#)

maximum transmission unit

- See MTU

mdix auto command [2-167](#)

memory (boot loader) command [A-13](#)

mkdir (boot loader) command [A-14](#)

mode, MVR [2-174](#)

modes, commands [1-1](#)

monitor session command [2-169](#)

more (boot loader) command [A-15](#)

MSTP

- displaying [2-355](#)

- interoperability [2-45](#)

- link type [2-406](#)

MST region

- aborting changes [2-412](#)

- applying changes [2-412](#)

- configuration name [2-412](#)

- configuration revision number [2-413](#)

- current or pending display [2-413](#)

- displaying [2-355](#)

- MST configuration mode [2-412](#)

- VLANs-to-instance mapping [2-412](#)

- path cost [2-414](#)

- protocol mode [2-410](#)

- restart protocol migration process [2-45](#)

MSTP (continued)

root port

- loop guard [2-404](#)

- preventing from becoming designated [2-404](#)

- restricting which can be root [2-404](#)

- root guard [2-404](#)

root switch

- affects of extended system ID [2-402](#)

- hello-time [2-417, 2-428](#)

- interval between BDPU messages [2-419](#)

- interval between hello BPDU messages [2-417, 2-428](#)

- max-age [2-419](#)

- maximum hop count before discarding BPDU [2-421](#)

- port priority for selection of [2-423](#)

- primary or secondary [2-428](#)

- switch priority [2-426](#)

state changes

- blocking to forwarding state [2-435](#)

- enabling BPDU filtering [2-394, 2-432](#)

- enabling BPDU guard [2-396, 2-432](#)

- enabling Port Fast [2-432, 2-435](#)

- forward-delay time [2-416](#)

- length of listening and learning states [2-416](#)

- rapid transition to forwarding [2-406](#)

- shutting down Port Fast-enabled ports [2-432](#)

- state information display [2-354](#)

MTU

- configuring size [2-469](#)

- displaying global setting [2-362](#)

multicast group address, MVR [2-177](#)

multicast groups, MVR [2-175](#)

multicast router learning method [2-126](#)

multicast router ports, configuring [2-126](#)

multicast storm control [2-442](#)

multicast VLAN, MVR [2-174](#)

multicast VLAN registration

- See MVR

multiple hosts on authorized port [2-57](#)

Multiple Spanning Tree Protocol

See MSTP

MVR

and address aliasing [2-175](#)

configuring [2-174](#)

configuring interfaces [2-177](#)

debug messages, display [B-12](#)

displaying [2-331](#)

displaying interface information [2-333](#)

members, displaying [2-335](#)

mvr (global configuration) command [2-174](#)

mvr (interface configuration) command [2-177](#)

mvr vlan group command [2-178](#)

N

native VLANs [2-467](#)

network node interface [2-202](#)

nonegotiate, speed [2-440, 2-441](#)

non-IP protocols

denying [2-53](#)

forwarding [2-184](#)

non-IP traffic access lists [2-141](#)

non-IP traffic forwarding

denying [2-53](#)

permitting [2-184](#)

normal-range VLANs [2-486](#)

note, description [xvi](#)

no vlan command [2-486](#)

O

output policy maps

and QoS group classification [2-165](#)

and traffic shaping [2-235](#)

commands not supported in [2-198](#)

configuration guidelines [2-198](#)

output policy maps (continued)

priority in [2-205](#)

queue limit in [2-210](#)

P

PAGP

See EtherChannel

pagp learn-method command [2-180](#)

pagp port-priority command [2-182](#)

parent policy maps [2-222](#)

password-recovery mechanism, enabling and disabling [2-218](#)

permit command [2-184](#)

per-VLAN spanning-tree plus

See STP

physical-port learner [2-180](#)

PID, displaying [2-286](#)

PIM-DVMRP, as multicast router learning method [2-126](#)

police

multiple conform actions for a class [2-48](#)

multiple exceed actions for a class [2-79](#)

with priority [2-187](#)

police aggregate command [2-191](#)

police command [2-187](#)

policer aggregate command [2-193](#)

policer configuration

default for NNIs [C-18](#)

default for UNIs [C-17](#)

policer cpu uni command [2-196](#)

policers

aggregate [2-191, 2-193](#)

for CPU protection [2-196](#)

individual [2-187](#)

policy-map class, configuring multiple actions [2-48, 2-79](#)

policy-map class configuration mode [2-32](#)

policy-map class police configuration mode [2-48, 2-189](#)

policy-map command [2-197](#)

policy-map configuration mode [2-197](#)

policy maps

- and CoS classification [2-160](#)
- and DSCP classification [2-161](#)
- and IP precedence classification [2-163](#)
- and policing [2-189](#)
- applying [2-220](#)
- applying to an interface [2-198, 2-220, 2-232](#)
- child [2-222](#)
- creating [2-197](#)
- displaying [2-344](#)
- hierarchical [2-222](#)
- parent [2-222](#)
- policers
 - for a single class [2-187](#)
 - for multiple classes [2-191, 2-193, 2-196, 2-222](#)
- setting priority [2-204](#)
- setting QoS group identifier [2-230](#)
- traffic classification, defining [2-32](#)
- traffic marking
 - setting CoS values [2-224](#)
 - setting DSCP values [2-226](#)
 - setting IP precedence values [2-228](#)

Port Aggregation Protocol

See EtherChannel

port-based authentication

- AAA method list [2-3](#)
- debug messages, display [B-2](#)
- enabling 802.1x
 - globally [2-65](#)
 - per interface [2-61](#)
- host modes [2-57](#)
- IEEE 802.1x AAA accounting methods [2-1](#)
- initialize an interface [2-58, 2-67](#)
- manual control of authorization state [2-61](#)
- multiple hosts on authorized port [2-57](#)
- periodic re-authentication
 - enabling [2-64](#)
 - time between attempts [2-68](#)

port-based authentication (continued)

- quiet period between failed authentication exchanges [2-68](#)
- re-authenticating 802.1x-enabled ports [2-63](#)
- resetting configurable 802.1x parameters [2-56](#)
- switch-to-authentication server retransmission time [2-68](#)
- switch-to-client frame-retransmission number [2-59 to 2-60](#)
- switch-to-client retransmission time [2-68](#)
- test for IEEE 802.1x readiness [2-66](#)
- port-channel load-balance command [2-200](#)
- Port Fast, for spanning tree [2-435](#)
- port ranges, defining [2-50](#)
- ports, debugging [B-45](#)
- ports, protected [2-465](#)
- port security
 - aging [2-461](#)
 - debug messages, display [B-47](#)
 - enabling [2-457](#)
 - violation error recovery [2-77](#)
- port shaping [2-236](#)
- port-type command [2-202](#)
- port types, MVR [2-177](#)
- power information, displaying [2-262](#)
- precedence
 - for QoS traffic marking [2-228](#)
 - setting in policy maps [2-228](#)
- priority command [2-204](#)
- priority queuing, QoS [2-204](#)
- priority with police, QoS [2-204](#)
- private-vlan command [2-207](#)
- private VLANs
 - association [2-463](#)
 - configuring [2-207](#)
 - configuring ports [2-454](#)
 - displaying [2-369](#)
 - host ports [2-454](#)

private VLANs (continued)

- mapping
 - configuring [2-463](#)
 - promiscuous ports [2-454](#)
- privileged EXEC mode [1-2, 1-3](#)
- product identification information, displaying [2-286](#)
- promiscuous ports, private VLANs [2-454](#)
- PVST+
 - See STP

Q**QoS**

- aggregate policers
 - applying [2-191](#)
 - creating [2-193](#)
 - displaying [2-341](#)
- class maps
 - creating [2-34](#)
 - defining the match criteria [2-160](#)
 - displaying [2-245](#)
- displaying statistics for [2-344, C-24](#)
- policy maps
 - applying an aggregate policer [2-191, 2-193, 2-196, 2-222](#)
 - applying to an interface [2-220, 2-232](#)
 - creating [2-197](#)
 - defining policers [2-187](#)
 - displaying policy maps [2-344](#)
 - setting CoS values [2-224](#)
 - setting DSCP values [2-226](#)
 - setting IP precedence values [2-228](#)
 - setting QoS group identifier [2-230](#)
 - traffic classifications [2-32](#)
- table maps
 - configuring [2-471](#)
 - displaying [2-363](#)

- QoS groups
 - as match criteria [2-165](#)
 - for QoS traffic classification [2-230](#)
 - setting in policy maps [2-230](#)
- QoS match criteria
 - ACLs [2-159](#)
 - CoS value [2-160](#)
 - DSCP value [2-161](#)
 - precedence value [2-163](#)
 - QoS group number [2-165](#)
- quality of service
 - See QoS
- querytime, MVR [2-174](#)
- queue-limit command [2-210](#)

R

- rapid per-VLAN spanning-tree plus
 - See STP
- rapid PVST+
 - See STP
- re-authenticating 802.1x-enabled ports [2-63](#)
- re-authentication
 - periodic [2-64](#)
 - time between attempts [2-68](#)
- receiver ports, MVR [2-177](#)
- receiving flow-control packets [2-81](#)
- recovery mechanism
 - causes [2-77](#)
 - display [2-243, 2-263, 2-267](#)
 - timer interval [2-77](#)
- remote-span command [2-213](#)
- Remote Switched Port Analyzer
 - See RSPAN
- rename (boot loader) command [A-16](#)
- renew ip dhcp snooping database command [2-215](#)
- reset (boot loader) command [A-17](#)
- rmdir (boot loader) command [A-18](#)
- rmon collection stats command [2-217](#)

root guard, for spanning tree [2-404](#)

RSPAN

- configuring [2-169](#)
- displaying [2-329](#)
- filter RSPAN traffic [2-169](#)
- remote-span command [2-213](#)
- sessions
 - add interfaces to [2-169](#)
 - displaying [2-329](#)
 - start new [2-169](#)

S

SDM templates

- displaying [2-353](#)

secure ports, limitations [2-459](#)

sending flow-control packets [2-81](#)

service password-recovery command [2-218](#)

service policy (policy-map class configuration) command [2-222](#)

service-policy interface configuration command [2-220](#)

service-policy policy-map class configuration command [2-222](#)

set (boot loader) command [A-19](#)

set cos command [2-224](#)

set dscp command [2-226](#)

set precedence command [2-228](#)

set qos-group command [2-230](#)

setup command [2-232](#)

SFPs, displaying information about [2-286](#)

shape average command [2-235](#)

show access-lists command [2-237](#)

show aggregate-policer command [2-363](#)

show archive status command [2-240](#)

show boot command [2-241](#)

show class-map command [2-245](#)

show controllers cpu-interface command [2-246](#)

show controllers ethernet-controller command [2-248](#)

show controllers tcam command [2-255](#)

show controllers utilization command [2-257](#)

show controller utilization command [2-257](#)

show dot1x command [2-259](#)

show env command [2-262](#)

show errdisable detect command [2-263](#)

show errdisable flap-values command [2-265](#)

show errdisable recovery command [2-267](#)

show etherchannel command [2-269](#)

show flowcontrol command [2-272](#)

show idprom command [2-274](#)

show interfaces command [2-276](#)

show interfaces counters command [2-284](#)

show inventory command [2-286](#)

show ip dhcp snooping binding command [2-289](#)

show ip dhcp snooping command [2-288](#)

show ip dhcp snooping database command [2-291, 2-293](#)

show ip igmp profile command [2-296](#)

show ip igmp snooping command [2-297](#)

show ip igmp snooping command querier detail [2-303](#)

show ip igmp snooping groups command [2-299](#)

show ip igmp snooping mrouter command [2-301](#)

show ip igmp snooping querier command [2-303](#)

show ip igmp snooping querier detail command [2-303](#)

show lacp command [2-305](#)

show location [2-309](#)

show mac access-group command [2-309](#)

show mac address-table address command [2-313](#)

show mac address-table aging time command [2-315](#)

show mac address-table command [2-311](#)

show mac address-table count command [2-317](#)

show mac address-table dynamic command [2-319](#)

show mac address-table interface command [2-321](#)

show mac address-table notification command [2-323](#)

show mac address-table static command [2-325](#)

show mac address-table vlan command [2-327](#)

show monitor command [2-329](#)

show mvr command [2-331](#)

show mvr interface command [2-333](#)

show mvr members command [2-335](#)

- show pagp command [2-337](#)
- show parser macro command [2-339](#)
- show platform acl command [C-2](#)
- show platform configuration command [C-3](#)
- show platform etherchannel command [C-4](#)
- show platform forward command [C-5](#)
- show platform igmp snooping command [C-7](#)
- show platform layer4op command [C-9](#)
- show platform mac-address-table command [C-10](#)
- show platform messaging command [C-11](#)
- show platform monitor command [C-12](#)
- show platform mvr table command [C-13](#)
- show platform pm command [C-14](#)
- show platform policer cpu command [C-16](#)
- show platform port-asic command [C-19](#)
- show platform port-security command [C-23](#)
- show platform qos command [C-24](#)
- show platform resource-manager command [C-27](#)
- show platform snmp counters command [C-29](#)
- show platform spanning-tree synchronization command [C-30](#)
- show platform stp-instance command [C-31](#)
- show platform tcam command [C-32](#)
- show platform vlan command [C-35](#)
- show policer aggregate command [2-341](#)
- show policer cpu uni-eni command [2-342](#)
- show policy-map command [2-344](#)
- show policy-map interface output fields [2-347](#)
- show port security command [2-348](#)
- show port-type command [2-351](#)
- show sdm prefer command [2-353](#)
- show spanning-tree command [2-354](#)
- show storm-control command [2-360](#)
- show system mtu command [2-362](#)
- show udd command [2-365](#)
- show version command [2-367](#)
- show vlan access-map command [2-374](#)
- show vlan command [2-369](#)
- show vlan command, fields [2-371](#)
- show vlan filter command [2-375](#)
- show vmps command [2-377](#)
- shutdown command [2-379](#)
- shutdown vlan command [2-380](#)
- small violation-rate command [2-381](#)
- SNMP host, specifying [2-386](#)
- SNMP informs, enabling the sending of [2-383](#)
- snmp-server enable traps command [2-383](#)
- snmp-server host command [2-386](#)
- snmp trap mac-notification command [2-390](#)
- SNMP traps
 - enabling MAC address notification trap [2-390](#)
 - enabling the MAC address notification feature [2-144](#)
 - enabling the sending of [2-383](#)
- software images
 - deleting [2-52](#)
 - downloading [2-7](#)
 - upgrading [2-7](#)
 - uploading [2-13](#)
- software version, displaying [2-367](#)
- source ports, MVR [2-177](#)
- SPAN
 - configuring [2-169](#)
 - debug messages, display [B-11](#)
 - displaying [2-329](#)
 - filter SPAN traffic [2-169](#)
 - sessions
 - add interfaces to [2-169](#)
 - displaying [2-329](#)
 - start new [2-169](#)
- spanning-tree bpdupfilter command [2-392, 2-394](#)
- spanning-tree bpduguard command [2-396](#)
- spanning-tree cost command [2-398](#)
- spanning-tree etherchannel command [2-400](#)
- spanning-tree extend system-id command [2-402](#)
- spanning-tree guard command [2-404](#)
- spanning-tree link-type command [2-406](#)
- spanning-tree loopguard default command [2-408](#)
- spanning-tree mode command [2-410](#)

- spanning-tree mst configuration command [2-412](#)
- spanning-tree mst cost command [2-414](#)
- spanning-tree mst forward-time command [2-416](#)
- spanning-tree mst hello-time command [2-417](#)
- spanning-tree mst max-age command [2-419](#)
- spanning-tree mst max-hops command [2-421](#)
- spanning-tree mst port-priority command [2-423](#)
- spanning-tree mst pre-standard command [2-425](#)
- spanning-tree mst priority command [2-426](#)
- spanning-tree mst root command [2-428](#)
- spanning-tree portfast (global configuration) command [2-432](#)
- spanning-tree portfast (interface configuration) command [2-435](#)
- spanning-tree port-priority command [2-430](#)
- Spanning Tree Protocol
 - See STP
- spanning-tree vlan command [2-437](#)
- speed command [2-440](#)
- SSH, configuring version [2-130](#)
- static-access ports, configuring [2-447](#)
- statistics, Ethernet group [2-217](#)
- sticky learning, enabling [2-457](#)
- storm-control command [2-442](#)
- STP
 - counters, clearing [2-44](#)
 - debug messages, display
 - MSTP [B-53](#)
 - optimized BPDUs handling [B-52](#)
 - spanning-tree activity [B-49](#)
 - switch shim [B-55](#)
 - transmitted and received BPDUs [B-51](#)
 - enabling on ENIs [2-392](#)
 - EtherChannel misconfiguration [2-400](#)
 - extended system ID [2-402](#)
 - path cost [2-398](#)
 - protocol modes [2-410](#)

STP (continued)

- root port
 - loop guard [2-404](#)
 - preventing from becoming designated [2-404](#)
 - restricting which can be root [2-404](#)
 - root guard [2-404](#)
- root switch
 - affects of extended system ID [2-402, 2-438](#)
 - hello-time [2-437](#)
 - interval between BPDU messages [2-437](#)
 - interval between hello BPDU messages [2-437](#)
 - max-age [2-437](#)
 - port priority for selection of [2-430](#)
 - primary or secondary [2-437](#)
 - switch priority [2-437](#)
- state changes
 - blocking to forwarding state [2-435](#)
 - enabling BPDU filtering [2-394, 2-432](#)
 - enabling BPDU guard [2-396, 2-432](#)
 - enabling Port Fast [2-432, 2-435](#)
 - enabling timer to recover from error state [2-77](#)
 - forward-delay time [2-437](#)
 - length of listening and learning states [2-437](#)
 - shutting down Port Fast-enabled ports [2-432](#)
- state information display [2-354](#)
- VLAN options [2-426, 2-437](#)
- Switched Port Analyzer
 - See SPAN
- switching characteristics
 - modifying [2-445](#)
 - returning to interfaces [2-445](#)
- switchport access command [2-447](#)
- switchport block command [2-449](#)
- switchport command [2-445](#)
- switchport host command [2-451](#)
- switchport mode command [2-452](#)
- switchport mode private-vlan command [2-454](#)

switchport port-security aging command [2-461](#)
 switchport port-security command [2-457](#)
 switchport private-vlan command [2-463](#)
 switchport protected command [2-465](#)
 switchports, displaying [2-276](#)
 switchport trunk command [2-467](#)
 system message logging, save message to flash [2-137](#)
 system mtu command [2-469](#)

T

table-map command [2-471](#)
 table-map configuration mode [2-471](#)
 table maps
 configuring [2-471](#)
 displaying [2-363](#)
 QoS [2-471](#)
 tar files, creating, listing, and extracting [2-10](#)
 TDR, running [2-473](#)
 temperature information, displaying [2-262](#)
 test cable-diagnostics tdr command [2-473](#)
 traceroute mac command [2-474](#)
 traceroute mac ip command [2-477](#)
 traffic shaping, QoS [2-235](#)
 trunking, VLAN mode [2-452](#)
 trunk mode [2-452](#)
 trunk ports [2-452](#)
 type (boot loader) command [A-22](#)

U

UDLD

aggressive mode [2-479, 2-481](#)
 debug messages, display [B-61](#)
 enable globally [2-479](#)
 enable per interface [2-481](#)
 error recovery timer [2-77](#)
 message timer [2-479](#)

UDLD (continued)

normal mode [2-479, 2-481](#)
 reset a shutdown interface [2-483](#)
 status [2-365](#)
 udd command [2-479](#)
 udd port command [2-481](#)
 udd reset command [2-483](#)
 unicast storm control [2-442](#)
 UniDirectional Link Detection
 See UDLD
 uni-vlan command [2-484](#)
 unknown multicast traffic, preventing [2-449](#)
 unknown unicast traffic, preventing [2-449](#)
 unset (boot loader) command [A-23](#)
 upgrading
 software images [2-7](#)
 monitoring status of [2-240](#)
 upgrading information
 See release notes
 user EXEC mode [1-2](#)
 user network interface [2-202](#)

V

version (boot loader) command [A-25](#)
 vlan access-map command [2-489](#)
 VLAN access map configuration mode [2-489](#)
 VLAN access maps
 actions [2-5](#)
 displaying [2-374](#)
 vlan command [2-486](#)
 VLAN configuration mode
 commands [2-486](#)
 description [1-4](#)
 entering [2-486](#)
 summary [1-2](#)
 vlan filter command [2-491](#)

VLAN filters, displaying [2-375](#)

VLAN ID range [2-486](#)

VLAN maps

applying [2-491](#)

creating [2-489](#)

defining [2-157](#)

displaying [2-374](#)

VLAN Query Protocol

See VQP

VLANs

adding [2-486](#)

configuring [2-486](#)

debug messages, display

activation of [B-59](#)

VLAN IOS file system error tests [B-58](#)

VLAN manager activity [B-57](#)

displaying configurations [2-369](#)

extended-range [2-486](#)

MAC addresses

displaying [2-327](#)

number of [2-317](#)

normal-range [2-486](#)

private [2-454](#)

configuring [2-207](#)

displaying [2-369](#)

See also private VLANs

restarting [2-380](#)

saving the configuration [2-486](#)

shutting down [2-380](#)

suspending [2-380](#)

VMPS

configuring servers [2-496](#)

displaying [2-377](#)

error recovery timer [2-77](#)

reconfirming dynamic VLAN assignments [2-493](#)

vmips reconfirm (global configuration) command [2-494](#)

vmips reconfirm (privileged EXEC) command [2-493](#)

vmips retry command [2-495](#)

vmips server command [2-496](#)

VQP

and dynamic-access ports [2-448](#)

clearing client statistics [2-47](#)

displaying information [2-377](#)

per-server retry count [2-495](#)

reconfirmation interval [2-494](#)

reconfirming dynamic VLAN assignments [2-493](#)

W

Weighted Tail Drop

See WTD

WTD, queue-limit command [2-210](#)