



INDEX

A

aaa accounting dot1x command [1](#)
aaa authentication dot1x command [3](#)
AAA methods [3](#)
access control entries
 See ACEs
access control lists
 See ACLs
access groups
 IP [89](#)
 MAC, displaying [306](#)
 matching for QoS classification [159](#)
access mode [448](#)
access ports [448](#)
ACEs [54, 185](#)
ACLs
 as match criteria for QoS classes [159](#)
 deny [52](#)
 displaying [235](#)
 for non-IP protocols [141](#)
 IP [89](#)
 on Layer 2 interfaces [89](#)
 permit [183](#)
action command [5](#)
address aliasing [174](#)
aggregate policers
 applying [190](#)
 creating [192](#)
 displaying [338](#)
 QoS [193](#)
aggregate-port learner [179](#)
allowed VLANs [463](#)

archive download-sw command [7](#)
archive tar command [10](#)
archive upload-sw command [13](#)
attaching policy maps to interfaces [218](#)
authorization state of controlled port [61](#)
autonegotiation of duplex mode [72](#)

B

bandwidth, configuring for QoS [15](#)
bandwidth command [15](#)
boot (boot loader) command [2](#)
boot config-file command [18](#)
boot enable-break command [19](#)
boot helper command [20](#)
boot helper-config file command [21](#)
booting
 Cisco IOS image [24](#)
 displaying environment variables [239](#)
 interrupting [19](#)
 manually [22](#)
boot loader
 accessing [1](#)
 booting
 Cisco IOS image [2](#)
 helper image [20](#)
 directories
 creating [14](#)
 displaying a list of [7](#)
 removing [18](#)
 displaying
 available commands [12](#)
 memory heap utilization [13](#)
 version [25](#)

boot loader (continued)

environment variables

- described 19
- displaying settings 19
- location of 20
- setting 19
- unsetting 23

files

- copying 5
- deleting 6
- displaying a list of 7
- displaying the contents of 4, 15, 22
- renaming 16

file system

- formatting 10
- initializing flash 9
- running a consistency check 11

prompt 1

resetting the system 17

boot manual command 22

boot private-config-file command 23

boot system command 24

BPDU filtering, for spanning tree 390, 428

BPDU guard, for spanning tree 392, 428

broadcast storm control 438

burst bytes, in QoS policers 186, 192

C

cat (boot loader) command 4

CBWFQ, configuring 15

channel-group command 25

channel-protocol command 29

child policy maps 220

class-based traffic shaping 233

class-based weighted fair queuing

See CBWFQ

class command 31

class-map command 33

class-map configuration mode 33

class maps

- creating 33
- defining the match criteria 160
- displaying 243
- matching in 33

class of service

See CoS

clear lacp command 37

clear mac address-table command 38

clear pagp command 39

clear policer cpu uni-eni counters command 40

clear port-security command 41

clear spanning-tree counters command 43

clear spanning-tree detected-protocols command 44

clear vmps statistics command 46

command modes defined 1

committed information rate in QoS policers 186, 192

configuration files

- password recovery disable considerations 1
- specifying the name 18, 23

configuring multiple interfaces 86

conform-action command 47

control-plane policer 40

control-plane policer information, displaying 339

control-plane security 195

control plane statistics, clearing 40

copy (boot loader) command 5

CoS

- as match criteria for QoS groups 160
- for QoS classification 222
- setting value in policy maps 222

CPU ASIC statistics, displaying 244

CPU protection policers, displaying 15

D

debug dot1x command 2

debug etherchannel command 3

- debug interface command 4
- debug ip igmp filter command 5
- debug ip igmp max-groups command 6
- debug ip igmp snooping command 7
- debug lacp command 8
- debug mac-notification command 9
- debug matm command 10
- debug monitor command 11
- debug mvrdbg command 12
- debug nvram command 13
- debug pagp command 14
- debug platform acl command 15
- debug platform cpu-queues command 16
- debug platform dot1x command 18
- debug platform etherchannel command 19
- debug platform forw-tcam command 20
- debug platform ip dhcp command 21
- debug platform ip igmp snooping command 22
- debug platform led command 24
- debug platform matm command 25
- debug platform messaging application command 26
- debug platform phy command 27
- debug platform pm command 29
- debug platform policer cpu uni-eni command 31
- debug platform port-asic command 32
- debug platform port-security command 33
- debug platform qos-acl-tcam command 34
- debug platform remote-commands command 35
- debug platform resource-manager command 36
- debug platform snmp command 37
- debug platform span command 38
- debug platform supervisor-asic command 39
- debug platform sw-bridge command 40
- debug platform tcam command 41
- debug platform udd command 43
- debug platform vlan command 44
- debug pm command 45
- debug port-security command 47
- debug qos-manager command 48
- debug spanning-tree bpdu command 51
- debug spanning-tree bpdu-opt command 52
- debug spanning-tree command 49
- debug spanning-tree mstp command 53
- debug spanning-tree switch command 55
- debug sw-vlan command 57
- debug sw-vlan ifs command 58
- debug sw-vlan notification command 59
- debug udd command 61
- debug vqpc command 63
- default policer configuration
 - NNIs 17
 - UNIs 16
- define interface-range command 49
- delete (boot loader) command 6
- delete command 51
- deny command 52
- detect mechanism, causes 73
- DHCP snooping
 - accepting untrusted packets from edge switch 100
 - enabling
 - on a VLAN 106
 - option 82 98, 100
 - trust on an interface 104
 - error recovery timer 77
 - rate limiting 103
- DHCP snooping binding database
 - binding file, configuring 96
 - bindings
 - adding 94
 - deleting 94
 - displaying 286
 - clearing database agent statistics 35
 - database agent, configuring 96
 - displaying
 - binding entries 286
 - database agent status 288, 290
 - renewing 214

differentiated service code point

See DSCP

dir (boot loader) command 7

directories, deleting 51

dot1x default command 55

dot1x host-mode command 56

dot1x initialize command 58

dot1x max-req command 59, 60

dot1x port-control command 61

dot1x re-authenticate command 63

dot1x reauthentication command 64

dot1x system-auth-control command 65

dot1x test eapol-capable command 66

dot1x test timeout command 67

dot1x timeout command 68

dot1x violation-mode command 70

dropping packets, with ACL matches 5

DSCP

as match criteria for QoS groups 161

for QoS traffic marking 224

setting in policy maps 224

duplex command 71

dynamic-access ports

configuring 443

restrictions 444

Dynamic Host Configuration Protocol (DHCP)

See DHCP snooping

E

EAP-request/identity frame

maximum number to send 60

response time before retransmitting 68

environment variables, displaying 239

errdisable detect cause command 73

errdisable detect cause small-frame command 75

errdisable recovery cause small-frame 79

errdisable recovery command 77

error conditions, displaying 263

error disable detection 73

error-disabled interfaces, displaying 274

EtherChannel

assigning Ethernet interface to channel group 25

creating port-channel logical interface 84

debug EtherChannel/PAgP, display 3

debug platform-specific events, display 19

displaying 267

interface information, displaying 274

LACP

clearing channel-group information 37

debug messages, display 8

displaying 302

modes 25

port priority for hot-standby ports 132

restricting a protocol 29

system priority 134

load-distribution methods 199

PAgP

aggregate-port learner 179

clearing channel-group information 39

debug messages, display 14

displaying 334

error detection for 73

error recovery timer 77

learn method 179

modes 25

physical-port learner 179

priority of interface for transmitted traffic 181

Ethernet controller, internal register display 246

Ethernet statistics, collecting 215

exceed-action command 80

extended-range VLANs

and allowed VLAN list 463

configuring 482

extended system ID for STP 398

F

fan information, displaying [260](#)
 files, deleting [51](#)
 flash_init (boot loader) command [9](#)
 flowcontrol command [82](#)
 format (boot loader) command [10](#)
 forwarding packets, with ACL matches [5](#)
 forwarding results, display [5](#)
 frame forwarding information, displaying [5](#)
 fsck (boot loader) command [11](#)

G

global configuration mode [2, 3](#)

H

hardware ACL statistics [235](#)
 help (boot loader) command [12](#)
 host connection, port configuration [447](#)
 host ports, private VLANs [450](#)

I

IEEE 802.1x
 and switchport modes [448](#)
 violation error recovery [77](#)
 See also port-based authentication
 IGMP filters
 applying [109](#)
 debug messages, display [5](#)
 IGMP groups, setting maximum [111](#)
 IGMP maximum groups, debugging [6](#)
 IGMP profiles
 creating [113](#)
 displaying [293](#)

IGMP snooping

adding ports as a static member of a group [128](#)
 displaying [294, 298, 300](#)
 enabling [115](#)
 enabling the configurable-leave timer [117](#)
 enabling the Immediate-Leave feature [125](#)
 flooding query count [123](#)
 interface topology change notification behavior [124](#)
 multicast table [296](#)
 querier [119](#)
 query solicitation [123](#)
 report suppression [121](#)
 switch topology change notification behavior [123](#)

images

See software images

Immediate-Leave feature, MVR [176](#)

immediate-leave processing [125](#)

input policy maps

and ACL classification [159](#)
 and aggregate policers [193](#)
 commands not supported in [197](#)
 configuration guidelines [197](#)

interface command [88](#)

interface configuration mode [2, 4](#)

interface port-channel command [84](#)

interface range command [86](#)

interface-range macros [49](#)

interfaces

assigning Ethernet interface to channel group [25](#)
 configuring [71](#)
 configuring multiple [86](#)
 creating port-channel logical [84](#)
 debug messages, display [4](#)
 disabling [375](#)
 displaying the MAC address table [318](#)
 restarting [375](#)

interface speed, configuring [436](#)

internal registers, displaying [246, 253](#)

Internet Group Management Protocol

See IGMP

invalid GBIC

- error detection for [73](#)
- error recovery timer [77](#)

ip address command [91](#)IP addresses, setting [91](#)IP address matching [157](#)

IP DHCP snooping

- See DHCP snooping

ip dhcp snooping binding command [94](#)ip dhcp snooping command [93](#)ip dhcp snooping database command [96](#)ip dhcp snooping information option allow-untrusted command [100](#)ip dhcp snooping information option command [98](#)ip dhcp snooping information option format remote-id command [102](#)ip dhcp snooping limit rate command [103](#)ip dhcp snooping trust command [104](#)ip dhcp snooping verify command [105](#)ip dhcp snooping vlan command [106](#)ip dhcp snooping vlan information option format-type circuit-id string command [107](#)ip igmp filter command [109](#)ip igmp max-groups command [111](#)ip igmp profile command [113](#)ip igmp snooping command [115](#)ip igmp snooping last-member-query-interval command [117](#)ip igmp snooping querier command [119](#)ip igmp snooping report-suppression command [121](#)ip igmp snooping tcn command [123](#)ip igmp snooping tcn flood command [124](#)ip igmp snooping vlan immediate-leave command [125](#)ip igmp snooping vlan mrouter command [126](#)ip igmp snooping vlan static command [128](#)IP multicast addresses [173](#)IP precedence, as match criteria for QoS groups [163](#)IP source guard, displaying dynamic binding entries [286](#)ip ssh command [130](#)

J

jumbo frames

- See MTU

L

LACP

- See EtherChannel

lacp port-priority command [132](#)lacp system-priority command [134](#)

Layer 2 traceroute

- IP addresses [473](#)

- MAC addresses [470](#)

line configuration mode [2, 4](#)

Link Aggregation Control Protocol

- See EtherChannel

link flap

- error detection for [73](#)

- error recovery timer [77](#)

load-distribution methods for EtherChannel [199](#)logging event command [136](#)logging file command [137](#)logical interface [84](#)

loopback error

- detection for [73](#)

- recovery timer [77](#)

loop guard, for spanning tree [400, 404](#)

Mmac access-group command [139](#)MAC access-groups, displaying [306](#)MAC access list configuration mode [141](#)mac access-list extended command [141](#)MAC access lists [52](#)

MAC addresses

displaying

aging time [312](#)all [310](#)dynamic [316](#)notification settings [320](#)number of addresses in a VLAN [314](#)per interface [318](#)per VLAN [324](#)static [322](#)static and dynamic entries [308](#)

dynamic

aging time [143](#)deleting [38](#)displaying [316](#)enabling MAC address notification [144](#)matching [157](#)

static

adding and removing [146](#)displaying [322](#)dropping on an interface [147](#)tables [310](#)MAC address notification, debugging [9](#)mac address-table aging-time [139, 157](#)mac address-table aging-time command [143](#)mac address-table notification command [144](#)mac address-table static command [146](#)mac address-table static drop command [147](#)macro description command [151](#)macro global command [152](#)macro global description command [154](#)macro name command [155](#)

macros

adding a description [151](#)adding a global description [154](#)applying [152](#)creating [155](#)displaying [336](#)interface range [49, 86](#)specifying parameter values [152](#)tracing [152](#)mapping tables, QoS [467](#)

maps

class

creating [33](#)

VLAN

creating [485](#)defining [157](#)displaying [371](#)match access-group command [159](#)match cos command [160](#)match ip dscp command [161](#)match ip precedence command [163](#)match qos-group command [165](#)

maximum transmission unit

See MTU

mdix auto command [167](#)memory (boot loader) command [13](#)mkdir (boot loader) command [14](#)mode, MVR [173](#)modes, commands [1](#)monitor session command [169](#)more (boot loader) command [15](#)

MSTP

- displaying [353](#)
- interoperability [44](#)
- link type [402](#)
- MST region
 - aborting changes [408](#)
 - applying changes [408](#)
 - configuration name [408](#)
 - configuration revision number [409](#)
 - current or pending display [409](#)
 - displaying [353](#)
 - MST configuration mode [408](#)
 - VLANs-to-instance mapping [408](#)
- path cost [410](#)
- protocol mode [406](#)
- restart protocol migration process [44](#)
- root port
 - loop guard [400](#)
 - preventing from becoming designated [400](#)
 - restricting which can be root [400](#)
 - root guard [400](#)
- root switch
 - affects of extended system ID [398](#)
 - hello-time [413, 424](#)
 - interval between BDPU messages [415](#)
 - interval between hello BPDU messages [413, 424](#)
 - max-age [415](#)
 - maximum hop count before discarding BPDU [417](#)
 - port priority for selection of [419](#)
 - primary or secondary [424](#)
 - switch priority [422](#)

MSTP (continued)

- state changes
 - blocking to forwarding state [431](#)
 - enabling BPDU filtering [390, 428](#)
 - enabling BPDU guard [392, 428](#)
 - enabling Port Fast [428, 431](#)
 - forward-delay time [412](#)
 - length of listening and learning states [412](#)
 - rapid transition to forwarding [402](#)
 - shutting down Port Fast-enabled ports [428](#)
 - state information display [352](#)
- MTU
- configuring size [465](#)
 - displaying global setting [360](#)
- multicast group address, MVR [176](#)
- multicast groups, MVR [174](#)
- multicast router learning method [126](#)
- multicast router ports, configuring [126](#)
- multicast storm control [438](#)
- multicast VLAN, MVR [173](#)
- multicast VLAN registration
- See MVR
- multiple hosts on authorized port [56](#)
- Multiple Spanning Tree Protocol
- See MSTP
- MVR
- and address aliasing [174](#)
 - configuring [173](#)
 - configuring interfaces [176](#)
 - debug messages, display [12](#)
 - displaying [328](#)
 - displaying interface information [330](#)
 - members, displaying [332](#)
- mvr (global configuration) command [173](#)
- mvr (interface configuration) command [176](#)
- mvr vlan group command [177](#)

N

native VLANs [463](#)
network node interface [201](#)
nonegotiate, speed [436, 437](#)
non-IP protocols
 denying [52](#)
 forwarding [183](#)
non-IP traffic access lists [141](#)
non-IP traffic forwarding
 denying [52](#)
 permitting [183](#)
normal-range VLANs [482](#)
no vlan command [482](#)

O

output policy maps
 and QoS group classification [165](#)
 and traffic shaping [233](#)
 commands not supported in [197](#)
 configuration guidelines [197](#)
 priority in [204](#)
 queue limit in [209](#)

P

PAgP
 See EtherChannel
pagp learn-method command [179](#)
pagp port-priority command [181](#)
parent policy maps [220](#)
password-recovery mechanism, enabling and disabling [216](#)
permit command [183](#)
per-VLAN spanning-tree plus
 See STP
physical-port learner [179](#)
PID, displaying [284](#)

PIM-DVMRP, as multicast router learning method [126](#)

police

 multiple conform actions for a class [47](#)
 multiple exceed actions for a class [80](#)
 with priority [186](#)

police aggregate command [190](#)

police command [186](#)

policer aggregate command [192](#)

policer configuration

 default for NNIs [17](#)
 default for UNIs [16](#)

policer cpu uni command [195](#)

policers

 aggregate [190, 192](#)
 for CPU protection [195](#)
 individual [186](#)

policy-map class, configuring multiple actions [47, 80](#)

policy-map class configuration mode [31](#)

policy-map class police configuration mode [47, 188](#)

policy-map command [196](#)

policy-map configuration mode [196](#)

policy maps

 and CoS classification [160](#)
 and DSCP classification [161](#)
 and IP precedence classification [163](#)
 and policing [188](#)

 applying [218](#)

 applying to an interface [197, 218, 230](#)

 child [220](#)

 creating [196](#)

 displaying [342](#)

 hierarchical [220](#)

 parent [220](#)

 policers

 for a single class [186](#)

 for multiple classes [190, 192, 195, 220](#)

 setting priority [203](#)

 setting QoS group identifier [228](#)

 traffic classification, defining [31](#)

policy maps (continued)

- traffic marking
 - setting CoS values [222](#)
 - setting DSCP values [224](#)
 - setting IP precedence values [226](#)

Port Aggregation Protocol

See EtherChannel

port-based authentication

- AAA method list [3](#)
- configuring violation modes [70](#)
- debug messages, display [2](#)
- enabling 802.1x
 - globally [65](#)
 - per interface [61](#)
- host modes [56](#)
- IEEE 802.1x AAA accounting methods [1](#)
- initialize an interface [58, 67](#)
- manual control of authorization state [61](#)
- multiple hosts on authorized port [56](#)
- periodic re-authentication
 - enabling [64](#)
 - time between attempts [68](#)
- quiet period between failed authentication exchanges [68](#)
- re-authenticating 802.1x-enabled ports [63](#)
- resetting configurable 802.1x parameters [55](#)
- switch-to-authentication server retransmission time [68](#)
- switch-to-client frame-retransmission number [59 to 60](#)
- switch-to-client retransmission time [68](#)
- test for IEEE 802.1x readiness [66](#)

port-channel load-balance command [199](#)

Port Fast, for spanning tree [431](#)

port ranges, defining [49](#)

ports, debugging [45](#)

ports, protected [461](#)

port security

- aging [457](#)
- debug messages, display [47](#)
- enabling [453](#)
- violation error recovery [77](#)

port shaping [234](#)

port-type command [201](#)

port types, MVR [176](#)

power information, displaying [260](#)

precedence

- for QoS traffic marking [226](#)
- setting in policy maps [226](#)

priority command [203](#)

priority queuing, QoS [203](#)

priority with police, QoS [203](#)

private-vlan command [206](#)

private VLANs

- association [459](#)
- configuring [206](#)
- configuring ports [450](#)
- displaying [367](#)
- host ports [450](#)
- mapping
 - configuring [459](#)
- promiscuous ports [450](#)

privileged EXEC mode [2, 3](#)

product identification information, displaying [284](#)

promiscuous ports, private VLANs [450](#)

PVST+

See STP

Q

QoS

aggregate policers

- applying [190](#)
- creating [192](#)
- displaying [338](#)

class maps

- creating [33](#)
- defining the match criteria [160](#)
- displaying [243](#)

displaying statistics for [342, 23](#)

policy maps

- applying an aggregate policer [190, 192, 195, 220](#)
- applying to an interface [218, 230](#)
- creating [196](#)
- defining policers [186](#)
- displaying policy maps [342](#)
- setting CoS values [222](#)
- setting DSCP values [224](#)
- setting IP precedence values [226](#)
- setting QoS group identifier [228](#)
- traffic classifications [31](#)

table maps

- configuring [467](#)
- displaying [361](#)

QoS groups

- as match criteria [165](#)
- for QoS traffic classification [228](#)
- setting in policy maps [228](#)

QoS match criteria

- ACLs [159](#)
- CoS value [160](#)
- DSCP value [161](#)
- precedence value [163](#)
- QoS group number [165](#)

quality of service

See QoS

querytime, MVR [173](#)

queue-limit command [209](#)

R

rapid per-VLAN spanning-tree plus

See STP

rapid PVST+

See STP

re-authenticating 802.1x-enabled ports [63](#)

re-authentication

- periodic [64](#)
- time between attempts [68](#)

receiver ports, MVR [176](#)

receiving flow-control packets [82](#)

recovery mechanism

- causes [77](#)
- display [241, 261, 265](#)
- timer interval [77](#)

remote-span command [212](#)

Remote Switched Port Analyzer

See RSPAN

rename (boot loader) command [16](#)

renew ip dhcp snooping database command [214](#)

reset (boot loader) command [17](#)

rmdir (boot loader) command [18](#)

rmon collection stats command [215](#)

root guard, for spanning tree [400](#)

RSPAN

- configuring [169](#)
- displaying [326](#)
- filter RSPAN traffic [169](#)
- remote-span command [212](#)
- sessions
 - add interfaces to [169](#)
 - displaying [326](#)
 - start new [169](#)

S

SDM templates

displaying 351

secure ports, limitations 455

sending flow-control packets 82

service password-recovery command 216

service policy (policy-map class configuration) command 220

service-policy interface configuration command 218

service-policy policy-map class configuration command 220

set (boot loader) command 19

set cos command 222

set dscp command 224

set precedence command 226

set qos-group command 228

setup command 230

SFPs, displaying information about 284

shape average command 233

show access-lists command 235

show aggregate-policer command 361

show archive status command 238

show boot command 239

show class-map command 243

show controllers cpu-interface command 244

show controllers ethernet-controller command 246

show controllers team command 253

show controllers utilization command 255

show controller utilization command 255

show dot1x command 257

show env command 260

show errdisable detect command 261

show errdisable flap-values command 263

show errdisable recovery command 265

show etherchannel command 267

show flowcontrol command 270

show idprom command 272

show interfaces command 274

show interfaces counters command 282

show inventory command 284

show ip dhcp snooping binding command 286

show ip dhcp snooping command 285

show ip dhcp snooping database command 288, 290

show ip igmp profile command 293

show ip igmp snooping command 294

show ip igmp snooping command querier detail 300

show ip igmp snooping groups command 296

show ip igmp snooping mrouter command 298

show ip igmp snooping querier command 300

show ip igmp snooping querier detail command 300

show lacp command 302

show mac access-group command 306

show mac address-table address command 310

show mac address-table aging time command 312

show mac address-table command 308

show mac address-table count command 314

show mac address-table dynamic command 316

show mac address-table interface command 318

show mac address-table notification command 320

show mac address-table static command 322

show mac address-table vlan command 324

show monitor command 326

show mvr command 328

show mvr interface command 330

show mvr members command 332

show pagp command 334

show parser macro command 336

show platform acl command 2

show platform configuration command 3

show platform etherchannel command 4

show platform forward command 5

show platform igmp snooping command 7

show platform layer4op command 9

show platform mac-address-table command 10

show platform messaging command 11

show platform monitor command 12

show platform mvr table command 13

- show platform pm command [14](#)
- show platform policer cpu command [15](#)
- show platform port-asic command [18](#)
- show platform port-security command [22](#)
- show platform qos command [23](#)
- show platform resource-manager command [26](#)
- show platform snmp counters command [28](#)
- show platform spanning-tree synchronization command [29](#)
- show platform stp-instance command [30](#)
- show platform tcam command [31](#)
- show platform vlan command [33](#)
- show policer aggregate command [338](#)
- show policer cpu uni-eni command [339](#)
- show policy-map command [342](#)
- show policy-map interface output fields [345](#)
- show port security command [346](#)
- show port-type command [349](#)
- show sdm prefer command [351](#)
- show spanning-tree command [352](#)
- show storm-control command [358](#)
- show system mtu command [360](#)
- show udd command [363](#)
- show version command [365](#)
- show vlan access-map command [371](#)
- show vlan command [367](#)
- show vlan command, fields [369](#)
- show vlan filter command [372](#)
- show vmpls command [373](#)
- shutdown command [375](#)
- shutdown vlan command [376](#)
- small violation-rate command [377](#)
- SNMP host, specifying [382](#)
- SNMP informs, enabling the sending of [379](#)
- snmp-server enable traps command [379](#)
- snmp-server host command [382](#)
- snmp trap mac-notification command [386](#)

SNMP traps

- enabling MAC address notification trap [386](#)
- enabling the MAC address notification feature [144](#)
- enabling the sending of [379](#)

software images

- deleting [51](#)
- downloading [7](#)
- upgrading [7](#)
- uploading [13](#)

software version, displaying [365](#)

source ports, MVR [176](#)

SPAN

- configuring [169](#)
- debug messages, display [11](#)
- displaying [326](#)
- filter SPAN traffic [169](#)
- sessions
 - add interfaces to [169](#)
 - displaying [326](#)
 - start new [169](#)

spanning-tree bpdupfilter command [388, 390](#)

spanning-tree bpduguard command [392](#)

spanning-tree cost command [394](#)

spanning-tree etherchannel command [396](#)

spanning-tree extend system-id command [398](#)

spanning-tree guard command [400](#)

spanning-tree link-type command [402](#)

spanning-tree loopguard default command [404](#)

spanning-tree mode command [406](#)

spanning-tree mst configuration command [408](#)

spanning-tree mst cost command [410](#)

spanning-tree mst forward-time command [412](#)

spanning-tree mst hello-time command [413](#)

spanning-tree mst max-age command [415](#)

spanning-tree mst max-hops command [417](#)

spanning-tree mst port-priority command [419](#)

spanning-tree mst pre-standard command [421](#)

spanning-tree mst priority command [422](#)

spanning-tree mst root command [424](#)

spanning-tree portfast (global configuration)
command [428](#)

spanning-tree portfast (interface configuration)
command [431](#)

spanning-tree port-priority command [426](#)

Spanning Tree Protocol

See STP

spanning-tree vlan command [433](#)

speed command [436](#)

SSH, configuring version [130](#)

static-access ports, configuring [443](#)

statistics, Ethernet group [215](#)

sticky learning, enabling [453](#)

storm-control command [438](#)

STP

counters, clearing [43](#)

debug messages, display

MSTP [53](#)

optimized BPDUs handling [52](#)

spanning-tree activity [49](#)

switch shim [55](#)

transmitted and received BPDUs [51](#)

enabling on ENIs [388](#)

EtherChannel misconfiguration [396](#)

extended system ID [398](#)

path cost [394](#)

protocol modes [406](#)

root port

loop guard [400](#)

preventing from becoming designated [400](#)

restricting which can be root [400](#)

root guard [400](#)

STP (continued)

root switch

affects of extended system ID [398, 434](#)

hello-time [433](#)

interval between BDPU messages [433](#)

interval between hello BPDU messages [433](#)

max-age [433](#)

port priority for selection of [426](#)

primary or secondary [433](#)

switch priority [433](#)

state changes

blocking to forwarding state [431](#)

enabling BPDU filtering [390, 428](#)

enabling BPDU guard [392, 428](#)

enabling Port Fast [428, 431](#)

enabling timer to recover from error state [77](#)

forward-delay time [433](#)

length of listening and learning states [433](#)

shutting down Port Fast-enabled ports [428](#)

state information display [352](#)

VLAN options [422, 433](#)

Switched Port Analyzer

See SPAN

switching characteristics

modifying [441](#)

returning to interfaces [441](#)

switchport access command [443](#)

switchport block command [445](#)

switchport command [441](#)

switchport host command [447](#)

switchport mode command [448](#)

switchport mode private-vlan command [450](#)

switchport port-security aging command [457](#)

switchport port-security command [453](#)

switchport private-vlan command [459](#)

switchport protected command [461](#)

switchports, displaying [274](#)
 switchport trunk command [463](#)
 system message logging, save message to flash [137](#)
 system mtu command [465](#)

T

table-map command [467](#)
 table-map configuration mode [467](#)
 table maps
 configuring [467](#)
 displaying [361](#)
 QoS [467](#)
 tar files, creating, listing, and extracting [10](#)
 TDR, running [469](#)
 temperature information, displaying [260](#)
 test cable-diagnostics tdr command [469](#)
 traceroute mac command [470](#)
 traceroute mac ip command [473](#)
 traffic shaping, QoS [233](#)
 trunking, VLAN mode [448](#)
 trunk mode [448](#)
 trunk ports [448](#)
 type (boot loader) command [22](#)

U

UDLD
 aggressive mode [475, 477](#)
 debug messages, display [61](#)
 enable globally [475](#)
 enable per interface [477](#)
 error recovery timer [77](#)
 message timer [475](#)
 normal mode [475, 477](#)
 reset a shutdown interface [479](#)
 status [363](#)
 udd command [475](#)
 udd port command [477](#)

udd reset command [479](#)
 unicast storm control [438](#)
 UniDirectional Link Detection
 See UDLD
 uni-vlan command [480](#)
 unknown multicast traffic, preventing [445](#)
 unknown unicast traffic, preventing [445](#)
 unset (boot loader) command [23](#)
 upgrading
 software images [7](#)
 monitoring status of [238](#)
 user EXEC mode [2](#)
 user network interface [201](#)

V

version (boot loader) command [25](#)
 vlan access-map command [485](#)
 VLAN access map configuration mode [485](#)
 VLAN access maps
 actions [5](#)
 displaying [371](#)
 vlan command [482](#)
 VLAN configuration mode
 commands [482](#)
 description [4](#)
 entering [482](#)
 summary [2](#)
 vlan filter command [487](#)
 VLAN filters, displaying [372](#)
 VLAN ID range [482](#)
 VLAN maps
 applying [487](#)
 creating [485](#)
 defining [157](#)
 displaying [371](#)
 VLAN Query Protocol
 See VQP

VLANs

- adding [482](#)
- configuring [482](#)
- debug messages, display
 - activation of [59](#)
 - VLAN IOS file system error tests [58](#)
 - VLAN manager activity [57](#)
- displaying configurations [367](#)
- extended-range [482](#)
- MAC addresses
 - displaying [324](#)
 - number of [314](#)
- normal-range [482](#)
- private [450](#)
 - configuring [206](#)
 - displaying [367](#)
 - See also private VLANs
- restarting [376](#)
- saving the configuration [482](#)
- shutting down [376](#)
- suspending [376](#)

VMPS

- configuring servers [492](#)
 - displaying [373](#)
 - error recovery timer [77](#)
 - reconfirming dynamic VLAN assignments [489](#)
- vmips reconfirm (global configuration) command [490](#)
- vmips reconfirm (privileged EXEC) command [489](#)
- vmips retry command [491](#)
- vmips server command [492](#)

VQP

- and dynamic-access ports [444](#)
- clearing client statistics [46](#)
- displaying information [373](#)
- per-server retry count [491](#)
- reconfirmation interval [490](#)
- reconfirming dynamic VLAN assignments [489](#)

W

Weighted Tail Drop

See WTD

WTD, queue-limit command [209](#)