



INDEX

A

aaa accounting dot1x command [1](#)
aaa authentication dot1x command [3](#)
AAA methods [3](#)
access control entries
 See ACEs
access control lists
 See ACLs
access groups
 IP [95](#)
 MAC, displaying [340](#)
 matching for QoS classification [180](#)
access mode [482](#)
access ports [482](#)
ACEs [60, 208](#)
ACLs
 as match criteria for QoS classes [180](#)
 deny [58](#)
 displaying [261](#)
 for non-IP protocols [162](#)
 IP [95](#)
 on Layer 2 interfaces [95](#)
 permit [206](#)
action command [5](#)
address aliasing [195](#)
aggregate policers
 applying [217](#)
 creating [213](#)
 displaying [372](#)
 QoS [214](#)
aggregate-port learner [200](#)
allowed VLANs [497](#)

archive download-sw command [7](#)
archive tar command [10](#)
archive upload-sw command [13](#)
arp access-list command [15](#)
attaching policy maps to interfaces [244](#)
authorization state of controlled port [67](#)
autonegotiation of duplex mode [78](#)

B

bandwidth, configuring for QoS [17](#)
bandwidth command [17](#)
boot (boot loader) command [2](#)
boot config-file command [20](#)
boot enable-break command [21](#)
boot helper command [22](#)
boot helper-config file command [23](#)
booting
 Cisco IOS image [26](#)
 displaying environment variables [266](#)
 interrupting [21](#)
 manually [24](#)
boot loader
 accessing [1](#)
 booting
 Cisco IOS image [2](#)
 helper image [22](#)
 directories
 creating [14](#)
 displaying a list of [7](#)
 removing [18](#)

boot loader (continued)

displaying

- available commands [12](#)
- memory heap utilization [13](#)
- version [25](#)

environment variables

- described [19](#)
- displaying settings [19](#)
- location of [20](#)
- setting [19](#)
- unsetting [23](#)

files

- copying [5](#)
- deleting [6](#)
- displaying a list of [7](#)
- displaying the contents of [4, 15, 22](#)
- renaming [16](#)

file system

- formatting [10](#)
- initializing flash [9](#)
- running a consistency check [11](#)

prompt [1](#)resetting the system [17](#)boot manual command [24](#)boot private-config-file command [25](#)boot system command [26](#)BPDU filtering, for spanning tree [424, 462](#)BPDU guard, for spanning tree [426, 462](#)broadcast storm control [472](#)burst bytes, in QoS policers [209, 213](#)**C**cat (boot loader) command [4](#)CBWFQ, configuring [17](#)channel-group command [27](#)channel-protocol command [31](#)child policy maps [246](#)class-based traffic shaping [259](#)

class-based weighted fair queuing

See CBWFQ

class command [33](#)class-map command [35](#)class-map configuration mode [35](#)

class maps

- creating [35](#)
- defining the match criteria [181](#)
- displaying [270](#)
- matching in [35](#)

class of service

See CoS

clear ip arp inspection log command [37](#)clear ip arp inspection statistics command [38](#)clear lacp command [41](#)clear mac address-table command [42](#)clear pagp command [43](#)clear policer cpu uni-eni counters command [44](#)clear port-security command [45](#)clear spanning-tree counters command [47](#)clear spanning-tree detected-protocols command [48](#)clear vmpls statistics command [50](#)command modes defined [1](#)committed information rate in QoS policers [209, 213](#)

configuration files

- password recovery disable considerations [1](#)
- specifying the name [20, 25](#)

configuring multiple interfaces [92](#)conform-action command [51](#)control-plane policer [44](#)control-plane policer information, displaying [373](#)control-plane security [219](#)control plane statistics, clearing [44](#)copy (boot loader) command [5](#)

CoS

- as match criteria for QoS groups [181](#)
- for QoS classification [248](#)
- setting value in policy maps [248](#)

CPU ASIC statistics, displaying [271](#)
 CPU protection policers, displaying [16](#)

D

debug dot1x command [2](#)
 debug etherchannel command [3](#)
 debug interface command [4](#)
 debug ip igmp filter command [5](#)
 debug ip igmp max-groups command [6](#)
 debug ip igmp snooping command [7](#)
 debug lacp command [8](#)
 debug mac-notification command [9](#)
 debug matm command [10](#)
 debug monitor command [11](#)
 debug mvrdbg command [12](#)
 debug nvram command [13](#)
 debug pagp command [14](#)
 debug platform acl command [15](#)
 debug platform cpu-queues command [16](#)
 debug platform dot1x command [18](#)
 debug platform etherchannel command [19](#)
 debug platform forw-team command [20](#)
 debug platform ip arp inspection command [21](#)
 debug platform ip dhcp command [22](#)
 debug platform ip igmp snooping command [23](#)
 debug platform ip source-guard command [25](#)
 debug platform led command [26](#)
 debug platform matm command [27](#)
 debug platform messaging application command [28](#)
 debug platform phy command [29](#)
 debug platform pm command [31](#)
 debug platform policer cpu uni-eni command [33](#)
 debug platform port-asic command [34](#)
 debug platform port-security command [35](#)
 debug platform qos-acl-tcam command [36](#)
 debug platform remote-commands command [37](#)
 debug platform resource-manager command [38](#)
 debug platform snmp command [39](#)
 debug platform span command [40](#)
 debug platform supervisor-asic command [41](#)
 debug platform sw-bridge command [42](#)
 debug platform tcam command [43](#)
 debug platform udd command [45](#)
 debug platform vlan command [46](#)
 debug pm command [47](#)
 debug port-security command [49](#)
 debug qos-manager command [50](#)
 debug spanning-tree bpdu command [53](#)
 debug spanning-tree bpdu-opt command [54](#)
 debug spanning-tree command [51](#)
 debug spanning-tree mstp command [55](#)
 debug spanning-tree switch command [57](#)
 debug sw-vlan command [59](#)
 debug sw-vlan ifs command [60](#)
 debug sw-vlan notification command [61](#)
 debug udd command [63](#)
 debug vqpc command [65](#)
 default policer configuration
 NNIs [18](#)
 UNIs [17](#)
 define interface-range command [53](#)
 delete (boot loader) command [6](#)
 delete command [55](#)
 deny (ARP access-list configuration) command [56](#)
 deny command [58](#)
 detect mechanism, causes [79](#)
 DHCP snooping
 accepting untrusted packets from edge switch [118](#)
 enabling
 on a VLAN [124](#)
 option 82 [116, 118](#)
 trust on an interface [122](#)
 error recovery timer [83](#)
 rate limiting [121](#)

- DHCP snooping binding database
 - binding file, configuring [114](#)
 - bindings
 - adding [112](#)
 - deleting [112](#)
 - displaying [317](#)
 - clearing database agent statistics [39](#)
 - database agent, configuring [114](#)
 - displaying
 - binding entries [317](#)
 - database agent status [319, 321](#)
 - renewing [239](#)
- differentiated service code point
 - See DSCP
- dir (boot loader) command [7](#)
- directories, deleting [55](#)
- dot1x default command [61](#)
- dot1x host-mode command [62](#)
- dot1x initialize command [64](#)
- dot1x max-req command [65, 66](#)
- dot1x port-control command [67](#)
- dot1x re-authenticate command [69](#)
- dot1x reauthentication command [70](#)
- dot1x system-auth-control command [71](#)
- dot1x test eapol-capable command [72](#)
- dot1x test timeout command [73](#)
- dot1x timeout command [74](#)
- dot1x violation-mode command [76](#)
- dropping packets, with ACL matches [5](#)
- DSCP
 - as match criteria for QoS groups [182](#)
 - for QoS traffic marking [250](#)
 - setting in policy maps [250](#)
- duplex command [77](#)
- dynamic-access ports
 - configuring [477](#)
 - restrictions [478](#)
- dynamic ARP inspection
 - ARP ACLs
 - apply to a VLAN [99](#)
 - define [15](#)
 - deny packets [56](#)
 - display [265](#)
 - permit packets [204](#)
 - clear
 - log buffer [37](#)
 - statistics [38](#)
 - display
 - ARP ACLs [265](#)
 - configuration and operating state [312](#)
 - log buffer [312](#)
 - statistics [312](#)
 - trust state and rate limit [312](#)
 - enable per VLAN [108](#)
 - log buffer
 - clear [37](#)
 - configure [103](#)
 - display [312](#)
 - rate-limit incoming ARP packets [101](#)
 - statistics
 - clear [38](#)
 - display [312](#)
 - trusted interface state [105](#)
 - type of packet logged [109](#)
 - validation checks [106](#)
- Dynamic Host Configuration Protocol (DHCP)
 - See DHCP snooping

E

- EAP-request/identity frame
 - maximum number to send [66](#)
 - response time before retransmitting [74](#)
- environment variables, displaying [266](#)
- errdisable detect cause command [79](#)
- errdisable detect cause small-frame comand [81](#)

errdisable recovery cause small-frame [85](#)
 errdisable recovery command [83](#)
 error conditions, displaying [290](#)
 error disable detection [79](#)
 error-disabled interfaces, displaying [301](#)
 EtherChannel
 assigning Ethernet interface to channel group [27](#)
 creating port-channel logical interface [90](#)
 debug EtherChannel/PAGP, display [3](#)
 debug platform-specific events, display [19](#)
 displaying [294](#)
 interface information, displaying [301](#)
 LACP
 clearing channel-group information [41](#)
 debug messages, display [8](#)
 displaying [336](#)
 modes [27](#)
 port priority for hot-standby ports [153](#)
 restricting a protocol [31](#)
 system priority [155](#)
 load-distribution methods [224](#)
 PAGP
 aggregate-port learner [200](#)
 clearing channel-group information [43](#)
 debug messages, display [14](#)
 displaying [368](#)
 error detection for [79](#)
 error recovery timer [83](#)
 learn method [200](#)
 modes [27](#)
 physical-port learner [200](#)
 priority of interface for transmitted traffic [202](#)
 Ethernet controller, internal register display [273](#)
 Ethernet statistics, collecting [241](#)
 exceed-action command [86](#)
 extended-range VLANs
 and allowed VLAN list [497](#)
 configuring [517](#)
 extended system ID for STP [432](#)

F

fan information, displaying [287](#)
 files, deleting [55](#)
 flash_init (boot loader) command [9](#)
 flowcontrol command [88](#)
 format (boot loader) command [10](#)
 forwarding packets, with ACL matches [5](#)
 forwarding results, display [6](#)
 frame forwarding information, displaying [6](#)
 fsck (boot loader) command [11](#)

G

global configuration mode [2, 3](#)

H

hardware ACL statistics [261](#)
 help (boot loader) command [12](#)
 host connection, port configuration [481](#)
 host ports, private VLANs [484](#)

I

IEEE 802.1x
 and switchport modes [482](#)
 violation error recovery [83](#)
 See also port-based authentication
 IGMP filters
 applying [127](#)
 debug messages, display [5](#)
 IGMP groups, setting maximum [129](#)
 IGMP maximum groups, debugging [6](#)
 IGMP profiles
 creating [131](#)
 displaying [324](#)

IGMP snooping

- adding ports as a static member of a group [146](#)
- displaying [325, 329, 331](#)
- enabling [133](#)
- enabling the configurable-leave timer [135](#)
- enabling the Immediate-Leave feature [143](#)
- flooding query count [141](#)
- interface topology change notification behavior [142](#)
- multicast table [327](#)
- querier [137](#)
- query solicitation [141](#)
- report suppression [139](#)
- switch topology change notification behavior [141](#)

images

See software images

Immediate-Leave feature, MVR [197](#)immediate-leave processing [143](#)

input policy maps

- and ACL classification [180](#)
- and aggregate policers [215](#)
- commands not supported in [222](#)
- configuration guidelines [222](#)

interface command [94](#)interface configuration mode [2, 4](#)interface port-channel command [90](#)interface range command [92](#)interface-range macros [53](#)

interfaces

- assigning Ethernet interface to channel group [27](#)
- configuring [77](#)
- configuring multiple [92](#)
- creating port-channel logical [90](#)
- debug messages, display [4](#)
- disabling [409](#)
- displaying the MAC address table [352](#)
- restarting [409](#)

interface speed, configuring [470](#)internal registers, displaying [273, 280](#)

Internet Group Management Protocol

See IGMP

invalid GBIC

- error detection for [79](#)
- error recovery timer [83](#)

ip address command [97](#)IP addresses, setting [97](#)IP address matching [178](#)ip arp inspection filter vlan command [99](#)ip arp inspection limit command [101](#)ip arp inspection log-buffer command [103](#)ip arp inspection trust command [105](#)ip arp inspection validate command [106](#)ip arp inspection vlan command [108](#)ip arp inspection vlan logging command [109](#)

IP DHCP snooping

See DHCP snooping

ip dhcp snooping binding command [112](#)ip dhcp snooping command [111](#)ip dhcp snooping database command [114](#)ip dhcp snooping information option allow-untrusted command [118](#)ip dhcp snooping information option command [116](#)ip dhcp snooping information option format remote-id command [120](#)ip dhcp snooping limit rate command [121](#)ip dhcp snooping trust command [122](#)ip dhcp snooping verify command [123](#)ip dhcp snooping vlan command [124](#)ip dhcp snooping vlan information option format-type circuit-id string command [125](#)ip igmp filter command [127](#)ip igmp max-groups command [129](#)ip igmp profile command [131](#)ip igmp snooping command [133](#)ip igmp snooping last-member-query-interval command [135](#)ip igmp snooping querier command [137](#)ip igmp snooping report-suppression command [139](#)ip igmp snooping tcn command [141](#)

ip igmp snooping tcn flood command [142](#)
 ip igmp snooping vlan immediate-leave command [143](#)
 ip igmp snooping vlan mrouter command [144](#)
 ip igmp snooping vlan static command [146](#)
 IP multicast addresses [194](#)
 IP precedence, as match criteria for QoS groups [184](#)
 ip source binding command [148](#)
 IP source guard
 disabling [152](#)
 displaying
 binding entries [333](#)
 configuration [334](#)
 enabling [152](#)
 static IP source bindings [148](#)
 IP source guard, displaying dynamic binding entries [317](#)
 ip ssh command [150](#)
 ip verify source command [152](#)

J

jumbo frames
 See MTU

L

LACP
 See EtherChannel
 lacp port-priority command [153](#)
 lacp system-priority command [155](#)
 Layer 2 traceroute
 IP addresses [508](#)
 MAC addresses [505](#)
 line configuration mode [2, 4](#)
 Link Aggregation Control Protocol
 See EtherChannel
 link flap
 error detection for [79](#)
 error recovery timer [83](#)

load-distribution methods for EtherChannel [224](#)
 logging event command [157](#)
 logging file command [158](#)
 logical interface [90](#)
 loopback error
 detection for [79](#)
 recovery timer [83](#)
 loop guard, for spanning tree [434, 438](#)

M

mac access-group command [160](#)
 MAC access-groups, displaying [340](#)
 MAC access list configuration mode [162](#)
 mac access-list extended command [162](#)
 MAC access lists [58](#)
 MAC addresses
 displaying
 aging time [346](#)
 all [344](#)
 dynamic [350](#)
 notification settings [354](#)
 number of addresses in a VLAN [348](#)
 per interface [352](#)
 per VLAN [358](#)
 static [356](#)
 static and dynamic entries [342](#)
 dynamic
 aging time [164](#)
 deleting [42](#)
 displaying [350](#)
 enabling MAC address notification [165](#)
 matching [178](#)
 static
 adding and removing [167](#)
 displaying [356](#)
 dropping on an interface [168](#)
 tables [344](#)
 MAC address notification, debugging [9](#)

- mac address-table aging-time [160, 178](#)
- mac address-table aging-time command [164](#)
- mac address-table notification command [165](#)
- mac address-table static command [167](#)
- mac address-table static drop command [168](#)
- macro description command [172](#)
- macro global command [173](#)
- macro global description command [175](#)
- macro name command [176](#)
- macros
 - adding a description [172](#)
 - adding a global description [175](#)
 - applying [173](#)
 - creating [176](#)
 - displaying [370](#)
 - interface range [53, 92](#)
 - specifying parameter values [173](#)
 - tracing [173](#)
- mapping tables, QoS [501](#)
- maps
 - class
 - creating [35](#)
 - VLAN
 - creating [520](#)
 - defining [178](#)
 - displaying [405](#)
- match access-group command [180](#)
- match cos command [181](#)
- match ip dscp command [182](#)
- match ip precedence command [184](#)
- match qos-group command [186](#)
- maximum transmission unit
 - See MTU
- mdix auto command [188](#)
- memory (boot loader) command [13](#)
- mkdir (boot loader) command [14](#)
- mode, MVR [194](#)
- modes, commands [1](#)
- monitor session command [190](#)
- more (boot loader) command [15](#)
- MSTP
 - displaying [387](#)
 - interoperability [48](#)
 - link type [436](#)
 - MST region
 - aborting changes [442](#)
 - applying changes [442](#)
 - configuration name [442](#)
 - configuration revision number [443](#)
 - current or pending display [443](#)
 - displaying [387](#)
 - MST configuration mode [442](#)
 - VLANs-to-instance mapping [442](#)
 - path cost [444](#)
 - protocol mode [440](#)
 - restart protocol migration process [48](#)
 - root port
 - loop guard [434](#)
 - preventing from becoming designated [434](#)
 - restricting which can be root [434](#)
 - root guard [434](#)
 - root switch
 - affects of extended system ID [432](#)
 - hello-time [447, 458](#)
 - interval between BDPU messages [449](#)
 - interval between hello BPDU messages [447, 458](#)
 - max-age [449](#)
 - maximum hop count before discarding BPDU [451](#)
 - port priority for selection of [453](#)
 - primary or secondary [458](#)
 - switch priority [456](#)

MSTP (continued)

state changes

- blocking to forwarding state [465](#)
- enabling BPDU filtering [424, 462](#)
- enabling BPDU guard [426, 462](#)
- enabling Port Fast [462, 465](#)
- forward-delay time [446](#)
- length of listening and learning states [446](#)
- rapid transition to forwarding [436](#)
- shutting down Port Fast-enabled ports [462](#)

state information display [386](#)

MTU

- configuring size [499](#)
- displaying global setting [394](#)

multicast group address, MVR [197](#)

multicast groups, MVR [195](#)

multicast router learning method [144](#)

multicast router ports, configuring [144](#)

multicast storm control [472](#)

multicast VLAN, MVR [194](#)

multicast VLAN registration

See MVR

multiple hosts on authorized port [62](#)

Multiple Spanning Tree Protocol

See MSTP

MVR

- and address aliasing [195](#)
- configuring [194](#)
- configuring interfaces [197](#)
- debug messages, display [12](#)
- displaying [362](#)
- displaying interface information [364](#)
- members, displaying [366](#)

mvr (global configuration) command [194](#)

mvr (interface configuration) command [197](#)

mvr vlan group command [198](#)

N

native VLANs [497](#)

network node interface [226](#)

nonegotiate, speed [470, 471](#)

non-IP protocols

- denying [58](#)
- forwarding [206](#)

non-IP traffic access lists [162](#)

non-IP traffic forwarding

- denying [58](#)
- permitting [206](#)

normal-range VLANs [517](#)

no vlan command [517](#)

O

output policy maps

- and QoS group classification [186](#)
- and traffic shaping [259](#)
- commands not supported in [222](#)
- configuration guidelines [222](#)
- priority in [229](#)
- queue limit in [234](#)

P

PAGP

See EtherChannel

pagp learn-method command [200](#)

pagp port-priority command [202](#)

parent policy maps [246](#)

password-recovery mechanism, enabling and disabling [242](#)

permit (ARP access-list configuration) command [204](#)

permit command [206](#)

per-VLAN spanning-tree plus

See STP

physical-port learner [200](#)

- PID, displaying [311](#)
- PIM-DVMRP, as multicast router learning method [144](#)
- police
 - multiple conform actions for a class [51](#)
 - multiple exceed actions for a class [86](#)
 - with priority [209](#)
- police aggregate command [217](#)
- police command [209](#)
- policer aggregate command [213](#)
- policer configuration
 - default for NNIs [18](#)
 - default for UNIs [17](#)
- policer cpu uni command [219](#)
- policers
 - aggregate [213, 217](#)
 - for CPU protection [219](#)
 - individual [209](#)
- policy-map class, configuring multiple actions [51, 86](#)
- policy-map class configuration mode [33](#)
- policy-map class police configuration mode [51, 211](#)
- policy-map command [221](#)
- policy-map configuration mode [221](#)
- policy maps
 - and CoS classification [181](#)
 - and DSCP classification [182](#)
 - and IP precedence classification [184](#)
 - and policing [211](#)
 - applying [244](#)
 - applying to an interface [222, 244, 256](#)
 - child [246](#)
 - creating [221](#)
 - displaying [376](#)
 - hierarchical [246](#)
 - parent [246](#)
 - policers
 - for a single class [209](#)
 - for multiple classes [213, 217, 219, 246](#)
 - setting priority [228](#)
 - setting QoS group identifier [254](#)
- policy maps (continued)
 - traffic classification, defining [33](#)
 - traffic marking
 - setting CoS values [248](#)
 - setting DSCP values [250](#)
 - setting IP precedence values [252](#)
- Port Aggregation Protocol
 - See EtherChannel
- port-based authentication
 - AAA method list [3](#)
 - configuring violation modes [76](#)
 - debug messages, display [2](#)
 - enabling 802.1x
 - globally [71](#)
 - per interface [67](#)
 - host modes [62](#)
 - IEEE 802.1x AAA accounting methods [1](#)
 - initialize an interface [64, 73](#)
 - manual control of authorization state [67](#)
 - multiple hosts on authorized port [62](#)
 - periodic re-authentication
 - enabling [70](#)
 - time between attempts [74](#)
 - quiet period between failed authentication exchanges [74](#)
 - re-authenticating 802.1x-enabled ports [69](#)
 - resetting configurable 802.1x parameters [61](#)
 - switch-to-authentication server retransmission time [74](#)
 - switch-to-client frame-retransmission number [65 to 66](#)
 - switch-to-client retransmission time [74](#)
 - test for IEEE 802.1x readiness [72](#)
- port-channel load-balance command [224](#)
- Port Fast, for spanning tree [465](#)
- port ranges, defining [53](#)
- ports, debugging [47](#)
- ports, protected [495](#)

port security

- aging [491](#)
- debug messages, display [49](#)
- enabling [487](#)
- violation error recovery [83](#)

port shaping [260](#)

port-type command [226](#)

port types, MVR [197](#)

power information, displaying [287](#)

power-supply status, displaying [287](#)

precedence

- for QoS traffic marking [252](#)
- setting in policy maps [252](#)

priority command [228](#)

priority queuing, QoS [228](#)

priority with police, QoS [228](#)

private-vlan command [231](#)

private VLANs

- association [493](#)
- configuring [231](#)
- configuring ports [484](#)
- displaying [401](#)
- host ports [484](#)
- mapping
 - configuring [493](#)
- promiscuous ports [484](#)

privileged EXEC mode [2, 3](#)

product identification information, displaying [311](#)

promiscuous ports, private VLANs [484](#)

PVST+

- See STP

Q

QoS

aggregate policers

- applying [217](#)
- creating [213](#)
- displaying [372](#)

class maps

- creating [35](#)
- defining the match criteria [181](#)
- displaying [270](#)

displaying statistics for [376, 25](#)

policy maps

- applying an aggregate policer [213, 217, 219, 246](#)
- applying to an interface [244, 256](#)
- creating [221](#)
- defining policers [209](#)
- displaying policy maps [376](#)
- setting CoS values [248](#)
- setting DSCP values [250](#)
- setting IP precedence values [252](#)
- setting QoS group identifier [254](#)
- traffic classifications [33](#)

table maps

- configuring [501](#)
- displaying [395](#)

QoS groups

- as match criteria [186](#)
- for QoS traffic classification [254](#)
- setting in policy maps [254](#)

QoS match criteria

- ACLs [180](#)
- CoS value [181](#)
- DSCP value [182](#)
- precedence value [184](#)
- QoS group number [186](#)

quality of service

See QoS

querytime, MVR [194](#)

queue-limit command [234](#)

R

rapid per-VLAN spanning-tree plus

See STP

rapid PVST+

See STP

re-authenticating 802.1x-enabled ports [69](#)

re-authentication

periodic [70](#)

time between attempts [74](#)

receiver ports, MVR [197](#)

receiving flow-control packets [88](#)

recovery mechanism

causes [83](#)

display [268](#), [288](#), [292](#)

timer interval [84](#)

remote-span command [237](#)

Remote Switched Port Analyzer

See RSPAN

rename (boot loader) command [16](#)

renew ip dhcp snooping database command [239](#)

reset (boot loader) command [17](#)

rmdir (boot loader) command [18](#)

rmon collection stats command [241](#)

root guard, for spanning tree [434](#)

RSPAN

configuring [190](#)

displaying [360](#)

filter RSPAN traffic [190](#)

remote-span command [237](#)

sessions

add interfaces to [190](#)

displaying [360](#)

start new [190](#)

S

SDM templates

displaying [385](#)

secure ports, limitations [489](#)

sending flow-control packets [88](#)

service password-recovery command [242](#)

service policy (policy-map class configuration) command [246](#)

service-policy interface configuration command [244](#)

service-policy policy-map class configuration command [246](#)

set (boot loader) command [19](#)

set cos command [248](#)

set dscp command [250](#)

set precedence command [252](#)

set qos-group command [254](#)

setup command [256](#)

SFPs, displaying information about [311](#)

shape average command [259](#)

show access-lists command [261](#)

show aggregate-policer command [395](#)

show archive status command [264](#)

show arp access-list command [265](#)

show boot command [266](#)

show class-map command [270](#)

show controllers cpu-interface command [271](#)

show controllers ethernet-controller command [273](#)

show controllers tcam command [280](#)

show controllers utilization command [282](#)

show controller utilization command [282](#)

show dot1x command [284](#)

show env command [287](#)

show errdisable detect command [288](#)

show errdisable flap-values command [290](#)

show errdisable recovery command [292](#)

show etherchannel command [294](#)

show flowcontrol command [297](#)

show idprom command [299](#)

- show interfaces command 301
- show interfaces counters command 309
- show inventory command 311
- show ip arp inspection command 312
- show ip dhcp snooping binding command 317
- show ip dhcp snooping command 316
- show ip dhcp snooping database command 319, 321
- show ip igmp profile command 324
- show ip igmp snooping command 325
- show ip igmp snooping command querier detail 331
- show ip igmp snooping groups command 327
- show ip igmp snooping mrouter command 329
- show ip igmp snooping querier command 331
- show ip igmp snooping querier detail command 331
- show ip source binding command 333
- show ip verify source command 334
- show lacp command 336
- show mac access-group command 340
- show mac address-table address command 344
- show mac address-table aging time command 346
- show mac address-table command 342
- show mac address-table count command 348
- show mac address-table dynamic command 350
- show mac address-table interface command 352
- show mac address-table notification command 354
- show mac address-table static command 356
- show mac address-table vlan command 358
- show monitor command 360
- show mvr command 362
- show mvr interface command 364
- show mvr members command 366
- show pagp command 368
- show parser macro command 370
- show platform acl command 2
- show platform configuration command 3
- show platform dl command 4
- show platform etherchannel command 5
- show platform forward command 6
- show platform igmp snooping command 8
- show platform layer4op command 10, 32
- show platform mac-address-table command 11
- show platform messaging command 12
- show platform monitor command 13
- show platform mvr table command 14
- show platform pm command 15
- show platform policer cpu command 16
- show platform port-asic command 19
- show platform port-security command 24
- show platform qos command 25
- show platform resource-manager command 28
- show platform snmp counters command 30
- show platform spanning-tree synchronization command 31
- show platform stp-instance command 33
- show platform team command 34
- show platform vlan command 37
- show policer aggregate command 372
- show policer cpu uni-eni command 373
- show policy-map command 376
- show policy-map interface output fields 379
- show port security command 380
- show port-type command 383
- show sdm prefer command 385
- show spanning-tree command 386
- show storm-control command 392
- show system mtu command 394
- show udd command 397
- show version command 399
- show vlan access-map command 405
- show vlan command 401
- show vlan command, fields 403
- show vlan filter command 406
- show vmps command 407
- shutdown command 409
- shutdown vlan command 410
- small violation-rate command 411
- SNMP host, specifying 416
- SNMP informs, enabling the sending of 413

- snmp-server enable traps command [413](#)
- snmp-server host command [416](#)
- snmp trap mac-notification command [420](#)
- SNMP traps
 - enabling MAC address notification trap [420](#)
 - enabling the MAC address notification feature [165](#)
 - enabling the sending of [413](#)
- software images
 - deleting [55](#)
 - downloading [7](#)
 - upgrading [7](#)
 - uploading [13](#)
- software version, displaying [399](#)
- source ports, MVR [197](#)
- SPAN
 - configuring [190](#)
 - debug messages, display [11](#)
 - displaying [360](#)
 - filter SPAN traffic [190](#)
 - sessions
 - add interfaces to [190](#)
 - displaying [360](#)
 - start new [190](#)
- spanning-tree bpdupfilter command [422, 424](#)
- spanning-tree bpduguard command [426](#)
- spanning-tree cost command [428](#)
- spanning-tree etherchannel command [430](#)
- spanning-tree extend system-id command [432](#)
- spanning-tree guard command [434](#)
- spanning-tree link-type command [436](#)
- spanning-tree loopguard default command [438](#)
- spanning-tree mode command [440](#)
- spanning-tree mst configuration command [442](#)
- spanning-tree mst cost command [444](#)
- spanning-tree mst forward-time command [446](#)
- spanning-tree mst hello-time command [447](#)
- spanning-tree mst max-age command [449](#)
- spanning-tree mst max-hops command [451](#)
- spanning-tree mst port-priority command [453](#)
- spanning-tree mst pre-standard command [455](#)
- spanning-tree mst priority command [456](#)
- spanning-tree mst root command [458](#)
- spanning-tree portfast (global configuration) command [462](#)
- spanning-tree portfast (interface configuration) command [465](#)
- spanning-tree port-priority command [460](#)
- Spanning Tree Protocol
 - See STP
- spanning-tree vlan command [467](#)
- speed command [470](#)
- SSH, configuring version [150](#)
- static-access ports, configuring [477](#)
- statistics, Ethernet group [241](#)
- sticky learning, enabling [487](#)
- storm-control command [472](#)
- STP
 - counters, clearing [47](#)
 - debug messages, display
 - MSTP [55](#)
 - optimized BPDUs handling [54](#)
 - spanning-tree activity [51](#)
 - switch shim [57](#)
 - transmitted and received BPDUs [53](#)
 - enabling on ENIs [422](#)
 - EtherChannel misconfiguration [430](#)
 - extended system ID [432](#)
 - path cost [428](#)
 - protocol modes [440](#)
 - root port
 - loop guard [434](#)
 - preventing from becoming designated [434](#)
 - restricting which can be root [434](#)
 - root guard [434](#)

STP (continued)

root switch

- affects of extended system ID [432, 468](#)
- hello-time [467](#)
- interval between BPDU messages [467](#)
- interval between hello BPDU messages [467](#)
- max-age [467](#)
- port priority for selection of [460](#)
- primary or secondary [467](#)
- switch priority [467](#)

state changes

- blocking to forwarding state [465](#)
- enabling BPDU filtering [424, 462](#)
- enabling BPDU guard [426, 462](#)
- enabling Port Fast [462, 465](#)
- enabling timer to recover from error state [83](#)
- forward-delay time [467](#)
- length of listening and learning states [467](#)
- shutting down Port Fast-enabled ports [462](#)

state information display [386](#)VLAN options [456, 467](#)

Switched Port Analyzer

See SPAN

switching characteristics

modifying [475](#)returning to interfaces [475](#)switchport access command [477](#)switchport block command [479](#)switchport command [475](#)switchport host command [481](#)switchport mode command [482](#)switchport mode private-vlan command [484](#)switchport port-security aging command [491](#)switchport port-security command [487](#)switchport private-vlan command [493](#)switchport protected command [495](#)switchports, displaying [301](#)switchport trunk command [497](#)system message logging, save message to flash [158](#)system mtu command [499](#)

Ttable-map command [501](#)table-map configuration mode [501](#)

table maps

configuring [501](#)displaying [395](#)QoS [501](#)tar files, creating, listing, and extracting [10](#)TDR, running [503](#)temperature information, displaying [287](#)temperature status, displaying [287](#)test cable-diagnostics tdr command [503](#)traceroute mac command [505](#)traceroute mac ip command [508](#)traffic shaping, QoS [259](#)trunking, VLAN mode [482](#)trunk mode [482](#)trunk ports [482](#)type (boot loader) command [22](#)

U

UDLD

aggressive mode [510, 512](#)debug messages, display [63](#)enable globally [510](#)enable per interface [512](#)error recovery timer [83](#)message timer [510](#)normal mode [510, 512](#)reset a shutdown interface [514](#)status [397](#)udld command [510](#)udld port command [512](#)udld reset command [514](#)

- unicast storm control [472](#)
- UniDirectional Link Detection
 - See UDLD
- uni-vlan command [515](#)
- unknown multicast traffic, preventing [479](#)
- unknown unicast traffic, preventing [479](#)
- unset (boot loader) command [23](#)
- upgrading
 - software images [7](#)
 - monitoring status of [264](#)
- user EXEC mode [2](#)
- user network interface [226](#)

V

- version (boot loader) command [25](#)
- vlan access-map command [520](#)
- VLAN access map configuration mode [520](#)
- VLAN access maps
 - actions [5](#)
 - displaying [405](#)
- vlan command [517](#)
- VLAN configuration mode
 - commands [517](#)
 - description [4](#)
 - entering [517](#)
 - summary [2](#)
- vlan filter command [522](#)
- VLAN filters, displaying [406](#)
- VLAN ID range [517](#)
- VLAN maps
 - applying [522](#)
 - creating [520](#)
 - defining [178](#)
 - displaying [405](#)

VLAN Query Protocol

- See VQP

VLANs

- adding [517](#)
- configuring [517](#)
- debug messages, display
 - activation of [61](#)
 - VLAN IOS file system error tests [60](#)
 - VLAN manager activity [59](#)
- displaying configurations [401](#)
- extended-range [517](#)
- MAC addresses
 - displaying [358](#)
 - number of [348](#)
- normal-range [517](#)
- private [484](#)
 - configuring [231](#)
 - displaying [401](#)
 - See also private VLANs
- restarting [410](#)
- saving the configuration [517](#)
- shutting down [410](#)
- suspending [410](#)

VMPS

- configuring servers [527](#)
- displaying [407](#)
- error recovery timer [83](#)
- reconfirming dynamic VLAN assignments [524](#)
- vmmps reconfirm (global configuration) command [525](#)
- vmmps reconfirm (privileged EXEC) command [524](#)
- vmmps retry command [526](#)
- vmmps server command [527](#)

VQP

- and dynamic-access ports [478](#)
- clearing client statistics [50](#)
- displaying information [407](#)
- per-server retry count [526](#)
- reconfirmation interval [525](#)
- reconfirming dynamic VLAN assignments [524](#)

W

Weighted Tail Drop

See WTD

WTD, queue-limit command [234](#)

