



A

aaa accounting dot1x command [2-1](#)
aaa authentication dot1x command [2-3](#)
AAA methods [2-3](#)
access control entries
 See ACEs
access control lists
 See ACLs
access groups
 IP [2-91](#)
 MAC, displaying [2-346](#)
 matching for QoS classification [2-180](#)
access mode [2-485](#)
access ports [2-485](#)
ACEs [2-62](#), [2-209](#)
ACLs
 as match criteria for QoS classes [2-180](#)
 deny [2-60](#)
 displaying [2-263](#)
 for non-IP protocols [2-160](#)
 IP [2-91](#)
 on Layer 2 interfaces [2-91](#)
 permit [2-207](#)
action command [2-5](#)
address aliasing [2-196](#)
aggregate policers
 applying [2-213](#)
 creating [2-215](#)
 displaying [2-379](#)
 QoS [2-216](#)
aggregate-port learner [2-201](#)
allowed VLANs [2-501](#)

archive download-sw command [2-7](#)
archive tar command [2-10](#)
archive upload-sw command [2-13](#)
arp access-list command [2-15](#)
attaching policy maps to interfaces [2-246](#)
audience [xv](#)
authorization state of controlled port [2-68](#)
autonegotiation of duplex mode [2-76](#)

B

backup interfaces
 configuring [2-480](#)
 displaying [2-305](#)
bandwidth, configuring for QoS [2-17](#)
bandwidth command [2-17](#)
boot (boot loader) command [A-2](#)
boot boothlpr command [2-20](#)
boot config-file command [2-21](#)
boot enable-break command [2-22](#)
boot helper command [2-23](#)
boot helper-config file command [2-24](#)
booting
 Cisco IOS image [2-27](#)
 displaying environment variables [2-268](#)
 interrupting [2-22](#)
 manually [2-25](#)
boot loader
 accessing [A-1](#)
 booting
 Cisco IOS image [A-2](#)
 helper image [2-23](#)
 directories

boot loader (continued)

- creating [A-15](#)
- displaying a list of [A-7](#)
- removing [A-19](#)

displaying

- available commands [A-12](#)
- memory heap utilization [A-14](#)
- version [A-26](#)

environment variables

- described [A-20](#)
- displaying settings [A-20](#)
- location of [A-21](#)
- setting [A-20](#)
- unsetting [A-24](#)

files

- copying [A-5](#)
- deleting [A-6](#)
- displaying a list of [A-7](#)
- displaying the contents of [A-4, A-16, A-23](#)
- renaming [A-17](#)

file system

- formatting [A-10](#)
- initializing flash [A-9](#)
- running a consistency check [A-11](#)

loading helper images [A-13](#)prompt [A-1](#)resetting the system [A-18](#)boot manual command [2-25](#)boot private-config-file command [2-26](#)boot system command [2-27](#)BPDU filtering, for spanning tree [2-428, 2-464](#)BPDU guard, for spanning tree [2-430, 2-464](#)broadcast storm control [2-473](#)burst bytes, in QoS policers [2-210, 2-215](#)CBWFQ, configuring [2-17](#)CDP, enabling protocol tunneling for [2-148](#)channel-group command [2-28](#)channel-protocol command [2-32](#)child policy maps [2-248](#)class-based traffic shaping [2-261](#)

class-based weighted fair queuing

See CBWFQ

class command [2-34](#)class-map command [2-36](#)class-map configuration mode [2-36](#)

class maps

- creating [2-36](#)
- defining the match criteria [2-181](#)
- displaying [2-272](#)
- matching in [2-36](#)

class of service

See CoS

clear ip arp inspection log command [2-38](#)clear ip arp inspection statistics command [2-39](#)clear ipc command [2-41](#)clear ip dhcp snooping database statistics command [2-40](#)clear l2protocol-tunnel counters command [2-42](#)clear lacp command [2-43](#)clear mac address-table command [2-44](#)clear pagp command [2-45](#)clear policer cpu uni counters command [2-46](#)clear port-security command [2-47](#)clear spanning-tree counters command [2-49](#)clear spanning-tree detected-protocols command [2-50](#)clear vmps statistics command [2-52](#)command modes defined [1-1](#)committed information rate in QoS policers [2-210, 2-215](#)

configuration, initial

See also getting started guide and hardware installation guide

configuration files

- password recovery disable considerations [A-1](#)
- specifying the name [2-21, 2-26](#)

C

cat (boot loader) command [A-4](#)caution, description [xvi](#)

- configuring multiple interfaces [2-87](#)
- conform-action command [2-53](#)
- control-plane policer [2-46](#)
- control-plane policer information, displaying [2-380](#)
- control-plane security [2-218](#)
- control plane statistics, clearing [2-46](#)
- conventions
 - command [xvi](#)
 - for examples [xvi](#)
 - publication [xvi](#)
 - text [xvi](#)
- copy (boot loader) command [A-5](#)
- CoS
 - as match criteria for QoS groups [2-181](#)
 - for QoS classification [2-250](#)
 - setting value in policy maps [2-250](#)
- CoS value, assigning to Layer 2 protocol packets [2-151](#)
- CPU ASIC statistics, displaying [2-273](#)
- CPU protection policers, displaying [C-18](#)

D

- debug backup command [B-2](#)
- debug dot1x command [B-3](#)
- debug etherchannel command [B-4](#)
- debug interface command [B-8](#)
- debug ip dhcp snooping command [B-6](#)
- debug ip igmp filter command [B-9](#)
- debug ip igmp max-groups command [B-10](#)
- debug ip igmp snooping command [B-11](#)
- debug ip verify source packet command [B-7](#)
- debug lacp command [B-12](#)
- debug mac-notification command [B-13](#)
- debug matm command [B-14](#)
- debug monitor command [B-15](#)
- debug mvrdbg command [B-16](#)
- debug nvram command [B-17](#)
- debug pagp command [B-18](#)
- debug platform acl command [B-19](#)
- debug platform backup interface command [B-20](#)
- debug platform cpu-queues command [B-21](#)
- debug platform dot1x command [B-23](#)
- debug platform etherchannel command [B-24](#)
- debug platform forw-tcam command [B-25](#)
- debug platform ip arp inspection command [B-26](#)
- debug platform ipc command [B-34](#)
- debug platform ip dhcp command [B-27](#)
- debug platform ip igmp snooping command [B-28](#)
- debug platform ip multicast command [B-30](#)
- debug platform led command [B-35](#)
- debug platform matm command [B-36](#)
- debug platform messaging application command [B-37](#)
- debug platform phy command [B-38](#)
- debug platform pm command [B-40](#)
- debug platform policer cpu uni command [B-42](#)
- debug platform port-asic command [B-43](#)
- debug platform port-security command [B-44](#)
- debug platform qos-acl-tcam command [B-45](#)
- debug platform remote-commands command [B-46](#)
- debug platform resource-manager command [B-47](#)
- debug platform snmp command [B-48](#)
- debug platform span command [B-49](#)
- debug platform supervisor-asic command [B-50](#)
- debug platform sw-bridge command [B-51](#)
- debug platform tcam command [B-52](#)
- debug platform udd command [B-54](#)
- debug platform vlan command [B-55](#)
- debug pm command [B-56](#)
- debug port-security command [B-58](#)
- debug qos-manager command [B-59](#)
- debug spanning-tree bpdu command [B-62](#)
- debug spanning-tree bpdu-opt command [B-63](#)
- debug spanning-tree command [B-60](#)
- debug spanning-tree mstp command [B-64](#)
- debug spanning-tree switch command [B-66](#)
- debug sw-vlan command [B-68](#)
- debug sw-vlan ifs command [B-70](#)
- debug sw-vlan notification command [B-71](#)

- debug udd command [B-73](#)
- debug vqpc command [B-75](#)
- define interface-range command [2-55](#)
- delete (boot loader) command [A-6](#)
- delete command [2-57](#)
- deny (ARP access-list configuration) command [2-58](#)
- deny command [2-60](#)
- detect mechanism, causes [2-77](#)
- DHCP snooping
 - accepting untrusted packets from edge switch [2-116](#)
 - enabling
 - on a VLAN [2-121](#)
 - option 82 [2-114, 2-116](#)
 - trust on an interface [2-119](#)
 - error recovery timer [2-79](#)
 - rate limiting [2-118](#)
- DHCP snooping binding database
 - binding file, configuring [2-112](#)
 - bindings
 - adding [2-110](#)
 - deleting [2-110](#)
 - displaying [2-320](#)
 - clearing database agent statistics [2-40](#)
 - database agent, configuring [2-112](#)
 - displaying
 - binding entries [2-320](#)
 - database agent status [2-322](#)
 - renewing [2-239](#)
- differentiated service code point
 - See DSCP
- dir (boot loader) command [A-7](#)
- directories, deleting [2-57](#)
- documentation, related [xvi](#)
- document conventions [xvi](#)
- dot1x default command [2-63](#)
- dot1x host-mode command [2-64](#)
- dot1x initialize command [2-65](#)
- dot1x max-req command [2-66, 2-67](#)
- dot1x port-control command [2-68](#)
- dot1x re-authenticate command [2-70](#)
- dot1x reauthentication command [2-71](#)
- dot1x system-auth-control command [2-72](#)
- dot1x timeout command [2-73](#)
- dropping packets, with ACL matches [2-5](#)
- drop threshold, Layer 2 protocol tunneling [2-148](#)
- DSCP
 - as match criteria for QoS groups [2-182](#)
 - for QoS traffic marking [2-252](#)
 - setting in policy maps [2-252](#)
- duplex command [2-75](#)
- dynamic-access ports
 - configuring [2-478](#)
 - restrictions [2-479](#)
- dynamic ARP inspection
 - ARP ACLs
 - apply to a VLAN [2-96](#)
 - define [2-15](#)
 - deny packets [2-58](#)
 - display [2-267](#)
 - permit packets [2-205](#)
 - clear
 - log buffer [2-38](#)
 - statistics [2-39](#)
 - display
 - ARP ACLs [2-267](#)
 - configuration and operating state [2-316](#)
 - log buffer [2-316](#)
 - statistics [2-316](#)
 - trust state and rate limit [2-316](#)
 - enable per VLAN [2-106](#)
 - error detection for [2-77](#)
 - error recovery timer [2-79](#)
 - log buffer
 - clear [2-38](#)
 - configure [2-100](#)
 - display [2-316](#)
 - rate-limit incoming ARP packets [2-98](#)
 - statistics

dynamic ARP inspection (continued)

- clear [2-39](#)
- display [2-316](#)
- trusted interface state [2-102](#)
- type of packet logged [2-107](#)
- validation checks [2-104](#)

Dynamic Host Configuration Protocol (DHCP)

- See DHCP snooping

E

EAP-request/identity frame

- maximum number to send [2-67](#)
 - response time before retransmitting [2-73](#)
- environment variables, displaying [2-268](#)
- errdisable detect cause command [2-77](#)
- errdisable recovery command [2-79](#)
- error conditions, displaying [2-294](#)
- error disable detection [2-77](#)
- error-disabled interfaces, displaying [2-305](#)

EtherChannel

- assigning Ethernet interface to channel group [2-28](#)
- creating port-channel logical interface [2-85](#)
- debug EtherChannel/PAgP, display [B-4](#)
- debug platform-specific events, display [B-24](#)
- displaying [2-298](#)
- enabling Layer 2 protocol tunneling for
 - LACP [2-149](#)
 - PAgP [2-149](#)
 - UDLD [2-149](#)

- interface information, displaying [2-305](#)

LACP

- clearing channel-group information [2-43](#)
- debug messages, display [B-12](#)
- displaying [2-342](#)
- modes [2-28](#)
- port priority for hot-standby ports [2-152](#)
- restricting a protocol [2-32](#)
- system priority [2-154](#)

- load-distribution methods [2-222](#)

PAgP

- aggregate-port learner [2-201](#)
- clearing channel-group information [2-45](#)
- debug messages, display [B-18](#)
- displaying [2-375](#)
- error detection for [2-77](#)
- error recovery timer [2-79](#)
- learn method [2-201](#)
- modes [2-28](#)
- physical-port learner [2-201](#)
- priority of interface for transmitted traffic [2-203](#)

- Ethernet controller, internal register display [2-275](#)

- Ethernet statistics, collecting [2-241](#)

- examples, conventions for [xvi](#)

- exceed-action command [2-81](#)

extended-range VLANs

- and allowed VLAN list [2-501](#)
- configuring [2-521](#)

- extended system ID for STP [2-436](#)

F

- fan information, displaying [2-291](#)

- files, deleting [2-57](#)

- flash_init (boot loader) command [A-9](#)

Flex Links

- configuring [2-480](#)
- displaying [2-305](#)

- flowcontrol command [2-83](#)

- format (boot loader) command [A-10](#)

- forwarding packets, with ACL matches [2-5](#)

- forwarding results, display [C-5](#)

- frame forwarding information, displaying [C-5](#)

- fsck (boot loader) command [A-11](#)

G

global configuration mode [1-2, 1-3](#)

H

hardware ACL statistics [2-263](#)
 help (boot loader) command [A-12](#)
 host connection, port configuration [2-484](#)
 host ports, private VLANs [2-488](#)

I

IEEE 802.1Q trunk ports and native VLANs [2-526](#)

IEEE 802.1Q tunnel ports

- configuring [2-485](#)
- displaying [2-286](#)
- limitations [2-486](#)

IEEE 802.1x

- and switchport modes [2-486](#)
- violation error recovery [2-79](#)
- See also port-based authentication

IGMP filters

- applying [2-122](#)
- debug messages, display [B-9](#)

IGMP groups, setting maximum [2-123](#)

IGMP maximum groups, debugging [B-10](#)

IGMP profiles

- creating [2-125](#)
- displaying [2-324](#)

IGMP snooping

- adding ports as a static member of a group [2-141](#)
- displaying [2-325, 2-329, 2-331](#)
- enabling [2-127](#)
- enabling the configurable-leave timer [2-129](#)
- enabling the Immediate-Leave feature [2-138](#)
- flooding query count [2-135](#)
- interface topology change notification behavior [2-137](#)
- multicast table [2-327](#)

- querier [2-131](#)

- query solicitation [2-135](#)

- report suppression [2-133](#)

- switch topology change notification behavior [2-135](#)

images

- See software images

Immediate-Leave feature, MVR [2-198](#)

immediate-leave processing [2-138](#)

initial configuration

- See also getting started guide and hardware installation guide

input policy maps

- and ACL classification [2-180](#)
- and aggregate policers [2-216](#)
- commands not supported in [2-220](#)
- configuration guidelines [2-220](#)

interface command [2-89](#)

interface configuration mode [1-2, 1-4](#)

interface port-channel command [2-85](#)

interface range command [2-87](#)

interface-range macros [2-55](#)

interfaces

- assigning Ethernet interface to channel group [2-28](#)
- configuring [2-75](#)
- configuring multiple [2-87](#)
- creating port-channel logical [2-85](#)
- debug messages, display [B-8](#)
- disabling [2-417](#)
- displaying the MAC address table [2-358](#)
- restarting [2-417](#)

interface speed, configuring [2-471](#)

internal registers, displaying [2-275, 2-282](#)

Internet Group Management Protocol

- See IGMP

invalid GBIC

- error detection for [2-77](#)
- error recovery timer [2-79](#)

ip address command [2-94](#)

IP addresses, setting [2-94](#)

IP address matching [2-178](#)
 ip arp inspection filter vlan command [2-96](#)
 ip arp inspection limit command [2-98](#)
 ip arp inspection log-buffer command [2-100](#)
 ip arp inspection trust command [2-102](#)
 ip arp inspection validate command [2-104](#)
 ip arp inspection vlan command [2-106](#)
 ip arp inspection vlan logging command [2-107](#)
 IP DHCP snooping
 See DHCP snooping
 ip dhcp snooping binding command [2-110](#)
 ip dhcp snooping command [2-109](#)
 ip dhcp snooping database command [2-112](#)
 ip dhcp snooping information option allow-untrusted
 command [2-116](#)
 ip dhcp snooping information option command [2-114](#)
 ip dhcp snooping limit rate command [2-118](#)
 ip dhcp snooping trust command [2-119](#)
 ip dhcp snooping verify command [2-120](#)
 ip dhcp snooping vlan command [2-121](#)
 ip igmp filter command [2-122](#)
 ip igmp max-groups command [2-123](#)
 ip igmp profile command [2-125](#)
 ip igmp snooping command [2-127](#)
 ip igmp snooping last-member-query-interval
 command [2-129](#)
 ip igmp snooping querier command [2-131](#)
 ip igmp snooping report-suppression command [2-133](#)
 ip igmp snooping tcn command [2-135](#)
 ip igmp snooping tcn flood command [2-137](#)
 ip igmp snooping vlan immediate-leave command [2-138](#)
 ip igmp snooping vlan mrouter command [2-139](#)
 ip igmp snooping vlan static command [2-141](#)
 IP multicast addresses [2-195](#)
 IP precedence, as match criteria for QoS groups [2-184](#)
 ip source binding command [2-143](#)
 IP source guard
 disabling [2-147](#)
 displaying

 binding entries [2-333](#)
 configuration [2-334](#)
 enabling [2-147](#)
 static IP source bindings [2-143](#)
 IP source guard, displaying
 dynamic binding entries [2-320](#)
 ip ssh command [2-145](#)
 ip verify source command [2-147](#)

J

jumbo frames
 See MTU

L

l2protocol-tunnel command [2-148](#)
 l2protocol-tunnel cos command [2-151](#)
 LACP
 See EtherChannel
 lacp port-priority command [2-152](#)
 lacp system-priority command [2-154](#)
 Layer 2 mode, enabling [2-476](#)
 Layer 2 protocol ports, displaying [2-340](#)
 Layer 2 protocol-tunnel
 error detection for [2-77](#)
 error recovery timer [2-79](#)
 Layer 2 protocol tunnel counters [2-42](#)
 Layer 2 protocol tunneling error recovery [2-149](#)
 Layer 2 traceroute
 IP addresses [2-512](#)
 MAC addresses [2-509](#)
 Layer 3 mode, enabling [2-476](#)
 line configuration mode [1-2, 1-4](#)
 Link Aggregation Control Protocol
 See EtherChannel

link flap

- error detection for [2-77](#)
- error recovery timer [2-79](#)

load_helper (boot loader) command [A-13](#)load-distribution methods for EtherChannel [2-222](#)logging file command [2-156](#)logical interface [2-85](#)

loopback error

- detection for [2-77](#)
- recovery timer [2-79](#)

loop guard, for spanning tree [2-438, 2-442](#)

M
mac access-group command [2-158](#)MAC access-groups, displaying [2-346](#)MAC access list configuration mode [2-160](#)mac access-list extended command [2-160](#)MAC access lists [2-60](#)

MAC addresses

- disabling MAC address learning per VLAN [2-163](#)

displaying

- aging time [2-352](#)
- all [2-350](#)
- dynamic [2-356](#)
- notification settings [2-360, 2-361](#)
- number of addresses in a VLAN [2-354](#)
- per interface [2-358](#)
- per VLAN [2-365](#)
- static [2-363](#)
- static and dynamic entries [2-348](#)

dynamic

- aging time [2-162](#)
- deleting [2-44](#)
- displaying [2-356](#)

enabling MAC address notification [2-165](#)matching [2-178](#)

static

- adding and removing [2-167](#)

displaying [2-363](#)dropping on an interface [2-168](#)tables [2-350](#)MAC address notification, debugging [B-13](#)mac address-table aging-time [2-158, 2-178](#)mac address-table aging-time command [2-162](#)mac address-table learning command [2-163](#)mac address-table notification command [2-165](#)mac address-table static command [2-167](#)mac address-table static drop command [2-168](#)macro description command [2-172](#)macro global command [2-173](#)macro global description command [2-175](#)macro name command [2-176](#)

macros

adding a description [2-172](#)adding a global description [2-175](#)applying [2-173](#)creating [2-176](#)displaying [2-377](#)interface range [2-55, 2-87](#)specifying parameter values [2-173](#)tracing [2-173](#)

manual

audience [xv](#)purpose of [xv](#)mapping tables, QoS [2-506](#)

maps

VLAN

creating [2-524](#)defining [2-178](#)displaying [2-413](#)match access-group command [2-180](#)match cos command [2-181](#)match ip dscp command [2-182](#)match ip precedence command [2-184](#)match qos-group command [2-186](#)

maximum transmission unit

See MTU

- mdix auto command [2-188](#)
- memory (boot loader) command [A-14](#)
- mkdir (boot loader) command [A-15](#)
- mode, MVR [2-195](#)
- modes, commands [1-1](#)
- monitor session command [2-190](#)
- more (boot loader) command [A-16](#)
- MSTP
 - displaying [2-394](#)
 - interoperability [2-50](#)
 - link type [2-440](#)
 - MST region
 - aborting changes [2-446](#)
 - applying changes [2-446](#)
 - configuration name [2-446](#)
 - configuration revision number [2-446](#)
 - current or pending display [2-446](#)
 - displaying [2-394](#)
 - MST configuration mode [2-446](#)
 - VLANs-to-instance mapping [2-446](#)
 - path cost [2-448](#)
 - protocol mode [2-444](#)
 - restart protocol migration process [2-50](#)
 - root port
 - loop guard [2-438](#)
 - preventing from becoming designated [2-438](#)
 - restricting which can be root [2-438](#)
 - root guard [2-438](#)
 - root switch
 - affects of extended system ID [2-436](#)
 - hello-time [2-451, 2-460](#)
 - interval between BPDU messages [2-453](#)
 - interval between hello BPDU messages [2-451, 2-460](#)
 - max-age [2-453](#)
 - maximum hop count before discarding BPDU [2-455](#)
 - port priority for selection of [2-457](#)
 - primary or secondary [2-460](#)
 - switch priority [2-459](#)
 - state changes
 - blocking to forwarding state [2-466](#)
 - enabling BPDU filtering [2-428, 2-464](#)
 - enabling BPDU guard [2-430, 2-464](#)
 - enabling Port Fast [2-464, 2-466](#)
 - forward-delay time [2-450](#)
 - length of listening and learning states [2-450](#)
 - rapid transition to forwarding [2-440](#)
 - shutting down Port Fast-enabled ports [2-464](#)
 - state information display [2-393](#)
- MTU
 - configuring size [2-504](#)
 - displaying global setting [2-400](#)
- multicast group address, MVR [2-198](#)
- multicast groups, MVR [2-196](#)
- multicast router learning method [2-139](#)
- multicast router ports, configuring [2-139](#)
- multicast storm control [2-473](#)
- multicast VLAN, MVR [2-195](#)
- multicast VLAN registration
 - See MVR
- multiple hosts on authorized port [2-64](#)
- Multiple Spanning Tree Protocol
 - See MSTP
- MVR
 - and address aliasing [2-196](#)
 - configuring [2-195](#)
 - configuring interfaces [2-198](#)
 - debug messages, display [B-16](#)
 - displaying [2-369](#)
 - displaying interface information [2-371](#)
 - members, displaying [2-373](#)
- mvr (global configuration) command [2-195](#)
- mvr (interface configuration) command [2-198](#)
- mvr vlan group command [2-199](#)

N

native VLANs [2-501](#)
 native VLAN tagging [2-526](#)
 network node interface [2-224](#)
 negotiate, speed [2-471, 2-472](#)
 non-IP protocols
 denying [2-60](#)
 forwarding [2-207](#)
 non-IP traffic access lists [2-160](#)
 non-IP traffic forwarding
 denying [2-60](#)
 permitting [2-207](#)
 normal-range VLANs [2-521](#)
 note, description [xvi](#)
 no vlan command [2-521](#)

O

output policy maps
 and QoS group classification [2-186](#)
 and traffic shaping [2-261](#)
 commands not supported in [2-220](#)
 configuration guidelines [2-220](#)
 priority in [2-227](#)
 queue limit in [2-234](#)

P

PAgP
 See EtherChannel
 pagp learn-method command [2-201](#)
 pagp port-priority command [2-203](#)
 parent policy maps [2-248](#)
 password-recovery mechanism, enabling and
 disabling [2-244](#)
 permit (ARP access-list configuration) command [2-205](#)
 permit command [2-207](#)

per-VLAN spanning-tree plus
 See STP
 physical-port learner [2-201](#)
 PID, displaying [2-315](#)
 PIM-DVMRP, as multicast router learning method [2-139](#)
 police
 multiple conform actions for a class [2-53](#)
 multiple exceed actions for a class [2-81](#)
 with priority [2-210](#)
 police aggregate command [2-213](#)
 police command [2-210](#)
 policer aggregate command [2-215](#)
 policer cpu uni command [2-218](#)
 policers
 aggregate [2-213, 2-215](#)
 for CPU protection [2-218](#)
 individual [2-210](#)
 policy-map class, configuring multiple actions [2-53, 2-81](#)
 policy-map class configuration mode [2-34](#)
 policy-map class police configuration mode [2-53, 2-212](#)
 policy-map command [2-219](#)
 policy-map configuration mode [2-219](#)
 policy maps
 and CoS classification [2-181](#)
 and DSCP classification [2-182](#)
 and IP precedence classification [2-184](#)
 and policing [2-211](#)
 applying [2-246](#)
 applying to an interface [2-220, 2-246, 2-258](#)
 child [2-248](#)
 creating [2-219](#)
 displaying [2-382](#)
 hierarchical [2-248](#)
 parent [2-248](#)
 policers
 for a single class [2-210](#)
 for multiple classes [2-213, 2-215, 2-218, 2-248](#)
 setting priority [2-226](#)
 setting QoS group identifier [2-256](#)

- policy maps (continued)
 - traffic classification, defining [2-34](#)
 - traffic marking
 - setting CoS values [2-250](#)
 - setting DSCP values [2-252](#)
 - setting IP precedence values [2-254](#)
- Port Aggregation Protocol
 - See EtherChannel
- port-based authentication
 - AAA method list [2-3](#)
 - debug messages, display [B-3](#)
 - enabling 802.1x
 - globally [2-72](#)
 - per interface [2-68](#)
 - host modes [2-64](#)
 - IEEE 802.1x AAA accounting methods [2-1](#)
 - initialize an interface [2-65](#)
 - manual control of authorization state [2-68](#)
 - multiple hosts on authorized port [2-64](#)
 - periodic re-authentication
 - enabling [2-71](#)
 - time between attempts [2-73](#)
 - quiet period between failed authentication exchanges [2-73](#)
 - re-authenticating 802.1x-enabled ports [2-70](#)
 - resetting configurable 802.1x parameters [2-63](#)
 - switch-to-authentication server retransmission time [2-73](#)
 - switch-to-client frame-retransmission number [2-66 to 2-67](#)
 - switch-to-client retransmission time [2-73](#)
- port-channel load-balance command [2-222](#)
- Port Fast, for spanning tree [2-466](#)
- port ranges, defining [2-55](#)
- ports, debugging [B-56](#)
- ports, protected [2-499](#)
- port security
 - aging [2-495](#)
 - debug messages, display [B-58](#)
 - enabling [2-491](#)
 - violation error recovery [2-79](#)
- port shaping [2-262](#)
- port-type command [2-224](#)
- port types, MVR [2-198](#)
- power information, displaying [2-291](#)
- precedence
 - for QoS traffic marking [2-254](#)
 - setting in policy maps [2-254](#)
- priority command [2-226](#)
- priority queuing, QoS [2-226](#)
- priority with police, QoS [2-226](#)
- private-vlan command [2-229](#)
- private-vlan mapping command [2-232](#)
- private VLANs
 - association [2-497](#)
 - configuring [2-229](#)
 - configuring ports [2-488](#)
 - displaying [2-408](#)
 - host ports [2-488](#)
 - mapping
 - configuring [2-497](#)
 - displaying [2-305](#)
 - promiscuous ports [2-488](#)
- privileged EXEC mode [1-2, 1-3](#)
- product identification information, displaying [2-315](#)
- promiscuous ports, private VLANs [2-488](#)
- PVST+
 - See STP

Q

QoS

- aggregate policers
 - applying [2-213](#)
 - creating [2-215](#)
 - displaying [2-379](#)
- class maps
 - creating [2-36](#)

QoS (continued)

- defining the match criteria [2-181](#)

- displaying [2-272](#)

- displaying statistics for [2-382, C-28](#)

policy maps

- applying an aggregate policer [2-213, 2-215, 2-218, 2-248](#)

- applying to an interface [2-246, 2-258](#)

- creating [2-219](#)

- defining policers [2-210](#)

- displaying policy maps [2-382](#)

- setting CoS values [2-250](#)

- setting DSCP values [2-252](#)

- setting IP precedence values [2-254](#)

- setting QoS group identifier [2-256](#)

- traffic classifications [2-34](#)

table maps

- configuring [2-506](#)

- displaying [2-401](#)

QoS groups

- as match criteria [2-186](#)

- for QoS traffic classification [2-256](#)

- setting in policy maps [2-256](#)

QoS match criteria

- ACLs [2-180](#)

- CoS value [2-181](#)

- DSCP value [2-182](#)

- precedence value [2-184](#)

- QoS group number [2-186](#)

quality of service

- See QoS

- querytime, MVR [2-195](#)

- queue-limit command [2-234](#)

- re-authenticating 802.1x-enabled ports [2-70](#)

re-authentication

- periodic [2-71](#)

- time between attempts [2-73](#)

- receiver ports, MVR [2-198](#)

- receiving flow-control packets [2-83](#)

recovery mechanism

- causes [2-79](#)

- display [2-270, 2-292, 2-296](#)

- timer interval [2-79](#)

- remote-span command [2-237](#)

Remote Switched Port Analyzer

- See RSPAN

- rename (boot loader) command [A-17](#)

- renew ip dhcp snooping database command [2-239](#)

- reset (boot loader) command [A-18](#)

- resource templates, displaying [2-391](#)

- rmdir (boot loader) command [A-19](#)

- rmon collection stats command [2-241](#)

- root guard, for spanning tree [2-438](#)

routed ports

- IP addresses on [2-95](#)

- number supported [2-95](#)

RSPAN

- configuring [2-190](#)

- displaying [2-367](#)

- filter RSPAN traffic [2-190](#)

- remote-span command [2-237](#)

sessions

- add interfaces to [2-190](#)

- displaying [2-367](#)

- start new [2-190](#)

R

- rapid per-VLAN spanning-tree plus

- See STP

- rapid PVST+

- See STP

S

- sdm prefer command [2-242](#)

SDM templates

- allowed resources [2-242](#)

- displaying [2-391](#)

- secure ports, limitations [2-492](#)
- sending flow-control packets [2-83](#)
- service password-recovery command [2-244](#)
- service policy (policy-map class configuration) command [2-248](#)
- service-policy interface configuration command [2-246](#)
- service-policy policy-map class configuration command [2-248](#)
- set (boot loader) command [A-20](#)
- set cos command [2-250](#)
- set dscp command [2-252](#)
- set precedence command [2-254](#)
- set qos-group command [2-256](#)
- setup command [2-258](#)
- SFPs, displaying information about [2-315](#)
- shape average command [2-261](#)
- show access-lists command [2-263](#)
- show aggregate-policer command [2-401](#)
- show archive status command [2-266](#)
- show arp access-list command [2-267](#)
- show boot command [2-268](#)
- show class-map command [2-272](#)
- show controllers cpu-interface command [2-273](#)
- show controllers ethernet-controller command [2-275](#)
- show controllers tcam command [2-282](#)
- show controllers utilization command [2-284](#)
- show controller utilization command [2-284](#)
- show dot1q-tunnel command [2-286](#)
- show dot1x command [2-288](#)
- show env command [2-291](#)
- show errdisable detect command [2-292](#)
- show errdisable flap-values command [2-294](#)
- show errdisable recovery command [2-296](#)
- show etherchannel command [2-298](#)
- show flowcontrol command [2-301](#)
- show idprom command [2-303](#)
- show interfaces command [2-305](#)
- show interfaces counters command [2-313](#)
- show inventory command [2-315](#)
- show ip arp inspection command [2-316](#)
- show ipc command [2-336](#)
- show ip dhcp snooping binding command [2-320](#)
- show ip dhcp snooping command [2-319](#)
- show ip dhcp snooping database command [2-322](#)
- show ip igmp profile command [2-324](#)
- show ip igmp snooping command [2-325](#)
- show ip igmp snooping command querier detail [2-331](#)
- show ip igmp snooping groups command [2-327](#)
- show ip igmp snooping mrouter command [2-329](#)
- show ip igmp snooping querier command [2-331](#)
- show ip igmp snooping querier detail command [2-331](#)
- show ip source binding command [2-333](#)
- show ip verify source command [2-334](#)
- show l2protocol-tunnel command [2-340](#)
- show lacp command [2-342](#)
- show mac access-group command [2-346](#)
- show mac address-table address command [2-350](#)
- show mac address-table aging time command [2-352](#)
- show mac address-table command [2-348](#)
- show mac address-table count command [2-354](#)
- show mac address-table dynamic command [2-356](#)
- show mac address-table interface command [2-358](#)
- show mac address-table learning command [2-360](#)
- show mac address-table notification command [2-361](#)
- show mac address-table static command [2-363](#)
- show mac address-table vlan command [2-365](#)
- show monitor command [2-367](#)
- show mvr command [2-369](#)
- show mvr interface command [2-371](#)
- show mvr members command [2-373](#)
- show pagp command [2-375](#)
- show parser macro command [2-377](#)
- show platform acl command [C-2](#)
- show platform configuration command [C-3](#)
- show platform etherchannel command [C-4](#)
- show platform forward command [C-5](#)
- show platform igmp snooping command [C-7](#)
- show platform ipc trace command [C-12](#)

- show platform ip multicast command [C-9](#)
- show platform ip unicast command [C-10](#)
- show platform layer4op command [C-13](#)
- show platform mac-address-table command [C-14](#)
- show platform messaging command [C-15](#)
- show platform monitor command [C-16](#)
- show platform mvr table command [C-17](#)
- show platform pm command [C-21](#)
- show platform policer cpu command [C-18](#)
- show platform port-asic command [C-23](#)
- show platform port-security command [C-27](#)
- show platform qos command [C-28](#)
- show platform resource-manager command [C-31](#)
- show platform snmp counters command [C-33](#)
- show platform spanning-tree synchronization command [C-34](#)
- show platform stp-instance command [C-35](#)
- show platform tcam command [C-36](#)
- show platform vlan command [C-39](#)
- show policer aggregate command [2-379](#)
- show policer cpu uni command [2-380](#)
- show policy-map command [2-382](#)
- show policy-map interface output fields [2-385](#)
- show port security command [2-386](#)
- show port-type command [2-389](#)
- show sdm prefer command [2-391](#)
- show spanning-tree command [2-393](#)
- show storm-control command [2-398](#)
- show system mtu command [2-400](#)
- show udd command [2-403](#)
- show version command [2-406](#)
- show vlan access-map command [2-413](#)
- show vlan command [2-408](#)
- show vlan command, fields [2-410](#)
- show vlan filter command [2-414](#)
- show vmps command [2-415](#)
- shutdown command [2-417](#)
- shutdown threshold, Layer 2 protocol tunneling [2-148](#)
- shutdown vlan command [2-418](#)
- SNMP host, specifying [2-422](#)
- SNMP informs, enabling the sending of [2-419](#)
- snmp-server enable traps command [2-419](#)
- snmp-server host command [2-422](#)
- snmp trap mac-notification command [2-426](#)
- SNMP traps
 - enabling MAC address notification trap [2-426](#)
 - enabling the MAC address notification feature [2-165](#)
 - enabling the sending of [2-419](#)
- software images
 - deleting [2-57](#)
 - downloading [2-7](#)
 - upgrading [2-7](#)
 - uploading [2-13](#)
- software version, displaying [2-406](#)
- source ports, MVR [2-198](#)
- SPAN
 - configuring [2-190](#)
 - debug messages, display [B-15](#)
 - displaying [2-367](#)
 - filter SPAN traffic [2-190](#)
 - sessions
 - add interfaces to [2-190](#)
 - displaying [2-367](#)
 - start new [2-190](#)
- spanning-tree bpdudfilter command [2-428](#)
- spanning-tree bpduguard command [2-430](#)
- spanning-tree cost command [2-432](#)
- spanning-tree etherchannel command [2-434](#)
- spanning-tree extend system-id command [2-436](#)
- spanning-tree guard command [2-438](#)
- spanning-tree link-type command [2-440](#)
- spanning-tree loopguard default command [2-442](#)
- spanning-tree mode command [2-444](#)
- spanning-tree mst configuration command [2-446](#)
- spanning-tree mst cost command [2-448](#)
- spanning-tree mst forward-time command [2-450](#)
- spanning-tree mst hello-time command [2-451](#)
- spanning-tree mst max-age command [2-453](#)

- spanning-tree mst max-hops command [2-455](#)
- spanning-tree mst port-priority command [2-457](#)
- spanning-tree mst priority command [2-459](#)
- spanning-tree mst root command [2-460](#)
- spanning-tree portfast (global configuration) command [2-464](#)
- spanning-tree portfast (interface configuration) command [2-466](#)
- spanning-tree port-priority command [2-462](#)
- Spanning Tree Protocol
 - See STP
- spanning-tree vlan command [2-468](#)
- speed command [2-471](#)
- SSH, configuring version [2-145](#)
- static-access ports, configuring [2-478](#)
- statistics, Ethernet group [2-241](#)
- sticky learning, enabling [2-491](#)
- storm-control command [2-473](#)
- STP
 - counters, clearing [2-49](#)
 - debug messages, display
 - MSTP [B-64](#)
 - optimized BPDUs handling [B-63](#)
 - spanning-tree activity [B-60](#)
 - switch shim [B-66](#)
 - transmitted and received BPDUs [B-62](#)
 - enabling protocol tunneling for [2-148](#)
 - EtherChannel misconfiguration [2-434](#)
 - extended system ID [2-436](#)
 - path cost [2-432](#)
 - protocol modes [2-444](#)
 - root port
 - loop guard [2-438](#)
 - preventing from becoming designated [2-438](#)
 - restricting which can be root [2-438](#)
 - root guard [2-438](#)
 - root switch
 - affects of extended system ID [2-436, 2-469](#)
 - hello-time [2-468](#)
 - interval between BPDU messages [2-468](#)
 - interval between hello BPDU messages [2-468](#)
 - max-age [2-468](#)
 - port priority for selection of [2-462](#)
 - primary or secondary [2-468](#)
 - switch priority [2-468](#)
 - state changes
 - blocking to forwarding state [2-466](#)
 - enabling BPDU filtering [2-428, 2-464](#)
 - enabling BPDU guard [2-430, 2-464](#)
 - enabling Port Fast [2-464, 2-466](#)
 - enabling timer to recover from error state [2-79](#)
 - forward-delay time [2-468](#)
 - length of listening and learning states [2-468](#)
 - shutting down Port Fast-enabled ports [2-464](#)
 - state information display [2-393](#)
 - VLAN options [2-459, 2-468](#)
- SVIs, creating [2-89](#)
- Switched Port Analyzer
 - See SPAN
- switching characteristics
 - modifying [2-476](#)
 - returning to interfaces [2-476](#)
- switchport access command [2-478](#)
- switchport backup interface command [2-480](#)
- switchport block command [2-482](#)
- switchport command [2-476](#)
- switchport host command [2-484](#)
- switchport mode command [2-485](#)
- switchport mode private-vlan command [2-488](#)
- switchport port-security aging command [2-495](#)
- switchport port-security command [2-491](#)
- switchport private-vlan command [2-497](#)
- switchport protected command [2-499](#)
- switchports, displaying [2-305](#)
- switchport trunk command [2-501](#)
- system env temperature threshold yellow command [2-503](#)
- system message logging, save message to flash [2-156](#)

system mtu command [2-504](#)
 system resource templates [2-242](#)

T

table-map command [2-506](#)
 table-map configuration mode [2-506](#)
 table maps
 configuring [2-506](#)
 displaying [2-401](#)
 QoS [2-506](#)
 tar files, creating, listing, and extracting [2-10](#)
 TDR, running [2-508](#)
 temperature information, displaying [2-291](#)
 templates, system resources [2-242](#)
 test cable-diagnostics tdr command [2-508](#)
 traceroute mac command [2-509](#)
 traceroute mac ip command [2-512](#)
 traffic shaping, QoS [2-261](#)
 trunking, VLAN mode [2-485](#)
 trunk mode [2-485](#)
 trunk ports [2-485](#)
 tunnel ports, Layer 2 protocol, displaying [2-340](#)
 type (boot loader) command [A-23](#)

U

UDLD

 aggressive mode [2-514, 2-516](#)
 debug messages, display [B-73](#)
 enable globally [2-514](#)
 enable per interface [2-516](#)
 error recovery timer [2-79](#)
 message timer [2-514](#)
 normal mode [2-514, 2-516](#)
 reset a shutdown interface [2-518](#)
 status [2-403](#)
 udd command [2-514](#)

udd port command [2-516](#)
 udd reset command [2-518](#)
 unicast storm control [2-473](#)
 UniDirectional Link Detection
 See UDLD
 uni-vlan command [2-519](#)
 unknown multicast traffic, preventing [2-482](#)
 unknown unicast traffic, preventing [2-482](#)
 unset (boot loader) command [A-24](#)
 upgrading
 software images [2-7](#)
 monitoring status of [2-266](#)
 upgrading information
 See release notes
 user EXEC mode [1-2](#)
 user network interface [2-224](#)

V

version (boot loader) command [A-26](#)
 vlan access-map command [2-524](#)
 VLAN access map configuration mode [2-524](#)
 VLAN access maps
 actions [2-5](#)
 displaying [2-413](#)
 vlan command [2-521](#)
 VLAN configuration mode
 commands [2-521](#)
 description [1-4](#)
 entering [2-521](#)
 summary [1-2](#)
 vlan dot1q tag native command [2-526](#)
 vlan filter command [2-528](#)
 VLAN filters, displaying [2-414](#)
 VLAN ID range [2-521](#)

VLAN maps

- applying [2-528](#)
- creating [2-524](#)
- defining [2-178](#)
- displaying [2-413](#)

VLAN Query Protocol

See VQP

VLANs

- adding [2-521](#)
- configuring [2-521](#)
- debug messages, display
 - activation of [B-71](#)
 - VLAN IOS file system error tests [B-70](#)
 - VLAN manager activity [B-68](#)
- displaying configurations [2-408](#)
- extended-range [2-521](#)
- MAC addresses
 - displaying [2-365](#)
 - number of [2-354](#)
- normal-range [2-521](#)
- private [2-488](#)
 - configuring [2-229](#)
 - displaying [2-408](#)

See also private VLANs
- restarting [2-418](#)
- saving the configuration [2-521](#)
- shutting down [2-418](#)
- suspending [2-418](#)

VMPS

- configuring servers [2-533](#)
- displaying [2-415](#)
- error recovery timer [2-79](#)
- reconfirming dynamic VLAN assignments [2-530](#)
- vmmps reconfirm (global configuration) command [2-531](#)
- vmmps reconfirm (privileged EXEC) command [2-530](#)
- vmmps retry command [2-532](#)
- vmmps server command [2-533](#)

VQP

- and dynamic-access ports [2-479](#)
- clearing client statistics [2-52](#)
- displaying information [2-415](#)
- per-server retry count [2-532](#)
- reconfirmation interval [2-531](#)
- reconfirming dynamic VLAN assignments [2-530](#)
- VTP, enabling tunneling for [2-148](#)

W

Weighted Tail Drop

See WTD

- WTD, queue-limit command [2-234](#)

