



A

aaa accounting dot1x command [2-1](#)
aaa authentication dot1x command [2-3](#)
AAA methods [2-3](#)
access control entries
 See ACEs
access control lists
 See ACLs
access groups
 IP [2-100](#)
 MAC, displaying [2-387](#)
 matching for QoS classification [2-198](#)
access mode [2-532](#)
access ports [2-532](#)
ACEs [2-63](#), [2-233](#)
ACLs
 as match criteria for QoS classes [2-198](#)
 deny [2-61](#)
 displaying [2-292](#)
 for non-IP protocols [2-176](#)
 IP [2-100](#)
 on Layer 2 interfaces [2-100](#)
 permit [2-231](#)
action command [2-5](#)
address aliasing [2-219](#)
aggregate policers
 applying [2-238](#)
 creating [2-240](#)
 displaying [2-422](#)
 QoS [2-241](#)
aggregate-port learner [2-225](#)
allowed VLANs [2-548](#)

archive download-sw command [2-7](#)
archive tar command [2-10](#)
archive upload-sw command [2-13](#)
arp access-list command [2-15](#)
attaching policy maps to interfaces [2-274](#)
audience [xvii](#)
authorization state of controlled port [2-69](#)
autonegotiation of duplex mode [2-77](#)

B

backup interfaces
 configuring [2-526](#)
 displaying [2-342](#)
bandwidth, configuring for QoS [2-17](#)
bandwidth command [2-17](#)
boot (boot loader) command [A-2](#)
boot bootlpr command [2-20](#)
boot config-file command [2-21](#)
boot enable-break command [2-22](#)
boot helper command [2-23](#)
boot helper-config file command [2-24](#)
booting
 Cisco IOS image [2-27](#)
 displaying environment variables [2-297](#)
 interrupting [2-22](#)
 manually [2-25](#)

boot loader

- accessing [A-1](#)
- booting
 - Cisco IOS image [A-2](#)
 - helper image [2-23](#)
- directories
 - creating [A-15](#)
 - displaying a list of [A-7](#)
 - removing [A-19](#)
- displaying
 - available commands [A-12](#)
 - memory heap utilization [A-14](#)
 - version [A-26](#)
- environment variables
 - described [A-20](#)
 - displaying settings [A-20](#)
 - location of [A-21](#)
 - setting [A-20](#)
 - unsetting [A-24](#)
- files
 - copying [A-5](#)
 - deleting [A-6](#)
 - displaying a list of [A-7](#)
 - displaying the contents of [A-4, A-16, A-23](#)
 - renaming [A-17](#)
- file system
 - formatting [A-10](#)
 - initializing flash [A-9](#)
 - running a consistency check [A-11](#)
- loading helper images [A-13](#)
- prompt [A-1](#)
- resetting the system [A-18](#)

boot manual command [2-25](#)

boot private-config-file command [2-26](#)

boot system command [2-27](#)

BPDU filtering, for spanning tree [2-472, 2-510](#)

BPDU guard, for spanning tree [2-474, 2-510](#)

broadcast storm control [2-519](#)

bundling characteristics, UNI [2-83](#)

burst bytes, in QoS policers [2-234, 2-240](#)

C

cat (boot loader) command [A-4](#)

caution, description [xviii](#)

CBWFQ, configuring [2-17](#)

CDP, enabling protocol tunneling for [2-160](#)

CFM [2-224](#)

CFM as OAM protocol [2-224](#)

channel-group command [2-28](#)

channel-protocol command [2-32](#)

child policy maps [2-276](#)

class-based traffic shaping [2-290](#)

class-based weighted fair queuing

- See CBWFQ

class command [2-34](#)

class-map command [2-36](#)

class-map configuration mode [2-37](#)

class maps

- creating [2-36](#)
- defining the match criteria [2-199](#)
- displaying [2-301](#)
- matching in [2-36](#)

class of service

- See CoS

clear ip arp inspection log command [2-38](#)

clear ip arp inspection statistics command [2-39](#)

clear ipc command [2-41](#)

clear ip dhcp snooping database statistics command [2-40](#)

clear l2protocol-tunnel counters command [2-42](#)

clear lacp command [2-43](#)

clear mac address-table command [2-44, 2-45](#)

clear pagp command [2-46](#)

clear policer cpu uni counters command [2-47](#)

clear port-security command [2-48](#)

clear spanning-tree counters command [2-50](#)

clear spanning-tree detected-protocols command [2-51](#)

clear vmps statistics command [2-53](#)

- command modes defined [1-1](#)
- committed information rate in QoS policers [2-234, 2-240](#)
- configuration, initial
 - See also getting started guide and hardware installation guide
- configuration files
 - password recovery disable considerations [A-1](#)
 - specifying the name [2-21, 2-26](#)
- configuring multiple interfaces [2-96](#)
- conform-action command [2-54](#)
- control-plane policer [2-47](#)
- control-plane policer information, displaying [2-423](#)
- control-plane security [2-243](#)
- control plane statistics, clearing [2-47](#)
- conventions
 - command [xviii](#)
 - for examples [xviii](#)
 - publication [xviii](#)
 - text [xviii](#)
- copy (boot loader) command [A-5](#)
- CoS
 - as match criteria for QoS groups [2-199](#)
 - for QoS classification [2-279](#)
 - setting value in policy maps [2-279](#)
- CoS value, assigning to Layer 2 protocol packets [2-163](#)
- CPU ASIC statistics, displaying [2-302](#)
- CPU protection policers, displaying [C-21](#)

D

- debug backup command [B-2](#)
- debug dot1x command [B-3](#)
- debug etherchannel command [B-4](#)
- debug interface command [B-10](#)
- debug ip dhcp snooping command [B-8](#)
- debug ip igmp filter command [B-11](#)
- debug ip igmp max-groups command [B-12](#)
- debug ip igmp snooping command [B-13](#)
- debug ip verify source packet command [B-9](#)
- debug lacp command [B-14](#)
- debug mac-notification command [B-15](#)
- debug matm command [B-16](#)
- debug matm move update command [B-17](#)
- debug monitor command [B-18](#)
- debug mvrdbg command [B-19](#)
- debug nvram command [B-20](#)
- debug pagp command [B-21](#)
- debug platform acl command [B-22](#)
- debug platform backup interface command [B-24](#)
- debug platform cfm command [B-23](#)
- debug platform cpu-queues command [B-25](#)
- debug platform dot1x command [B-27](#)
- debug platform etherchannel command [B-28](#)
- debug platform forw-tcam command [B-29](#)
- debug platform ip arp inspection command [B-30](#)
- debug platform ipc command [B-38](#)
- debug platform ip dhcp command [B-31](#)
- debug platform ip igmp snooping command [B-32](#)
- debug platform ip multicast command [B-34](#)
- debug platform led command [B-39](#)
- debug platform matm command [B-40](#)
- debug platform messaging application command [B-41](#)
- debug platform phy command [B-42](#)
- debug platform pm command [B-44](#)
- debug platform policer cpu uni command [B-46](#)
- debug platform port-asic command [B-47](#)
- debug platform port-security command [B-48](#)
- debug platform qos-acl-tcam command [B-49](#)
- debug platform remote-commands command [B-50](#)
- debug platform resource-manager command [B-51](#)
- debug platform snmp command [B-52](#)
- debug platform span command [B-53](#)
- debug platform supervisor-asic command [B-54](#)
- debug platform sw-bridge command [B-55](#)
- debug platform tcam command [B-56](#)
- debug platform udd command [B-58](#)
- debug platform vlan command [B-59](#)
- debug pm command [B-60](#)

- debug port-security command [B-62](#)
- debug qos-manager command [B-63](#)
- debug spanning-tree bpdu command [B-66](#)
- debug spanning-tree bpdu-opt command [B-67](#)
- debug spanning-tree command [B-64](#)
- debug spanning-tree mstp command [B-68](#)
- debug spanning-tree switch command [B-70](#)
- debug sw-vlan command [B-72](#)
- debug sw-vlan ifs command [B-74](#)
- debug sw-vlan notification command [B-75](#)
- debug udd command [B-77](#)
- debug vqpc command [B-79](#)
- default
 - policer configuration
 - NNIs [C-23](#)
 - UNIs [C-22](#)
- define interface-range command [2-56](#)
- delete (boot loader) command [A-6](#)
- delete command [2-58](#)
- deny (ARP access-list configuration) command [2-59](#)
- deny command [2-61](#)
- detect mechanism, causes [2-78](#)
- DHCP snooping
 - accepting untrusted packets from edge switch [2-125](#)
 - enabling
 - on a VLAN [2-131](#)
 - option 82 [2-123, 2-125](#)
 - trust on an interface [2-129](#)
 - error recovery timer [2-80](#)
 - rate limiting [2-128](#)
- DHCP snooping binding database
 - binding file, configuring [2-121](#)
 - bindings
 - adding [2-119](#)
 - deleting [2-119](#)
 - displaying [2-358](#)
 - clearing database agent statistics [2-40](#)

DHCP snooping binding database (continued)

- database agent, configuring [2-121](#)
- displaying
 - binding entries [2-358](#)
 - database agent status [2-360](#)
 - renewing [2-266](#)
- differentiated service code point
 - See DSCP
- dir (boot loader) command [A-7](#)
- directories, deleting [2-58](#)
- documentation, related [xviii](#)
- document conventions [xviii](#)
- domains, CFM [2-224](#)
- dot1x default command [2-64](#)
- dot1x host-mode command [2-65](#)
- dot1x initialize command [2-66](#)
- dot1x max-req command [2-67, 2-68](#)
- dot1x port-control command [2-69](#)
- dot1x re-authenticate command [2-71](#)
- dot1x reauthentication command [2-72](#)
- dot1x system-auth-control command [2-73](#)
- dot1x timeout command [2-74](#)
- dropping packets, with ACL matches [2-5](#)
- drop threshold, Layer 2 protocol tunneling [2-160](#)
- DSCP
 - as match criteria for QoS groups [2-200, 2-206](#)
 - for QoS traffic marking [2-281](#)
 - setting in policy maps [2-281](#)
- dual-purpose uplink ports
 - selecting the type [2-211](#)
- duplex command [2-76](#)
- dynamic-access ports
 - configuring [2-524](#)
 - restrictions [2-525](#)

dynamic ARP inspection

ARP ACLs

apply to a VLAN [2-105](#)define [2-15](#)deny packets [2-59](#)display [2-296](#)permit packets [2-229](#)

clear

log buffer [2-38](#)statistics [2-39](#)

display

ARP ACLs [2-296](#)configuration and operating state [2-354](#)log buffer [2-354](#)statistics [2-354](#)trust state and rate limit [2-354](#)enable per VLAN [2-115](#)error detection for [2-78](#)error recovery timer [2-80](#)

log buffer

clear [2-38](#)configure [2-109](#)display [2-354](#)rate-limit incoming ARP packets [2-107](#)

statistics

clear [2-39](#)display [2-354](#)trusted interface state [2-111](#)type of packet logged [2-116](#)validation checks [2-113](#)

Dynamic Host Configuration Protocol (DHCP)

See DHCP snooping

E

EAP-request/identity frame

maximum number to send [2-68](#)response time before retransmitting [2-74](#)E-LMI mapping [2-83](#)environment variables, displaying [2-297](#)errdisable detect cause command [2-78](#)errdisable recovery command [2-80](#)error conditions, displaying [2-325](#)error disable detection [2-78](#)error-disabled interfaces, displaying [2-342](#)

EtherChannel

assigning Ethernet interface to channel group [2-28](#)creating port-channel logical interface [2-94](#)debug EtherChannel/PAGP, display [B-4](#)debug platform-specific events, display [B-28](#)displaying [2-329](#)

enabling Layer 2 protocol tunneling for

LACP [2-161](#)PAGP [2-161](#)UDLD [2-161](#)interface information, displaying [2-342](#)

LACP

clearing channel-group information [2-43](#)debug messages, display [B-14](#)displaying [2-381](#)modes [2-28](#)port priority for hot-standby ports [2-164](#)restricting a protocol [2-32](#)system priority [2-166](#)load-distribution methods [2-247](#)

PAGP

aggregate-port learner [2-225](#)clearing channel-group information [2-46](#)debug messages, display [B-21](#)displaying [2-418](#)error detection for [2-78](#)error recovery timer [2-80](#)learn method [2-225](#)modes [2-28](#)physical-port learner [2-225](#)priority of interface for transmitted traffic [2-227](#)Ethernet controller, internal register display [2-304](#)ethernet evc command [2-82](#)

ethernet lmi ce-vlan map command [2-83, 2-85](#)

Ethernet Local Management Interface

See E-LMI

Ethernet service

debugging [B-6](#)

displaying [2-332](#)

Ethernet service instance [2-270](#)

Ethernet service interfaces [2-336](#)

Ethernet statistics, collecting [2-267](#)

Ethernet UNI configuration [2-87](#)

ethernet uni id command [2-89](#)

Ethernet virtual connections

See EVCs

EVC configuration mode [2-82](#)

EVCs [2-82](#)

and VLANs [2-87](#)

service instances [2-270](#)

UNI counts [2-569](#)

EVC service

point-to-multipoint [2-569](#)

point-to-point [2-569](#)

examples, conventions for [xviii](#)

exceed-action command [2-90](#)

extended-range VLANs

and allowed VLAN list [2-548](#)

configuring [2-573](#)

extended system ID for STP [2-480](#)

F

fan information, displaying [2-320](#)

files, deleting [2-58](#)

flash_init (boot loader) command [A-9](#)

Flex Links

configuring [2-526](#)

displaying [2-342](#)

flowcontrol command [2-92](#)

format (boot loader) command [A-10](#)

forwarding packets, with ACL matches [2-5](#)

forwarding results, display [C-6](#)

frame forwarding information, displaying [C-6](#)

fsck (boot loader) command [A-11](#)

G

global configuration mode [1-2, 1-3](#)

H

hardware ACL statistics [2-292](#)

help (boot loader) command [A-12](#)

host connection, port configuration [2-531](#)

host ports, private VLANs [2-535](#)

I

IEEE 802.1ag Connectivity Fault Management

See CFM

IEEE 802.1Q trunk ports and native VLANs [2-578](#)

IEEE 802.1Q tunnel ports

configuring [2-532](#)

displaying [2-315](#)

limitations [2-533](#)

IEEE 802.1x

and switchport modes [2-533](#)

violation error recovery [2-80](#)

See also port-based authentication

IGMP filters

applying [2-134](#)

debug messages, display [B-11](#)

IGMP groups, setting maximum [2-135](#)

IGMP maximum groups, debugging [B-12](#)

IGMP profiles

creating [2-137](#)

displaying [2-362](#)

IGMP snooping

- adding ports as a static member of a group [2-152](#)
- displaying [2-363, 2-367, 2-369](#)
- enabling [2-139](#)
- enabling the configurable-leave timer [2-141](#)
- enabling the Immediate-Leave feature [2-149](#)
- flooding query count [2-147](#)
- interface topology change notification behavior [2-148](#)
- multicast table [2-365](#)
- querier [2-143](#)
- query solicitation [2-147](#)
- report suppression [2-145](#)
- switch topology change notification behavior [2-147](#)

images

- See software images

Immediate-Leave feature, MVR [2-221](#)

immediate-leave processing [2-149](#)

initial configuration

- See also getting started guide and hardware installation guide

input policy maps

- and ACL classification [2-198](#)
- and aggregate policers [2-241](#)
- commands not supported in [2-245](#)
- configuration guidelines [2-245](#)

interface command [2-98](#)

interface configuration mode [1-2, 1-4](#)

interface port-channel command [2-94](#)

interface range command [2-96](#)

interface-range macros [2-56](#)

interfaces

- assigning Ethernet interface to channel group [2-28](#)
- configuring [2-76](#)
- configuring multiple [2-96](#)
- creating port-channel logical [2-94](#)
- debug messages, display [B-10](#)
- disabling [2-461](#)
- displaying the MAC address table [2-399](#)
- restarting [2-461](#)

interface speed, configuring [2-517](#)

internal registers, displaying [2-304, 2-311](#)

Internet Group Management Protocol

- See IGMP

invalid GBIC

- error detection for [2-78](#)
- error recovery timer [2-80](#)

ip address command [2-103](#)

IP addresses, setting [2-103](#)

IP address matching [2-196](#)

ip arp inspection filter vlan command [2-105](#)

ip arp inspection limit command [2-107](#)

ip arp inspection log-buffer command [2-109](#)

ip arp inspection trust command [2-111](#)

ip arp inspection validate command [2-113](#)

ip arp inspection vlan command [2-115](#)

ip arp inspection vlan logging command [2-116](#)

IP DHCP snooping

- See DHCP snooping

ip dhcp snooping binding command [2-119](#)

ip dhcp snooping command [2-118](#)

ip dhcp snooping database command [2-121](#)

ip dhcp snooping information option allow-untrusted command [2-125](#)

ip dhcp snooping information option command [2-123](#)

ip dhcp snooping information option format remote-id command [2-127](#)

ip dhcp snooping limit rate command [2-128](#)

ip dhcp snooping trust command [2-129](#)

ip dhcp snooping verify command [2-130](#)

ip dhcp snooping vlan command [2-131](#)

ip dhcp snooping vlan information option format-type circuit-id string command [2-132](#)

ip igmp filter command [2-134](#)

ip igmp max-groups command [2-135](#)

ip igmp profile command [2-137](#)

ip igmp snooping command [2-139](#)

ip igmp snooping last-member-query-interval command [2-141](#)

ip igmp snooping querier command [2-143](#)

ip igmp snooping report-suppression command [2-145](#)
 ip igmp snooping tcn command [2-147](#)
 ip igmp snooping tcn flood command [2-148](#)
 ip igmp snooping vlan immediate-leave command [2-149](#)
 ip igmp snooping vlan mrouter command [2-150](#)
 ip igmp snooping vlan static command [2-152](#)
 IP multicast addresses [2-218](#)
 IP precedence, as match criteria for QoS groups [2-202](#)
 ip source binding command [2-154](#)
 IP source guard
 disabling [2-158](#)
 displaying
 binding entries [2-371](#)
 configuration [2-373](#)
 enabling [2-158](#)
 static IP source bindings [2-154](#)
 IP source guard, displaying
 dynamic binding entries [2-358](#)
 ip ssh command [2-156](#)
 ip verify source command [2-158](#)

J

jumbo frames
 See MTU

L

l2protocol-tunnel command [2-160](#)
 l2protocol-tunnel cos command [2-163](#)
 LACP
 See EtherChannel
 lacp port-priority command [2-164](#)
 lacp system-priority command [2-166](#)
 Layer 2 mode, enabling [2-522](#)
 Layer 2 protocol ports, displaying [2-379](#)

Layer 2 protocol-tunnel
 error detection for [2-78](#)
 error recovery timer [2-80](#)
 Layer 2 protocol tunnel counters [2-42](#)
 Layer 2 protocol tunneling error recovery [2-161](#)
 Layer 2 traceroute
 IP addresses [2-562](#)
 MAC addresses [2-559](#)
 Layer 3 mode, enabling [2-522](#)
 line configuration mode [1-2, 1-4](#)
 Link Aggregation Control Protocol
 See EtherChannel
 link flap
 error detection for [2-78](#)
 error recovery timer [2-80](#)
 link state group command [2-168](#)
 link state track command [2-170](#)
 load_helper (boot loader) command [A-13](#)
 load-distribution methods for EtherChannel [2-247](#)
 logging event command [2-171](#)
 logging file command [2-172](#)
 logical interface [2-94](#)
 loopback error
 detection for [2-78](#)
 recovery timer [2-80](#)
 loop guard, for spanning tree [2-482, 2-486](#)

M

mac access-group command [2-174](#)
 MAC access-groups, displaying [2-387](#)
 MAC access list configuration mode [2-176](#)
 mac access-list extended command [2-176](#)
 MAC access lists [2-61](#)

MAC addresses

- disabling MAC address learning per VLAN [2-179](#)
- displaying
 - aging time [2-393](#)
 - all [2-391](#)
 - dynamic [2-397](#)
 - MAC address-table move updates [2-402](#)
 - notification settings [2-401, 2-404](#)
 - number of addresses in a VLAN [2-395](#)
 - per interface [2-399](#)
 - per VLAN [2-408](#)
 - static [2-406](#)
 - static and dynamic entries [2-389](#)
- dynamic
 - aging time [2-178](#)
 - deleting [2-44](#)
 - displaying [2-397](#)
- enabling MAC address notification [2-183](#)
- enabling MAC address-table move update [2-181](#)
- matching [2-196](#)
- static
 - adding and removing [2-185](#)
 - displaying [2-406](#)
 - dropping on an interface [2-186](#)
- tables [2-391](#)

MAC address notification, debugging [B-15](#)

mac address-table aging-time [2-174, 2-196](#)

mac address-table aging-time command [2-178](#)

mac address-table learning command [2-179](#)

mac address-table move update command [2-181](#)

mac address-table notification command [2-183](#)

mac address-table static command [2-185](#)

mac address-table static drop command [2-186](#)

macro description command [2-190](#)

macro global command [2-191](#)

macro global description command [2-193](#)

macro name command [2-194](#)

macros

- adding a description [2-190](#)
- adding a global description [2-193](#)
- applying [2-191](#)
- creating [2-194](#)
- displaying [2-420](#)
- interface range [2-56, 2-96](#)
- specifying parameter values [2-191](#)
- tracing [2-191](#)

maintenance end points [2-569](#)

manual

- audience [xvii](#)
- purpose of [xvii](#)

mapping tables, QoS [2-555](#)

maps

- class
 - creating [2-36](#)
- VLAN
 - creating [2-576](#)
 - defining [2-196](#)
 - displaying [2-456](#)

match access-group command [2-198](#)

match cos command [2-199](#)

match ip dscp command [2-200](#)

match ip precedence command [2-202](#)

match qos-group command [2-204](#)

match vlan command [2-206](#)

maximum transmission unit

- See MTU

mdix auto command [2-209](#)

media-type command [2-211](#)

memory (boot loader) command [A-14](#)

mkdir (boot loader) command [A-15](#)

mode, MVR [2-218](#)

modes, commands [1-1](#)

monitor session command [2-213](#)

more (boot loader) command [A-16](#)

MSTP

- displaying [2-437](#)
- interoperability [2-51](#)
- link type [2-484](#)
- MST region
 - aborting changes [2-490](#)
 - applying changes [2-490](#)
 - configuration name [2-490](#)
 - configuration revision number [2-490](#)
 - current or pending display [2-490](#)
 - displaying [2-437](#)
 - MST configuration mode [2-490](#)
 - VLANs-to-instance mapping [2-490](#)
- path cost [2-492](#)
- protocol mode [2-488](#)
- restart protocol migration process [2-51](#)
- root port
 - loop guard [2-482](#)
 - preventing from becoming designated [2-482](#)
 - restricting which can be root [2-482](#)
 - root guard [2-482](#)
- root switch
 - affects of extended system ID [2-480](#)
 - hello-time [2-495, 2-506](#)
 - interval between BPDU messages [2-497](#)
 - interval between hello BPDU messages [2-495, 2-506](#)
 - max-age [2-497](#)
 - maximum hop count before discarding BPDU [2-499](#)
 - port priority for selection of [2-501](#)
 - primary or secondary [2-506](#)
 - switch priority [2-504](#)

MSTP (continued)

- state changes
 - blocking to forwarding state [2-512](#)
 - enabling BPDU filtering [2-472, 2-510](#)
 - enabling BPDU guard [2-474, 2-510](#)
 - enabling Port Fast [2-510, 2-512](#)
 - forward-delay time [2-494](#)
 - length of listening and learning states [2-494](#)
 - rapid transition to forwarding [2-484](#)
 - shutting down Port Fast-enabled ports [2-510](#)
 - state information display [2-436](#)
- MTU
 - configuring size [2-552](#)
 - displaying global setting [2-444](#)
- multicast group address, MVR [2-221](#)
- multicast groups, MVR [2-219](#)
- multicast router learning method [2-150](#)
- multicast router ports, configuring [2-150](#)
- multicast storm control [2-519](#)
- multicast VLAN, MVR [2-218](#)
- multicast VLAN registration
 - See MVR
- multiple hosts on authorized port [2-65](#)
- Multiple Spanning Tree Protocol
 - See MSTP
- multiplexing, UNI [2-87](#)
- MVR
 - and address aliasing [2-219](#)
 - configuring [2-218](#)
 - configuring interfaces [2-221](#)
 - debug messages, display [B-19](#)
 - displaying [2-412](#)
 - displaying interface information [2-414](#)
 - members, displaying [2-416](#)
 - mvr (global configuration) command [2-218](#)
 - mvr (interface configuration) command [2-221](#)
 - mvr vlan group command [2-222](#)

N

native VLANs [2-548](#)
 native VLAN tagging [2-578](#)
 network node interface [2-249](#)
 nonegotiate, speed [2-517, 2-518](#)
 non-IP protocols
 denying [2-61](#)
 forwarding [2-231](#)
 non-IP traffic access lists [2-176](#)
 non-IP traffic forwarding
 denying [2-61](#)
 permitting [2-231](#)
 normal-range VLANs [2-573](#)
 note, description [xviii](#)
 no vlan command [2-573](#)

O

OAM protocol [2-224](#)
 oam protocol cfm svlan command [2-224](#)
 operation, administration, and maintenance protocol
 See OAM
 output policy maps
 and QoS group classification [2-204](#)
 and traffic shaping [2-290](#)
 commands not supported in [2-245](#)
 configuration guidelines [2-245](#)
 priority in [2-254](#)
 queue limit in [2-261](#)

P

PAgP
 See EtherChannel
 pagp learn-method command [2-225](#)
 pagp port-priority command [2-227](#)
 parent policy maps [2-277](#)
 password-recovery mechanism, enabling and disabling [2-272](#)
 permit (ARP access-list configuration) command [2-229](#)
 permit command [2-231](#)
 per-VLAN spanning-tree plus
 See STP
 physical-port learner [2-225](#)
 PID, displaying [2-352](#)
 PIM-DVMRP, as multicast router learning method [2-150](#)
 police
 multiple conform actions for a class [2-54](#)
 multiple exceed actions for a class [2-90](#)
 with priority [2-234](#)
 police aggregate command [2-238](#)
 police command [2-234](#)
 policer aggregate command [2-240](#)
 policer configuration
 default for NNIs [C-23](#)
 default for UNIs [C-22](#)
 policer cpu uni command [2-243](#)
 policers
 aggregate [2-238, 2-240](#)
 for CPU protection [2-243](#)
 individual [2-234](#)
 policy-map class, configuring multiple actions [2-54, 2-90](#)
 policy-map class configuration mode [2-34](#)
 policy-map class police configuration mode [2-54, 2-236](#)
 policy-map command [2-244](#)
 policy-map configuration mode [2-244](#)
 policy maps
 and CoS classification [2-199](#)
 and DSCP classification [2-200](#)
 and IP precedence classification [2-202](#)
 and policing [2-236](#)
 applying [2-274](#)
 applying to an interface [2-245, 2-274, 2-287](#)
 child [2-276](#)
 creating [2-244](#)
 displaying [2-425](#)

policy maps (continued)

- hierarchical [2-276](#)
- parent [2-277](#)
- policers
 - for a single class [2-234](#)
 - for multiple classes [2-238, 2-240, 2-243, 2-276](#)
- setting priority [2-253](#)
- setting QoS group identifier [2-285](#)
- traffic classification, defining [2-34](#)
- traffic marking
 - setting CoS values [2-279](#)
 - setting DSCP values [2-281](#)
 - setting IP precedence values [2-283](#)

Port Aggregation Protocol

See EtherChannel

port-based authentication

- AAA method list [2-3](#)
- debug messages, display [B-3](#)
- enabling 802.1x
 - globally [2-73](#)
 - per interface [2-69](#)
- host modes [2-65](#)
- IEEE 802.1x AAA accounting methods [2-1](#)
- initialize an interface [2-66](#)
- manual control of authorization state [2-69](#)
- multiple hosts on authorized port [2-65](#)
- periodic re-authentication
 - enabling [2-72](#)
 - time between attempts [2-74](#)
- quiet period between failed authentication exchanges [2-74](#)
- re-authenticating 802.1x-enabled ports [2-71](#)
- resetting configurable 802.1x parameters [2-64](#)
- switch-to-authentication server retransmission time [2-74](#)
- switch-to-client frame-retransmission number [2-67 to 2-68](#)
- switch-to-client retransmission time [2-74](#)

port-channel load-balance command [2-247](#)**Port Fast, for spanning tree [2-512](#)****port ranges, defining [2-56](#)****ports, debugging [B-60](#)****ports, protected [2-546](#)****port security**

- aging [2-542](#)
- debug messages, display [B-62](#)
- enabling [2-538](#)
- violation error recovery [2-80](#)

port shaping [2-291](#)**port-type command [2-249](#)****port types, MVR [2-221](#)****power information, displaying [2-320](#)****power-supply dual command [2-251](#)****precedence**

- for QoS traffic marking [2-283](#)
- setting in policy maps [2-283](#)

priority command [2-253](#)**priority queuing, QoS [2-253](#)****priority with police, QoS [2-253](#)****private-vlan command [2-256](#)****private-vlan mapping command [2-259](#)****private VLANs**

- association [2-544](#)
- configuring [2-256](#)
- configuring ports [2-535](#)
- displaying [2-451](#)
- host ports [2-535](#)
- mapping
 - configuring [2-544](#)
 - displaying [2-342](#)
- promiscuous ports [2-535](#)

privileged EXEC mode [1-2, 1-3](#)**product identification information, displaying [2-352](#)****promiscuous ports, private VLANs [2-535](#)****PVST+**

See STP

Q

QoS

aggregate policers

applying [2-238](#)

creating [2-240](#)

displaying [2-422](#)

class maps

creating [2-36](#)

defining the match criteria [2-199](#)

displaying [2-301](#)

displaying statistics for [2-425](#), [C-29](#)

policy maps

applying an aggregate policer [2-238](#), [2-240](#), [2-243](#), [2-276](#)

applying to an interface [2-274](#), [2-287](#)

creating [2-244](#)

defining policers [2-234](#)

displaying policy maps [2-425](#)

setting CoS values [2-279](#)

setting DSCP values [2-281](#)

setting IP precedence values [2-283](#)

setting QoS group identifier [2-285](#)

traffic classifications [2-34](#)

table maps

configuring [2-555](#)

displaying [2-445](#)

QoS groups

as match criteria [2-204](#)

for QoS traffic classification [2-285](#)

setting in policy maps [2-285](#)

QoS match criteria

ACLs [2-198](#)

CoS value [2-199](#)

DSCP value [2-200](#), [2-206](#)

precedence value [2-202](#)

QoS group number [2-204](#)

quality of service

See QoS

querytime, MVR [2-218](#)

queue-limit command [2-261](#)

R

rapid per-VLAN spanning-tree plus

See STP

rapid PVST+

See STP

re-authenticating 802.1x-enabled ports [2-71](#)

re-authentication

periodic [2-72](#)

time between attempts [2-74](#)

receiver ports, MVR [2-221](#)

receiving flow-control packets [2-92](#)

recovery mechanism

causes [2-80](#)

display [2-299](#), [2-323](#), [2-327](#)

timer interval [2-80](#)

remote-span command [2-264](#)

Remote Switched Port Analyzer

See RSPAN

rename (boot loader) command [A-17](#)

renew ip dhcp snooping database command [2-266](#)

reset (boot loader) command [A-18](#)

resource templates, displaying [2-434](#)

rmdir (boot loader) command [A-19](#)

rmon collection stats command [2-267](#)

root guard, for spanning tree [2-482](#)

routed ports

IP addresses on [2-104](#)

number supported [2-104](#)

RSPAN

configuring [2-213](#)

displaying [2-410](#)

filter RSPAN traffic [2-213](#)

remote-span command [2-264](#)

RSPAN (continued)

sessions

add interfaces to [2-213](#)displaying [2-410](#)start new [2-213](#)**S**sdm prefer command [2-268](#)

SDM templates

allowed resources [2-269](#)displaying [2-434](#)secure ports, limitations [2-540](#)sending flow-control packets [2-92](#)service instance command [2-270](#)service instances, displaying [2-334](#)service password-recovery command [2-272](#)service policy (policy-map class configuration)
command [2-276](#)service-policy interface configuration command [2-274](#)service-policy policy-map class configuration
command [2-276](#)set (boot loader) command [A-20](#)set cos command [2-279](#)set dscp command [2-281](#)set precedence command [2-283](#)set qos-group command [2-285](#)setup command [2-287](#)SFPs, displaying information about [2-352](#)shape average command [2-290](#)show access-lists command [2-292](#)show aggregate-policer command [2-445](#)show archive status command [2-295](#)show arp access-list command [2-296](#)show boot command [2-297](#)show class-map command [2-301](#)show controllers cpu-interface command [2-302](#)show controllers ethernet-controller command [2-304](#)show controllers tcam command [2-311](#)show controllers utilization command [2-313](#)show controller utilization command [2-313](#)show dot1q-tunnel command [2-315](#)show dot1x command [2-317](#)show env command [2-320](#)show errdisable detect command [2-323](#)show errdisable flap-values command [2-325](#)show errdisable recovery command [2-327](#)show etherchannel command [2-329](#)show ethernet service evc command [2-332](#)show ethernet service instance command [2-334](#)show ethernet service interface command [2-336](#)show flowcontrol command [2-338](#)show idprom command [2-340](#)show interfaces command [2-342](#)show interfaces counters command [2-350](#)show inventory command [2-352](#)show ip arp inspection command [2-354](#)show ipc command [2-375](#)show ip dhcp snooping binding command [2-358](#)show ip dhcp snooping command [2-357](#)show ip dhcp snooping database command [2-360](#)show ip igmp profile command [2-362](#)show ip igmp snooping command [2-363](#)show ip igmp snooping command querier detail [2-369](#)show ip igmp snooping groups command [2-365](#)show ip igmp snooping mrouter command [2-367](#)show ip igmp snooping querier command [2-369](#)show ip igmp snooping querier detail command [2-369](#)show ip source binding command [2-371](#)show ip verify source command [2-373](#)show l2protocol-tunnel command [2-379](#)show lacp command [2-381](#)show link state group command [2-385](#)show mac access-group command [2-387](#)show mac address-table address command [2-391](#)show mac address-table aging time command [2-393](#)show mac address-table command [2-389](#)show mac address-table count command [2-395](#)

- show mac address-table dynamic command [2-397](#)
- show mac address-table interface command [2-399](#)
- show mac address-table learning command [2-401](#)
- show mac address-table move update command [2-402](#)
- show mac address-table notification command [2-45](#), [2-404](#), [B-17](#)
- show mac address-table static command [2-406](#)
- show mac address-table vlan command [2-408](#)
- show monitor command [2-410](#)
- show mvr command [2-412](#)
- show mvr interface command [2-414](#)
- show mvr members command [2-416](#)
- show pagp command [2-418](#)
- show parser macro command [2-420](#)
- show platform acl command [C-2](#)
- show platform cfm command [C-3](#)
- show platform configuration command [C-4](#)
- show platform etherchannel command [C-5](#)
- show platform forward command [C-6](#)
- show platform igmp snooping command [C-8](#)
- show platform ipc trace command [C-13](#)
- show platform ip multicast command [C-10](#)
- show platform ip unicast command [C-11](#)
- show platform layer4op command [C-14](#)
- show platform mac-address-table command [C-15](#)
- show platform messaging command [C-16](#)
- show platform monitor command [C-17](#)
- show platform mvr table command [C-18](#)
- show platform pm command [C-19](#)
- show platform policer cpu command [C-21](#)
- show platform port-asic command [C-24](#)
- show platform port-security command [C-28](#)
- show platform qos command [C-29](#)
- show platform resource-manager command [C-32](#)
- show platform snmp counters command [C-34](#)
- show platform spanning-tree synchronization command [C-35](#)
- show platform stp-instance command [C-36](#)
- show platform team command [C-37](#)
- show platform vlan command [C-40](#)
- show policer aggregate command [2-422](#)
- show policer cpu uni command [2-423](#)
- show policy-map command [2-425](#)
- show policy-map interface output fields [2-428](#)
- show port security command [2-429](#)
- show port-type command [2-432](#)
- show sdm prefer command [2-434](#)
- show spanning-tree command [2-436](#)
- show storm-control command [2-442](#)
- show system mtu command [2-444](#)
- show udd command [2-447](#)
- show version command [2-449](#)
- show vlan access-map command [2-456](#)
- show vlan command [2-451](#)
- show vlan command, fields [2-453](#)
- show vlan filter command [2-457](#)
- show vmps command [2-458](#)
- shutdown command [2-461](#)
- shutdown threshold, Layer 2 protocol tunneling [2-160](#)
- shutdown vlan command [2-462](#)
- SNMP host, specifying [2-466](#)
- SNMP informs, enabling the sending of [2-463](#)
- snmp-server enable traps command [2-463](#)
- snmp-server host command [2-466](#)
- snmp trap mac-notification command [2-470](#)
- SNMP traps
 - enabling MAC address notification trap [2-470](#)
 - enabling the MAC address notification feature [2-183](#)
 - enabling the sending of [2-463](#)
- software images
 - deleting [2-58](#)
 - downloading [2-7](#)
 - upgrading [2-7](#)
 - uploading [2-13](#)
- software version, displaying [2-449](#)
- source ports, MVR [2-221](#)

SPAN

- configuring [2-213](#)
- debug messages, display [B-18](#)
- displaying [2-410](#)
- filter SPAN traffic [2-213](#)
- sessions
 - add interfaces to [2-213](#)
 - displaying [2-410](#)
 - start new [2-213](#)
- spanning-tree bpdupfilter command [2-472](#)
- spanning-tree bpduguard command [2-474](#)
- spanning-tree cost command [2-476](#)
- spanning-tree etherchannel command [2-478](#)
- spanning-tree extend system-id command [2-480](#)
- spanning-tree guard command [2-482](#)
- spanning-tree link-type command [2-484](#)
- spanning-tree loopguard default command [2-486](#)
- spanning-tree mode command [2-488](#)
- spanning-tree mst configuration command [2-490](#)
- spanning-tree mst cost command [2-492](#)
- spanning-tree mst forward-time command [2-494](#)
- spanning-tree mst hello-time command [2-495](#)
- spanning-tree mst max-age command [2-497](#)
- spanning-tree mst max-hops command [2-499](#)
- spanning-tree mst port-priority command [2-501](#)
- spanning-tree mst pre-standard command [2-503](#)
- spanning-tree mst priority command [2-504](#)
- spanning-tree mst root command [2-506](#)
- spanning-tree portfast (global configuration)
 - command [2-510](#)
- spanning-tree portfast (interface configuration)
 - command [2-512](#)
- spanning-tree port-priority command [2-508](#)
- Spanning Tree Protocol
 - See STP
- spanning-tree vlan command [2-514](#)
- speed command [2-517](#)
- SSH, configuring version [2-156](#)
- static-access ports, configuring [2-524](#)

statistics, Ethernet group [2-267](#)

sticky learning, enabling [2-538](#)

storm-control command [2-519](#)

STP

- counters, clearing [2-50](#)
- debug messages, display
 - MSTP [B-68](#)
 - optimized BPDUs handling [B-67](#)
 - spanning-tree activity [B-64](#)
 - switch shim [B-70](#)
 - transmitted and received BPDUs [B-66](#)
- enabling protocol tunneling for [2-160](#)
- EtherChannel misconfiguration [2-478](#)
- extended system ID [2-480](#)
- path cost [2-476](#)
- protocol modes [2-488](#)
- root port
 - loop guard [2-482](#)
 - preventing from becoming designated [2-482](#)
 - restricting which can be root [2-482](#)
 - root guard [2-482](#)
- root switch
 - affects of extended system ID [2-480, 2-515](#)
 - hello-time [2-514](#)
 - interval between BPDU messages [2-514](#)
 - interval between hello BPDU messages [2-514](#)
 - max-age [2-514](#)
 - port priority for selection of [2-508](#)
 - primary or secondary [2-514](#)
 - switch priority [2-514](#)

STP (continued)

- state changes
 - blocking to forwarding state [2-512](#)
 - enabling BPDU filtering [2-472, 2-510](#)
 - enabling BPDU guard [2-474, 2-510](#)
 - enabling Port Fast [2-510, 2-512](#)
 - enabling timer to recover from error state [2-80](#)
 - forward-delay time [2-514](#)
 - length of listening and learning states [2-514](#)
 - shutting down Port Fast-enabled ports [2-510](#)
- state information display [2-436](#)
- VLAN options [2-504, 2-514](#)

SVIs, creating [2-98](#)

Switched Port Analyzer

- See SPAN

switching characteristics

- modifying [2-522](#)
- returning to interfaces [2-522](#)

switchport access command [2-524](#)

switchport backup interface command [2-526](#)

switchport block command [2-529](#)

switchport command [2-522](#)

switchport host command [2-531](#)

switchport mode command [2-532](#)

switchport mode private-vlan command [2-535](#)

switchport port-security aging command [2-542](#)

switchport port-security command [2-538](#)

switchport private-vlan command [2-544](#)

switchport protected command [2-546](#)

switchports, displaying [2-342](#)

switchport trunk command [2-548](#)

system env temperature threshold yellow command [2-550](#)

system message logging, save message to flash [2-172](#)

system mtu command [2-552](#)

system resource templates [2-268](#)

T

table-map command [2-555](#)

table-map configuration mode [2-555](#)

table maps

- configuring [2-555](#)
- displaying [2-445](#)
- QoS [2-555](#)

tar files, creating, listing, and extracting [2-10](#)

TDR, running [2-557](#)

temperature information, displaying [2-320](#)

templates, system resources [2-268](#)

test cable-diagnostics tdr command [2-557](#)

traceroute mac command [2-559](#)

traceroute mac ip command [2-562](#)

traffic shaping, QoS [2-290](#)

trunking, VLAN mode [2-532](#)

trunk mode [2-532](#)

trunk ports [2-532](#)

tunnel ports, Layer 2 protocol, displaying [2-379](#)

type (boot loader) command [A-23](#)

U**UDLD**

- aggressive mode [2-564, 2-566](#)
- debug messages, display [B-77](#)
- enable globally [2-564](#)
- enable per interface [2-566](#)
- error recovery timer [2-80](#)
- message timer [2-564](#)
- normal mode [2-564, 2-566](#)
- reset a shutdown interface [2-568](#)
- status [2-447](#)

udld command [2-564](#)

udld port command [2-566](#)

udld reset command [2-568](#)

UNI

- bundling and multiplexing [2-87](#)
- Ethernet [2-87](#)

unicast storm control [2-519](#)

uni count command [2-569](#)

UniDirectional Link Detection

See UDLD

UNI ID, Ethernet [2-89](#)

uni-vlan command [2-571](#)

unknown multicast traffic, preventing [2-529](#)

unknown unicast traffic, preventing [2-529](#)

unset (boot loader) command [A-24](#)

upgrading

software images [2-7](#)

monitoring status of [2-295](#)

upgrading information

See release notes

user EXEC mode [1-2](#)

user network interface [2-249](#)

V

version (boot loader) command [A-26](#)

vlan access-map command [2-576](#)

VLAN access map configuration mode [2-576](#)

VLAN access maps

actions [2-5](#)

displaying [2-456](#)

vlan command [2-573](#)

VLAN configuration mode

commands [2-573](#)

description [1-4](#)

entering [2-573](#)

summary [1-2](#)

vlan dot1q tag native command [2-578](#)

vlan filter command [2-580](#)

VLAN filters, displaying [2-457](#)

VLAN ID range [2-573](#)

VLAN maps

applying [2-580](#)

creating [2-576](#)

defining [2-196](#)

displaying [2-456](#)

VLAN Query Protocol

See VQP

VLANs

adding [2-573](#)

configuring [2-573](#)

debug messages, display

activation of [B-75](#)

VLAN IOS file system error tests [B-74](#)

VLAN manager activity [B-72](#)

displaying configurations [2-451](#)

extended-range [2-573](#)

MAC addresses

displaying [2-408](#)

number of [2-395](#)

normal-range [2-573](#)

private [2-535](#)

configuring [2-256](#)

displaying [2-451](#)

See also private VLANs

restarting [2-462](#)

saving the configuration [2-573](#)

shutting down [2-462](#)

suspending [2-462](#)

VMPS

configuring servers [2-585](#)

displaying [2-458](#)

error recovery timer [2-80](#)

reconfirming dynamic VLAN assignments [2-582](#)

vmpls reconfirm (global configuration) command [2-583](#)

vmpls reconfirm (privileged EXEC) command [2-582](#)

vmpls retry command [2-584](#)

vmpls server command [2-585](#)

VQP

and dynamic-access ports [2-525](#)

clearing client statistics [2-53](#)

displaying information [2-458](#)

per-server retry count [2-584](#)

reconfirmation interval [2-583](#)

reconfirming dynamic VLAN assignments [2-582](#)

VTP, enabling tunneling for [2-160](#)

W

Weighted Tail Drop

See WTD

WTD, queue-limit command [2-261](#)

