



INDEX

A

aaa accounting dot1x command [2-1](#)
aaa authentication dot1x command [2-3](#)
AAA methods [2-3](#)
access control entries
 See ACEs
access control lists
 See ACLs
access groups
 IP [2-104](#)
 MAC, displaying [2-417](#)
 matching for QoS classification [2-207](#)
access mode [2-567](#)
access ports [2-567](#)
ACEs [2-64, 2-242](#)
ACLs
 as match criteria for QoS classes [2-207](#)
 deny [2-62](#)
 displaying [2-312](#)
 for non-IP protocols [2-185](#)
 IP [2-104](#)
 on Layer 2 interfaces [2-104](#)
 permit [2-240](#)
action command [2-5](#)
address aliasing [2-228](#)
aggregate policers
 applying [2-247](#)
 creating [2-249](#)
 displaying [2-452](#)
 QoS [2-250](#)

aggregate-port learner [2-234](#)
allowed VLANs [2-583](#)
archive download-sw command [2-7](#)
archive tar command [2-10](#)
archive upload-sw command [2-13](#)
arp access-list command [2-15](#)
attaching policy maps to interfaces [2-294](#)
audience [xvii](#)
authorization state of controlled port [2-70](#)
autonegotiation of duplex mode [2-78](#)

B

backup interfaces
 configuring [2-560](#)
 displaying [2-362](#)
bandwidth, configuring for QoS [2-17](#)
bandwidth command [2-17](#)
boot (boot loader) command [A-2](#)
boot bootlpr command [2-20](#)
boot config-file command [2-21](#)
boot enable-break command [2-22](#)
boot helper command [2-23](#)
boot helper-config file command [2-24](#)
booting
 Cisco IOS image [2-27](#)
 displaying environment variables [2-317](#)
 interrupting [2-22](#)
 manually [2-25](#)

boot loader

accessing [A-1](#)

booting

Cisco IOS image [A-2](#)helper image [2-23](#)

directories

creating [A-14](#)displaying a list of [A-7](#)removing [A-18](#)

displaying

available commands [A-12](#)memory heap utilization [A-13](#)version [A-25](#)

environment variables

described [A-19](#)displaying settings [A-19](#)location of [A-20](#)setting [A-19](#)unsetting [A-23](#)

files

copying [A-5](#)deleting [A-6](#)displaying a list of [A-7](#)displaying the contents of [A-4, A-15, A-22](#)renaming [A-16](#)

file system

formatting [A-10](#)initializing flash [A-9](#)running a consistency check [A-11](#)prompt [A-1](#)resetting the system [A-17](#)boot manual command [2-25](#)boot private-config-file command [2-26](#)boot system command [2-27](#)BPDU filtering, for spanning tree [2-506, 2-544](#)BPDU guard, for spanning tree [2-508, 2-544](#)broadcast storm control [2-553](#)bundling characteristics, UNI [2-86](#)burst bytes, in QoS policers [2-243, 2-249](#)**C**cat (boot loader) command [A-4](#)caution, description [xviii](#)CBWFQ, configuring [2-17](#)CDP, enabling protocol tunneling for [2-165](#)CFM [2-233](#)CFM as OAM protocol [2-233](#)channel-group command [2-28](#)channel-protocol command [2-32](#)child policy maps [2-296](#)class-based traffic shaping [2-310](#)

class-based weighted fair queuing

See CBWFQ

class command [2-34](#)class-map command [2-36](#)class-map configuration mode [2-37](#)

class maps

creating [2-36](#)defining the match criteria [2-208](#)displaying [2-321](#)matching in [2-36](#)

class of service

See CoS

clear ip arp inspection log command [2-38](#)clear ip arp inspection statistics command [2-39](#)clear ipc command [2-42](#)clear l2protocol-tunnel counters command [2-43](#)clear lacp command [2-44](#)clear mac address-table command [2-45, 2-46](#)clear pagp command [2-47](#)clear policer cpu uni counters command [2-48](#)clear port-security command [2-49](#)clear spanning-tree counters command [2-51](#)clear spanning-tree detected-protocols command [2-52](#)clear vmpps statistics command [2-54](#)command modes defined [1-1](#)committed information rate in QoS policers [2-243, 2-249](#)

configuration, initial
 See also getting started guide and hardware installation guide

configuration files
 password recovery disable considerations [A-1](#)
 specifying the name [2-21, 2-26](#)

configuring multiple interfaces [2-99](#)

conform-action command [2-55](#)

control-plane policer [2-48](#)

control-plane policer information, displaying [2-453](#)

control-plane security [2-252](#)

control plane statistics, clearing [2-48](#)

conventions
 command [xviii](#)
 for examples [xviii](#)
 publication [xviii](#)
 text [xviii](#)

copy (boot loader) command [A-5](#)

CoS
 as match criteria for QoS groups [2-208](#)
 for QoS classification [2-299](#)
 setting value in policy maps [2-299](#)

CoS value, assigning to Layer 2 protocol packets [2-168](#)

CPU ASIC statistics, displaying [2-322](#)

CPU protection policers, displaying [C-21](#)

D

debug backup command [B-2](#)

debug dot1x command [B-3](#)

debug etherchannel command [B-4](#)

debug interface command [B-9](#)

debug ip dhcp snooping command [B-7](#)

debug ip igmp filter command [B-10](#)

debug ip igmp max-groups command [B-11](#)

debug ip igmp snooping command [B-12](#)

debug ip verify source packet command [B-8](#)

debug lacp command [B-13](#)

debug mac-notification command [B-14](#)

debug matm command [B-15](#)

debug matm move update command [B-16](#)

debug monitor command [B-17](#)

debug mvrdbg command [B-18](#)

debug nvram command [B-19](#)

debug pagp command [B-20](#)

debug platform acl command [B-21](#)

debug platform backup interface command [B-23](#)

debug platform cfm command [B-22](#)

debug platform cpu-queues command [B-24](#)

debug platform dot1x command [B-26](#)

debug platform etherchannel command [B-27](#)

debug platform forw-tcam command [B-28](#)

debug platform ip arp inspection command [B-29](#)

debug platform ipc command [B-37](#)

debug platform ip dhcp command [B-30](#)

debug platform ip igmp snooping command [B-31](#)

debug platform ip multicast command [B-33](#)

debug platform led command [B-38](#)

debug platform matm command [B-39](#)

debug platform messaging application command [B-40](#)

debug platform phy command [B-41](#)

debug platform pm command [B-43](#)

debug platform policer cpu uni command [B-45](#)

debug platform port-asic command [B-46](#)

debug platform port-security command [B-47](#)

debug platform qos-acl-tcam command [B-48](#)

debug platform remote-commands command [B-49](#)

debug platform resource-manager command [B-50](#)

debug platform snmp command [B-51](#)

debug platform span command [B-52](#)

debug platform supervisor-asic command [B-53](#)

debug platform sw-bridge command [B-54](#)

debug platform tcam command [B-55](#)

debug platform udd command [B-57](#)

debug platform vlan command [B-58](#)

debug pm command [B-59](#)

debug port-security command [B-61](#)

debug qos-manager command [B-62](#)

- debug spanning-tree bpdu command [B-65](#)
- debug spanning-tree bpdu-opt command [B-66](#)
- debug spanning-tree command [B-63](#)
- debug spanning-tree mstp command [B-67](#)
- debug spanning-tree switch command [B-69](#)
- debug sw-vlan command [B-71](#)
- debug sw-vlan ifs command [B-73](#)
- debug sw-vlan notification command [B-74](#)
- debug udd command [B-76](#)
- debug vqpc command [B-78](#)
- default
 - policer configuration
 - NNIs [C-23](#)
 - UNIs [C-22](#)
- define interface-range command [2-57](#)
- delete (boot loader) command [A-6](#)
- delete command [2-59](#)
- deny (ARP access-list configuration) command [2-60](#)
- deny command [2-62](#)
- detect mechanism, causes [2-79](#)
- DHCP snooping
 - accepting untrusted packets from edge switch [2-129](#)
 - enabling
 - on a VLAN [2-135](#)
 - option 82 [2-127, 2-129](#)
 - trust on an interface [2-133](#)
 - error recovery timer [2-81](#)
 - rate limiting [2-132](#)
- DHCP snooping binding database
 - binding file, configuring [2-125](#)
 - bindings
 - adding [2-123](#)
 - deleting [2-123](#)
 - displaying [2-382](#)
 - clearing database agent statistics [2-40](#)
 - database agent, configuring [2-125](#)
- DHCP snooping binding database (continued)**
 - displaying
 - binding entries [2-382](#)
 - database agent status [2-384, 2-386](#)
 - renewing [2-275](#)
 - differentiated service code point
 - See DSCP
 - dir (boot loader) command [A-7](#)
 - directories, deleting [2-59](#)
 - documentation, related [xviii](#)
 - document conventions [xviii](#)
 - domains, CFM [2-233](#)
 - dot1x default command [2-65](#)
 - dot1x host-mode command [2-66](#)
 - dot1x initialize command [2-67](#)
 - dot1x max-req command [2-68, 2-69](#)
 - dot1x port-control command [2-70](#)
 - dot1x re-authenticate command [2-72](#)
 - dot1x reauthentication command [2-73](#)
 - dot1x system-auth-control command [2-74](#)
 - dot1x timeout command [2-75](#)
 - dropping packets, with ACL matches [2-5](#)
 - drop threshold, Layer 2 protocol tunneling [2-165](#)
 - DSCP
 - as match criteria for QoS groups [2-209, 2-215](#)
 - for QoS traffic marking [2-301](#)
 - setting in policy maps [2-301](#)
 - dual-purpose uplink ports, selecting the type [2-220](#)
 - duplex command [2-77](#)
 - dynamic-access ports
 - configuring [2-558](#)
 - restrictions [2-559](#)
 - dynamic ARP inspection
 - ARP ACLs
 - apply to a VLAN [2-109](#)
 - define [2-15](#)
 - deny packets [2-60](#)
 - display [2-316](#)
 - permit packets [2-238](#)

dynamic ARP inspection (continued)

- clear
 - log buffer [2-38](#)
 - statistics [2-39](#)
- display
 - ARP ACLs [2-316](#)
 - configuration and operating state [2-377](#)
 - log buffer [2-377](#)
 - statistics [2-377](#)
 - trust state and rate limit [2-377](#)
- enable per VLAN [2-119](#)
- error detection for [2-79](#)
- error recovery timer [2-81](#)
- log buffer
 - clear [2-38](#)
 - configure [2-113](#)
 - display [2-377](#)
- rate-limit incoming ARP packets [2-111](#)
- statistics
 - clear [2-39](#)
 - display [2-377](#)
- trusted interface state [2-115](#)
- type of packet logged [2-120](#)
- validation checks [2-117](#)

Dynamic Host Configuration Protocol (DHCP)

See DHCP snooping

E**EAP-request/identity frame**

- maximum number to send [2-69](#)
- response time before retransmitting [2-75](#)

E-LMI

- enabling [2-84](#)

E-LMI mapping [2-86](#)**environment variables, displaying** [2-317](#)**errdisable detect cause command** [2-79](#)**errdisable recovery command** [2-81](#)**error conditions, displaying** [2-345](#)**error disable detection** [2-79](#)**error-disabled interfaces, displaying** [2-362](#)**EtherChannel**

- assigning Ethernet interface to channel group [2-28](#)
- creating port-channel logical interface [2-97](#)
- debug EtherChannel/PAgP, display [B-4](#)
- debug platform-specific events, display [B-27](#)
- displaying [2-349](#)
- enabling Layer 2 protocol tunneling for
 - LACP [2-166](#)
 - PAgP [2-166](#)
 - UDLD [2-166](#)

interface information, displaying [2-362](#)**LACP**

- clearing channel-group information [2-44](#)
- debug messages, display [B-13](#)
- displaying [2-408](#)
- modes [2-28](#)
- port priority for hot-standby ports [2-169](#)
- restricting a protocol [2-32](#)
- system priority [2-171](#)

load-distribution methods [2-256](#)**PAgP**

- aggregate-port learner [2-234](#)
- clearing channel-group information [2-47](#)
- debug messages, display [B-20](#)
- displaying [2-448](#)
- error detection for [2-79](#)
- error recovery timer [2-81](#)
- learn method [2-234](#)
- modes [2-28](#)
- physical-port learner [2-234](#)
- priority of interface for transmitted traffic [2-236](#)

ethermet lmi ce command [2-84](#)**Ethernet controller, internal register display** [2-324](#)**ethernet evc command** [2-83](#)**ethernet lim global command** [2-84](#)**ethernet lmi ce-vlan map command** [2-86, 2-88](#)**ethernet lmi command** [2-84](#)

Ethernet Local Management Interface

See E-LMI

Ethernet service

debugging [B-5](#)displaying [2-352](#)Ethernet service instance [2-290](#)Ethernet service interfaces [2-356](#)Ethernet statistics, collecting [2-287](#)Ethernet UNI configuration [2-90](#)ethernet uni id command [2-92](#)

Ethernet virtual connections

See EVCs

EVC configuration mode [2-83](#)EVCs [2-83](#)and VLANs [2-90](#)service instances [2-290](#)UNI counts [2-604](#)

EVC service

point-to-multipoint [2-604](#)point-to-point [2-604](#)examples, conventions for [xviii](#)exceed-action command [2-93](#)

extended-range VLANs

and allowed VLAN list [2-583](#)configuring [2-608](#)extended system ID for STP [2-514](#)

Ffan information, displaying [2-340](#)files, deleting [2-59](#)flash_init (boot loader) command [A-9](#)

Flex Links

configuring [2-560](#)configuring preferred VLAN [2-562](#)displaying [2-362](#)flowcontrol command [2-95](#)format (boot loader) command [A-10](#)forwarding packets, with ACL matches [2-5](#)forwarding results, display [C-6](#)frame forwarding information, displaying [C-6](#)fsck (boot loader) command [A-11](#)

Gglobal configuration mode [1-2, 1-3](#)

Hhardware ACL statistics [2-312](#)help (boot loader) command [A-12](#)host connection, port configuration [2-566](#)host ports, private VLANs [2-570](#)

I

IEEE 802.1ag Connectivity Fault Management

See CFM

IEEE 802.1Q trunk ports and native VLANs [2-613](#)

IEEE 802.1Q tunnel ports

configuring [2-567](#)displaying [2-335](#)limitations [2-568](#)

IEEE 802.1x

and switchport modes [2-568](#)violation error recovery [2-81](#)

See also port-based authentication

IGMP filters

applying [2-138](#)debug messages, display [B-10](#)IGMP groups, setting maximum [2-140](#)IGMP maximum groups, debugging [B-11](#)

IGMP profiles

creating [2-142](#)displaying [2-389](#)

- IGMP snooping
 - adding ports as a static member of a group [2-157](#)
 - displaying [2-390, 2-394, 2-396](#)
 - enabling [2-144](#)
 - enabling the configurable-leave timer [2-146](#)
 - enabling the Immediate-Leave feature [2-154](#)
 - flooding query count [2-152](#)
 - interface topology change notification behavior [2-153](#)
 - multicast table [2-392](#)
 - querier [2-148](#)
 - query solicitation [2-152](#)
 - report suppression [2-150](#)
 - switch topology change notification behavior [2-152](#)
- images
 - See software images
- Immediate-Leave feature, MVR [2-230](#)
- immediate-leave processing [2-154](#)
- initial configuration
 - See also getting started guide and hardware installation guide
- input policy maps
 - and ACL classification [2-207](#)
 - and aggregate policers [2-250](#)
 - commands not supported in [2-254](#)
 - configuration guidelines [2-254](#)
- interface command [2-102](#)
- interface configuration mode [1-2, 1-4](#)
- interface port-channel command [2-97](#)
- interface range command [2-99](#)
- interface-range macros [2-57](#)
- interfaces
 - assigning Ethernet interface to channel group [2-28](#)
 - configuring [2-77](#)
 - configuring multiple [2-99](#)
 - creating port-channel logical [2-97](#)
 - debug messages, display [B-9](#)
 - disabling [2-493](#)
 - displaying the MAC address table [2-429](#)
 - restarting [2-493](#)
 - interface speed, configuring [2-551](#)
 - internal registers, displaying [2-324, 2-331](#)
 - Internet Group Management Protocol
 - See IGMP
 - invalid GBIC
 - error detection for [2-79](#)
 - error recovery timer [2-81](#)
 - ip address command [2-107](#)
 - IP addresses, setting [2-107](#)
 - IP address matching [2-205](#)
 - ip arp inspection filter vlan command [2-109](#)
 - ip arp inspection limit command [2-111](#)
 - ip arp inspection log-buffer command [2-113](#)
 - ip arp inspection trust command [2-115](#)
 - ip arp inspection validate command [2-117](#)
 - ip arp inspection vlan command [2-119](#)
 - ip arp inspection vlan logging command [2-120](#)
 - IP DHCP snooping
 - See DHCP snooping
 - ip dhcp snooping binding command [2-123](#)
 - ip dhcp snooping command [2-122](#)
 - ip dhcp snooping database command [2-125](#)
 - ip dhcp snooping information option allow-untrusted command [2-129](#)
 - ip dhcp snooping information option command [2-127](#)
 - ip dhcp snooping information option format remote-id command [2-131](#)
 - ip dhcp snooping limit rate command [2-132](#)
 - ip dhcp snooping trust command [2-133](#)
 - ip dhcp snooping verify command [2-134](#)
 - ip dhcp snooping vlan command [2-135](#)
 - ip dhcp snooping vlan information option format-type circuit-id string command [2-136](#)
 - ip igmp filter command [2-138](#)
 - ip igmp max-groups command [2-140](#)
 - ip igmp profile command [2-142](#)
 - ip igmp snooping command [2-144](#)
 - ip igmp snooping last-member-query-interval command [2-146](#)
 - ip igmp snooping querier command [2-148](#)

ip igmp snooping report-suppression command [2-150](#)
 ip igmp snooping tcn command [2-152](#)
 ip igmp snooping tcn flood command [2-153](#)
 ip igmp snooping vlan immediate-leave command [2-154](#)
 ip igmp snooping vlan mrouter command [2-155](#)
 ip igmp snooping vlan static command [2-157](#)
 IP multicast addresses [2-227](#)
 IP precedence, as match criteria for QoS groups [2-211](#)
 ip source binding command [2-159](#)
 IP source guard

- disabling [2-163](#)
- displaying
 - binding entries [2-398](#)
 - configuration [2-400](#)
- enabling [2-163](#)
- static IP source bindings [2-159](#)

 IP source guard, displaying dynamic binding entries [2-382](#)
 ip ssh command [2-161](#)
 ip verify source command [2-163](#)

J

jumbo frames
 See MTU

L

l2protocol-tunnel command [2-165](#)
 l2protocol-tunnel cos command [2-168](#)
 LACP

- See EtherChannel

 lacp port-priority command [2-169](#)
 lacp system-priority command [2-171](#)
 Layer 2 mode, enabling [2-556](#)
 Layer 2 protocol ports, displaying [2-406](#)
 Layer 2 protocol-tunnel

- error detection for [2-79](#)
- error recovery timer [2-81](#)

Layer 2 protocol tunnel counters [2-43](#)
 Layer 2 protocol tunneling error recovery [2-166](#)
 Layer 2 traceroute

- IP addresses [2-597](#)
- MAC addresses [2-594](#)

 Layer 3 mode, enabling [2-556](#)
 line configuration mode [1-2, 1-4](#)
 Link Aggregation Control Protocol

- See EtherChannel

 link flap

- error detection for [2-79](#)
- error recovery timer [2-81](#)

 link state group command [2-173](#)
 link state track command [2-175](#)
 load-distribution methods for EtherChannel [2-256](#)
 location (global configuration) command [2-176](#)
 location (interface configuration) command [2-178](#)
 logging event command [2-180](#)
 logging file command [2-181](#)
 logical interface [2-97](#)
 loopback error

- detection for [2-79](#)
- recovery timer [2-81](#)

 loop guard, for spanning tree [2-516, 2-520](#)

M

mac access-group command [2-183](#)
 MAC access-groups, displaying [2-417](#)
 MAC access list configuration mode [2-185](#)
 mac access-list extended command [2-185](#)
 MAC access lists [2-62](#)

MAC addresses

disabling MAC address learning per VLAN [2-188](#)

displaying

aging time [2-423](#)

all [2-421](#)

dynamic [2-427](#)

MAC address-table move updates [2-432](#)

notification settings [2-431, 2-434](#)

number of addresses in a VLAN [2-425](#)

per interface [2-429](#)

per VLAN [2-438](#)

static [2-436](#)

static and dynamic entries [2-419](#)

dynamic

aging time [2-187](#)

deleting [2-45](#)

displaying [2-427](#)

enabling MAC address notification [2-192](#)

enabling MAC address-table move update [2-190](#)

matching [2-205](#)

static

adding and removing [2-194](#)

displaying [2-436](#)

dropping on an interface [2-195](#)

tables [2-421](#)

MAC address notification, debugging [B-14](#)

mac address-table aging-time [2-183, 2-205](#)

mac address-table aging-time command [2-187](#)

mac address-table learning command [2-188](#)

mac address-table move update command [2-190](#)

mac address-table notification command [2-192](#)

mac address-table static command [2-194](#)

mac address-table static drop command [2-195](#)

macro description command [2-199](#)

macro global command [2-200](#)

macro global description command [2-202](#)

macro name command [2-203](#)

macros

adding a description [2-199](#)

adding a global description [2-202](#)

applying [2-200](#)

creating [2-203](#)

displaying [2-450](#)

interface range [2-57, 2-99](#)

specifying parameter values [2-200](#)

tracing [2-200](#)

maintenance end points [2-604](#)

manual

audience [xvii](#)

purpose of [xvii](#)

mapping tables, QoS [2-590](#)

maps

class

creating [2-36](#)

VLAN

creating [2-611](#)

defining [2-205](#)

displaying [2-489](#)

match access-group command [2-207](#)

match cos command [2-208](#)

match ip dscp command [2-209](#)

match ip precedence command [2-211](#)

match qos-group command [2-213](#)

match vlan command [2-215](#)

maximum transmission unit

See MTU

mdix auto command [2-218](#)

media-type command [2-220](#)

memory (boot loader) command [A-13](#)

mkdir (boot loader) command [A-14](#)

mode, MVR [2-227](#)

modes, commands [1-1](#)

monitor session command [2-222](#)

more (boot loader) command [A-15](#)

MSTP

- displaying [2-469, 2-470](#)
- interoperability [2-52](#)
- link type [2-518](#)
- MST region
 - aborting changes [2-524](#)
 - applying changes [2-524](#)
 - configuration name [2-524](#)
 - configuration revision number [2-524](#)
 - current or pending display [2-524](#)
 - displaying [2-469, 2-470](#)
 - MST configuration mode [2-524](#)
 - VLANs-to-instance mapping [2-524](#)
- path cost [2-526](#)
- protocol mode [2-522](#)
- restart protocol migration process [2-52](#)
- root port
 - loop guard [2-516](#)
 - preventing from becoming designated [2-516](#)
 - restricting which can be root [2-516](#)
 - root guard [2-516](#)
- root switch
 - affects of extended system ID [2-514](#)
 - hello-time [2-529, 2-540](#)
 - interval between BPDU messages [2-531](#)
 - interval between hello BPDU messages [2-529, 2-540](#)
 - max-age [2-531](#)
 - maximum hop count before discarding BPDU [2-533](#)
 - port priority for selection of [2-535](#)
 - primary or secondary [2-540](#)
 - switch priority [2-538](#)

MSTP (continued)

- state changes
 - blocking to forwarding state [2-546](#)
 - enabling BPDU filtering [2-506, 2-544](#)
 - enabling BPDU guard [2-508, 2-544](#)
 - enabling Port Fast [2-544, 2-546](#)
 - forward-delay time [2-528](#)
 - length of listening and learning states [2-528](#)
 - rapid transition to forwarding [2-518](#)
 - shutting down Port Fast-enabled ports [2-544](#)
 - state information display [2-468](#)
- MTU
- configuring size [2-587](#)
 - displaying global setting [2-477](#)
- multicast group address, MVR [2-230](#)
- multicast groups, MVR [2-228](#)
- multicast router learning method [2-155](#)
- multicast router ports, configuring [2-155](#)
- multicast storm control [2-553](#)
- multicast VLAN, MVR [2-227](#)
- multicast VLAN registration
- See MVR
- multiple hosts on authorized port [2-66](#)
- Multiple Spanning Tree Protocol
- See MSTP
- multiplexing, UNI [2-90](#)
- MVR
- and address aliasing [2-228](#)
 - configuring [2-227](#)
 - configuring interfaces [2-230](#)
 - debug messages, display [B-18](#)
 - displaying [2-442](#)
 - displaying interface information [2-444](#)
 - members, displaying [2-446](#)
 - mvr (global configuration) command [2-227](#)
 - mvr (interface configuration) command [2-230](#)
 - mvr vlan group command [2-231](#)

N

native VLANs [2-583](#)
 native VLAN tagging [2-613](#)
 network node interface [2-258](#)
 nonegotiate, speed [2-551, 2-552](#)
 non-IP protocols
 denying [2-62](#)
 forwarding [2-240](#)
 non-IP traffic access lists [2-185](#)
 non-IP traffic forwarding
 denying [2-62](#)
 permitting [2-240](#)
 normal-range VLANs [2-608](#)
 note, description [xviii](#)
 no vlan command [2-608](#)

O

OAM PDUs [2-88](#)
 OAM protocol [2-233](#)
 oam protocol cfm svlan command [2-233](#)
 operation, administration, and maintenance protocol
 See OAM
 output policy maps
 and QoS group classification [2-213](#)
 and traffic shaping [2-310](#)
 commands not supported in [2-254](#)
 configuration guidelines [2-254](#)
 priority in [2-263](#)
 queue limit in [2-270](#)

P

PAgP
 See EtherChannel
 pagp learn-method command [2-234](#)
 pagp port-priority command [2-236](#)
 parent policy maps [2-297](#)

password-recovery mechanism, enabling and disabling [2-292](#)
 permit (ARP access-list configuration) command [2-238](#)
 permit command [2-240](#)
 per-VLAN spanning-tree plus
 See STP
 physical-port learner [2-234](#)
 PID, displaying [2-375](#)
 PIM-DVMRP, as multicast router learning method [2-155](#)
 police
 multiple conform actions for a class [2-55](#)
 multiple exceed actions for a class [2-93](#)
 with priority [2-243](#)
 police aggregate command [2-247](#)
 police command [2-243](#)
 policer aggregate command [2-249](#)
 policer configuration
 default for NNIs [C-23](#)
 default for UNIs [C-22](#)
 policer cpu uni command [2-252](#)
 policers
 aggregate [2-247, 2-249](#)
 for CPU protection [2-252](#)
 individual [2-243](#)
 policy-map class, configuring multiple actions [2-55, 2-93](#)
 policy-map class configuration mode [2-34](#)
 policy-map class police configuration mode [2-55, 2-245](#)
 policy-map command [2-253](#)
 policy-map configuration mode [2-253](#)
 policy maps
 and CoS classification [2-208](#)
 and DSCP classification [2-209](#)
 and IP precedence classification [2-211](#)
 and policing [2-245](#)
 applying [2-294](#)
 applying to an interface [2-254, 2-294, 2-307](#)
 child [2-296](#)
 creating [2-253](#)
 displaying [2-455](#)

policy maps (continued)

- hierarchical [2-296](#)
- parent [2-297](#)
- policers
 - for a single class [2-243](#)
 - for multiple classes [2-247, 2-249, 2-252, 2-296](#)
- setting priority [2-262](#)
- setting QoS group identifier [2-305](#)
- traffic classification, defining [2-34](#)
- traffic marking
 - setting CoS values [2-299](#)
 - setting DSCP values [2-301](#)
 - setting IP precedence values [2-303](#)

Port Aggregation Protocol

See EtherChannel

port-based authentication

- AAA method list [2-3](#)
- debug messages, display [B-3](#)
- enabling 802.1x
 - globally [2-74](#)
 - per interface [2-70](#)
- host modes [2-66](#)
- IEEE 802.1x AAA accounting methods [2-1](#)
- initialize an interface [2-67](#)
- manual control of authorization state [2-70](#)
- multiple hosts on authorized port [2-66](#)
- periodic re-authentication
 - enabling [2-73](#)
 - time between attempts [2-75](#)
- quiet period between failed authentication exchanges [2-75](#)
- re-authenticating 802.1x-enabled ports [2-72](#)
- resetting configurable 802.1x parameters [2-65](#)
- switch-to-authentication server retransmission time [2-75](#)
- switch-to-client frame-retransmission number [2-68 to 2-69](#)
- switch-to-client retransmission time [2-75](#)

port-channel load-balance command [2-256](#)

Port Fast, for spanning tree [2-546](#)

port ranges, defining [2-57](#)

ports, debugging [B-59](#)

ports, protected [2-581](#)

port security

- aging [2-577](#)
- debug messages, display [B-61](#)
- enabling [2-573](#)
- violation error recovery [2-81](#)

port shaping [2-311](#)

port-type command [2-258](#)

port types, MVR [2-230](#)

power information, displaying [2-340](#)

power-supply dual command [2-260](#)

precedence

- for QoS traffic marking [2-303](#)
- setting in policy maps [2-303](#)

priority command [2-262](#)

priority queuing, QoS [2-262](#)

priority with police, QoS [2-262](#)

private-vlan command [2-265](#)

private-vlan mapping command [2-268](#)

private VLANs

- association [2-579](#)
- configuring [2-265](#)
- configuring ports [2-570](#)
- displaying [2-484](#)
- host ports [2-570](#)
- mapping
 - configuring [2-579](#)
 - displaying [2-362](#)
- promiscuous ports [2-570](#)

privileged EXEC mode [1-2, 1-3](#)

product identification information, displaying [2-375](#)

promiscuous ports, private VLANs [2-570](#)

PVST+

See STP

Q

QoS

- aggregate policers
 - applying [2-247](#)
 - creating [2-249](#)
 - displaying [2-452](#)
- class maps
 - creating [2-36](#)
 - defining the match criteria [2-208](#)
 - displaying [2-321](#)
- displaying statistics for [2-455, C-29](#)
- policy maps
 - applying an aggregate policer [2-247, 2-249, 2-252, 2-296](#)
 - applying to an interface [2-294, 2-307](#)
 - creating [2-253](#)
 - defining policers [2-243](#)
 - displaying policy maps [2-455](#)
 - setting CoS values [2-299](#)
 - setting DSCP values [2-301](#)
 - setting IP precedence values [2-303](#)
 - setting QoS group identifier [2-305](#)
 - traffic classifications [2-34](#)
- table maps
 - configuring [2-590](#)
 - displaying [2-478](#)

QoS groups

- as match criteria [2-213](#)
- for QoS traffic classification [2-305](#)
- setting in policy maps [2-305](#)

QoS match criteria

- ACLs [2-207](#)
- CoS value [2-208](#)
- DSCP value [2-209, 2-215](#)
- precedence value [2-211](#)
- QoS group number [2-213](#)

quality of service

- See QoS

querytime, MVR [2-227](#)

queue-limit command [2-270](#)

R

- rapid per-VLAN spanning-tree plus
 - See STP
- rapid PVST+
 - See STP
- re-authenticating 802.1x-enabled ports [2-72](#)
- re-authentication
 - periodic [2-73](#)
 - time between attempts [2-75](#)
- receiver ports, MVR [2-230](#)
- receiving flow-control packets [2-95](#)
- recovery mechanism
 - causes [2-81](#)
 - display [2-319, 2-343, 2-347](#)
 - timer interval [2-81](#)
- remote-span command [2-273](#)
- Remote Switched Port Analyzer
 - See RSPAN
- rename (boot loader) command [A-16](#)
- renew ip dhcp snooping database command [2-275](#)
- rep admin vlan command [2-277](#)
- rep block port command [2-278](#)
- rep preempt delay command [2-281](#)
- rep preempt segment command [2-283](#)
- rep segment command [2-284](#)
- rep stcn command [2-286](#)
- reset (boot loader) command [A-17](#)
- resource templates, displaying [2-466](#)
- rmdir (boot loader) command [A-18](#)
- rmon collection stats command [2-287](#)
- root guard, for spanning tree [2-516](#)
- routed ports
 - IP addresses on [2-108](#)
 - number supported [2-108](#)

RSPAN

- configuring [2-222](#)
- displaying [2-440](#)
- filter RSPAN traffic [2-222](#)
- remote-span command [2-273](#)
- sessions
 - add interfaces to [2-222](#)
 - displaying [2-440](#)
 - start new [2-222](#)

S

sdm prefer command [2-288](#)

SDM templates

- allowed resources [2-289](#)
- displaying [2-466](#)

secure ports, limitations [2-575](#)

sending flow-control packets [2-95](#)

service instance command [2-290](#)

service instances, displaying [2-354](#)

service password-recovery command [2-292](#)

service policy (policy-map class configuration) command [2-296](#)

service-policy interface configuration command [2-294](#)

service-policy policy-map class configuration command [2-296](#)

set (boot loader) command [A-19](#)

set cos command [2-299](#)

set dscp command [2-301](#)

set precedence command [2-303](#)

set qos-group command [2-305](#)

setup command [2-307](#)

SFPs, displaying information about [2-375](#)

shape average command [2-310](#)

show access-lists command [2-312](#)

show aggregate-policer command [2-478](#)

show archive status command [2-315](#)

show arp access-list command [2-316](#)

show boot command [2-317](#)

show class-map command [2-321](#)

show controllers cpu-interface command [2-322](#)

show controllers ethernet-controller command [2-324](#)

show controllers team command [2-331](#)

show controllers utilization command [2-333](#)

show controller utilization command [2-333](#)

show dot1q-tunnel command [2-335](#)

show dot1x command [2-337](#)

show env command [2-340](#)

show errdisable detect command [2-343](#)

show errdisable flap-values command [2-345](#)

show errdisable recovery command [2-347](#)

show etherchannel command [2-349](#)

show ethernet service evc command [2-352](#)

show ethernet service instance command [2-354](#)

show ethernet service interface command [2-356](#)

show flowcontrol command [2-358](#)

show idprom command [2-360](#)

show interface rep command [2-373](#)

show interfaces command [2-362](#)

show interfaces counters command [2-371](#)

show inventory command [2-375](#)

show ip arp inspection command [2-377](#)

show ipc command [2-402](#)

show ip dhcp snooping binding command [2-382](#)

show ip dhcp snooping command [2-381](#)

show ip dhcp snooping database command [2-384, 2-386](#)

show ip igmp profile command [2-389](#)

show ip igmp snooping command [2-390](#)

show ip igmp snooping command querier detail [2-396](#)

show ip igmp snooping groups command [2-392](#)

show ip igmp snooping mrouter command [2-394](#)

show ip igmp snooping querier command [2-396](#)

show ip igmp snooping querier detail command [2-396](#)

show ip source binding command [2-398](#)

show ip verify source command [2-400](#)

show l2protocol-tunnel command [2-406](#)

show lacp command [2-408](#)

show link state group command [2-412](#)

- show location [2-414](#)
- show location command [2-414](#)
- show mac access-group command [2-417](#)
- show mac address-table address command [2-421](#)
- show mac address-table aging time command [2-423](#)
- show mac address-table command [2-419](#)
- show mac address-table count command [2-425](#)
- show mac address-table dynamic command [2-427](#)
- show mac address-table interface command [2-429](#)
- show mac address-table learning command [2-431](#)
- show mac address-table move update command [2-432](#)
- show mac address-table notification command [2-46, 2-434, B-16](#)
- show mac address-table static command [2-436](#)
- show mac address-table vlan command [2-438](#)
- show monitor command [2-440](#)
- show mvr command [2-442](#)
- show mvr interface command [2-444](#)
- show mvr members command [2-446](#)
- show pagp command [2-448](#)
- show parser macro command [2-450](#)
- show platform acl command [C-2](#)
- show platform cfm command [C-3](#)
- show platform configuration command [C-4](#)
- show platform etherchannel command [C-5](#)
- show platform forward command [C-6](#)
- show platform igmp snooping command [C-8](#)
- show platform ipc trace command [C-13](#)
- show platform ip multicast command [C-10](#)
- show platform ip unicast command [C-11](#)
- show platform layer4op command [C-14](#)
- show platform mac-address-table command [C-15](#)
- show platform messaging command [C-16](#)
- show platform monitor command [C-17](#)
- show platform mvr table command [C-18](#)
- show platform pm command [C-19](#)
- show platform policer cpu command [C-21](#)
- show platform port-asic command [C-24](#)
- show platform port-security command [C-28](#)
- show platform qos command [C-29](#)
- show platform resource-manager command [C-32](#)
- show platform snmp counters command [C-34](#)
- show platform spanning-tree synchronization command [C-35](#)
- show platform stp-instance command [C-36](#)
- show platform team command [C-37](#)
- show platform vlan command [C-40](#)
- show policer aggregate command [2-452](#)
- show policer cpu uni command [2-453](#)
- show policy-map command [2-455](#)
- show policy-map interface output fields [2-458](#)
- show port security command [2-459](#)
- show port-type command [2-462](#)
- show rep topology command [2-464](#)
- show sdm prefer command [2-466](#)
- show spanning-tree command [2-468](#)
- show storm-control command [2-475](#)
- show system mtu command [2-477](#)
- show udd command [2-480](#)
- show version command [2-482](#)
- show vlan access-map command [2-489](#)
- show vlan command [2-484](#)
- show vlan command, fields [2-486](#)
- show vlan filter command [2-490](#)
- show vmps command [2-491](#)
- shutdown command [2-493](#)
- shutdown threshold, Layer 2 protocol tunneling [2-165](#)
- shutdown vlan command [2-494](#)
- SNMP host, specifying [2-500](#)
- SNMP informs, enabling the sending of [2-496](#)
- snmp mib rep trap-rate command [2-495](#)
- snmp-server enable traps command [2-496](#)
- snmp-server host command [2-500](#)
- snmp trap mac-notification command [2-504](#)
- SNMP traps
 - enabling MAC address notification trap [2-504](#)
 - enabling the MAC address notification feature [2-192](#)
 - enabling the sending of [2-496](#)

software images

- deleting [2-59](#)
- downloading [2-7](#)
- upgrading [2-7](#)
- uploading [2-13](#)

software version, displaying [2-482](#)source ports, MVR [2-230](#)

SPAN

- configuring [2-222](#)
- debug messages, display [B-17](#)
- displaying [2-440](#)
- filter SPAN traffic [2-222](#)
- sessions
 - add interfaces to [2-222](#)
 - displaying [2-440](#)
 - start new [2-222](#)

spanning-tree bpdudfilter command [2-506](#)spanning-tree bpduguard command [2-508](#)spanning-tree cost command [2-510](#)spanning-tree etherchannel command [2-512](#)spanning-tree extend system-id command [2-514](#)spanning-tree guard command [2-516](#)spanning-tree link-type command [2-518](#)spanning-tree loopguard default command [2-520](#)spanning-tree mode command [2-522](#)spanning-tree mst configuration command [2-524](#)spanning-tree mst cost command [2-526](#)spanning-tree mst forward-time command [2-528](#)spanning-tree mst hello-time command [2-529](#)spanning-tree mst max-age command [2-531](#)spanning-tree mst max-hops command [2-533](#)spanning-tree mst port-priority command [2-535](#)spanning-tree mst pre-standard command [2-537](#)spanning-tree mst priority command [2-538](#)spanning-tree mst root command [2-540](#)spanning-tree portfast (global configuration)
command [2-544](#)spanning-tree portfast (interface configuration)
command [2-546](#)spanning-tree port-priority command [2-542](#)

Spanning Tree Protocol

See STP

spanning-tree vlan command [2-548](#)speed command [2-551](#)SSH, configuring version [2-161](#)static-access ports, configuring [2-558](#)statistics, Ethernet group [2-287](#)sticky learning, enabling [2-573](#)storm-control command [2-553](#)

STP

counters, clearing [2-51](#)

debug messages, display

MSTP [B-67](#)optimized BPDUs handling [B-66](#)spanning-tree activity [B-63](#)switch shim [B-69](#)transmitted and received BPDUs [B-65](#)enabling protocol tunneling for [2-165](#)EtherChannel misconfiguration [2-512](#)extended system ID [2-514](#)path cost [2-510](#)protocol modes [2-522](#)

root port

loop guard [2-516](#)preventing from becoming designated [2-516](#)restricting which can be root [2-516](#)root guard [2-516](#)

root switch

affects of extended system ID [2-514, 2-549](#)hello-time [2-548](#)interval between BDPU messages [2-548](#)interval between hello BPDU messages [2-548](#)max-age [2-548](#)port priority for selection of [2-542](#)primary or secondary [2-548](#)switch priority [2-548](#)

STP (continued)

state changes

- blocking to forwarding state [2-546](#)
- enabling BPDU filtering [2-506, 2-544](#)
- enabling BPDU guard [2-508, 2-544](#)
- enabling Port Fast [2-544, 2-546](#)
- enabling timer to recover from error state [2-81](#)
- forward-delay time [2-548](#)
- length of listening and learning states [2-548](#)
- shutting down Port Fast-enabled ports [2-544](#)

state information display [2-468](#)VLAN options [2-538, 2-548](#)SVIs, creating [2-102](#)

Switched Port Analyzer

See SPAN

switching characteristics

- modifying [2-556](#)
- returning to interfaces [2-556](#)

switchport access command [2-558](#)switchport backup interface command [2-560](#)switchport block command [2-564](#)switchport command [2-556](#)switchport host command [2-566](#)switchport mode command [2-567](#)switchport mode private-vlan command [2-570](#)switchport port-security aging command [2-577](#)switchport port-security command [2-573](#)switchport private-vlan command [2-579](#)switchport protected command [2-581](#)switchports, displaying [2-362](#)switchport trunk command [2-583](#)system env temperature threshold yellow command [2-585](#)system message logging, save message to flash [2-181](#)system mtu command [2-587](#)system resource templates [2-288](#)table-map configuration mode [2-590](#)

table maps

- configuring [2-590](#)
- displaying [2-478](#)
- QoS [2-590](#)

tar files, creating, listing, and extracting [2-10](#)TDR, running [2-592](#)temperature information, displaying [2-340](#)templates, system resources [2-288](#)test cable-diagnostics tdr command [2-592](#)traceroute mac command [2-594](#)traceroute mac ip command [2-597](#)traffic shaping, QoS [2-310](#)trunking, VLAN mode [2-567](#)trunk mode [2-567](#)trunk ports [2-567](#)tunnel ports, Layer 2 protocol, displaying [2-406](#)type (boot loader) command [A-22](#)

U

UDLD

aggressive mode [2-599, 2-601](#)debug messages, display [B-76](#)enable globally [2-599](#)enable per interface [2-601](#)error recovery timer [2-81](#)message timer [2-599](#)normal mode [2-599, 2-601](#)reset a shutdown interface [2-603](#)status [2-480](#)udld command [2-599](#)udld port command [2-601](#)udld reset command [2-603](#)

UNI

bundling and multiplexing [2-90](#)Ethernet [2-90](#)unicast storm control [2-553](#)uni count command [2-604](#)

Ttable-map command [2-590](#)

UniDirectional Link Detection

See UDLD

UNI ID, Ethernet [2-92](#)uni-vlan command [2-606](#)unknown multicast traffic, preventing [2-564](#)unknown unicast traffic, preventing [2-564](#)unset (boot loader) command [A-23](#)

upgrading

software images [2-7](#)monitoring status of [2-315](#)

upgrading information

See release notes

user EXEC mode [1-2](#)user network interface [2-258](#)**V**version (boot loader) command [A-25](#)vlan access-map command [2-611](#)VLAN access map configuration mode [2-611](#)

VLAN access maps

actions [2-5](#)displaying [2-489](#)vlan command [2-608](#)

VLAN configuration mode

commands [2-608](#)description [1-4](#)entering [2-608](#)summary [1-2](#)vlan dot1q tag native command [2-613](#)vlan filter command [2-615](#)VLAN filters, displaying [2-490](#)VLAN ID range [2-608](#)

VLAN maps

applying [2-615](#)creating [2-611](#)defining [2-205](#)displaying [2-489](#)

VLAN Query Protocol

See VQP

VLANs

adding [2-608](#)configuring [2-608](#)

debug messages, display

activation of [B-74](#)VLAN IOS file system error tests [B-73](#)VLAN manager activity [B-71](#)displaying configurations [2-484](#)extended-range [2-608](#)

MAC addresses

displaying [2-438](#)number of [2-425](#)normal-range [2-608](#)private [2-570](#)configuring [2-265](#)displaying [2-484](#)

See also private VLANs

restarting [2-494](#)saving the configuration [2-608](#)shutting down [2-494](#)suspending [2-494](#)

VMPS

configuring servers [2-620](#)displaying [2-491](#)error recovery timer [2-81](#)reconfirming dynamic VLAN assignments [2-617](#)vmpls reconfirm (global configuration) command [2-617](#)vmpls reconfirm (privileged EXEC) command [2-617](#)vmpls retry command [2-619](#)vmpls server command [2-620](#)

VQP

and dynamic-access ports [2-559](#)clearing client statistics [2-54](#)displaying information [2-491](#)per-server retry count [2-619](#)reconfirmation interval [2-618](#)reconfirming dynamic VLAN assignments [2-617](#)

VTP, enabling tunneling for [2-165](#)

W

Weighted Tail Drop

See WTD

WTD, queue-limit command [2-270](#)

