



INDEX

A

aaa accounting dot1x command [2-1](#)
aaa authentication dot1x command [2-3](#)
AAA methods [2-3](#)
access control entries
 See ACEs
access control lists
 See ACLs
access groups
 IP [2-111](#)
 MAC, displaying [2-428](#)
 matching for QoS classification [2-214](#)
access mode [2-584](#)
access ports [2-584](#)
ACEs [2-66](#), [2-249](#)
ACLs
 as match criteria for QoS classes [2-214](#)
 deny [2-64](#)
 displaying [2-320](#)
 for non-IP protocols [2-192](#)
 IP [2-111](#)
 on Layer 2 interfaces [2-111](#)
 permit [2-247](#)
action command [2-5](#)
address aliasing [2-235](#)
aggregate policers
 applying [2-254](#)
 creating [2-256](#)
 displaying [2-463](#)
 QoS [2-257](#)
aggregate-port learner [2-241](#)
allowed VLANs [2-600](#)

archive download-sw command [2-7](#)
archive tar command [2-10](#)
archive upload-sw command [2-13](#)
arp access-list command [2-15](#)
attaching policy maps to interfaces [2-302](#)
audience [xvii](#)
authorization state of controlled port [2-72](#)
autonegotiation of duplex mode [2-82](#)

B

backup interfaces
 configuring [2-577](#)
 displaying [2-371](#)
bandwidth, configuring for QoS [2-17](#)
bandwidth command [2-17](#)
boot (boot loader) command [A-2](#)
boot bootlpr command [2-20](#)
boot config-file command [2-21](#)
boot enable-break command [2-22](#)
boot helper command [2-23](#)
boot helper-config file command [2-24](#)
booting
 Cisco IOS image [2-27](#)
 displaying environment variables [2-325](#)
 interrupting [2-22](#)
 manually [2-25](#)

boot loader

accessing [A-1](#)

booting

Cisco IOS image [A-2](#)helper image [2-23](#)

directories

creating [A-14](#)displaying a list of [A-7](#)removing [A-18](#)

displaying

available commands [A-12](#)memory heap utilization [A-13](#)version [A-25](#)

environment variables

described [A-19](#)displaying settings [A-19](#)location of [A-20](#)setting [A-19](#)unsetting [A-23](#)

files

copying [A-5](#)deleting [A-6](#)displaying a list of [A-7](#)displaying the contents of [A-4, A-15, A-22](#)renaming [A-16](#)

file system

formatting [A-10](#)initializing flash [A-9](#)running a consistency check [A-11](#)prompt [A-1](#)resetting the system [A-17](#)boot manual command [2-25](#)boot private-config-file command [2-26](#)boot system command [2-27](#)BPDU filtering, for spanning tree [2-522, 2-560](#)BPDU guard, for spanning tree [2-524, 2-560](#)broadcast storm control [2-570](#)bundling characteristics, UNI [2-93](#)burst bytes, in QoS policers [2-250, 2-256](#)**C**cat (boot loader) command [A-4](#)caution, description [xviii](#)CBWFQ, configuring [2-17](#)CDP, enabling protocol tunneling for [2-172](#)CFM [2-240](#)CFM as OAM protocol [2-240](#)channel-group command [2-28](#)channel-protocol command [2-32](#)child policy maps [2-304](#)class-based traffic shaping [2-318](#)

class-based weighted fair queuing

See CBWFQ

class command [2-34](#)class-map command [2-36](#)class-map configuration mode [2-37](#)

class maps

creating [2-36](#)defining the match criteria [2-215](#)displaying [2-329](#)matching in [2-36](#)

class of service

See CoS

clear ip arp inspection log command [2-38](#)clear ip arp inspection statistics command [2-39](#)clear ipc command [2-42](#)clear l2protocol-tunnel counters command [2-43](#)clear lacp command [2-44](#)clear mac address-table command [2-45, 2-46](#)clear pagp command [2-47](#)clear policer cpu uni-eni counters command [2-48](#)clear port-security command [2-49](#)clear spanning-tree counters command [2-51](#)clear spanning-tree detected-protocols command [2-52](#)clear vmpps statistics command [2-54](#)command modes defined [1-1](#)committed information rate in QoS policers [2-250, 2-256](#)

configuration, initial
 See also getting started guide and hardware installation guide

configuration files
 password recovery disable considerations [A-1](#)
 specifying the name [2-21, 2-26](#)

configuring multiple interfaces [2-106](#)

conform-action command [2-55](#)

control-plane policer [2-48](#)

control-plane policer information, displaying [2-464](#)

control-plane security [2-259](#)

control plane statistics, clearing [2-48](#)

conventions
 command [xviii](#)
 for examples [xviii](#)
 publication [xviii](#)
 text [xviii](#)

copy (boot loader) command [A-5](#)

CoS
 as match criteria for QoS groups [2-215](#)
 for QoS classification [2-307](#)
 setting value in policy maps [2-307](#)

CoS value, assigning to Layer 2 protocol packets [2-175](#)

CPU ASIC statistics, displaying [2-330](#)

CPU protection policers, displaying [C-21](#)

cpu traffic qos [2-57](#)

D

debug backup command [B-2](#)

debug dot1x command [B-3](#)

debug etherchannel command [B-4](#)

debug interface command [B-9](#)

debug ip dhcp snooping command [B-7](#)

debug ip igmp filter command [B-10](#)

debug ip igmp max-groups command [B-11](#)

debug ip igmp snooping command [B-12](#)

debug ip verify source packet command [B-8](#)

debug lacp command [B-13](#)

debug mac-notification command [B-14](#)

debug matm command [B-15](#)

debug matm move update command [B-16](#)

debug monitor command [B-17](#)

debug mvrdbg command [B-18](#)

debug nvram command [B-19](#)

debug pagp command [B-20](#)

debug platform acl command [B-21](#)

debug platform backup interface command [B-23](#)

debug platform cfm command [B-22](#)

debug platform cpu-queues command [B-24](#)

debug platform dot1x command [B-26](#)

debug platform etherchannel command [B-27](#)

debug platform forw-tcam command [B-28](#)

debug platform ip arp inspection command [B-29](#)

debug platform ipc command [B-37](#)

debug platform ip dhcp command [B-30](#)

debug platform ip igmp snooping command [B-31](#)

debug platform ip multicast command [B-33](#)

debug platform led command [B-38](#)

debug platform matm command [B-39](#)

debug platform messaging application command [B-40](#)

debug platform phy command [B-41](#)

debug platform pm command [B-43](#)

debug platform policer cpu uni-eni command [B-45](#)

debug platform port-asic command [B-46](#)

debug platform port-security command [B-47](#)

debug platform qos-acl-tcam command [B-48](#)

debug platform remote-commands command [B-49](#)

debug platform resource-manager command [B-50](#)

debug platform snmp command [B-51](#)

debug platform span command [B-52](#)

debug platform supervisor-asic command [B-53](#)

debug platform sw-bridge command [B-54](#)

debug platform tcam command [B-55](#)

debug platform udd command [B-57](#)

debug platform vlan command [B-58](#)

debug pm command [B-59](#)

debug port-security command [B-61](#)

- debug qos-manager command [B-62](#)
- debug spanning-tree bpdu command [B-65](#)
- debug spanning-tree bpdu-opt command [B-66](#)
- debug spanning-tree command [B-63](#)
- debug spanning-tree mstp command [B-67](#)
- debug spanning-tree switch command [B-69](#)
- debug sw-vlan command [B-71](#)
- debug sw-vlan ifs command [B-73](#)
- debug sw-vlan notification command [B-74](#)
- debug udd command [B-76](#)
- debug vqpc command [B-78](#)
- default policer configuration
 - NNIs [C-23](#)
 - UNIs [C-22](#)
- define interface-range command [2-59](#)
- delete (boot loader) command [A-6](#)
- delete command [2-61](#)
- deny (ARP access-list configuration) command [2-62](#)
- deny command [2-64](#)
- detect mechanism, causes [2-83](#)
- DHCP snooping
 - accepting untrusted packets from edge switch [2-136](#)
 - enabling
 - on a VLAN [2-142](#)
 - option 82 [2-134, 2-136](#)
 - trust on an interface [2-140](#)
 - error recovery timer [2-88](#)
 - rate limiting [2-139](#)
- DHCP snooping binding database
 - binding file, configuring [2-132](#)
 - bindings
 - adding [2-130](#)
 - deleting [2-130](#)
 - displaying [2-393](#)
 - clearing database agent statistics [2-40](#)
 - database agent, configuring [2-132](#)
- DHCP snooping binding database (continued)
 - displaying
 - binding entries [2-393](#)
 - database agent status [2-395, 2-397](#)
 - renewing [2-282](#)
 - differentiated service code point
 - See DSCP
 - Digital Optical Monitoring
 - see DoM
 - dir (boot loader) command [A-7](#)
 - directories, deleting [2-61](#)
 - documentation, related [xviii](#)
 - document conventions [xviii](#)
 - DoM
 - displaying supported transceivers [2-383](#)
 - domains, CFM [2-240](#)
 - dot1x default command [2-67](#)
 - dot1x host-mode command [2-68](#)
 - dot1x initialize command [2-69](#)
 - dot1x max-req command [2-70, 2-71](#)
 - dot1x port-control command [2-72](#)
 - dot1x re-authenticate command [2-74](#)
 - dot1x reauthentication command [2-75](#)
 - dot1x system-auth-control command [2-76](#)
 - dot1x test eapol-capable command [2-77](#)
 - dot1x test timeout command [2-78](#)
 - dot1x timeout command [2-79](#)
 - dropping packets, with ACL matches [2-5](#)
 - drop threshold, Layer 2 protocol tunneling [2-172](#)
 - DSCP
 - as match criteria for QoS groups [2-216, 2-222](#)
 - for QoS traffic marking [2-309](#)
 - setting in policy maps [2-309](#)
 - dual-purpose uplink ports, selecting the type [2-227](#)
 - duplex command [2-81](#)
 - dynamic-access ports
 - configuring [2-575](#)
 - restrictions [2-576](#)

dynamic ARP inspection

ARP ACLs

apply to a VLAN [2-116](#)define [2-15](#)deny packets [2-62](#)display [2-324](#)permit packets [2-245](#)

clear

log buffer [2-38](#)statistics [2-39](#)

display

ARP ACLs [2-324](#)configuration and operating state [2-388](#)log buffer [2-388](#)statistics [2-388](#)trust state and rate limit [2-388](#)enable per VLAN [2-126](#)error detection for [2-83](#)error recovery timer [2-88](#)

log buffer

clear [2-38](#)configure [2-120](#)display [2-388](#)rate-limit incoming ARP packets [2-118](#)

statistics

clear [2-39](#)display [2-388](#)trusted interface state [2-122](#)type of packet logged [2-127](#)validation checks [2-124](#)

Dynamic Host Configuration Protocol (DHCP)

See DHCP snooping

E-LMI

enabling [2-91](#)mapping [2-93](#)environment variables, displaying [2-325](#)errdisable detect cause command [2-83](#)errdisable detect cause small-frame comand [2-85](#)errdisable recovery cause small-frame [2-87](#)errdisable recovery command [2-88](#)error conditions, displaying [2-354](#)error disable detection [2-83](#)error-disabled interfaces, displaying [2-371](#)

EtherChannel

assigning Ethernet interface to channel group [2-28](#)creating port-channel logical interface [2-104](#)debug EtherChannel/PAGP, display [B-4](#)debug platform-specific events, display [B-27](#)displaying [2-358](#)

enabling Layer 2 protocol tunneling for

LACP [2-173](#)PAGP [2-173](#)UDLD [2-173](#)interface information, displaying [2-371](#)

LACP

clearing channel-group information [2-44](#)debug messages, display [B-13](#)displaying [2-419](#)modes [2-28](#)port priority for hot-standby ports [2-176](#)restricting a protocol [2-32](#)system priority [2-178](#)load-distribution methods [2-263](#)

E

EAP-request/identity frame

maximum number to send [2-71](#)response time before retransmitting [2-79](#)

EtherChannel (continued)

PAGP

- aggregate-port learner [2-241](#)
- clearing channel-group information [2-47](#)
- debug messages, display [B-20](#)
- displaying [2-459](#)
- error detection for [2-83](#)
- error recovery timer [2-88](#)
- learn method [2-241](#)
- modes [2-28](#)
- physical-port learner [2-241](#)
- priority of interface for transmitted traffic [2-243](#)

ethermet lmi ce command [2-91](#)

Ethernet controller, internal register display [2-332](#)

ethernet evc command [2-90](#)

ethernet lim global command [2-91](#)

ethernet lmi ce-vlan map command [2-93, 2-95](#)

ethernet lmi command [2-91](#)

Ethernet Local Management Interface

See E-LMI

Ethernet service

- debugging [B-5](#)
- displaying [2-361](#)

Ethernet service instance [2-298](#)

Ethernet service interfaces [2-365](#)

Ethernet statistics, collecting [2-295](#)

Ethernet UNI configuration [2-97](#)

ethernet uni id command [2-99](#)

Ethernet virtual connections

See EVCs

EVC configuration mode [2-90](#)

EVCs [2-90](#)

- and VLANs [2-97](#)
- service instances [2-298](#)
- UNI counts [2-621](#)

EVC service

- point-to-multipoint [2-621](#)
- point-to-point [2-621](#)

examples, conventions for [xviii](#)

exceed-action command [2-100](#)

extended-range VLANs

- and allowed VLAN list [2-600](#)
- configuring [2-625](#)

extended system ID for STP [2-530](#)

F

fan information, displaying [2-349](#)

files, deleting [2-61](#)

flash_init (boot loader) command [A-9](#)

Flex Links

- configuring [2-577](#)
- configuring preferred VLAN [2-579](#)
- displaying [2-371](#)

flowcontrol command [2-102](#)

format (boot loader) command [A-10](#)

forwarding packets, with ACL matches [2-5](#)

forwarding results, display [C-6](#)

frame forwarding information, displaying [C-6](#)

fsck (boot loader) command [A-11](#)

G

global configuration mode [1-2, 1-3](#)

H

hardware ACL statistics [2-320](#)

help (boot loader) command [A-12](#)

host connection, port configuration [2-583](#)

host ports, private VLANs [2-587](#)

I

IEEE 802.1ag Connectivity Fault Management

See CFM

IEEE 802.1Q trunk ports and native VLANs [2-630](#)

- IEEE 802.1Q tunnel ports
 - configuring [2-584](#)
 - displaying [2-344](#)
 - limitations [2-585](#)
- IEEE 802.1x
 - and switchport modes [2-585](#)
 - violation error recovery [2-88](#)
 - See also port-based authentication
- IGMP filters
 - applying [2-145](#)
 - debug messages, display [B-10](#)
- IGMP groups, setting maximum [2-147](#)
- IGMP maximum groups, debugging [B-11](#)
- IGMP profiles
 - creating [2-149](#)
 - displaying [2-400](#)
- IGMP snooping
 - adding ports as a static member of a group [2-164](#)
 - displaying [2-401, 2-405, 2-407](#)
 - enabling [2-151](#)
 - enabling the configurable-leave timer [2-153](#)
 - enabling the Immediate-Leave feature [2-161](#)
 - flooding query count [2-159](#)
 - interface topology change notification behavior [2-160](#)
 - multicast table [2-403](#)
 - querier [2-155](#)
 - query solicitation [2-159](#)
 - report suppression [2-157](#)
 - switch topology change notification behavior [2-159](#)
- images
 - See software images
- Immediate-Leave feature, MVR [2-237](#)
- immediate-leave processing [2-161](#)
- initial configuration
 - See also getting started guide and hardware installation guide
- input policy maps
 - and ACL classification [2-214](#)
 - and aggregate policers [2-257](#)
 - commands not supported in [2-261](#)
 - configuration guidelines [2-261](#)
- interface command [2-109](#)
- interface configuration mode [1-2, 1-4](#)
- interface port-channel command [2-104](#)
- interface range command [2-106](#)
- interface-range macros [2-57, 2-59](#)
- interfaces
 - assigning Ethernet interface to channel group [2-28](#)
 - configuring [2-81](#)
 - configuring multiple [2-106](#)
 - creating port-channel logical [2-104](#)
 - debug messages, display [B-9](#)
 - disabling [2-505](#)
 - displaying the MAC address table [2-440](#)
 - restarting [2-505](#)
- interface speed, configuring [2-568](#)
- internal registers, displaying [2-332, 2-339, 2-343](#)
- Internet Group Management Protocol
 - See IGMP
- invalid GBIC
 - error detection for [2-83](#)
 - error recovery timer [2-88](#)
- ip address command [2-114](#)
- IP addresses, setting [2-114](#)
- IP address matching [2-212](#)
- ip arp inspection filter vlan command [2-116](#)
- ip arp inspection limit command [2-118](#)
- ip arp inspection log-buffer command [2-120](#)
- ip arp inspection trust command [2-122](#)
- ip arp inspection validate command [2-124](#)
- ip arp inspection vlan command [2-126](#)
- ip arp inspection vlan logging command [2-127](#)
- IP DHCP snooping
 - See DHCP snooping
- ip dhcp snooping binding command [2-130](#)

ip dhcp snooping command [2-129](#)
 ip dhcp snooping database command [2-132](#)
 ip dhcp snooping information option allow-untrusted command [2-136](#)
 ip dhcp snooping information option command [2-134](#)
 ip dhcp snooping information option format remote-id command [2-138](#)
 ip dhcp snooping limit rate command [2-139](#)
 ip dhcp snooping trust command [2-140](#)
 ip dhcp snooping verify command [2-141](#)
 ip dhcp snooping vlan command [2-142](#)
 ip dhcp snooping vlan information option format-type circuit-id string command [2-143](#)
 ip igmp filter command [2-145](#)
 ip igmp max-groups command [2-147](#)
 ip igmp profile command [2-149](#)
 ip igmp snooping command [2-151](#)
 ip igmp snooping last-member-query-interval command [2-153](#)
 ip igmp snooping querier command [2-155](#)
 ip igmp snooping report-suppression command [2-157](#)
 ip igmp snooping tcn command [2-159](#)
 ip igmp snooping tcn flood command [2-160](#)
 ip igmp snooping vlan immediate-leave command [2-161](#)
 ip igmp snooping vlan mrouter command [2-162](#)
 ip igmp snooping vlan static command [2-164](#)
 IP multicast addresses [2-234](#)
 IP precedence, as match criteria for QoS groups [2-218](#)
 ip source binding command [2-166](#)
 IP source guard

- disabling [2-170](#)
- displaying
 - binding entries [2-409](#)
 - configuration [2-411](#)
- enabling [2-170](#)
- static IP source bindings [2-166](#)

 IP source guard, displaying dynamic binding entries [2-393](#)
 ip ssh command [2-168](#)
 ip verify source command [2-170](#)

J

jumbo frames
 See MTU

L

l2protocol-tunnel command [2-172](#)
 l2protocol-tunnel cos command [2-175](#)
 LACP

- See EtherChannel

 lacp port-priority command [2-176](#)
 lacp system-priority command [2-178](#)
 Layer 2 mode, enabling [2-573](#)
 Layer 2 protocol ports, displaying [2-417](#)
 Layer 2 protocol-tunnel

- error detection for [2-83](#)
- error recovery timer [2-88](#)

 Layer 2 protocol tunnel counters [2-43](#)
 Layer 2 protocol tunneling error recovery [2-173](#)
 Layer 2 traceroute

- IP addresses [2-614](#)
- MAC addresses [2-611](#)

 Layer 3 mode, enabling [2-573](#)
 line configuration mode [1-2, 1-4](#)
 Link Aggregation Control Protocol

- See EtherChannel

 link flap

- error detection for [2-83](#)
- error recovery timer [2-88](#)

 link state group command [2-180](#)
 link state track command [2-182](#)
 load-distribution methods for EtherChannel [2-263](#)
 location (global configuration) command [2-183](#)
 location (interface configuration) command [2-185](#)
 logging event command [2-187](#)
 logging file command [2-188](#)
 logical interface [2-104](#)

loopback error

- detection for [2-83](#)
- recovery timer [2-88](#)

loop guard, for spanning tree [2-532, 2-536](#)

M

mac access-group command [2-190](#)

MAC access-groups, displaying [2-428](#)

MAC access list configuration mode [2-192](#)

mac access-list extended command [2-192](#)

MAC access lists [2-64](#)

MAC addresses

disabling MAC address learning per VLAN [2-195](#)

displaying

- aging time [2-434](#)
- all [2-432](#)
- dynamic [2-438](#)
- MAC address-table move updates [2-443](#)
- notification settings [2-442, 2-445](#)
- number of addresses in a VLAN [2-436](#)
- per interface [2-440](#)
- per VLAN [2-449](#)
- static [2-447](#)
- static and dynamic entries [2-430](#)

dynamic

- aging time [2-194](#)
- deleting [2-45](#)
- displaying [2-438](#)

enabling MAC address notification [2-199](#)

enabling MAC address-table move update [2-197](#)

matching [2-212](#)

static

- adding and removing [2-201](#)
- displaying [2-447](#)
- dropping on an interface [2-202](#)

tables [2-432](#)

MAC address notification, debugging [B-14](#)

mac address-table aging-time [2-190, 2-212](#)

mac address-table aging-time command [2-194](#)

mac address-table learning command [2-195](#)

mac address-table move update command [2-197](#)

mac address-table notification command [2-199](#)

mac address-table static command [2-201](#)

mac address-table static drop command [2-202](#)

macro description command [2-206](#)

macro global command [2-207](#)

macro global description command [2-209](#)

macro name command [2-210](#)

macros

- adding a description [2-206](#)
- adding a global description [2-209](#)
- applying [2-207](#)
- creating [2-210](#)
- displaying [2-461](#)
- interface range [2-59, 2-106](#)
- specifying parameter values [2-207](#)
- tracing [2-207](#)

maintenance end points [2-621](#)

manual

- audience [xvii](#)
- purpose of [xvii](#)

mapping tables, QoS [2-607](#)

maps

class

- creating [2-36](#)

VLAN

- creating [2-628](#)
- defining [2-212](#)
- displaying [2-501](#)

match access-group command [2-214](#)

match cos command [2-215](#)

match ip dscp command [2-216](#)

match ip precedence command [2-218](#)

match qos-group command [2-220](#)

match vlan command [2-222](#)

maximum transmission unit

See MTU

mdix auto command [2-225](#)
 media-type command [2-227](#)
 memory (boot loader) command [A-13](#)
 mkdir (boot loader) command [A-14](#)
 mode, MVR [2-234](#)
 modes, commands [1-1](#)
 monitor session command [2-229](#)
 more (boot loader) command [A-15](#)
 MSTP
 displaying [2-480, 2-481, 2-482](#)
 interoperability [2-52](#)
 link type [2-534](#)
 MST region
 aborting changes [2-540](#)
 applying changes [2-540](#)
 configuration name [2-540](#)
 configuration revision number [2-541](#)
 current or pending display [2-541](#)
 displaying [2-480, 2-481, 2-482](#)
 MST configuration mode [2-540](#)
 VLANs-to-instance mapping [2-540](#)
 path cost [2-542](#)
 protocol mode [2-538](#)
 restart protocol migration process [2-52](#)
 root port
 loop guard [2-532](#)
 preventing from becoming designated [2-532](#)
 restricting which can be root [2-532](#)
 root guard [2-532](#)
 root switch
 affects of extended system ID [2-530](#)
 hello-time [2-545, 2-556](#)
 interval between BPDU messages [2-547](#)
 interval between hello BPDU messages [2-545, 2-556](#)
 max-age [2-547](#)
 maximum hop count before discarding BPDU [2-549](#)
 port priority for selection of [2-551](#)

MSTP (continued)

 root switch (continued)
 primary or secondary [2-556](#)
 switch priority [2-554](#)
 state changes
 blocking to forwarding state [2-563](#)
 enabling BPDU filtering [2-522, 2-560](#)
 enabling BPDU guard [2-524, 2-560](#)
 enabling Port Fast [2-560, 2-563](#)
 forward-delay time [2-544](#)
 length of listening and learning states [2-544](#)
 rapid transition to forwarding [2-534](#)
 shutting down Port Fast-enabled ports [2-560](#)
 state information display [2-479](#)
 MTU
 configuring size [2-604](#)
 displaying global setting [2-489](#)
 multicast group address, MVR [2-237](#)
 multicast groups, MVR [2-235](#)
 multicast router learning method [2-162](#)
 multicast router ports, configuring [2-162](#)
 multicast storm control [2-570](#)
 multicast VLAN, MVR [2-234](#)
 multicast VLAN registration
 See MVR
 multiple hosts on authorized port [2-68](#)
 Multiple Spanning Tree Protocol
 See MSTP
 multiplexing, UNI [2-97](#)
 MVR
 and address aliasing [2-235](#)
 configuring [2-234](#)
 configuring interfaces [2-237](#)
 debug messages, display [B-18](#)
 displaying [2-453](#)
 displaying interface information [2-455](#)
 members, displaying [2-457](#)
 mvr (global configuration) command [2-234](#)

mvr (interface configuration) command [2-237](#)
 mvr vlan group command [2-238](#)

N

native VLANs [2-600](#)
 native VLAN tagging [2-630](#)
 network node interface [2-265](#)
 nonegotiate, speed [2-568](#), [2-569](#)
 non-IP protocols
 denying [2-64](#)
 forwarding [2-247](#)
 non-IP traffic access lists [2-192](#)
 non-IP traffic forwarding
 denying [2-64](#)
 permitting [2-247](#)
 normal-range VLANs [2-625](#)
 note, description [xviii](#)
 no vlan command [2-625](#)

O

OAM PDUs [2-95](#)
 OAM protocol [2-240](#)
 oam protocol cfm svlan command [2-240](#)
 operation, administration, and maintenance protocol
 See OAM
 output policy maps
 and QoS group classification [2-220](#)
 and traffic shaping [2-318](#)
 commands not supported in [2-261](#)
 configuration guidelines [2-261](#)
 priority in [2-270](#)
 queue limit in [2-277](#)

P

PAgP
 See EtherChannel
 pagp learn-method command [2-241](#)
 pagp port-priority command [2-243](#)
 parent policy maps [2-305](#)
 password-recovery mechanism, enabling and disabling [2-300](#)
 permit (ARP access-list configuration) command [2-245](#)
 permit command [2-247](#)
 per-VLAN spanning-tree plus
 See STP
 physical-port learner [2-241](#)
 PID, displaying [2-386](#)
 PIM-DVMRP, as multicast router learning method [2-162](#)
 police
 multiple conform actions for a class [2-55](#)
 multiple exceed actions for a class [2-100](#)
 with priority [2-250](#)
 police aggregate command [2-254](#)
 police command [2-250](#)
 policer aggregate command [2-256](#)
 policer configuration
 default for NNIs [C-23](#)
 default for UNIs [C-22](#)
 policer cpu uni command [2-259](#)
 policers
 aggregate [2-254](#), [2-256](#)
 for CPU protection [2-259](#)
 individual [2-250](#)
 policy-map class, configuring multiple actions [2-55](#), [2-100](#)
 policy-map class configuration mode [2-34](#)
 policy-map class police configuration mode [2-55](#), [2-252](#)
 policy-map command [2-260](#)
 policy-map configuration mode [2-260](#)

policy maps

- and CoS classification [2-215](#)
- and DSCP classification [2-216](#)
- and IP precedence classification [2-218](#)
- and policing [2-252](#)
- applying [2-302](#)
- applying to an interface [2-261, 2-302, 2-315](#)
- child [2-304](#)
- creating [2-260](#)
- displaying [2-466](#)
- hierarchical [2-304](#)
- parent [2-305](#)
- policers
 - for a single class [2-250](#)
 - for multiple classes [2-254, 2-256, 2-259, 2-304](#)
- setting priority [2-269](#)
- setting QoS group identifier [2-313](#)
- traffic classification, defining [2-34](#)
- traffic marking
 - setting CoS values [2-307](#)
 - setting DSCP values [2-309](#)
 - setting IP precedence values [2-311](#)

Port Aggregation Protocol

See EtherChannel

port-based authentication

- AAA method list [2-3](#)
- debug messages, display [B-3](#)
- enabling 802.1x
 - globally [2-76](#)
 - per interface [2-72](#)
- host modes [2-68](#)
- IEEE 802.1x AAA accounting methods [2-1](#)
- initialize an interface [2-69, 2-78](#)
- manual control of authorization state [2-72](#)
- multiple hosts on authorized port [2-68](#)
- periodic re-authentication
 - enabling [2-75](#)
 - time between attempts [2-79](#)

port-based authentication (continued)

- quiet period between failed authentication exchanges [2-79](#)
- re-authenticating 802.1x-enabled ports [2-74](#)
- resetting configurable 802.1x parameters [2-67](#)
- switch-to-authentication server retransmission time [2-79](#)
- switch-to-client frame-retransmission number [2-70 to 2-71](#)
- switch-to-client retransmission time [2-79](#)
- test for IEEE 802.1x readiness [2-77](#)
- port-channel load-balance command [2-263](#)
- Port Fast, for spanning tree [2-563](#)
- port ranges, defining [2-57, 2-59](#)
- ports, debugging [B-59](#)
- ports, protected [2-598](#)
- port security
 - aging [2-594](#)
 - debug messages, display [B-61](#)
 - enabling [2-590](#)
 - violation error recovery [2-88](#)
- port shaping [2-319](#)
- port-type command [2-265](#)
- port types, MVR [2-237](#)
- power information, displaying [2-349](#)
- power-supply dual command [2-267](#)
- precedence
 - for QoS traffic marking [2-311](#)
 - setting in policy maps [2-311](#)
- priority command [2-269](#)
- priority queuing, QoS [2-269](#)
- priority with police, QoS [2-269](#)
- private-vlan command [2-272](#)
- private-vlan mapping command [2-275](#)
- private VLANs
 - association [2-596](#)
 - configuring [2-272](#)
 - configuring ports [2-587](#)
 - displaying [2-496](#)
 - host ports [2-587](#)

private VLANs (continued)

- mapping
 - configuring [2-596](#)
 - displaying [2-371](#)
- promiscuous ports [2-587](#)
- privileged EXEC mode [1-2, 1-3](#)
- product identification information, displaying [2-386](#)
- promiscuous ports, private VLANs [2-587](#)
- PVST+
 - See STP

Q**QoS**

- aggregate policers
 - applying [2-254](#)
 - creating [2-256](#)
 - displaying [2-463](#)
- class maps
 - creating [2-36](#)
 - defining the match criteria [2-215](#)
 - displaying [2-329](#)
- displaying statistics for [2-466, C-29](#)
- policy maps
 - applying an aggregate policer [2-254, 2-256, 2-259, 2-304](#)
 - applying to an interface [2-302, 2-315](#)
 - creating [2-260](#)
 - defining policers [2-250](#)
 - displaying policy maps [2-466](#)
 - setting CoS values [2-307](#)
 - setting DSCP values [2-309](#)
 - setting IP precedence values [2-311](#)
 - setting QoS group identifier [2-313](#)
 - traffic classifications [2-34](#)
- table maps
 - configuring [2-607](#)
 - displaying [2-490](#)
- QoS groups
 - as match criteria [2-220](#)
 - for QoS traffic classification [2-313](#)
 - setting in policy maps [2-313](#)
- QoS match criteria
 - ACLs [2-214](#)
 - CoS value [2-215](#)
 - DSCP value [2-216, 2-222](#)
 - precedence value [2-218](#)
 - QoS group number [2-220](#)
- quality of service
 - See QoS
- querytime, MVR [2-234](#)
- queue-limit command [2-277](#)

R

- rapid per-VLAN spanning-tree plus
 - See STP
- rapid PVST+
 - See STP
- re-authenticating 802.1x-enabled ports [2-74](#)
- re-authentication
 - periodic [2-75](#)
 - time between attempts [2-79](#)
- receiver ports, MVR [2-237](#)
- receiving flow-control packets [2-102](#)
- recovery mechanism
 - causes [2-88](#)
 - display [2-327, 2-352, 2-356](#)
 - timer interval [2-88](#)
- remote-span command [2-280](#)
- Remote Switched Port Analyzer
 - See RSPAN
- rename (boot loader) command [A-16](#)
- renew ip dhcp snooping database command [2-282](#)
- rep admin vlan command [2-284](#)
- rep block port command [2-285](#)
- rep preempt delay command [2-288](#)

rep preempt segment command [2-290](#)
 rep segment command [2-291](#)
 rep sten command [2-293](#)
 reset (boot loader) command [A-17](#)
 resource templates, displaying [2-477](#)
 rmdir (boot loader) command [A-18](#)
 rmon collection stats command [2-295](#)
 root guard, for spanning tree [2-532](#)
 routed ports

- IP addresses on [2-115](#)
- number supported [2-115](#)

RSPAN

- configuring [2-229](#)
- displaying [2-451](#)
- filter RSPAN traffic [2-229](#)
- remote-span command [2-280](#)
- sessions
 - add interfaces to [2-229](#)
 - displaying [2-451](#)
 - start new [2-229](#)

S

sdm prefer command [2-296](#)

SDM templates

- allowed resources [2-297](#)
- displaying [2-477](#)

secure ports, limitations [2-592](#)

sending flow-control packets [2-102](#)

service instance command [2-298](#)

service instances, displaying [2-363](#)

service password-recovery command [2-300](#)

service policy (policy-map class configuration) command [2-304](#)

service-policy interface configuration command [2-302](#)

service-policy policy-map class configuration command [2-304](#)

set (boot loader) command [A-19](#)

set cos command [2-307](#)

set dscp command [2-309](#)

set precedence command [2-311](#)

set qos-group command [2-313](#)

setup command [2-315](#)

SFPs, displaying information about [2-386](#)

shape average command [2-318](#)

show access-lists command [2-320](#)

show aggregate-policer command [2-490](#)

show archive status command [2-323](#)

show arp access-list command [2-324](#)

show boot command [2-325](#)

show class-map command [2-329](#)

show controllers cpu-interface command [2-330](#)

show controllers ethernet-controller command [2-332](#)

show controllers team command [2-339](#)

show controllers utilization command [2-341](#)

show controller utilization command [2-341](#)

show cpu traffic qos [2-343](#)

show dot1q-tunnel command [2-344](#)

show dot1x command [2-346](#)

show env command [2-349](#)

show errdisable detect command [2-352](#)

show errdisable flap-values command [2-354](#)

show errdisable recovery command [2-356](#)

show etherchannel command [2-358](#)

show ethernet service evc command [2-361](#)

show ethernet service instance command [2-363](#)

show ethernet service interface command [2-365](#)

show flowcontrol command [2-367](#)

show idprom command [2-369](#)

show interface rep command [2-381](#)

show interfaces command [2-371](#)

show interfaces counters command [2-379](#)

show interface transceivers command [2-383](#)

show inventory command [2-386](#)

show ip arp inspection command [2-388](#)

show ipc command [2-413](#)

show ip dhcp snooping binding command [2-393](#)

show ip dhcp snooping command [2-392](#)

- show ip dhcp snooping database command [2-395, 2-397](#)
- show ip igmp profile command [2-400](#)
- show ip igmp snooping command [2-401](#)
- show ip igmp snooping command querier detail [2-407](#)
- show ip igmp snooping groups command [2-403](#)
- show ip igmp snooping mrouter command [2-405](#)
- show ip igmp snooping querier command [2-407](#)
- show ip igmp snooping querier detail command [2-407](#)
- show ip source binding command [2-409](#)
- show ip verify source command [2-411](#)
- show l2protocol-tunnel command [2-417](#)
- show lacp command [2-419](#)
- show link state group command [2-423](#)
- show location [2-425](#)
- show location command [2-425](#)
- show mac access-group command [2-428](#)
- show mac address-table address command [2-432](#)
- show mac address-table aging time command [2-434](#)
- show mac address-table command [2-430](#)
- show mac address-table count command [2-436](#)
- show mac address-table dynamic command [2-438](#)
- show mac address-table interface command [2-440](#)
- show mac address-table learning command [2-442](#)
- show mac address-table move update command [2-443](#)
- show mac address-table notification command [2-46, 2-445, B-16](#)
- show mac address-table static command [2-447](#)
- show mac address-table vlan command [2-449](#)
- show monitor command [2-451](#)
- show mvr command [2-453](#)
- show mvr interface command [2-455](#)
- show mvr members command [2-457](#)
- show pagp command [2-459](#)
- show parser macro command [2-461](#)
- show platform acl command [C-2](#)
- show platform cfm command [C-3](#)
- show platform configuration command [C-4](#)
- show platform etherchannel command [C-5](#)
- show platform forward command [C-6](#)
- show platform igmp snooping command [C-8](#)
- show platform ipc trace command [C-13](#)
- show platform ip multicast command [C-10](#)
- show platform ip unicast command [C-11](#)
- show platform layer4op command [C-14](#)
- show platform mac-address-table command [C-15](#)
- show platform messaging command [C-16](#)
- show platform monitor command [C-17](#)
- show platform mvr table command [C-18](#)
- show platform pm command [C-19](#)
- show platform policer cpu command [C-21](#)
- show platform port-asic command [C-24](#)
- show platform port-security command [C-28](#)
- show platform qos command [C-29](#)
- show platform resource-manager command [C-32](#)
- show platform snmp counters command [C-34](#)
- show platform spanning-tree synchronization command [C-35](#)
- show platform stp-instance command [C-36](#)
- show platform team command [C-37](#)
- show platform vlan command [C-40](#)
- show policer aggregate command [2-463](#)
- show policer cpu uni-eni command [2-464](#)
- show policy-map command [2-466](#)
- show policy-map interface output fields [2-469](#)
- show port security command [2-470](#)
- show port-type command [2-473](#)
- show rep topology command [2-475](#)
- show sdm prefer command [2-477](#)
- show spanning-tree command [2-479](#)
- show storm-control command [2-487](#)
- show system mtu command [2-489](#)
- show udd command [2-492](#)
- show version command [2-494](#)
- show vlan access-map command [2-501](#)
- show vlan command [2-496](#)
- show vlan command, fields [2-498](#)
- show vlan filter command [2-502](#)
- show vmpls command [2-503](#)

- shutdown command [2-505](#)
- shutdown threshold, Layer 2 protocol tunneling [2-172](#)
- shutdown vlan command [2-506](#)
- small violation-rate command [2-507](#)
- SNMP host, specifying [2-514](#)
- SNMP informs, enabling the sending of [2-510](#)
- snmp mib rep trap-rate command [2-509](#)
- snmp-server enable traps command [2-510](#)
- snmp-server host command [2-514](#)
- snmp trap mac-notification command [2-518](#)
- SNMP traps
 - enabling MAC address notification trap [2-518](#)
 - enabling the MAC address notification feature [2-199](#)
 - enabling the sending of [2-510](#)
- software images
 - deleting [2-61](#)
 - downloading [2-7](#)
 - upgrading [2-7](#)
 - uploading [2-13](#)
- software version, displaying [2-494](#)
- source ports, MVR [2-237](#)
- SPAN
 - configuring [2-229](#)
 - debug messages, display [B-17](#)
 - displaying [2-451](#)
 - filter SPAN traffic [2-229](#)
 - sessions
 - add interfaces to [2-229](#)
 - displaying [2-451](#)
 - start new [2-229](#)
- spanning-tree bpdudfilter command [2-520, 2-522](#)
- spanning-tree bpduguard command [2-524](#)
- spanning-tree cost command [2-526](#)
- spanning-tree etherchannel command [2-528](#)
- spanning-tree extend system-id command [2-530](#)
- spanning-tree guard command [2-532](#)
- spanning-tree link-type command [2-534](#)
- spanning-tree loopguard default command [2-536](#)
- spanning-tree mode command [2-538](#)
- spanning-tree mst configuration command [2-540](#)
- spanning-tree mst cost command [2-542](#)
- spanning-tree mst forward-time command [2-544](#)
- spanning-tree mst hello-time command [2-545](#)
- spanning-tree mst max-age command [2-547](#)
- spanning-tree mst max-hops command [2-549](#)
- spanning-tree mst port-priority command [2-551](#)
- spanning-tree mst pre-standard command [2-553](#)
- spanning-tree mst priority command [2-554](#)
- spanning-tree mst root command [2-556](#)
- spanning-tree portfast (global configuration) command [2-560](#)
- spanning-tree portfast (interface configuration) command [2-563](#)
- spanning-tree port-priority command [2-558](#)
- Spanning Tree Protocol
 - See STP
- spanning-tree vlan command [2-565](#)
- speed command [2-568](#)
- SSH, configuring version [2-168](#)
- static-access ports, configuring [2-575](#)
- statistics, Ethernet group [2-295](#)
- sticky learning, enabling [2-590](#)
- storm-control command [2-570](#)
- STP
 - counters, clearing [2-51](#)
 - debug messages, display
 - MSTP [B-67](#)
 - optimized BPDUs handling [B-66](#)
 - spanning-tree activity [B-63](#)
 - switch shim [B-69](#)
 - transmitted and received BPDUs [B-65](#)
 - enabling on ENIs [2-520](#)
 - enabling protocol tunneling for [2-172](#)
 - EtherChannel misconfiguration [2-528](#)
 - extended system ID [2-530](#)
 - path cost [2-526](#)
 - protocol modes [2-538](#)

STP (continued)

- root port
 - loop guard [2-532](#)
 - preventing from becoming designated [2-532](#)
 - restricting which can be root [2-532](#)
 - root guard [2-532](#)
- root switch
 - affects of extended system ID [2-530, 2-566](#)
 - hello-time [2-565](#)
 - interval between BPDU messages [2-565](#)
 - interval between hello BPDU messages [2-565](#)
 - max-age [2-565](#)
 - port priority for selection of [2-558](#)
 - primary or secondary [2-565](#)
 - switch priority [2-565](#)
- state changes
 - blocking to forwarding state [2-563](#)
 - enabling BPDU filtering [2-522, 2-560](#)
 - enabling BPDU guard [2-524, 2-560](#)
 - enabling Port Fast [2-560, 2-563](#)
 - enabling timer to recover from error state [2-88](#)
 - forward-delay time [2-565](#)
 - length of listening and learning states [2-565](#)
 - shutting down Port Fast-enabled ports [2-560](#)
- state information display [2-479](#)
- VLAN options [2-554, 2-565](#)
- SVIs, creating [2-109](#)
- Switched Port Analyzer
 - See SPAN
- switching characteristics
 - modifying [2-573](#)
 - returning to interfaces [2-573](#)
- switchport access command [2-575](#)
- switchport backup interface command [2-577](#)
- switchport block command [2-581](#)
- switchport command [2-573](#)
- switchport host command [2-583](#)
- switchport mode command [2-584](#)
- switchport mode private-vlan command [2-587](#)

- switchport port-security aging command [2-594](#)
- switchport port-security command [2-590](#)
- switchport private-vlan command [2-596](#)
- switchport protected command [2-598](#)
- switchports, displaying [2-371](#)
- switchport trunk command [2-600](#)
- system env temperature threshold yellow command [2-602](#)
- system message logging, save message to flash [2-188](#)
- system mtu command [2-604](#)
- system resource templates [2-296](#)

T

- table-map command [2-607](#)
- table-map configuration mode [2-607](#)
- table maps
 - configuring [2-607](#)
 - displaying [2-490](#)
 - QoS [2-607](#)
- tar files, creating, listing, and extracting [2-10](#)
- TDR, running [2-609](#)
- temperature information, displaying [2-349](#)
- templates, system resources [2-296](#)
- test cable-diagnostics tdr command [2-609](#)
- traceroute mac command [2-611](#)
- traceroute mac ip command [2-614](#)
- traffic shaping, QoS [2-318](#)
- trunking, VLAN mode [2-584](#)
- trunk mode [2-584](#)
- trunk ports [2-584](#)
- tunnel ports, Layer 2 protocol, displaying [2-417](#)
- type (boot loader) command [A-22](#)

U

UDLD

- aggressive mode [2-616, 2-618](#)
- debug messages, display [B-76](#)
- enable globally [2-616](#)
- enable per interface [2-618](#)
- error recovery timer [2-88](#)
- message timer [2-616](#)
- normal mode [2-616, 2-618](#)
- reset a shutdown interface [2-620](#)
- status [2-492](#)

udld command [2-616](#)

udld port command [2-618](#)

udld reset command [2-620](#)

UNI

- bundling and multiplexing [2-97](#)
- Ethernet [2-97](#)

unicast storm control [2-570](#)

uni count command [2-621](#)

UniDirectional Link Detection

See UDLD

UNI ID, Ethernet [2-99](#)

uni-vlan command [2-623](#)

unknown multicast traffic, preventing [2-581](#)

unknown unicast traffic, preventing [2-581](#)

unset (boot loader) command [A-23](#)

upgrading

- software images [2-7](#)
- monitoring status of [2-323](#)

upgrading information

See release notes

user EXEC mode [1-2](#)

user network interface [2-265](#)

VLAN access map configuration mode [2-628](#)

VLAN access maps

- actions [2-5](#)
- displaying [2-501](#)

vlan command [2-625](#)

VLAN configuration mode

- commands [2-625](#)
- description [1-4](#)
- entering [2-625](#)
- summary [1-2](#)

vlan dot1q tag native command [2-630](#)

vlan filter command [2-632](#)

VLAN filters, displaying [2-502](#)

VLAN ID range [2-625](#)

VLAN maps

- applying [2-632](#)
- creating [2-628](#)
- defining [2-212](#)
- displaying [2-501](#)

VLAN Query Protocol

See VQP

VLANs

- adding [2-625](#)
- configuring [2-625](#)
- debug messages, display
 - activation of [B-74](#)
 - VLAN IOS file system error tests [B-73](#)
 - VLAN manager activity [B-71](#)
- displaying configurations [2-496](#)
- extended-range [2-625](#)
- MAC addresses
 - displaying [2-449](#)
 - number of [2-436](#)
- normal-range [2-625](#)
- private [2-587](#)
 - configuring [2-272](#)
 - displaying [2-496](#)
 - See also private VLANs
- restarting [2-506](#)

V

version (boot loader) command [A-25](#)

vlan access-map command [2-628](#)

VLANs (continued)

saving the configuration [2-625](#)

shutting down [2-506](#)

suspending [2-506](#)

VMPS

configuring servers [2-637](#)

displaying [2-503](#)

error recovery timer [2-88](#)

reconfirming dynamic VLAN assignments [2-634](#)

vmmps reconfirm (global configuration) command [2-635](#)

vmmps reconfirm (privileged EXEC) command [2-634](#)

vmmps retry command [2-636](#)

vmmps server command [2-637](#)

VQP

and dynamic-access ports [2-576](#)

clearing client statistics [2-54](#)

displaying information [2-503](#)

per-server retry count [2-636](#)

reconfirmation interval [2-635](#)

reconfirming dynamic VLAN assignments [2-634](#)

VTP, enabling tunneling for [2-172](#)

W

Weighted Tail Drop

See WTD

WTD, queue-limit command [2-277](#)

