



INDEX

A

aaa accounting dot1x command [2-1](#)
aaa authentication dot1x command [2-3](#)
AAA methods [2-3](#)
access control entries
 See ACEs
access control lists
 See ACLs
access groups
 IP [2-114](#)
 MAC, displaying [2-425](#)
 matching for QoS classification [2-216](#)
access mode [2-580](#)
access ports [2-580](#)
ACEs [2-66, 2-250](#)
ACLs
 as match criteria for QoS classes [2-216](#)
 deny [2-64](#)
 displaying [2-320](#)
 for non-IP protocols [2-194](#)
 IP [2-114](#)
 on Layer 2 interfaces [2-114](#)
 permit [2-248](#)
action command [2-5](#)
address aliasing [2-236](#)
aggregate policers
 applying [2-255](#)
 creating [2-257](#)
 displaying [2-460](#)
 QoS [2-258](#)
aggregate-port learner [2-242](#)
allowed VLANs [2-596](#)

archive download-sw command [2-7](#)
archive tar command [2-10](#)
archive upload-sw command [2-13](#)
arp access-list command [2-15](#)
attaching policy maps to interfaces [2-302](#)
authorization state of controlled port [2-73](#)
autonegotiation of duplex mode [2-85](#)

B

backup interfaces
 configuring [2-573](#)
 displaying [2-370](#)
bandwidth, configuring for QoS [2-17](#)
bandwidth command [2-17](#)
boot (boot loader) command [A-2](#)
boot config-file command [2-20](#)
boot enable-break command [2-21](#)
boot helper command [2-22](#)
boot helper-config file command [2-23](#)
booting
 Cisco IOS image [2-26](#)
 displaying environment variables [2-325](#)
 interrupting [2-21](#)
 manually [2-24](#)

boot loader

accessing [A-1](#)

booting

Cisco IOS image [A-2](#)helper image [2-22](#)

directories

creating [A-14](#)displaying a list of [A-7](#)removing [A-18](#)

displaying

available commands [A-12](#)memory heap utilization [A-13](#)version [A-25](#)

environment variables

described [A-19](#)displaying settings [A-19](#)location of [A-20](#)setting [A-19](#)unsetting [A-23](#)

files

copying [A-5](#)deleting [A-6](#)displaying a list of [A-7](#)displaying the contents of [A-4, A-15, A-22](#)renaming [A-16](#)

file system

formatting [A-10](#)initializing flash [A-9](#)running a consistency check [A-11](#)prompt [A-1](#)resetting the system [A-17](#)boot manual command [2-24](#)boot private-config-file command [2-25](#)boot system command [2-26](#)BPDU filtering, for spanning tree [2-518, 2-556](#)BPDU guard, for spanning tree [2-520, 2-556](#)broadcast storm control [2-566](#)bundling characteristics, UNI [2-97](#)burst bytes, in QoS policers [2-251, 2-257](#)**C**cat (boot loader) command [A-4](#)CBWFQ, configuring [2-17](#)CDP, enabling protocol tunneling for [2-174](#)CFM [2-241](#)CFM as OAM protocol [2-241](#)channel-group command [2-27](#)channel-protocol command [2-31](#)child policy maps [2-304](#)class-based traffic shaping [2-318](#)

class-based weighted fair queuing

See CBWFQ

class command [2-33](#)class-map command [2-35](#)class-map configuration mode [2-35](#)

class maps

creating [2-35](#)defining the match criteria [2-217](#)displaying [2-329](#)matching in [2-35](#)

class of service

See CoS

clear ip arp inspection log command [2-37](#)clear ip arp inspection statistics command [2-38](#)clear ipc command [2-41](#)clear l2protocol-tunnel counters command [2-42](#)clear lacp command [2-43](#)clear mac address-table command [2-44, 2-45](#)clear pagp command [2-46, 2-50](#)clear policer cpu uni-eni counters command [2-47](#)clear port-security command [2-48](#)clear spanning-tree counters command [2-51](#)clear spanning-tree detected-protocols command [2-52](#)clear vmps statistics command [2-54](#)command modes defined [1-1](#)committed information rate in QoS policers [2-251, 2-257](#)

- configuration files
 - password recovery disable considerations [A-1](#)
 - specifying the name [2-20, 2-25](#)
- configuring multiple interfaces [2-110](#)
- conform-action command [2-55](#)
- control-plane policer [2-47](#)
- control-plane policer information, displaying [2-461](#)
- control-plane security [2-260](#)
- control plane statistics, clearing [2-47](#)
- copy (boot loader) command [A-5](#)
- CoS
 - as match criteria for QoS groups [2-217](#)
 - for QoS classification [2-307](#)
 - setting value in policy maps [2-307](#)
- CoS value, assigning to Layer 2 protocol packets [2-177](#)
- CPU ASIC statistics, displaying [2-330](#)
- CPU protection policers, displaying [C-20](#)
- cpu traffic qos [2-57](#)

D

- debug backup command [B-2](#)
- debug dot1x command [B-3](#)
- debug etherchannel command [B-4](#)
- debug interface command [B-9](#)
- debug ip dhcp snooping command [B-7](#)
- debug ip igmp filter command [B-10](#)
- debug ip igmp max-groups command [B-11](#)
- debug ip igmp snooping command [B-12](#)
- debug ip verify source packet command [B-8](#)
- debug lacp command [B-13](#)
- debug mac-notification command [B-14](#)
- debug matm command [B-15](#)
- debug matm move update command [B-16](#)
- debug monitor command [B-17](#)
- debug mvrdbg command [B-18](#)
- debug nvram command [B-19](#)
- debug pagp command [B-20](#)
- debug platform acl command [B-21](#)
- debug platform backup interface command [B-23](#)
- debug platform cfm command [B-22](#)
- debug platform cpu-queues command [B-24](#)
- debug platform dot1x command [B-26](#)
- debug platform etherchannel command [B-27](#)
- debug platform forw-tcam command [B-28](#)
- debug platform ip arp inspection command [B-29](#)
- debug platform ipc command [B-37](#)
- debug platform ip dhcp command [B-30](#)
- debug platform ip igmp snooping command [B-31](#)
- debug platform ip multicast command [B-33](#)
- debug platform led command [B-38](#)
- debug platform matm command [B-39](#)
- debug platform messaging application command [B-40](#)
- debug platform phy command [B-41](#)
- debug platform pm command [B-43](#)
- debug platform policer cpu uni-eni command [B-45](#)
- debug platform port-asic command [B-46](#)
- debug platform port-security command [B-47](#)
- debug platform qos-acl-tcam command [B-48](#)
- debug platform remote-commands command [B-49](#)
- debug platform rep command [B-50](#)
- debug platform resource-manager command [B-51](#)
- debug platform snmp command [B-52](#)
- debug platform span command [B-53](#)
- debug platform supervisor-asic command [B-54](#)
- debug platform sw-bridge command [B-55](#)
- debug platform tcam command [B-56](#)
- debug platform udd command [B-58](#)
- debug platform vlan command [B-59](#)
- debug pm command [B-60](#)
- debug port-security command [B-62](#)
- debug qos-manager command [B-64](#)
- debug rep command [B-63](#)
- debug spanning-tree bpdu command [B-67](#)
- debug spanning-tree bpdu-opt command [B-68](#)
- debug spanning-tree command [B-65](#)
- debug spanning-tree mstp command [B-69](#)
- debug spanning-tree switch command [B-71](#)

- debug sw-vlan command [B-73](#)
- debug sw-vlan ifs command [B-74](#)
- debug sw-vlan notification command [B-75](#)
- debug udd command [B-77](#)
- debug vqpc command [B-79](#)
- default policer configuration
 - NNIs [C-22](#)
 - UNIs [C-21](#)
- define interface-range command [2-59](#)
- delete (boot loader) command [A-6](#)
- delete command [2-61](#)
- deny (ARP access-list configuration) command [2-62](#)
- deny command [2-64](#)
- detect mechanism, causes [2-86](#)
- DHCP snooping
 - accepting untrusted packets from edge switch [2-139](#)
 - enabling
 - on a VLAN [2-145](#)
 - option 82 [2-137, 2-139](#)
 - trust on an interface [2-143](#)
 - error recovery timer [2-90](#)
 - rate limiting [2-142](#)
- DHCP snooping binding database
 - binding file, configuring [2-135](#)
 - bindings
 - adding [2-133](#)
 - deleting [2-133](#)
 - displaying [2-391](#)
 - clearing database agent statistics [2-39](#)
 - database agent, configuring [2-135](#)
 - displaying
 - binding entries [2-391](#)
 - database agent status [2-393, 2-395](#)
 - renewing [2-283](#)
- differentiated service code point
 - See DSCP
- Digital Optical Monitoring
 - see DoM
- dir (boot loader) command [A-7](#)
- directories, deleting [2-61](#)
- DoM
 - displaying supported transceivers [2-382](#)
- domains, CFM [2-241](#)
- dot1x default command [2-67](#)
- dot1x host-mode command [2-68](#)
- dot1x initialize command [2-70](#)
- dot1x max-req command [2-71, 2-72](#)
- dot1x port-control command [2-73](#)
- dot1x re-authenticate command [2-75](#)
- dot1x reauthentication command [2-76](#)
- dot1x system-auth-control command [2-77](#)
- dot1x test eapol-capable command [2-78](#)
- dot1x test timeout command [2-79](#)
- dot1x timeout command [2-80](#)
- dot1x violation-mode command [2-82](#)
- dropping packets, with ACL matches [2-5](#)
- drop threshold, Layer 2 protocol tunneling [2-174](#)
- DSCP
 - as match criteria for QoS groups [2-218, 2-224](#)
 - for QoS traffic marking [2-309](#)
 - setting in policy maps [2-309](#)
- dual-purpose uplink ports, selecting the type [2-229](#)
- duplex command [2-84](#)
- dynamic-access ports
 - configuring [2-571](#)
 - restrictions [2-572](#)
- dynamic ARP inspection
 - ARP ACLs
 - apply to a VLAN [2-119](#)
 - define [2-15](#)
 - deny packets [2-62](#)
 - display [2-324](#)
 - permit packets [2-246](#)
 - clear
 - log buffer [2-37](#)
 - statistics [2-38](#)

dynamic ARP inspection (continued)

- display
 - ARP ACLs [2-324](#)
 - configuration and operating state [2-386](#)
 - log buffer [2-386](#)
 - statistics [2-386](#)
 - trust state and rate limit [2-386](#)
- enable per VLAN [2-129](#)
- error detection for [2-86](#)
- error recovery timer [2-90](#)
- log buffer
 - clear [2-37](#)
 - configure [2-123](#)
 - display [2-386](#)
- rate-limit incoming ARP packets [2-121](#)
- statistics
 - clear [2-38](#)
 - display [2-386](#)
- trusted interface state [2-125](#)
- type of packet logged [2-130](#)
- validation checks [2-127](#)

Dynamic Host Configuration Protocol (DHCP)

See DHCP snooping

E**EAP-request/identity frame**

- maximum number to send [2-72](#)
- response time before retransmitting [2-80](#)

E-LM

- mapping [2-97](#)

E-LMI

- enabling [2-95](#)

environment variables, displaying [2-325](#)

errdisable detect cause command [2-86](#)

errdisable detect cause small-frame command [2-88](#)

errdisable recovery cause small-frame [2-93](#)

errdisable recovery command [2-90](#)

error conditions, displaying [2-353](#)

error disable detection [2-86](#)

error-disabled interfaces, displaying [2-370](#)

EtherChannel

- assigning Ethernet interface to channel group [2-27](#)
- creating port-channel logical interface [2-108](#)
- debug EtherChannel/PAgP, display [B-4](#)
- debug platform-specific events, display [B-27](#)
- displaying [2-357](#)
- enabling Layer 2 protocol tunneling for

- LACP [2-175](#)

- PAgP [2-175](#)

- UDLD [2-175](#)

interface information, displaying [2-370](#)

LACP

- clearing channel-group information [2-43](#)
- debug messages, display [B-13](#)
- displaying [2-416](#)
- modes [2-27](#)
- port priority for hot-standby ports [2-178](#)
- restricting a protocol [2-31](#)
- system priority [2-180](#)

load-distribution methods [2-264](#)

PAgP

- aggregate-port learner [2-242](#)
- clearing channel-group information [2-46](#)
- debug messages, display [B-20](#)
- displaying [2-456](#)
- error detection for [2-86](#)
- error recovery timer [2-90](#)
- learn method [2-242](#)
- modes [2-27](#)
- physical-port learner [2-242](#)
- priority of interface for transmitted traffic [2-244](#)

ethermet lmi ce command [2-95](#)

Ethernet controller, internal register display [2-332](#)

ethernet evc command [2-94](#)

ethernet lim global command [2-95](#)

ethernet lmi ce-vlan map command [2-97, 2-99](#)

ethernet lmi command [2-95](#)

Ethernet Local Management Interface

See E-LMI

Ethernet service

debugging [B-5](#)

displaying [2-360](#)

Ethernet service instance [2-298](#)

Ethernet service interfaces [2-364](#)

Ethernet statistics, collecting [2-295](#)

Ethernet UNI configuration [2-101](#)

ethernet uni id command [2-103](#)

Ethernet virtual connections

See EVCs

EVC configuration mode [2-94](#)

EVCs [2-94](#)

and VLANs [2-101](#)

service instances [2-298](#)

UNI counts [2-617](#)

EVC service

point-to-multipoint [2-617](#)

point-to-point [2-617](#)

exceed-action command [2-104](#)

extended-range VLANs

and allowed VLAN list [2-596](#)

configuring [2-621](#)

extended system ID for STP [2-526](#)

F

fan information, displaying [2-348](#)

files, deleting [2-61](#)

flash_init (boot loader) command [A-9](#)

Flex Links

configuring [2-573](#)

configuring preferred VLAN [2-575](#)

displaying [2-370](#)

flowcontrol command [2-106](#)

format (boot loader) command [A-10](#)

forwarding packets, with ACL matches [2-5](#)

forwarding results, display [C-6](#)

frame forwarding information, displaying [C-6](#)

fsck (boot loader) command [A-11](#)

G

global configuration mode [1-2, 1-3](#)

H

hardware ACL statistics [2-320](#)

help (boot loader) command [A-12](#)

host connection, port configuration [2-579](#)

host ports, private VLANs [2-583](#)

I

IEEE 802.1ag Connectivity Fault Management

See CFM

IEEE 802.1Q trunk ports and native VLANs [2-626](#)

IEEE 802.1Q tunnel ports

configuring [2-580](#)

displaying [2-344](#)

limitations [2-581](#)

IEEE 802.1x

and switchport modes [2-581](#)

violation error recovery [2-90](#)

See also port-based authentication

IGMP filters

applying [2-148](#)

debug messages, display [B-10](#)

IGMP groups, setting maximum [2-150](#)

IGMP maximum groups, debugging [B-11](#)

IGMP profiles

creating [2-152](#)

displaying [2-398](#)

IGMP snooping

- adding ports as a static member of a group [2-167](#)
- displaying [2-399, 2-403, 2-405](#)
- enabling [2-154](#)
- enabling the configurable-leave timer [2-156](#)
- enabling the Immediate-Leave feature [2-164](#)
- flooding query count [2-162](#)
- interface topology change notification behavior [2-163](#)
- multicast table [2-401](#)
- querier [2-158](#)
- query solicitation [2-162](#)
- report suppression [2-160](#)
- switch topology change notification behavior [2-162](#)

images

See software images

Immediate-Leave feature, MVR [2-238](#)

immediate-leave processing [2-164](#)

input policy maps

- and ACL classification [2-216](#)
- and aggregate policers [2-258](#)
- commands not supported in [2-262](#)
- configuration guidelines [2-262](#)

interface command [2-112](#)

interface configuration mode [1-2, 1-4](#)

interface port-channel command [2-108](#)

interface range command [2-110](#)

interface-range macros [2-57, 2-59](#)

interfaces

- assigning Ethernet interface to channel group [2-27](#)
- configuring [2-84](#)
- configuring multiple [2-110](#)
- creating port-channel logical [2-108](#)
- debug messages, display [B-9](#)
- disabling [2-501](#)
- displaying the MAC address table [2-437](#)
- restarting [2-501](#)

interface speed, configuring [2-564](#)

internal registers, displaying [2-332, 2-339, 2-343](#)

Internet Group Management Protocol

See IGMP

invalid GBIC

- error detection for [2-86](#)
- error recovery timer [2-90](#)

ip address command [2-117](#)

IP addresses, setting [2-117](#)

IP address matching [2-214](#)

ip arp inspection filter vlan command [2-119](#)

ip arp inspection limit command [2-121](#)

ip arp inspection log-buffer command [2-123](#)

ip arp inspection trust command [2-125](#)

ip arp inspection validate command [2-127](#)

ip arp inspection vlan command [2-129](#)

ip arp inspection vlan logging command [2-130](#)

IP DHCP snooping

See DHCP snooping

ip dhcp snooping binding command [2-133](#)

ip dhcp snooping command [2-132](#)

ip dhcp snooping database command [2-135](#)

ip dhcp snooping information option allow-untrusted command [2-139](#)

ip dhcp snooping information option command [2-137](#)

ip dhcp snooping information option format remote-id command [2-141](#)

ip dhcp snooping limit rate command [2-142](#)

ip dhcp snooping trust command [2-143](#)

ip dhcp snooping verify command [2-144](#)

ip dhcp snooping vlan command [2-145](#)

ip dhcp snooping vlan information option format-type circuit-id string command [2-146](#)

ip igmp filter command [2-148](#)

ip igmp max-groups command [2-150](#)

ip igmp profile command [2-152](#)

ip igmp snooping command [2-154](#)

ip igmp snooping last-member-query-interval command [2-156](#)

ip igmp snooping querier command [2-158](#)

ip igmp snooping report-suppression command [2-160](#)

ip igmp snooping tcn command [2-162](#)

ip igmp snooping tcn flood command [2-163](#)
 ip igmp snooping vlan immediate-leave command [2-164](#)
 ip igmp snooping vlan mrouter command [2-165](#)
 ip igmp snooping vlan static command [2-167](#)
 IP multicast addresses [2-235](#)
 IP precedence, as match criteria for QoS groups [2-220](#)
 ip source binding command [2-169](#)
 IP source guard
 disabling [2-173](#)
 displaying
 binding entries [2-407](#)
 configuration [2-408](#)
 enabling [2-173](#)
 static IP source bindings [2-169](#)
 IP source guard, displaying dynamic binding entries [2-391](#)
 ip ssh command [2-171](#)
 ip verify source command [2-173](#)

J

jumbo frames
 See MTU

L

l2protocol-tunnel command [2-174](#)
 l2protocol-tunnel cos command [2-177](#)
 LACP
 See EtherChannel
 lacp port-priority command [2-178](#)
 lacp system-priority command [2-180](#)
 Layer 2 mode, enabling [2-569](#)
 Layer 2 protocol ports, displaying [2-414](#)
 Layer 2 protocol-tunnel
 error detection for [2-86](#)
 error recovery timer [2-90](#)
 Layer 2 protocol tunnel counters [2-42](#)
 Layer 2 protocol tunneling error recovery [2-175](#)

Layer 2 traceroute
 IP addresses [2-610](#)
 MAC addresses [2-607](#)
 Layer 3 mode, enabling [2-569](#)
 line configuration mode [1-2, 1-4](#)
 Link Aggregation Control Protocol
 See EtherChannel
 link flap
 error detection for [2-86](#)
 error recovery timer [2-90](#)
 link state group command [2-182](#)
 link state track command [2-184](#)
 load-distribution methods for EtherChannel [2-264](#)
 location (global configuration) command [2-185](#)
 location (interface configuration) command [2-187](#)
 logging event command [2-189](#)
 logging file command [2-190](#)
 logical interface [2-108](#)
 loopback error
 detection for [2-86](#)
 recovery timer [2-90](#)
 loop guard, for spanning tree [2-528, 2-532](#)

M

mac access-group command [2-192](#)
 MAC access-groups, displaying [2-425](#)
 MAC access list configuration mode [2-194](#)
 mac access-list extended command [2-194](#)
 MAC access lists [2-64](#)

MAC addresses

disabling MAC address learning per VLAN [2-197](#)

displaying

aging time [2-431](#)

all [2-429](#)

dynamic [2-435](#)

MAC address-table move updates [2-440](#)

notification settings [2-439, 2-442](#)

number of addresses in a VLAN [2-433](#)

per interface [2-437](#)

per VLAN [2-446](#)

static [2-444](#)

static and dynamic entries [2-427](#)

dynamic

aging time [2-196](#)

deleting [2-44](#)

displaying [2-435](#)

enabling MAC address notification [2-201](#)

enabling MAC address-table move update [2-199](#)

matching [2-214](#)

static

adding and removing [2-203](#)

displaying [2-444](#)

dropping on an interface [2-204](#)

tables [2-429](#)

MAC address notification, debugging [B-14](#)

mac address-table aging-time [2-192, 2-214](#)

mac address-table aging-time command [2-196](#)

mac address-table learning command [2-197](#)

mac address-table move update command [2-199](#)

mac address-table notification command [2-201](#)

mac address-table static command [2-203](#)

mac address-table static drop command [2-204](#)

macro description command [2-208](#)

macro global command [2-209](#)

macro global description command [2-211](#)

macro name command [2-212](#)

macros

adding a description [2-208](#)

adding a global description [2-211](#)

applying [2-209](#)

creating [2-212](#)

displaying [2-458](#)

interface range [2-59, 2-110](#)

specifying parameter values [2-209](#)

tracing [2-209](#)

maintenance end points [2-617](#)

mapping tables, QoS [2-603](#)

maps

class

creating [2-35](#)

VLAN

creating [2-624](#)

defining [2-214](#)

displaying [2-497](#)

match access-group command [2-216](#)

match cos command [2-217](#)

match ip dscp command [2-218](#)

match ip precedence command [2-220](#)

match qos-group command [2-222](#)

match vlan command [2-224](#)

maximum transmission unit

See MTU

mdix auto command [2-227](#)

media-type command [2-229](#)

memory (boot loader) command [A-13](#)

mkdir (boot loader) command [A-14](#)

mode, MVR [2-235](#)

modes, commands [1-1](#)

monitor session command [2-231](#)

more (boot loader) command [A-15](#)

MSTP

- displaying [2-477](#)
- interoperability [2-52](#)
- link type [2-530](#)
- MST region
 - aborting changes [2-536](#)
 - applying changes [2-536](#)
 - configuration name [2-536](#)
 - configuration revision number [2-537](#)
 - current or pending display [2-537](#)
 - displaying [2-477](#)
 - MST configuration mode [2-536](#)
 - VLANs-to-instance mapping [2-536](#)
- path cost [2-538](#)
- protocol mode [2-534](#)
- restart protocol migration process [2-52](#)
- root port
 - loop guard [2-528](#)
 - preventing from becoming designated [2-528](#)
 - restricting which can be root [2-528](#)
 - root guard [2-528](#)
- root switch
 - affects of extended system ID [2-526](#)
 - hello-time [2-541, 2-552](#)
 - interval between BPDU messages [2-543](#)
 - interval between hello BPDU messages [2-541, 2-552](#)
 - max-age [2-543](#)
 - maximum hop count before discarding BPDU [2-545](#)
 - port priority for selection of [2-547](#)
 - primary or secondary [2-552](#)
 - switch priority [2-550](#)

MSTP (continued)

- state changes
 - blocking to forwarding state [2-559](#)
 - enabling BPDU filtering [2-518, 2-556](#)
 - enabling BPDU guard [2-520, 2-556](#)
 - enabling Port Fast [2-556, 2-559](#)
 - forward-delay time [2-540](#)
 - length of listening and learning states [2-540](#)
 - rapid transition to forwarding [2-530](#)
 - shutting down Port Fast-enabled ports [2-556](#)
 - state information display [2-476](#)
- MTU
- configuring size [2-600](#)
 - displaying global setting [2-484](#)
- multicast group address, MVR [2-238](#)
- multicast groups, MVR [2-236](#)
- multicast router learning method [2-165](#)
- multicast router ports, configuring [2-165](#)
- multicast storm control [2-566](#)
- multicast VLAN, MVR [2-235](#)
- multicast VLAN registration
- See MVR
- multiple hosts on authorized port [2-68](#)
- Multiple Spanning Tree Protocol
- See MSTP
- multiplexing, UNI [2-101](#)
- MVR
- and address aliasing [2-236](#)
 - configuring [2-235](#)
 - configuring interfaces [2-238](#)
 - debug messages, display [B-18](#)
 - displaying [2-450](#)
 - displaying interface information [2-452](#)
 - members, displaying [2-454](#)
- mvr (global configuration) command [2-235](#)
- mvr (interface configuration) command [2-238](#)
- mvr vlan group command [2-239](#)

N

native VLANs [2-596](#)
 native VLAN tagging [2-626](#)
 network node interface [2-266](#)
 nonegotiate, speed [2-564](#), [2-565](#)
 non-IP protocols
 denying [2-64](#)
 forwarding [2-248](#)
 non-IP traffic access lists [2-194](#)
 non-IP traffic forwarding
 denying [2-64](#)
 permitting [2-248](#)
 normal-range VLANs [2-621](#)
 no vlan command [2-621](#)

O

OAM PDUs [2-99](#)
 OAM protocol [2-241](#)
 oam protocol cfm svlan command [2-241](#)
 operation, administration, and maintenance protocol
 See OAM
 output policy maps
 and QoS group classification [2-222](#)
 and traffic shaping [2-318](#)
 commands not supported in [2-262](#)
 configuration guidelines [2-262](#)
 priority in [2-271](#)
 queue limit in [2-278](#)

P

PAgP
 See EtherChannel
 pagp learn-method command [2-242](#)
 pagp port-priority command [2-244](#)
 parent policy maps [2-305](#)
 password-recovery mechanism, enabling and disabling [2-300](#)
 permit (ARP access-list configuration) command [2-246](#)
 permit command [2-248](#)
 per-VLAN spanning-tree plus
 See STP
 physical-port learner [2-242](#)
 PID, displaying [2-385](#)
 PIM-DVMRP, as multicast router learning method [2-165](#)
 police
 multiple conform actions for a class [2-55](#)
 multiple exceed actions for a class [2-104](#)
 with priority [2-251](#)
 police aggregate command [2-255](#)
 police command [2-251](#)
 policer aggregate command [2-257](#)
 policer configuration
 default for NNIs [C-22](#)
 default for UNIs [C-21](#)
 policer cpu uni command [2-260](#)
 policers
 aggregate [2-255](#), [2-257](#)
 for CPU protection [2-260](#)
 individual [2-251](#)
 policy-map class, configuring multiple actions [2-55](#), [2-104](#)
 policy-map class configuration mode [2-33](#)
 policy-map class police configuration mode [2-55](#), [2-253](#)
 policy-map command [2-261](#)
 policy-map configuration mode [2-261](#)
 policy maps
 and CoS classification [2-217](#)
 and DSCP classification [2-218](#)
 and IP precedence classification [2-220](#)
 and policing [2-253](#)
 applying [2-302](#)
 applying to an interface [2-262](#), [2-302](#), [2-315](#)
 child [2-304](#)
 creating [2-261](#)
 displaying [2-463](#)

policy maps (continued)

- hierarchical [2-304](#)
- parent [2-305](#)
- policers
 - for a single class [2-251](#)
 - for multiple classes [2-255, 2-257, 2-260, 2-304](#)
- setting priority [2-270](#)
- setting QoS group identifier [2-313](#)
- traffic classification, defining [2-33](#)
- traffic marking
 - setting CoS values [2-307](#)
 - setting DSCP values [2-309](#)
 - setting IP precedence values [2-311](#)

Port Aggregation Protocol

See EtherChannel

port-based authentication

- AAA method list [2-3](#)
- configuring violation modes [2-82](#)
- debug messages, display [B-3](#)
- enabling 802.1x
 - globally [2-77](#)
 - per interface [2-73](#)
- host modes [2-68](#)
- IEEE 802.1x AAA accounting methods [2-1](#)
- initialize an interface [2-70, 2-79](#)
- manual control of authorization state [2-73](#)
- multiple hosts on authorized port [2-68](#)
- periodic re-authentication
 - enabling [2-76](#)
 - time between attempts [2-80](#)
- quiet period between failed authentication exchanges [2-80](#)
- re-authenticating 802.1x-enabled ports [2-75](#)
- resetting configurable 802.1x parameters [2-67](#)
- switch-to-authentication server retransmission time [2-80](#)
- switch-to-client frame-retransmission number [2-71 to 2-72](#)
- switch-to-client retransmission time [2-80](#)
- test for IEEE 802.1x readiness [2-78](#)

port-channel load-balance command [2-264](#)

Port Fast, for spanning tree [2-559](#)

port ranges, defining [2-57, 2-59](#)

ports, debugging [B-60](#)

ports, protected [2-594](#)

port security

- aging [2-590](#)
- debug messages, display [B-62](#)
- enabling [2-586](#)
- violation error recovery [2-90](#)

port shaping [2-319](#)

port-type command [2-266](#)

port types, MVR [2-238](#)

power information, displaying [2-348](#)

power-supply dual command [2-268](#)

precedence

- for QoS traffic marking [2-311](#)
- setting in policy maps [2-311](#)

priority command [2-270](#)

priority queuing, QoS [2-270](#)

priority with police, QoS [2-270](#)

private-vlan command [2-273](#)

private-vlan mapping command [2-276](#)

private VLANs

- association [2-592](#)
- configuring [2-273](#)
- configuring ports [2-583](#)
- displaying [2-492](#)
- host ports [2-583](#)
- mapping
 - configuring [2-592](#)
 - displaying [2-370](#)
- promiscuous ports [2-583](#)

privileged EXEC mode [1-2, 1-3](#)

product identification information, displaying [2-385](#)

promiscuous ports, private VLANs [2-583](#)

PVST+

See STP

Q

QoS

aggregate policers

- applying [2-255](#)
- creating [2-257](#)
- displaying [2-460](#)

class maps

- creating [2-35](#)
- defining the match criteria [2-217](#)
- displaying [2-329](#)

displaying statistics for [2-463, C-28](#)

policy maps

- applying an aggregate policer [2-255, 2-257, 2-260, 2-304](#)
- applying to an interface [2-302, 2-315](#)
- creating [2-261](#)
- defining policers [2-251](#)
- displaying policy maps [2-463](#)
- setting CoS values [2-307](#)
- setting DSCP values [2-309](#)
- setting IP precedence values [2-311](#)
- setting QoS group identifier [2-313](#)
- traffic classifications [2-33](#)

table maps

- configuring [2-603](#)
- displaying [2-485](#)

QoS groups

- as match criteria [2-222](#)
- for QoS traffic classification [2-313](#)
- setting in policy maps [2-313](#)

QoS match criteria

- ACLs [2-216](#)
- CoS value [2-217](#)
- DSCP value [2-218, 2-224](#)
- precedence value [2-220](#)
- QoS group number [2-222](#)

quality of service

- See QoS

querytime, MVR [2-235](#)

queue-limit command [2-278](#)

R

rapid per-VLAN spanning-tree plus

See STP

rapid PVST+

See STP

re-authenticating 802.1x-enabled ports [2-75](#)

re-authentication

- periodic [2-76](#)
- time between attempts [2-80](#)

receiver ports, MVR [2-238](#)

receiving flow-control packets [2-106](#)

recovery mechanism

- causes [2-90](#)
- display [2-327, 2-351, 2-355](#)
- timer interval [2-91](#)

remote-span command [2-281](#)

Remote Switched Port Analyzer

See RSPAN

rename (boot loader) command [A-16](#)

renew ip dhcp snooping database command [2-283](#)

rep admin vlan command [2-284](#)

rep block port command [2-285](#)

rep lsl-age-timer command [2-288](#)

rep preempt delay command [2-289](#)

rep preempt segment command [2-291](#)

rep segment command [2-292](#)

rep sten command [2-294](#)

reset (boot loader) command [A-17](#)

resource templates, displaying [2-474](#)

rmdir (boot loader) command [A-18](#)

rmon collection stats command [2-295](#)

root guard, for spanning tree [2-528](#)

routed ports

- IP addresses on [2-118](#)
- number supported [2-118](#)

RSPAN

- configuring [2-231](#)
- displaying [2-448](#)
- filter RSPAN traffic [2-231](#)
- remote-span command [2-281](#)
- sessions
 - add interfaces to [2-231](#)
 - displaying [2-448](#)
 - start new [2-231](#)

S

sdm prefer command [2-296](#)

SDM templates

- allowed resources [2-297](#)
- displaying [2-474](#)

secure ports, limitations [2-587](#)

sending flow-control packets [2-106](#)

service instance command [2-298](#)

service instances, displaying [2-362](#)

service password-recovery command [2-300](#)

service policy (policy-map class configuration) command [2-304](#)

service-policy interface configuration command [2-302](#)

service-policy policy-map class configuration command [2-304](#)

set (boot loader) command [A-19](#)

set cos command [2-307](#)

set dscp command [2-309](#)

set precedence command [2-311](#)

set qos-group command [2-313](#)

setup command [2-315](#)

SFPs, displaying information about [2-385](#)

shape average command [2-318](#)

show access-lists command [2-320](#)

show aggregate-policer command [2-485](#)

show archive status command [2-323](#)

show arp access-list command [2-324](#)

show boot command [2-325](#)

show class-map command [2-329](#)

show controllers cpu-interface command [2-330](#)

show controllers ethernet-controller command [2-332](#)

show controllers team command [2-339](#)

show controllers utilization command [2-341](#)

show controller utilization command [2-341](#)

show cpu traffic qos [2-343](#)

show dot1q-tunnel command [2-344](#)

show dot1x command [2-345](#)

show env command [2-348](#)

show errdisable detect command [2-351](#)

show errdisable flap-values command [2-353](#)

show errdisable recovery command [2-355](#)

show etherchannel command [2-357](#)

show ethernet service evc command [2-360](#)

show ethernet service instance command [2-362](#)

show ethernet service interface command [2-364](#)

show flowcontrol command [2-366](#)

show idprom command [2-368](#)

show interface rep command [2-380](#)

show interfaces command [2-370](#)

show interfaces counters command [2-378](#)

show interfaces rep command [2-380](#)

show interface transceivers command [2-382](#)

show inventory command [2-385](#)

show ip arp inspection command [2-386](#)

show ipc command [2-410](#)

show ip dhcp snooping binding command [2-391](#)

show ip dhcp snooping command [2-390](#)

show ip dhcp snooping database command [2-393, 2-395](#)

show ip igmp profile command [2-398](#)

show ip igmp snooping command [2-399](#)

show ip igmp snooping command querier detail [2-405](#)

show ip igmp snooping groups command [2-401](#)

show ip igmp snooping mrouter command [2-403](#)

show ip igmp snooping querier command [2-405](#)

show ip igmp snooping querier detail command [2-405](#)

show ip source binding command [2-407](#)

show ip verify source command [2-408](#)

- show l2protocol-tunnel command [2-414](#)
- show lacp command [2-416](#)
- show link state group command [2-420](#)
- show location [2-422](#)
- show location command [2-422](#)
- show mac access-group command [2-425](#)
- show mac address-table address command [2-429](#)
- show mac address-table aging time command [2-431](#)
- show mac address-table command [2-427](#)
- show mac address-table count command [2-433](#)
- show mac address-table dynamic command [2-435](#)
- show mac address-table interface command [2-437](#)
- show mac address-table learning command [2-439](#)
- show mac address-table move update command [2-440](#)
- show mac address-table notification command [2-45, 2-442, B-16](#)
- show mac address-table static command [2-444](#)
- show mac address-table vlan command [2-446](#)
- show monitor command [2-448](#)
- show mvr command [2-450](#)
- show mvr interface command [2-452](#)
- show mvr members command [2-454](#)
- show pagp command [2-456](#)
- show parser macro command [2-458](#)
- show platform acl command [C-2](#)
- show platform cfm command [C-3](#)
- show platform configuration command [C-4](#)
- show platform etherchannel command [C-5](#)
- show platform forward command [C-6](#)
- show platform igmp snooping command [C-8](#)
- show platform ipc trace command [C-13](#)
- show platform ip multicast command [C-10](#)
- show platform ip unicast command [C-11](#)
- show platform layer4op command [C-14](#)
- show platform mac-address-table command [C-15](#)
- show platform messaging command [C-16](#)
- show platform monitor command [C-17](#)
- show platform mvr table command [C-18](#)
- show platform pm command [C-19](#)
- show platform policer cpu command [C-20](#)
- show platform port-asic command [C-23](#)
- show platform port-security command [C-27](#)
- show platform qos command [C-28](#)
- show platform resource-manager command [C-31](#)
- show platform snmp counters command [C-33](#)
- show platform spanning-tree synchronization command [C-34](#)
- show platform stp-instance command [C-35](#)
- show platform team command [C-36](#)
- show platform vlan command [C-39](#)
- show policer aggregate command [2-460](#)
- show policer cpu uni-eni command [2-461](#)
- show policy-map command [2-463](#)
- show policy-map interface output fields [2-466](#)
- show port security command [2-467](#)
- show port-type command [2-470](#)
- show rep topology command [2-472](#)
- show sdm prefer command [2-474](#)
- show spanning-tree command [2-476](#)
- show storm-control command [2-482](#)
- show system mtu command [2-484](#)
- show udd command [2-487](#)
- show version command [2-490](#)
- show vlan access-map command [2-497](#)
- show vlan command [2-492](#)
- show vlan command, fields [2-494](#)
- show vlan filter command [2-498](#)
- show vmps command [2-499](#)
- shutdown command [2-501](#)
- shutdown threshold, Layer 2 protocol tunneling [2-174](#)
- shutdown vlan command [2-502](#)
- small violation-rate command [2-503](#)
- SNMP host, specifying [2-510](#)
- SNMP informs, enabling the sending of [2-506](#)
- snmp mib rep trap-rate command [2-505](#)
- snmp-server enable traps command [2-506](#)
- snmp-server host command [2-510](#)
- snmp trap mac-notification command [2-514](#)

SNMP traps

- enabling MAC address notification trap [2-514](#)
- enabling the MAC address notification feature [2-201](#)
- enabling the sending of [2-506](#)

software images

- deleting [2-61](#)
- downloading [2-7](#)
- upgrading [2-7](#)
- uploading [2-13](#)

software version, displaying [2-490](#)source ports, MVR [2-238](#)

SPAN

- configuring [2-231](#)
- debug messages, display [B-17](#)
- displaying [2-448](#)
- filter SPAN traffic [2-231](#)
- sessions
 - add interfaces to [2-231](#)
 - displaying [2-448](#)
 - start new [2-231](#)

spanning-tree bpdudfilter command [2-516, 2-518](#)spanning-tree bpduguard command [2-520](#)spanning-tree cost command [2-522](#)spanning-tree etherchannel command [2-524](#)spanning-tree extend system-id command [2-526](#)spanning-tree guard command [2-528](#)spanning-tree link-type command [2-530](#)spanning-tree loopguard default command [2-532](#)spanning-tree mode command [2-534](#)spanning-tree mst configuration command [2-536](#)spanning-tree mst cost command [2-538](#)spanning-tree mst forward-time command [2-540](#)spanning-tree mst hello-time command [2-541](#)spanning-tree mst max-age command [2-543](#)spanning-tree mst max-hops command [2-545](#)spanning-tree mst port-priority command [2-547](#)spanning-tree mst pre-standard command [2-549](#)spanning-tree mst priority command [2-550](#)spanning-tree mst root command [2-552](#)

spanning-tree portfast (global configuration)

command [2-556](#)

spanning-tree portfast (interface configuration)

command [2-559](#)spanning-tree port-priority command [2-554](#)

Spanning Tree Protocol

See STP

spanning-tree vlan command [2-561](#)speed command [2-564](#)SSH, configuring version [2-171](#)static-access ports, configuring [2-571](#)statistics, Ethernet group [2-295](#)sticky learning, enabling [2-586](#)storm-control command [2-566](#)

STP

counters, clearing [2-51](#)

debug messages, display

MSTP [B-69](#)optimized BPDUs handling [B-68](#)spanning-tree activity [B-65](#)switch shim [B-71](#)transmitted and received BPDUs [B-67](#)enabling on ENIs [2-516](#)enabling protocol tunneling for [2-174](#)EtherChannel misconfiguration [2-524](#)extended system ID [2-526](#)path cost [2-522](#)protocol modes [2-534](#)

root port

loop guard [2-528](#)preventing from becoming designated [2-528](#)restricting which can be root [2-528](#)root guard [2-528](#)

STP (continued)

- root switch
 - affects of extended system ID [2-526, 2-562](#)
 - hello-time [2-561](#)
 - interval between BPDU messages [2-561](#)
 - interval between hello BPDU messages [2-561](#)
 - max-age [2-561](#)
 - port priority for selection of [2-554](#)
 - primary or secondary [2-561](#)
 - switch priority [2-561](#)
- state changes
 - blocking to forwarding state [2-559](#)
 - enabling BPDU filtering [2-518, 2-556](#)
 - enabling BPDU guard [2-520, 2-556](#)
 - enabling Port Fast [2-556, 2-559](#)
 - enabling timer to recover from error state [2-90](#)
 - forward-delay time [2-561](#)
 - length of listening and learning states [2-561](#)
 - shutting down Port Fast-enabled ports [2-556](#)
- state information display [2-476](#)
- VLAN options [2-550, 2-561](#)
- SVIs, creating [2-112](#)
- Switched Port Analyzer
 - See SPAN
- switching characteristics
 - modifying [2-569](#)
 - returning to interfaces [2-569](#)
- switchport access command [2-571](#)
- switchport backup interface command [2-573](#)
- switchport block command [2-577](#)
- switchport command [2-569](#)
- switchport host command [2-579](#)
- switchport mode command [2-580](#)
- switchport mode private-vlan command [2-583](#)
- switchport port-security aging command [2-590](#)
- switchport port-security command [2-586](#)
- switchport private-vlan command [2-592](#)
- switchport protected command [2-594](#)
- switchports, displaying [2-370](#)

- switchport trunk command [2-596](#)
- system env temperature threshold yellow command [2-598](#)
- system message logging, save message to flash [2-190](#)
- system mtu command [2-600](#)
- system resource templates [2-296](#)

T

- table-map command [2-603](#)
- table-map configuration mode [2-603](#)
- table maps
 - configuring [2-603](#)
 - displaying [2-485](#)
 - QoS [2-603](#)
- tar files, creating, listing, and extracting [2-10](#)
- TDR, running [2-605](#)
- temperature information, displaying [2-348](#)
- templates, system resources [2-296](#)
- test cable-diagnostics tdr command [2-605](#)
- traceroute mac command [2-607](#)
- traceroute mac ip command [2-610](#)
- traffic shaping, QoS [2-318](#)
- trunking, VLAN mode [2-580](#)
- trunk mode [2-580](#)
- trunk ports [2-580](#)
- tunnel ports, Layer 2 protocol, displaying [2-414](#)
- type (boot loader) command [A-22](#)

U**UDLD**

- aggressive mode [2-612, 2-614](#)
- debug messages, display [B-77](#)
- enable globally [2-612](#)
- enable per interface [2-614](#)
- error recovery timer [2-90](#)
- message timer [2-612](#)
- normal mode [2-612, 2-614](#)
- reset a shutdown interface [2-616](#)
- status [2-487](#)

udd command [2-612](#)
 udd port command [2-614](#)
 udd reset command [2-616](#)
 UNI
 bundling and multiplexing [2-101](#)
 Ethernet [2-101](#)
 unicast storm control [2-566](#)
 uni count command [2-617](#)
 UniDirectional Link Detection
 See UDLD
 UNI ID, Ethernet [2-103](#)
 uni-vlan command [2-619](#)
 unknown multicast traffic, preventing [2-577](#)
 unknown unicast traffic, preventing [2-577](#)
 unset (boot loader) command [A-23](#)
 upgrading
 software images [2-7](#)
 monitoring status of [2-323](#)
 user EXEC mode [1-2](#)
 user network interface [2-266](#)

V

version (boot loader) command [A-25](#)
 vlan access-map command [2-624](#)
 VLAN access map configuration mode [2-624](#)
 VLAN access maps
 actions [2-5](#)
 displaying [2-497](#)
 vlan command [2-621](#)
 VLAN configuration mode
 commands [2-621](#)
 description [1-4](#)
 entering [2-621](#)
 summary [1-2](#)
 vlan dot1q tag native command [2-626](#)
 vlan filter command [2-628](#)
 VLAN filters, displaying [2-498](#)
 VLAN ID range [2-621](#)

VLAN maps
 applying [2-628](#)
 creating [2-624](#)
 defining [2-214](#)
 displaying [2-497](#)
 VLAN Query Protocol
 See VQP
 VLANs
 adding [2-621](#)
 configuring [2-621](#)
 debug messages, display
 activation of [B-75](#)
 VLAN IOS file system error tests [B-74](#)
 VLAN manager activity [B-73](#)
 displaying configurations [2-492](#)
 extended-range [2-621](#)
 MAC addresses
 displaying [2-446](#)
 number of [2-433](#)
 normal-range [2-621](#)
 private [2-583](#)
 configuring [2-273](#)
 displaying [2-492](#)
 See also private VLANs
 restarting [2-502](#)
 saving the configuration [2-621](#)
 shutting down [2-502](#)
 suspending [2-502](#)
 VMPS
 configuring servers [2-633](#)
 displaying [2-499](#)
 error recovery timer [2-90](#)
 reconfirming dynamic VLAN assignments [2-630](#)
 vmps reconfirm (global configuration) command [2-631](#)
 vmps reconfirm (privileged EXEC) command [2-630](#)
 vmps retry command [2-632](#)
 vmps server command [2-633](#)

VQP

and dynamic-access ports [2-572](#)

clearing client statistics [2-54](#)

displaying information [2-499](#)

per-server retry count [2-632](#)

reconfirmation interval [2-631](#)

reconfirming dynamic VLAN assignments [2-630](#)

VTP, enabling tunneling for [2-174](#)

W

Weighted Tail Drop

See WTD

WTD, queue-limit command [2-278](#)

