



INDEX

A

aaa accounting dot1x command [2-1](#)
aaa authentication dot1x command [2-3](#)
AAA methods [2-3](#)
access control entries
 See ACEs
access control lists
 See ACLs
access groups
 IP [2-133](#)
 MAC, displaying [2-482](#)
 matching for QoS classification [2-249](#)
access list, IPv6 [2-196](#)
access mode [2-640](#)
access ports [2-640](#)
ACEs [2-77, 2-288](#)
ACLs
 as match criteria for QoS classes [2-249](#)
 deny [2-75](#)
 displaying [2-364](#)
 for non-IP protocols [2-227](#)
 IP [2-133](#)
 on Layer 2 interfaces [2-133](#)
 permit [2-286](#)
action command [2-5](#)
address aliasing [2-269](#)
aggregate policers
 applying [2-299](#)
 creating [2-295](#)
 displaying [2-517](#)
 QoS [2-297](#)
aggregate-port learner [2-275](#)

alarm-contact command [2-7](#)
alarm-contact status, displaying [2-396](#)
allowed VLANs [2-656](#)
archive download-sw command [2-9](#)
archive tar command [2-12](#)
archive upload-sw command [2-15](#)
arp (boot loader) command [A-2](#)
arp access-list command [2-17](#)
attaching policy maps to interfaces [2-347](#)
authorization state of controlled port [2-90](#)
autonegotiation of duplex mode [2-101](#)

B

backup interfaces
 configuring [2-633](#)
 displaying [2-418](#)
bandwidth, configuring for QoS [2-19](#)
bandwidth command [2-19](#)
boot (boot loader) command [A-3](#)
boot config-file command [2-22](#)
boot enable-break command [2-23](#)
boot helper command [2-24](#)
boot helper-config file command [2-25](#)
booting
 Cisco IOS image [2-28](#)
 displaying environment variables [2-369](#)
 interrupting [2-23](#)
 manually [2-26](#)

boot loader

accessing [A-1](#)

booting

Cisco IOS image [A-3](#)helper image [2-24](#)

directories

creating [A-18](#)displaying a list of [A-8](#)removing [A-22](#)

displaying

available commands [A-13](#)memory heap utilization [A-14](#)version [A-29](#)

environment variables

described [A-23](#)displaying settings [A-23](#)location of [A-24](#)setting [A-23](#)unsetting [A-27](#)

files

copying [A-6](#)deleting [A-7](#)displaying a list of [A-8](#)displaying the contents of [A-5, A-19, A-26](#)renaming [A-20](#)

file system

formatting [A-11](#)initializing flash [A-10](#)running a consistency check [A-12](#)prompt [A-1](#)resetting the system [A-21](#)boot manual command [2-26](#)boot private-config-file command [2-27](#)boot system command [2-28](#)BPDU filtering, for spanning tree [2-578, 2-616](#)BPDU guard, for spanning tree [2-580, 2-616](#)broadcast storm control [2-626](#)bundling characteristics, UNI [2-109](#)burst bytes, in QoS policers [2-290, 2-291, 2-295](#)**C**cat (boot loader) command [A-5](#)CBWFQ, configuring [2-19](#)CDP, enabling protocol tunneling for [2-207](#)CFM [2-274](#)CFM as OAM protocol [2-274](#)channel-group command [2-29](#)channel-protocol command [2-33](#)child policy maps [2-349](#)class-based traffic shaping [2-362](#)

class-based weighted fair queuing

See CBWFQ

class command [2-35](#)class-map command [2-37](#)class-map configuration mode [2-37](#)

class maps

creating [2-37](#)defining the match criteria [2-250](#)displaying [2-373](#)matching in [2-37](#)

class of service

See CoS

clear ip arp inspection log command [2-39](#)clear ip arp inspection statistics command [2-40](#)clear ipc command [2-43](#)clear ipv6 dhcp conflict command [2-44](#)clear l2protocol-tunnel counters command [2-45](#)clear lacp command [2-46](#)clear logging onboard command [2-47](#)clear mac address-table command [2-48, 2-49](#)clear pagp command [2-50, 2-54](#)clear policer cpu uni-eni counters command [2-51](#)clear port-security command [2-52](#)clear spanning-tree counters command [2-55](#)clear spanning-tree detected-protocols command [2-56](#)clear vmps statistics command [2-58](#)command modes defined [1-1](#)committed information rate in QoS policers [2-289, 2-295](#)

- configuration files
 - password recovery disable considerations [A-1](#)
 - specifying the name [2-22, 2-27](#)
- configuring multiple interfaces [2-129](#)
- conform-action command [2-59](#)
- control-plane policer [2-51](#)
- control-plane policer information, displaying [2-518](#)
- control-plane security [2-301](#)
- control plane statistics, clearing [2-51](#)
- copy (boot loader) command [A-6](#)
- copy logging onboard module command [2-61](#)
- CoS
 - as match criteria for QoS groups [2-250](#)
 - for QoS classification [2-351](#)
 - setting value in policy maps [2-351](#)
- CoS value, assigning to Layer 2 protocol packets [2-210](#)
- CPU ASIC statistics, displaying [2-374](#)
- CPU protection policers, displaying [C-26](#)
- cpu traffic qos [2-63](#)

D

- DC power supply [2-310](#)
- debug backup command [B-2](#)
- debug dot1x command [B-3](#)
- debug etherchannel command [B-4](#)
- debug interface command [B-9](#)
- debug ip dhcp snooping command [B-7](#)
- debug ip igmp filter command [B-10](#)
- debug ip igmp max-groups command [B-11](#)
- debug ip igmp snooping command [B-12](#)
- debug ip verify source packet command [B-8](#)
- debug lacp command [B-13](#)
- debug mac-notification command [B-14](#)
- debug matm command [B-15](#)
- debug matm move update command [B-16](#)
- debug monitor command [B-17](#)
- debug mvrdbg command [B-18](#)
- debug nvram command [B-19](#)

- debug pagp command [B-20](#)
- debug platform acl command [B-21](#)
- debug platform backup interface command [B-23](#)
- debug platform cfm command [B-22](#)
- debug platform cpu-queues command [B-24](#)
- debug platform dot1x command [B-26](#)
- debug platform etherchannel command [B-27](#)
- debug platform forw-tcam command [B-28](#)
- debug platform ip arp inspection command [B-29](#)
- debug platform ipc command [B-38](#)
- debug platform ip dhcp command [B-30](#)
- debug platform ip igmp snooping command [B-31](#)
- debug platform ip multicast command [B-33](#)
- debug platform ip source-guard command [B-35](#)
- debug platform led command [B-39](#)
- debug platform matm command [B-40](#)
- debug platform messaging application command [B-41](#)
- debug platform phy command [B-42](#)
- debug platform pm command [B-44](#)
- debug platform policer cpu uni-eni command [B-46](#)
- debug platform port-asic command [B-47](#)
- debug platform port-security command [B-48](#)
- debug platform qos-acl-tcam command [B-49](#)
- debug platform qos-manager command [B-50](#)
- debug platform remote-commands command [B-51](#)
- debug platform rep command [B-52](#)
- debug platform resource-manager command [B-53](#)
- debug platform snmp command [B-54](#)
- debug platform span command [B-55](#)
- debug platform supervisor-asic command [B-56](#)
- debug platform sw-bridge command [B-57](#)
- debug platform tcam command [B-58](#)
- debug platform udd command [B-60](#)
- debug platform vlan command [B-61](#)
- debug pm command [B-62](#)
- debug port-security command [B-64](#)
- debug qos-manager command [B-65](#)
- debug spanning-tree bpdu command [B-68](#)
- debug spanning-tree bpdu-opt command [B-69](#)

- debug spanning-tree command [B-66](#)
- debug spanning-tree mstp command [B-70](#)
- debug spanning-tree switch command [B-72](#)
- debug sw-vlan command [B-74](#)
- debug sw-vlan ifs command [B-75](#)
- debug sw-vlan notification command [B-76](#)
- debug udd command [B-78](#)
- debug vqpc command [B-80](#)
- default policer configuration
 - NNIs [C-29](#)
 - UNIs [C-27](#)
- define interface-range command [2-65](#)
- delete (boot loader) command [A-7](#)
- delete command [2-67](#)
- deny (ARP access-list configuration) command [2-68](#)
- deny (IPv6) command [2-70](#)
- deny command [2-75](#)
- detect mechanism, causes [2-102](#)
- DHCP snooping
 - accepting untrusted packets from edge switch [2-157](#)
 - enabling
 - on a VLAN [2-163](#)
 - option 82 [2-155, 2-157](#)
 - trust on an interface [2-161](#)
 - error recovery timer [2-104](#)
 - rate limiting [2-160](#)
- DHCP snooping binding database
 - binding file, configuring [2-153](#)
 - bindings
 - adding [2-151](#)
 - deleting [2-151](#)
 - displaying [2-439](#)
 - clearing database agent statistics [2-41](#)
 - database agent, configuring [2-153](#)
 - displaying
 - binding entries [2-439](#)
 - database agent status [2-441, 2-443](#)
 - renewing [2-325](#)
- diagnostic monitor command [2-78](#)
- diagnostic schedule test command [2-80](#)
- diagnostic start test command [2-82](#)
- differentiated service code point
 - See DSCP
- Digital Optical Monitoring
 - see DoM
- dir (boot loader) command [A-8](#)
- directories, deleting [2-67](#)
- DoM
 - displaying supported transceivers [2-430](#)
- domains, CFM [2-274](#)
- dot1x default command [2-84](#)
- dot1x host-mode command [2-85](#)
- dot1x initialize command [2-87](#)
- dot1x max-req command [2-88, 2-89](#)
- dot1x port-control command [2-90](#)
- dot1x re-authenticate command [2-92](#)
- dot1x reauthentication command [2-93](#)
- dot1x system-auth-control command [2-94](#)
- dot1x test eapol-capable command [2-95](#)
- dot1x test timeout command [2-96](#)
- dot1x timeout command [2-97](#)
- dot1x violation-mode command [2-99](#)
- dropping packets, with ACL matches [2-5](#)
- drop threshold, Layer 2 protocol tunneling [2-207](#)
- DSCP
 - as match criteria for QoS groups [2-251, 2-257](#)
 - for QoS traffic marking [2-353](#)
 - setting in policy maps [2-353](#)
- dual IPv4 and IPv6 templates [2-281](#)
- dual-purpose uplink ports, selecting the type [2-262](#)
- duplex command [2-100](#)
- dynamic-access ports
 - configuring [2-631](#)
 - restrictions [2-632](#)

dynamic ARP inspection

ARP ACLs

apply to a VLAN [2-138](#)define [2-17](#)deny packets [2-68](#)display [2-368](#)permit packets [2-279](#)

clear

log buffer [2-39](#)statistics [2-40](#)

display

ARP ACLs [2-368](#)configuration and operating state [2-434](#)log buffer [2-434](#)statistics [2-434](#)trust state and rate limit [2-434](#)enable per VLAN [2-147](#)error detection for [2-102](#)error recovery timer [2-104](#)

log buffer

clear [2-39](#)configure [2-142](#)display [2-434](#)rate-limit incoming ARP packets [2-140](#)

statistics

clear [2-40](#)display [2-434](#)trusted interface state [2-144](#)type of packet logged [2-148](#)validation checks [2-145](#)

Dynamic Host Configuration Protocol (DHCP)

See DHCP snooping

E-LMI

enabling [2-107](#)mapping [2-109](#)environment variables, displaying [2-369](#)errdisable detect cause command [2-102](#)errdisable recovery command [2-104](#)error conditions, displaying [2-400](#)error disable detection [2-102](#)error-disabled interfaces, displaying [2-418](#)

EtherChannel

assigning Ethernet interface to channel group [2-29](#)creating port-channel logical interface [2-127](#)debug EtherChannel/PAgP, display [B-4](#)debug platform-specific events, display [B-27](#)displaying [2-404](#)

enabling Layer 2 protocol tunneling for

LACP [2-208](#)PAgP [2-208](#)UDLD [2-208](#)interface information, displaying [2-418](#)

LACP

clearing channel-group information [2-46](#)debug messages, display [B-13](#)displaying [2-469](#)modes [2-29](#)port priority for hot-standby ports [2-211](#)restricting a protocol [2-33](#)system priority [2-213](#)load-distribution methods [2-306](#)

E

EAP-request/identity frame

maximum number to send [2-89](#)response time before retransmitting [2-97](#)

EtherChannel (continued)

PAgP

- aggregate-port learner [2-275](#)
- clearing channel-group information [2-50](#)
- debug messages, display [B-20](#)
- displaying [2-513](#)
- error detection for [2-102](#)
- error recovery timer [2-104](#)
- learn method [2-275](#)
- modes [2-29](#)
- physical-port learner [2-275](#)
- priority of interface for transmitted traffic [2-277](#)

ethernet lmi ce command [2-107](#)

Ethernet controller, internal register display [2-376](#)

ethernet evc command [2-106](#)

ethernet lim global command [2-107](#)

ethernet lmi ce-vlan map command [2-109, 2-116](#)

ethernet lmi command [2-107](#)

Ethernet Local Management Interface

See E-LMI

ethernet loopback interface configuration command [2-111](#)

ethernet loopback privileged EXEC command [2-114](#)

Ethernet service

- debugging [B-5](#)
- displaying [2-409](#)

Ethernet service instance [2-343](#)

Ethernet service interfaces [2-412](#)

Ethernet statistics, collecting [2-339](#)

Ethernet UNI configuration [2-118](#)

ethernet uni id command [2-120](#)

Ethernet virtual connections

See EVCs

EVC configuration mode [2-106](#)

EVCs [2-106](#)

- and VLANs [2-118](#)
- service instances [2-343](#)
- UNI counts [2-678](#)

EVC service

- point-to-multipoint [2-678](#)
- point-to-point [2-678](#)

exceed-action command [2-121](#)

extended-range VLANs

- and allowed VLAN list [2-656](#)
- configuring [2-684](#)

extended system ID for STP [2-586](#)

external alarms, configuring [2-7](#)

F

failure logging data

- clearing [2-47](#)
- copying [2-61](#)

fan information, displaying [2-396](#)

files, deleting [2-67](#)

flash_init (boot loader) command [A-10](#)

Flex Links

- configuring [2-633](#)
- configuring preferred VLAN [2-635](#)
- displaying [2-418](#)

flowcontrol command [2-123](#)

format (boot loader) command [A-11](#)

forwarding packets, with ACL matches [2-5](#)

forwarding results, display [C-8](#)

frame forwarding information, displaying [C-8](#)

front-end controller counter and status information [C-10](#)

fsck (boot loader) command [A-12](#)

G

global configuration mode [1-2, 1-3](#)

H

hardware ACL statistics [2-364](#)
 health-monitoring diagnostic testing [2-78](#)
 help (boot loader) command [A-13](#)
 host connection, port configuration [2-639](#)
 host ports, private VLANs [2-643](#)
 hw-module module logging onboard command [2-125](#)

I

IEEE 802.1ag Connectivity Fault Management
 See CFM
 IEEE 802.1Q trunk ports and native VLANs [2-689](#)
 IEEE 802.1Q tunnel ports
 configuring [2-640](#)
 displaying [2-392](#)
 limitations [2-641](#)
 IEEE 802.1x
 and switchport modes [2-641](#)
 violation error recovery [2-104](#)
 See also port-based authentication
 IGMP filters
 applying [2-166](#)
 debug messages, display [B-10](#)
 IGMP groups, setting maximum [2-168](#)
 IGMP maximum groups, debugging [B-11](#)
 IGMP profiles
 creating [2-170](#)
 displaying [2-446](#)
 IGMP snooping
 adding ports as a static member of a group [2-185](#)
 displaying [2-447, 2-451, 2-453](#)
 enabling [2-172](#)
 enabling the configurable-leave timer [2-174](#)
 enabling the Immediate-Leave feature [2-182](#)
 flooding query count [2-180](#)
 interface topology change notification behavior [2-181](#)
 multicast table [2-449](#)

IGMP snooping (continued)
 querier [2-176](#)
 query solicitation [2-180](#)
 report suppression [2-178](#)
 switch topology change notification behavior [2-180](#)
 images
 See software images
 Immediate-Leave feature, MVR [2-271](#)
 immediate-leave processing [2-182](#)
 input policy maps
 and ACL classification [2-249](#)
 and aggregate policers [2-297](#)
 commands not supported in [2-304](#)
 configuration guidelines [2-304](#)
 interface command [2-131](#)
 interface configuration mode [1-2, 1-4](#)
 interface port-channel command [2-127](#)
 interface range command [2-129](#)
 interface-range macros [2-63, 2-65](#)
 interfaces
 assigning Ethernet interface to channel group [2-29](#)
 configuring [2-100](#)
 configuring multiple [2-129](#)
 creating port-channel logical [2-127](#)
 debug messages, display [B-9](#)
 disabling [2-563](#)
 displaying the MAC address table [2-494](#)
 restarting [2-563](#)
 interface speed, configuring [2-624](#)
 internal registers, displaying [2-376, 2-383, 2-387](#)
 Internet Group Management Protocol
 See IGMP
 invalid GBIC
 error detection for [2-102](#)
 error recovery timer [2-104](#)
 ip address command [2-136](#)
 IP addresses, setting [2-136](#)
 IP address matching [2-247](#)
 ip arp inspection filter vlan command [2-138](#)

ip arp inspection limit command [2-140](#)
 ip arp inspection log-buffer command [2-142](#)
 ip arp inspection trust command [2-144](#)
 ip arp inspection validate command [2-145](#)
 ip arp inspection vlan command [2-147](#)
 ip arp inspection vlan logging command [2-148](#)
 IP DHCP snooping
 See DHCP snooping
 ip dhcp snooping binding command [2-151](#)
 ip dhcp snooping command [2-150](#)
 ip dhcp snooping database command [2-153](#)
 ip dhcp snooping information option allow-untrusted command [2-157](#)
 ip dhcp snooping information option command [2-155](#)
 ip dhcp snooping information option format remote-id command [2-159](#)
 ip dhcp snooping limit rate command [2-160](#)
 ip dhcp snooping trust command [2-161](#)
 ip dhcp snooping verify command [2-162](#)
 ip dhcp snooping vlan command [2-163](#)
 ip dhcp snooping vlan information option format-type circuit-id string command [2-164](#)
 ip igmp filter command [2-166](#)
 ip igmp max-groups command [2-168](#), [2-191](#), [2-193](#)
 ip igmp profile command [2-170](#)
 ip igmp snooping command [2-172](#)
 ip igmp snooping last-member-query-interval command [2-174](#)
 ip igmp snooping querier command [2-176](#)
 ip igmp snooping report-suppression command [2-178](#)
 ip igmp snooping tcn command [2-180](#)
 ip igmp snooping tcn flood command [2-181](#)
 ip igmp snooping vlan immediate-leave command [2-182](#)
 ip igmp snooping vlan mrouter command [2-183](#)
 ip igmp snooping vlan static command [2-185](#)
 IP multicast addresses [2-268](#)
 IP precedence, as match criteria for QoS groups [2-253](#)
 ip source binding command [2-187](#)

IP source guard
 disabling [2-195](#)
 displaying
 binding entries [2-455](#)
 configuration [2-456](#)
 enabling [2-195](#)
 static IP source bindings [2-187](#)
 IP source guard, displaying dynamic binding entries [2-439](#)
 ip ssh command [2-189](#)
 IPv6 access list, deny conditions [2-70](#)
 ipv6 access-list command [2-196](#)
 ipv6 address dhcp command [2-198](#)
 ipv6 dhcp client request vendor command [2-199](#)
 ipv6 dhcp ping packets command [2-200](#)
 ipv6 dhcp pool command [2-201](#)
 ipv6 dhcp server command [2-203](#)
 IPv6 SDM template [2-340](#)
 ipv6 traffic-filter command [2-205](#)
 ip verify source command [2-195](#)

J

jumbo frames
 See MTU

L

l2protocol-tunnel command [2-207](#)
 l2protocol-tunnel cos command [2-210](#)
 LACP
 See EtherChannel
 lacp port-priority command [2-211](#)
 lacp system-priority command [2-213](#)
 Layer 2 mode, enabling [2-629](#)
 Layer 2 protocol ports, displaying [2-467](#)
 Layer 2 protocol-tunnel
 error detection for [2-102](#)
 error recovery timer [2-104](#)

- Layer 2 protocol tunnel counters [2-45](#)
- Layer 2 protocol tunneling error recovery [2-208](#)
- Layer 2 traceroute
 - IP addresses [2-671](#)
 - MAC addresses [2-668](#)
- Layer 3 mode, enabling [2-629](#)
- line configuration mode [1-2, 1-4](#)
- Link Aggregation Control Protocol
 - See EtherChannel
- link flap
 - error detection for [2-102](#)
 - error recovery timer [2-104](#)
- link state group command [2-215](#)
- link state track command [2-217](#)
- load-distribution methods for EtherChannel [2-306](#)
- location (global configuration) command [2-218](#)
- location (interface configuration) command [2-220](#)
- logging event command [2-222](#)
- logging file command [2-223](#)
- logical interface [2-127](#)
- loopback error
 - detection for [2-102](#)
 - recovery timer [2-104](#)
- loop guard, for spanning tree [2-588, 2-592](#)

M

- mac access-group command [2-225](#)
- MAC access-groups, displaying [2-482](#)
- MAC access list configuration mode [2-227](#)
- mac access-list extended command [2-227](#)
- MAC access lists [2-75](#)

- MAC addresses
 - disabling MAC address learning per VLAN [2-230](#)
 - displaying
 - aging time [2-488](#)
 - all [2-486](#)
 - dynamic [2-492](#)
 - MAC address-table move updates [2-497](#)
 - notification settings [2-496, 2-499](#)
 - number of addresses in a VLAN [2-490](#)
 - per interface [2-494](#)
 - per VLAN [2-503](#)
 - static [2-501](#)
 - static and dynamic entries [2-484](#)
 - dynamic
 - aging time [2-229](#)
 - deleting [2-48](#)
 - displaying [2-492](#)
 - enabling MAC address notification [2-234](#)
 - enabling MAC address-table move update [2-232](#)
 - matching [2-247](#)
 - static
 - adding and removing [2-236](#)
 - displaying [2-501](#)
 - dropping on an interface [2-237](#)
 - tables [2-486](#)
- MAC address notification, debugging [B-14](#)
- mac address-table aging-time [2-225, 2-247](#)
- mac address-table aging-time command [2-229](#)
- mac address-table learning command [2-230](#)
- mac address-table move update command [2-232](#)
- mac address-table notification command [2-234](#)
- mac address-table static command [2-236](#)
- mac address-table static drop command [2-237](#)
- macro description command [2-241](#)
- macro global command [2-242](#)
- macro global description command [2-244](#)
- macro name command [2-245](#)

macros

- adding a description [2-241](#)
- adding a global description [2-244](#)
- applying [2-242](#)
- creating [2-245](#)
- displaying [2-515](#)
- interface range [2-65, 2-129](#)
- specifying parameter values [2-242](#)
- tracing [2-242](#)

maintenance end points [2-678](#)

mapping tables, QoS [2-664](#)

maps

class

- creating [2-37](#)

VLAN

- creating [2-687](#)
- defining [2-247](#)
- displaying [2-557](#)

match access-group command [2-249](#)

match cos command [2-250](#)

match ip dscp command [2-251](#)

match ip precedence command [2-253](#)

match qos-group command [2-255](#)

match vlan command [2-257](#)

maximum transmission unit

See MTU

mdix auto command [2-260](#)

ME 3400EG-2CS switch policers [C-26](#)

ME 3400E-24TS switch policers [C-26, C-27](#)

ME 3400EG-12CS switch policers [C-26](#)

media-type command [2-262](#)

memory (boot loader) command [A-14](#)

mgmt_clr (boot loader) command [A-15](#)

mgmt_init (boot loader) command [A-16, A-17](#)

mkdir (boot loader) command [A-18](#)

mode, MVR [2-268](#)

modes, commands [1-1](#)

monitor session command [2-264](#)

more (boot loader) command [A-19](#)

MSTP

displaying [2-537](#)

interoperability [2-56](#)

link type [2-590](#)

MST region

- aborting changes [2-596](#)
- applying changes [2-596](#)
- configuration name [2-596](#)
- configuration revision number [2-597](#)
- current or pending display [2-597](#)
- displaying [2-537](#)
- MST configuration mode [2-596](#)
- VLANs-to-instance mapping [2-596](#)

path cost [2-598](#)

protocol mode [2-594](#)

restart protocol migration process [2-56](#)

root port

- loop guard [2-588](#)
- preventing from becoming designated [2-588](#)
- restricting which can be root [2-588](#)
- root guard [2-588](#)

root switch

- affects of extended system ID [2-586](#)
- hello-time [2-601, 2-612](#)
- interval between BDPU messages [2-603](#)
- interval between hello BPDU messages [2-601, 2-612](#)
- max-age [2-603](#)
- maximum hop count before discarding BPDU [2-605](#)
- port priority for selection of [2-607](#)
- primary or secondary [2-612](#)
- switch priority [2-610](#)

MSTP (continued)

state changes

- blocking to forwarding state [2-619](#)
- enabling BPDU filtering [2-578, 2-616](#)
- enabling BPDU guard [2-580, 2-616](#)
- enabling Port Fast [2-616, 2-619](#)
- forward-delay time [2-600](#)
- length of listening and learning states [2-600](#)
- rapid transition to forwarding [2-590](#)
- shutting down Port Fast-enabled ports [2-616](#)

state information display [2-536](#)

MTU

- configuring size [2-662](#)
- displaying global setting [2-544](#)

multicast group address, MVR [2-271](#)multicast groups, MVR [2-269](#)multicast router learning method [2-183](#)multicast router ports, configuring [2-183](#)multicast storm control [2-626](#)multicast VLAN, MVR [2-268](#)

multicast VLAN registration

See MVR

multiple hosts on authorized port [2-85](#)

Multiple Spanning Tree Protocol

See MSTP

multiplexing, UNI [2-118](#)

MVR

- and address aliasing [2-269](#)
- configuring [2-268](#)
- configuring interfaces [2-271](#)
- debug messages, display [B-18](#)
- displaying [2-507](#)
- displaying interface information [2-509](#)
- members, displaying [2-511](#)
- mvr (global configuration) command [2-268](#)
- mvr (interface configuration) command [2-271](#)
- mvr vlan group command [2-272](#)

Nnative VLANs [2-656](#)native VLAN tagging [2-689](#)network node interface [2-308](#)nonegotiate, speed [2-624, 2-625](#)

non-IP protocols

denying [2-75](#)forwarding [2-286](#)non-IP traffic access lists [2-227](#)

non-IP traffic forwarding

denying [2-75](#)permitting [2-286](#)normal-range VLANs [2-684](#)no vlan command [2-684](#)

OOAM PDUs [2-116](#)OAM protocol [2-274](#)oam protocol cfm svlan command [2-274](#)on-board failure logging, displaying [2-478](#)on-board failure logging, enabling [2-125](#)

online diagnostics

enabling

scheduling [2-80](#)

global configuration mode

clearing test-based testing schedule [2-80](#)setting test-based testing [2-80](#)setting up test-based testing [2-80](#)removing scheduling [2-80](#)

scheduled switchover

disabling [2-80](#)enabling [2-80](#)setting test interval [2-80](#)starting testing [2-82](#)online diagnostic tests, displaying results [2-388](#)online diagnostic tests, starting [2-82](#)

operation, administration, and maintenance protocol

See OAM

output policy maps

and QoS group classification [2-255](#)

and traffic shaping [2-362](#)

commands not supported in [2-304](#)

configuration guidelines [2-304](#)

priority in [2-313](#)

queue limit in [2-320](#)

P

PAGP

See EtherChannel

pagp learn-method command [2-275](#)

pagp port-priority command [2-277](#)

parent policy maps [2-349](#)

password-recovery mechanism, enabling and disabling [2-345](#)

permit (ARP access-list configuration) command [2-279](#)

permit (IPv6) command [2-281](#)

permit command [2-286](#)

per-VLAN spanning-tree plus

See STP

physical-port learner [2-275](#)

PID, displaying [2-433](#)

PIM-DVMRP, as multicast router learning method [2-183](#)

police

multiple conform actions for a class [2-59](#)

multiple exceed actions for a class [2-121](#)

multiple violate actions for a class [2-682](#)

with priority [2-289](#)

police aggregate command [2-299](#)

police command [2-289](#)

policer aggregate command [2-295](#)

policer configuration

default for NNIs [C-29](#)

default for UNIs [C-27](#)

policer cpu uni command [2-301](#)

policers

aggregate [2-295, 2-299](#)

for CPU protection [2-301](#)

individual [2-289](#)

policy-map class, configuring multiple actions [2-59, 2-121, 2-682](#)

policy-map class configuration mode [2-35](#)

policy-map class police configuration mode [2-59, 2-293](#)

policy-map command [2-303](#)

policy-map configuration mode [2-303](#)

policy maps

and CoS classification [2-250](#)

and DSCP classification [2-251](#)

and IP precedence classification [2-253](#)

and policing [2-292](#)

applying [2-347](#)

applying to an interface [2-304, 2-347, 2-359](#)

child [2-349](#)

creating [2-303](#)

displaying [2-521](#)

hierarchical [2-349](#)

parent [2-349](#)

policers

for a single class [2-289](#)

for multiple classes [2-295, 2-299, 2-301, 2-349](#)

setting priority [2-312](#)

setting QoS group identifier [2-357](#)

traffic classification, defining [2-35](#)

traffic marking

setting CoS values [2-351](#)

setting DSCP values [2-353](#)

setting IP precedence values [2-355](#)

Port Aggregation Protocol

See EtherChannel

port-based authentication

AAA method list [2-3](#)

configuring violation modes [2-99](#)

debug messages, display [B-3](#)

enabling 802.1x

- port-based authentication (continued)
 - globally [2-94](#)
 - per interface [2-90](#)
 - host modes [2-85](#)
 - IEEE 802.1x AAA accounting methods [2-1](#)
 - initialize an interface [2-87, 2-96](#)
 - manual control of authorization state [2-90](#)
 - multiple hosts on authorized port [2-85](#)
 - periodic re-authentication
 - enabling [2-93](#)
 - time between attempts [2-97](#)
 - quiet period between failed authentication exchanges [2-97](#)
 - re-authenticating 802.1x-enabled ports [2-92](#)
 - resetting configurable 802.1x parameters [2-84](#)
 - switch-to-authentication server retransmission time [2-97](#)
 - switch-to-client frame-retransmission number [2-88 to 2-89](#)
 - switch-to-client retransmission time [2-97](#)
 - test for IEEE 802.1x readiness [2-95](#)
- port-channel load-balance command [2-306](#)
- Port Fast, for spanning tree [2-619](#)
- port ranges, defining [2-47, 2-61, 2-63, 2-65](#)
- ports, debugging [B-62](#)
- ports, protected [2-654](#)
- port security
 - aging [2-650](#)
 - debug messages, display [B-64](#)
 - enabling [2-646](#)
 - violation error recovery [2-104](#)
- port shaping [2-363](#)
- port-type command [2-308](#)
- port types, MVR [2-271](#)
- power information, displaying [2-396](#)
- power-supply alarm indications, configuring [2-310](#)
- power-supply dual command [2-310](#)
- power-supply status, displaying [2-396](#)
- precedence
 - for QoS traffic marking [2-355](#)
 - setting in policy maps [2-355](#)
- priority command [2-312](#)
- priority queuing, QoS [2-312](#)
- priority with police, QoS [2-312](#)
- private-vlan command [2-315](#)
- private-vlan mapping command [2-318](#)
- private VLANs
 - association [2-652](#)
 - configuring [2-315](#)
 - configuring ports [2-643](#)
 - displaying [2-552](#)
 - host ports [2-643](#)
 - mapping
 - configuring [2-652](#)
 - displaying [2-418](#)
 - promiscuous ports [2-643](#)
- privileged EXEC mode [1-2, 1-3](#)
- product identification information, displaying [2-433](#)
- promiscuous ports, private VLANs [2-643](#)
- PVST+
 - See STP

Q

- QoS
 - aggregate policers
 - applying [2-299](#)
 - creating [2-295](#)
 - displaying [2-517](#)
 - class maps
 - creating [2-37](#)
 - defining the match criteria [2-250](#)
 - displaying [2-373](#)
 - conform actions, configuring [2-60](#)
 - displaying statistics for [2-521, C-35](#)
 - exceed actions, configuring [2-122](#)

QoS (continued)

policy maps

applying an aggregate policer [2-295, 2-299, 2-301, 2-349](#)

applying to an interface [2-347, 2-359](#)

creating [2-303](#)

defining policers [2-289](#)

displaying policy maps [2-521](#)

setting CoS values [2-351](#)

setting DSCP values [2-353](#)

setting IP precedence values [2-355](#)

setting QoS group identifier [2-357](#)

traffic classifications [2-35](#)

table maps

configuring [2-664](#)

displaying [2-545](#)

violate actions, configuring [2-683](#)

QoS groups

as match criteria [2-255](#)

for QoS traffic classification [2-357](#)

setting in policy maps [2-357](#)

QoS match criteria

ACLs [2-249](#)

CoS value [2-250](#)

DSCP value [2-251, 2-257](#)

precedence value [2-253](#)

QoS group number [2-255](#)

quality of service

See QoS

querytime, MVR [2-268](#)

queue-limit command [2-320](#)

R

rapid per-VLAN spanning-tree plus

See STP

rapid PVST+

See STP

re-authenticating 802.1x-enabled ports [2-92](#)

re-authentication

periodic [2-93](#)

time between attempts [2-97](#)

receiver ports, MVR [2-271](#)

receiving flow-control packets [2-123](#)

recovery mechanism

causes [2-104](#)

display [2-371, 2-398, 2-402](#)

timer interval [2-105](#)

remote-span command [2-323](#)

Remote Switched Port Analyzer

See RSPAN

rename (boot loader) command [A-20](#)

renew ip dhcp snooping database command [2-325](#)

rep admin vlan command [2-326](#)

rep block port command [2-327](#)

rep lsl-age-timer command [2-330](#)

rep preempt delay command [2-331](#)

rep preempt segment command [2-333](#)

rep segment command [2-334](#)

rep stcn command [2-337](#)

reset (boot loader) command [A-21](#)

resource templates, displaying [2-534](#)

rmdir (boot loader) command [A-22](#)

rmon collection stats command [2-339](#)

root guard, for spanning tree [2-588](#)

routed ports

IP addresses on [2-137](#)

number supported [2-137](#)

RSPAN

configuring [2-264](#)

displaying [2-505](#)

filter RSPAN traffic [2-264](#)

remote-span command [2-323](#)

sessions

add interfaces to [2-264](#)

displaying [2-505](#)

start new [2-264](#)

S

- scheduled switchover
 - disabling [2-80](#)
 - enabling [2-80](#)
- scheduling diagnostic tests [2-80](#)
- sdm prefer command [2-340](#)
- SDM templates
 - allowed resources [2-341](#)
 - displaying [2-534](#)
 - dual IPv4 and IPv6 [2-340](#)
- secure ports, limitations [2-648](#)
- sending flow-control packets [2-123](#)
- service instance command [2-343](#)
- service instances, displaying [2-410](#)
- service password-recovery command [2-345](#)
- service policy (policy-map class configuration) command [2-349](#)
- service-policy interface configuration command [2-347](#)
- service-policy policy-map class configuration command [2-349](#)
- set (boot loader) command [A-23](#)
- set cos command [2-351](#)
- set dscp command [2-353](#)
- set precedence command [2-355](#)
- set qos-group command [2-357](#)
- setup command [2-359](#)
- SFPs, displaying information about [2-433](#)
- shape average command [2-362](#)
- show access-lists command [2-364](#)
- show aggregate-policer command [2-545](#)
- show archive status command [2-367](#)
- show arp access-list command [2-368](#)
- show boot command [2-369](#)
- show class-map command [2-373](#)
- show controllers cpu-interface command [2-374](#)
- show controllers ethernet-controller command [2-376](#)
- show controllers team command [2-383](#)
- show controllers utilization command [2-385](#)
- show controller utilization command [2-385](#)
- show cpu traffic qos [2-387](#)
- show diagnostic command [2-388](#)
- show dot1q-tunnel command [2-392](#)
- show dot1x command [2-393](#)
- show env command [2-396](#)
- show errdisable detect command [2-398](#)
- show errdisable flap-values command [2-400](#)
- show errdisable recovery command [2-402](#)
- show etherchannel command [2-404](#)
- show ethernet loopback command [2-407](#)
- show ethernet service evc command [2-409](#)
- show ethernet service instance command [2-410](#)
- show ethernet service interface command [2-412](#)
- show flowcontrol command [2-414](#)
- show idprom command [2-416](#)
- show interface rep command [2-428](#)
- show interfaces command [2-418](#)
- show interfaces counters command [2-426](#)
- show interfaces rep command [2-428](#)
- show interface transceivers command [2-430](#)
- show inventory command [2-433](#)
- show ip arp inspection command [2-434](#)
- show ipc command [2-458](#)
- show ip dhcp snooping binding command [2-439](#)
- show ip dhcp snooping command [2-438](#)
- show ip dhcp snooping database command [2-441, 2-443](#)
- show ip igmp profile command [2-446](#)
- show ip igmp snooping command [2-447](#)
- show ip igmp snooping command querier detail [2-453](#)
- show ip igmp snooping groups command [2-449](#)
- show ip igmp snooping mrouter command [2-451](#)
- show ip igmp snooping querier command [2-453](#)
- show ip igmp snooping querier detail command [2-453](#)
- show ip source binding command [2-455](#)
- show ipv6 access-list command [2-462](#)
- show ipv6 dhcp conflict command [2-464](#)
- show ipv6 route updated [2-465](#)
- show ipv6 route updated command [2-465](#)

- show ip verify source command [2-456](#)
- show l2protocol-tunnel command [2-467](#)
- show lacp command [2-469](#)
- show link state group command [2-473](#)
- show location [2-475](#)
- show location command [2-475](#)
- show logging onboard command [2-478](#)
- show mac access-group command [2-482](#)
- show mac address-table address command [2-486](#)
- show mac address-table aging time command [2-488](#)
- show mac address-table command [2-484](#)
- show mac address-table count command [2-490](#)
- show mac address-table dynamic command [2-492](#)
- show mac address-table interface command [2-494](#)
- show mac address-table learning command [2-496](#)
- show mac address-table move update command [2-497](#)
- show mac address-table notification command [2-49, 2-499, B-16](#)
- show mac address-table static command [2-501](#)
- show mac address-table vlan command [2-503](#)
- show monitor command [2-505](#)
- show mvr command [2-507](#)
- show mvr interface command [2-509](#)
- show mvr members command [2-511](#)
- show pagp command [2-513](#)
- show parser macro command [2-515](#)
- show platform acl command [C-2](#)
- show platform backup interface command [C-3](#)
- show platform cfm command [C-4](#)
- show platform configuration command [C-5](#)
- show platform dl command [C-6](#)
- show platform etherchannel command [C-7](#)
- show platform forward command [C-8](#)
- show platform frontend-controller command [C-10](#)
- show platform igmp snooping command [C-11](#)
- show platform ipc trace command [C-16](#)
- show platform ip multicast command [C-13](#)
- show platform ip unicast command [C-14](#)
- show platform ipv6 unicast command [C-17](#)
- show platform l2pt dm command [C-19](#)
- show platform layer4op command [C-20, C-42](#)
- show platform mac-address-table command [C-21](#)
- show platform messaging command [C-22](#)
- show platform monitor command [C-23](#)
- show platform mvr table command [C-24](#)
- show platform pm command [C-25](#)
- show platform policer cpu command [C-26](#)
- show platform port-asic command [C-30](#)
- show platform port-security command [C-34](#)
- show platform qos command [C-35](#)
- show platform resource-manager command [C-38](#)
- show platform snmp counters command [C-40](#)
- show platform spanning-tree synchronization command [C-41](#)
- show platform stp-instance command [C-43](#)
- show platform tcam command [C-44](#)
- show platform vlan command [C-47](#)
- show platform vlan mapping command [C-48](#)
- show policer aggregate command [2-517](#)
- show policer cpu uni-eni command [2-518](#)
- show policy-map command [2-521](#)
- show policy-map interface output fields [2-524](#)
- show port security command [2-526](#)
- show port-type command [2-529](#)
- show rep topology command [2-531](#)
- show sdm prefer command [2-534](#)
- show spanning-tree command [2-536](#)
- show storm-control command [2-542](#)
- show system mtu command [2-544](#)
- show udd command [2-547](#)
- show version command [2-550](#)
- show vlan access-map command [2-557](#)
- show vlan command [2-552](#)
- show vlan command, fields [2-554](#)
- show vlan filter command [2-558](#)
- show vlan mapping command [2-559](#)
- show vmps command [2-561](#)
- shutdown command [2-563](#)

- shutdown threshold, Layer 2 protocol tunneling [2-207](#)
- shutdown vlan command [2-564](#)
- SNMP host, specifying [2-570](#)
- SNMP informs, enabling the sending of [2-566](#)
- snmp mib rep trap-rate command [2-565](#)
- snmp-server enable traps command [2-566](#)
- snmp-server host command [2-570](#)
- snmp trap mac-notification command [2-574](#)
- SNMP traps
 - enabling MAC address notification trap [2-574](#)
 - enabling the MAC address notification feature [2-234](#)
 - enabling the sending of [2-566](#)
- software images
 - deleting [2-67](#)
 - downloading [2-9](#)
 - upgrading [2-9](#)
 - uploading [2-15](#)
- software version, displaying [2-550](#)
- source ports, MVR [2-271](#)
- SPAN
 - configuring [2-264](#)
 - debug messages, display [B-17](#)
 - displaying [2-505](#)
 - filter SPAN traffic [2-264](#)
 - sessions
 - add interfaces to [2-264](#)
 - displaying [2-505](#)
 - start new [2-264](#)
- spanning-tree bpdupfilter command [2-576, 2-578](#)
- spanning-tree bpduguard command [2-580](#)
- spanning-tree cost command [2-582](#)
- spanning-tree etherchannel command [2-584](#)
- spanning-tree extend system-id command [2-586](#)
- spanning-tree guard command [2-588](#)
- spanning-tree link-type command [2-590](#)
- spanning-tree loopguard default command [2-592](#)
- spanning-tree mode command [2-594](#)
- spanning-tree mst configuration command [2-596](#)
- spanning-tree mst cost command [2-598](#)
- spanning-tree mst forward-time command [2-600](#)
- spanning-tree mst hello-time command [2-601](#)
- spanning-tree mst max-age command [2-603](#)
- spanning-tree mst max-hops command [2-605](#)
- spanning-tree mst port-priority command [2-607](#)
- spanning-tree mst pre-standard command [2-609](#)
- spanning-tree mst priority command [2-610](#)
- spanning-tree mst root command [2-612](#)
- spanning-tree portfast (global configuration) command [2-616](#)
- spanning-tree portfast (interface configuration) command [2-619](#)
- spanning-tree port-priority command [2-614](#)
- Spanning Tree Protocol
 - See STP
- spanning-tree vlan command [2-621](#)
- speed command [2-624](#)
- SSH, configuring version [2-189](#)
- static-access ports, configuring [2-631](#)
- statistics, Ethernet group [2-339](#)
- sticky learning, enabling [2-646](#)
- storm-control command [2-626](#)
- STP
 - counters, clearing [2-55](#)
 - debug messages, display
 - MSTP [B-70](#)
 - optimized BPDUs handling [B-69](#)
 - spanning-tree activity [B-66](#)
 - switch shim [B-72](#)
 - transmitted and received BPDUs [B-68](#)
 - enabling on ENIs [2-576](#)
 - enabling protocol tunneling for [2-207](#)
 - EtherChannel misconfiguration [2-584](#)
 - extended system ID [2-586](#)
 - path cost [2-582](#)
 - protocol modes [2-594](#)

STP (continued)

root port

- loop guard [2-588](#)
- preventing from becoming designated [2-588](#)
- restricting which can be root [2-588](#)
- root guard [2-588](#)

root switch

- affects of extended system ID [2-586, 2-622](#)
- hello-time [2-621](#)
- interval between BDPUs messages [2-621](#)
- interval between hello BPDU messages [2-621](#)
- max-age [2-621](#)
- port priority for selection of [2-614](#)
- primary or secondary [2-621](#)
- switch priority [2-621](#)

state changes

- blocking to forwarding state [2-619](#)
- enabling BPDU filtering [2-578, 2-616](#)
- enabling BPDU guard [2-580, 2-616](#)
- enabling Port Fast [2-616, 2-619](#)
- enabling timer to recover from error state [2-104](#)
- forward-delay time [2-621](#)
- length of listening and learning states [2-621](#)
- shutting down Port Fast-enabled ports [2-616](#)

state information display [2-536](#)VLAN options [2-610, 2-621](#)SVIs, creating [2-131](#)

Switched Port Analyzer

See SPAN

switching characteristics

- modifying [2-629](#)
- returning to interfaces [2-629](#)

switchport access command [2-631](#)switchport backup interface command [2-633](#)switchport block command [2-637](#)switchport command [2-629](#)switchport host command [2-639](#)switchport mode command [2-640](#)switchport mode private-vlan command [2-643](#)switchport port-security aging command [2-650](#)switchport port-security command [2-646](#)switchport private-vlan command [2-652](#)switchport protected command [2-654](#)switchports, displaying [2-418](#)switchport trunk command [2-656](#)switchport vlan mapping command [2-658](#)system env temperature threshold yellow command [2-661](#)system message logging, save message to flash [2-223](#)system mtu command [2-662](#)system resource templates [2-340](#)

T
table-map command [2-664](#)table-map configuration mode [2-664](#)

table maps

- configuring [2-664](#)
- displaying [2-545](#)
- QoS [2-664](#)

tar files, creating, listing, and extracting [2-12](#)TDR, running [2-666](#)temperature information, displaying [2-396](#)temperature status, displaying [2-396](#)templates, system resources [2-340](#)test cable-diagnostics tdr command [2-666](#)traceroute mac command [2-668](#)traceroute mac ip command [2-671](#)traffic shaping, QoS [2-362](#)trunking, VLAN mode [2-640](#)trunk mode [2-640](#)trunk ports [2-640](#)tunnel ports, Layer 2 protocol, displaying [2-467](#)type (boot loader) command [A-26](#)

U

UDLD

- aggressive mode [2-673, 2-675](#)
- debug messages, display [B-78](#)
- enable globally [2-673](#)
- enable per interface [2-675](#)
- error recovery timer [2-104](#)
- message timer [2-673](#)
- normal mode [2-673, 2-675](#)
- reset a shutdown interface [2-677](#)
- status [2-547](#)

udld command [2-673](#)

udld port command [2-675](#)

udld reset command [2-677](#)

UNI

- bundling and multiplexing [2-118](#)
- Ethernet [2-118](#)

unicast storm control [2-626](#)

uni count command [2-678](#)

UniDirectional Link Detection

See UDLD

UNI ID, Ethernet [2-120](#)

uni-vlan command [2-680](#)

unknown multicast traffic, preventing [2-637](#)

unknown unicast traffic, preventing [2-637](#)

unset (boot loader) command [A-27](#)

upgrading

- software images [2-9](#)
- monitoring status of [2-367](#)

user EXEC mode [1-2](#)

user network interface [2-308](#)

V

version (boot loader) command [A-29](#)

violate-action command [2-682](#)

vlan access-map command [2-687](#)

VLAN access map configuration mode [2-687](#)

VLAN access maps

actions [2-5](#)

displaying [2-557](#)

vlan command [2-684](#)

VLAN configuration mode

commands [2-684](#)

description [1-4](#)

entering [2-684](#)

summary [1-2](#)

vlan dot1q tag native command [2-689](#)

vlan filter command [2-691](#)

VLAN filters, displaying [2-558](#)

VLAN ID range [2-684](#)

VLAN ID translation

See VLAN mapping

VLAN mapping

configuring [2-658](#)

described [2-659](#)

displaying [2-559](#)

VLAN maps

applying [2-691](#)

creating [2-687](#)

defining [2-247](#)

displaying [2-557](#)

VLAN Query Protocol

See VQP

VLANs

adding [2-684](#)

configuring [2-684](#)

debug messages, display

activation of [B-76](#)

VLAN IOS file system error tests [B-75](#)

VLAN manager activity [B-74](#)

displaying configurations [2-552](#)

extended-range [2-684](#)

MAC addresses

displaying [2-503](#)

number of [2-490](#)

normal-range [2-684](#)

VLANs (continued)

- private [2-643](#)
 - configuring [2-315](#)
 - displaying [2-552](#)
- See also private VLANs
- restarting [2-564](#)
- saving the configuration [2-684](#)
- shutting down [2-564](#)
- suspending [2-564](#)

VMPS

- configuring servers [2-696](#)
 - displaying [2-561](#)
 - error recovery timer [2-105](#)
 - reconfirming dynamic VLAN assignments [2-693](#)
- vmmps reconfirm (global configuration) command [2-694](#)
- vmmps reconfirm (privileged EXEC) command [2-693](#)
- vmmps retry command [2-695](#)
- vmmps server command [2-696](#)

VQP

- and dynamic-access ports [2-632](#)
 - clearing client statistics [2-58](#)
 - displaying information [2-561](#)
 - per-server retry count [2-695](#)
 - reconfirmation interval [2-694](#)
 - reconfirming dynamic VLAN assignments [2-693](#)
- VTP, enabling tunneling for [2-207](#)

W

Weighted Tail Drop

See WTD

WTD, queue-limit command [2-320](#)