

# CHAPTER 6

# **CTRS Unset Commands**

### October 2011

This chapter contains Cisco TelePresence Recording Server (CTRS) unset commands:

- unset network dns options, page 6-2
- unset network domain, page 6-3

### unset network dns options

#### unset network dns options [timeout] [attempts] [rotate]

Syntax Description	timeout	Defaults the wait time before considering a Domain Name System (DNS) query to have failed.	
	attempts	Defaults the number of attempts to make before failing.	
	rotate	Defaults the method for selecting a name server; this affects how loads are distributed across name servers.	
Command Modes	Admin		
Command History	Release	Modifications	
	1.6	This command was first documented.	
Usage Guidelines	Use this command to unset the Domain Name System (DNS) options. This command causes a temporar loss of network connections.		
Examples	admin: <b>unset network dns options timeout</b> *** WARNING *** This will cause the system to temporarily lose network connectivity		
	Do you want to continue ?		
	Enter "yes" to continue or any other key to abort yes executing		

# unset network domain

unset network domain

Syntax Description	None		
Command Modes	Admin		
Command History	Release	Modifications	
	1.8	This command was first documented.	
Usage Guidelines	This command unsets the domain name. The system asks whether you want to continue to execute this command. If you continue, the system will restart.		
<u> </u>			
Examples	admin: <b>unset ne</b> f Continue (y/n)		

