



# CHAPTER 6

## CTRS Unset Commands

---

**Revised: November 2009, OL-19547-01**

This chapter contains Cisco TelePresence Recording Server (CTRS) **unset** commands:

- [unset network dns options, page 6-2](#)



**Note**

For information about using the CTRS administration software, refer to the *Cisco TelePresence Recording Server Release 1.6 Administration Guide* at the following URL:

[http://www.cisco.com/en/US/products/ps10341/prod\\_maintenance\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps10341/prod_maintenance_guides_list.html)

---

■ unset network dns options

# unset network dns options

**unset network dns options [timeout] [attempts] [rotate]**

<b>Syntax Description</b>	<b>timeout</b>	Defaults the wait time before considering a Domain Name System (DNS) query to have failed.
	<b>attempts</b>	Defaults the number of attempts to make before failing.
	<b>rotate</b>	Defaults the method for selecting a name server; this affects how loads are distributed across name servers.

<b>Command Modes</b>	Admin
----------------------	-------

<b>Command History</b>	<b>Release</b>	<b>Modifications</b>
	1.6	This command was first documented.

<b>Usage Guidelines</b>	Use this command to unset the Domain Name System (DNS) options. This command causes a temporary loss of network connections.
-------------------------	--

<b>Examples</b>	<pre>admin:unset network dns options timeout       *** W A R N I N G *** This will cause the system to temporarily lose network connectivity  Do you want to continue ?  Enter "yes" to continue or any other key to abort yes executing...</pre>
-----------------	---