



INDEX

I

installing

- linux servers [1-1](#)
- using EFI Shell [1-2](#)

L

locking

- front panel [2-4](#)

U

updating

- flashing [2-3](#)
- transferring [2-3](#)

using

- `./fwup cimc activate` [2-5](#)
- `./fwup cimc frontpanel lock` [3-2](#)
- `./fwup cimc frontpanel unlock` [3-2](#)
- `./fwup cimc help` [3-1](#)
- `./fwup cimc show updatestatus` [2-4](#)
- `./fwup cimc show version` [2-2](#)
- `./fwup cimc update` [2-3](#)
- Overview [2-1](#)
- prerequisites [1-1](#)

