



Preface

This preface describes the audience and organization of the *Cisco C-Series Servers Troubleshooting Guide*. It also provides document conventions and information on how to obtain related documentation.

This preface contains the following topics:

- [Audience, page v](#)
- [Organization, page v](#)
- [Related Documentation, page v](#)
- [Document Conventions, page vi](#)
- [Obtaining Documentation and Submitting a Service Request, page vi](#)

Audience

This troubleshooting guide is designed for users who are responsible for the following:

- Implementing Cisco C-Series Servers
- Managing Cisco C-Series Servers

Organization

This troubleshooting guide is organized into the following chapters:

- [Chapter 1, “Introduction”](#)
- [Chapter 2, “Troubleshooting Server Hardware or Software Issues”](#)

Related Documentation

The documentation set for the Cisco Unified Computing System is available at this location:

- [Cisco C-Series Servers Documentation Roadmap](#)

Send document comments to ucs-docfeedback@cisco.com

Document Conventions

Command descriptions use these conventions:

Convention	Description
boldface font	Commands and keywords are in boldface.
<i>italic font</i>	Arguments for which you supply values are in italics.
[]	Elements in square brackets are optional.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Screen examples use these conventions:

screen font	Terminal sessions and information that the switch displays are in screen font.
boldface screen font	Information that you must enter is in boldface screen font.
<i>italic screen font</i>	Arguments for which you supply values are in italic screen font.
< >	Nonprinting characters, such as passwords, are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

This document uses the following conventions:



Note

Means reader *take note*. Notes contain helpful suggestions or references to material not covered in the manual.



Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as an RSS feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service. Cisco currently supports RSS Version 2.0.