



## Installing Plugins in Cisco Unity Connection 10.x

---

Application plugins extend the functionality of Cisco Unity Connection. For example, the Real-Time Monitoring Tool (RTMT) allows you to monitor the health of the system remotely through tools such as performance-monitoring counters and the Port Monitor.

Do the following procedure.



### Note

---

Before you install any plugins, you must disable all intrusion detection or antivirus services that run on the server where you will install the plugin.

---

### To Install a Plugin

- 
- Step 1** In Cisco Unity Connection Administration, expand **System Settings**, then select **Plugins**.
  - Step 2** On the **Search Plugins** page, select **Find**.
  - Step 3** For the plugin that you want to install, select **Download**.
  - Step 4** Follow the on-screen instructions for installing the plugin.
-

