

# Α

addressing options for non-networked phone systems 1-13 VPIM Networking 4-18 alternate names, adding for VPIM locations 4-14 audio format for VPIM Networking 4-19

# В

blind addressing, VPIM Networking 4-18
Bulk Administration Tool creating VPIM contacts 4-7, 4-8 errors, correcting (VPIM) 4-9

# С

ſ

Cisco Unity, changing a site gateway 5-3 Cisco Unity Connection site changing the gateway 5-3 intersite link with Cisco Unity, removing 5-4 linking 1-3 linking to Cisco Unity 1-3 linking two sites 2-16 prerequisites 2-1 procedures to setting up 2-3 removing a location 5-1 removing intersite link between two sites **5-6** task list 2-2 Cisco Unity sites, linking to Cisco Unity Connection 1-3 Cisco Voicemail Organization, definition 1-2 cross-server features notable behavior 6-22

overview 6-1 search space considerations 6-2 cross-server live reply definition 1-12 overview 6-16 prerequisites 6-16 procedures 6-18 task list 6-17 cross-server sign-in definition 1-12 overview 6-3 prerequisites 6-4 procedures 6-5, 6-11 task list 6-4 cross-server transfer definition 1-12 overview 6-9 prerequisites 6-10 procedures 6-11 task list 6-10 CSV files correcting errors for Bulk Administration Tool 4-9 creating VPIM contacts 4-7

# D

delivery locations, creating for VPIM 4-6 dialing domains 1-15 dial plan addressing options 1-13 considerations 1-13 directory size limits 1-10 directory synchronization

Networking Guide for Cisco Unity Connection Release 10.x

between Cisco Unity and Cisco Unity Connection sites 1-8

between two Connection sites 1-7

within a Cisco Unity Connection site 1-5

DNS, resolving names with IP addresses 4-4

### G

gateway changing **5-3** changing for a Cisco Unity site **5-3** 

### I

identified user messaging 1-14 intersite link between Cisco Unity and Cisco Unity Connection

prerequisites 3-1 procedures 3-4 task list 3-2 intersite links definition 1-2 removing 5-6 intrasite links, definition 1-1

## L

linking servers 2-7 location, removing 5-1

#### Ν

name resolution, VPIM 4-4

### R

replication

between Cisco Unity and Cisco Unity Connection sites 1-8

between two Connection sites 1-7 within a Cisco Unity Connection site 1-5

### S

search spaces 1-15 servers, linking 2-7 site, definition 1-1 system distribution lists and messaging 1-11

# V

**VPIM** contacts after creating 4-11 correcting CSV errors for Bulk Administration Tool 4-9 creating by using Bulk Administration Tool 4-8 creating by using CSV files 4-7 creating with Bulk Administration Tool 4-7 creating with Connection Administration 4-9 customizing directory update settings 4-11 deleting 4-15 VPIM locations adding alternate names 4-14 creating 4-6 customizing 4-6 VPIM Networking adding alternate names for VPIM locations 4-14 adding VPIM contacts with Connection Administration 4-9 addresses 4-17 addressing options 4-18 after creating VPIM contacts 4-11 audio formats 4-19 configuring remote voice messaging system 4-15 creating VPIM contacts with Bulk Administration Tool 4-7, 4-8 creating VPIM locations 4-6 customizing VPIM contact directory update settings 4-11

customizing VPIM locations 4-6 definition 1-5 deleting VPIM contacts 4-15 design decisions 4-3 DNS 4-4 messages 4-16 messaging similarities and limitations 4-18 overview 4-1 prerequisites 4-2 removing a VPIM location 4-15 resolving names with IP addresses 4-4 sample message 4-17 setting up 4-1 setup procedures 4-3 using CSV files for creating VPIM contacts 4-7 verifying connectivity with remote voice messaging system 4-5

ſ

Index

1