



## INDEX

---

### A

- abbreviated extensions [6-10](#)
- accounts
  - Operator [19-6](#)
  - UndeliverableMessagesMailbox [19-6](#)
  - Unity Connection Messaging System [19-6](#)
- adding
  - alternate names for a system distribution list [27-4](#)
  - AXL servers [29-5](#)
  - Cisco Unified Communications Manager servers [29-10](#)
  - description of message attachments [39-1](#)
  - global nicknames to list [14-12](#)
  - integration, phone system [29-2](#)
  - members to system distribution lists [27-3](#)
  - PIMG/TIMG units [29-15](#)
  - port [29-17](#)
  - port group [29-8](#)
  - SIP server [29-13](#)
  - system distribution lists [27-2](#)
  - TFTP server [29-12](#)
- addressing options, VPIM Networking [34-17](#)
- AGC, changing settings for port group [29-17](#)
- All Hours schedule [10-1](#)
- All Voice Mail Users distribution list [27-1](#)
- alternate contact numbers, configuring for call handlers [6-8](#)
- alternate conversations
  - Optional Conversation 1 [13-3](#)
  - overview [13-3](#)
- alternate names
  - adding for system distribution lists [27-4](#)
  - adding for VPIM locations [34-13](#)
- application plug-ins [3-1](#)
- Attempt Forward call routing rule [9-1](#)
- Attempt Sign-In call routing rule [9-1](#)
- audio format
  - changing for calls [16-1, 29-9](#)
  - changing for recordings [16-2, 17-5, 19-4](#)
  - VPIM Networking [34-18](#)
- authentication, configuring LDAP [43-5](#)
- authentication rules
  - default rules [18-2](#)
  - overview [18-2](#)
- automated attendant [4-9](#)
- automatic gain control (AGC), changing settings for port group [29-17](#)
- AXL servers
  - adding [29-5](#)
  - changing settings [29-7](#)
  - deleting [29-7](#)

---

### B

- backing up and restoring data [3-7](#)
- backup and restore application for migrations (COBRAS) [3-2](#)
- blind addressing, VPIM Networking [34-17](#)
- Broadcast Message Administrator
  - setting up access [26-2](#)
  - using [26-5](#)
- broadcast messages
  - changing default settings [26-6](#)
  - overview [26-1](#)
  - setting up access for sending [26-2](#)
- Bulk Administration Tool
  - accessing [3-2](#)

creating VPIM contacts [34-7, 34-8](#)

errors, correcting (VPIM) [34-8](#)

Bulk Edit utility, accessing [3-3](#)

## C

### calendar integration

about [35-1](#)

changing user configurations for the Cisco Unified MeetingPlace Express integration [35-32](#)

changing user configurations for the Cisco Unified MeetingPlace integration [35-24](#)

changing user configurations for the Exchange 2003 integration [35-17](#)

changing user configurations for the Exchange 2007 integration [35-8](#)

changing with Cisco Unified MeetingPlace [35-23](#)

changing with Cisco Unified MeetingPlace Express [35-30](#)

changing with Exchange 2003 [35-16](#)

changing with Exchange 2007 [35-8](#)

creating with Cisco Unified MeetingPlace [35-18](#)

creating with Cisco Unified MeetingPlace Express [35-25](#)

creating with Exchange 2003 [35-10](#)

creating with Exchange 2007 [35-1](#)

Exchange contacts [35-1](#)

caller input settings, changing user logon settings [14-7](#)

caller options, user settings [13-5](#)

### call handlers

caller input and one-key dialing [6-8](#)

call transfer settings [6-12](#)

default [6-1](#)

deleting [6-12](#)

Goodbye [6-2](#)

greetings [6-6](#)

modifying [6-5](#)

Opening Greeting [6-1](#)

Operator [6-2](#)

overview [4-2](#)

Route From Next Call Routing Rule Action, using with routing rules [4-5](#)

taking messages [6-11](#)

templates, modifying [6-3](#)

### call handler templates

creating [6-2](#)

default templates [6-2](#)

deleting [6-2](#)

modifying [6-2](#)

Call Handler Traffic report [41-3](#)

call holding, user settings in Cisco Unity Assistant [13-5](#)

call loop detection [29-4](#)

### call management

creating a map [5-1](#)

implementing a plan [5-2](#)

managing call handlers [6-1](#)

managing call routing tables [9-1](#)

managing directory handlers [7-1](#)

managing interview handlers [8-1](#)

managing restriction tables [11-1](#)

managing schedules and holidays [10-1](#)

overview [4-1](#)

planning [5-1](#)

### call routing tables

adding rules [9-2](#)

and the Route From Next Call Routing Rule action [4-5](#)

Attempt Forward rule [9-1](#)

Attempt Sign-In rule [9-1](#)

changing the order of rules [9-3](#)

default rules [9-1](#)

deleting rules [9-3](#)

modifying rules [9-2](#)

Opening Greeting rule [9-1](#)

overview [4-3](#)

calls, changing the audio format (or codec) for [16-1, 29-9](#)

call screening, user settings in Cisco Unity Assistant [13-5](#)

### call transfers

user settings in Cisco Unity Assistant [13-5](#)

- user settings in Connection conversation [13-5](#)
- call waiting, configuring hold time [14-3](#)
- capacity of hard disk, specifying maximum percentage [19-17](#)
- certificate, viewing for port [29-20](#)
- changing
  - addressing and recording order [14-1, 14-3](#)
  - addressing priority lists, how names are stored in [14-2](#)
  - AGC settings [29-17](#)
  - AXL server settings [29-7](#)
  - call loop detection settings [29-4](#)
  - Cisco Unified Communications Manager server settings [29-11](#)
  - codec preference settings [29-9](#)
  - description of message attachments [39-2](#)
  - dial prefix settings for live reply to unidentified callers [14-5](#)
  - message deletion options [14-5](#)
  - message skipping during playback (Optional Conversation 1) [14-10](#)
  - MWI settings [29-10](#)
  - phone system settings [29-3](#)
  - phone system trunk settings [29-21](#)
  - PIMG/TIMG settings [29-16](#)
  - port group advanced settings [29-16](#)
  - port group settings [29-9](#)
  - port settings [29-18](#)
  - SIP server settings [29-14](#)
  - SIP settings [29-16](#)
  - system prompt language [14-6](#)
  - TFTP server settings [29-13](#)
  - user logon settings during user greeting [14-7](#)
- Cisco DirSync service, activating [43-3](#)
- Cisco Fax Server integration
  - about [32-1](#)
  - changing the Cisco Unity Connection configuration [32-8](#)
  - changing the user configuration [32-9](#)
  - configuring Cisco Unity Connection [32-5](#)
  - configuring single number for calls and faxes [32-9](#)
  - configuring the Cisco Fax Server [32-2](#)
  - configuring users [32-7](#)
  - creating [32-1](#)
  - requirements [32-2](#)
  - testing [32-7](#)
- Cisco PCA, securing access to Cisco Unity Connection [25-1](#)
- Cisco SIP Proxy Server
  - adding [29-13](#)
  - changing settings [29-14](#)
  - deleting [29-14](#)
- Cisco Unified Communications Manager
  - adding servers [29-10](#)
  - adding TFTP server [29-12](#)
  - AXL servers, adding [29-5](#)
  - AXL servers, deleting [29-7](#)
  - changing AXL server settings [29-7](#)
  - changing server settings [29-11](#)
  - changing TFTP server settings [29-13](#)
  - deleting servers [29-11](#)
  - deleting TFTP server [29-12](#)
  - port certificate [29-20](#)
  - root certificate for Connection [29-22](#)
- Cisco Unified MeetingPlace
  - changing the calendar integration [35-23](#)
  - changing user configurations for the calendar integration [35-24](#)
  - creating a calendar integration [35-18](#)
- Cisco Unified MeetingPlace Express
  - changing the calendar integration [35-30](#)
  - changing user configurations for the calendar integration [35-32](#)
  - creating a calendar integration [35-25](#)
- Cisco Unified Mobility Advantage integration
  - about [30-1](#)
  - configuring Cisco Unity Connection [30-2](#)
  - requirements [30-2](#)
  - task list for creating [30-1](#)
  - testing [30-3](#)

- Cisco Unified Real-Time Monitoring Tool (RTMT) [3-7](#)
- Cisco Unified Serviceability [3-8](#)
- Cisco Unified Serviceability services
  - configuring enterprise parameters [37-1](#)
  - configuring service parameters [36-1](#)
  - descriptions of enterprise parameters [37-2](#)
  - descriptions of service parameters [36-2](#)
- Cisco Unity Connection Administration
  - accessing [2-1](#)
  - configuring browsers [1-1](#)
  - finding records [2-3](#)
  - interface [2-2](#)
  - using Help [2-2](#)
- Cisco Unity Connection conversation [13-1](#)
- Cisco Unity Greetings Administrator
  - overview [17-2](#)
  - setting up [17-4](#)
  - using [17-3](#)
- Cisco Utilities Database Link for Informix [3-10](#)
- Cisco Voice Technology Group Subscription tool [3-7](#)
- cluster, configuring and customizing [42-1](#)
- COBRAS backup and restore application [3-2](#)
- codec
  - changing for calls [16-1, 29-9](#)
  - changing for recordings [16-2, 17-5, 19-4](#)
  - changing preference settings [29-9](#)
- configuring
  - access to emails in external message store [40-1](#)
  - call waiting hold time [14-3](#)
  - cross-server logon and transfers [33-13](#)
  - one-key dialing [6-8](#)
  - smart host, for Digital Networking [33-10](#)
- Connection 1.x, migrating from [3-2](#)
- Connection Administration, accessing [3-2](#)
- Connection locations
  - manually synchronizing [33-17](#)
  - overview [33-19](#)
  - removing from the Digital Network [33-18](#)
- Connection Serviceability [3-6](#)
- Connection User Data Dump [3-10](#)
- conversation
  - allowing voice recognition users to say their voice mail passwords [14-10](#)
  - alternate conversation versions [13-3](#)
  - caller options [13-1](#)
  - changing addressing and recording order [14-1, 14-3](#)
  - changing dial prefix settings for live reply to unidentified callers [14-5](#)
  - changing how names are stored in user addressing priority lists [14-2](#)
  - changing message deletion options [14-5](#)
  - changing password re-entry behavior [14-8](#)
  - Cisco Unity Connection, overview [13-1](#)
  - customizing by administrators [13-2](#)
  - customizing by users [13-5](#)
  - documenting for users [3-10](#)
  - easy sign-in [14-8](#)
  - sign-in [14-8](#)
  - specifying caller information before message playback [14-4](#)
  - user options [13-1](#)
  - user settings in Cisco Unity Assistant [13-6](#)
  - user settings in Connection conversation [13-6](#)
  - using voice commands [13-3](#)
- creating
  - AXL servers [29-5](#)
  - call handler templates [6-2](#)
  - call management map [5-1](#)
  - call routing rules [9-2](#)
  - directory handlers [7-1](#)
  - holiday schedules [10-1](#)
  - interview handlers [8-1](#)
  - restriction tables [11-1](#)
  - schedules [10-2](#)
  - user accounts [ii-xix](#)
- credentials policies [18-1](#)
- cross-server logon and transfers
  - configuring [33-13](#)
  - overview [33-23](#)

## CSV files

- correcting errors for Bulk Administration Tool [34-8](#)
- creating VPIM contacts [34-7](#)

## CUDLI [3-10](#)

## Custom Keypad Mapping tool

- accessing [15-1](#)
- conversations that can be customized [15-3](#)
- documenting keypad for users [15-13](#)
- guidelines [15-2](#)
- resetting [15-2](#)
- using [15-1](#)

# D

## Database Proxy [3-8](#)

## deleting

- AXL servers [29-7](#)
- call handlers [6-12, 7-4](#)
- call handler templates [6-2](#)
- call routing rules [9-3](#)
- Cisco Unified Communications Manager servers [29-11](#)
- description of message attachments [39-2](#)
- integration, phone system [29-2](#)
- interview handlers [8-3](#)
- members from system distribution lists [27-3](#)
- phone system trunk [29-21](#)
- PIMG/TIMG units [29-15](#)
- port [29-18](#)
- port group [29-9](#)
- restriction tables [11-3](#)
- schedules [10-3](#)
- SIP server [29-14](#)
- TFTP server [29-12](#)

## delivery locations, creating for VPIM [34-6](#)

## demonstration license files, about [44-2](#)

## Dial Plan report [41-4](#)

## Dial Search Scope report [41-4](#)

## Digital Networking

## adding a server to an existing network [33-8](#)

## addressing options for non-networked phone systems [33-21](#)

## and Connection locations [33-19](#)

## and object replication [33-20](#)

## and private distribution lists [33-24](#)

## and system distribution lists [33-23](#)

## and VPIM locations [33-24](#)

## broadcast messages not supported between locations [33-25](#)

## checking or modifying the server display name and SMTP domain name [33-5](#)

## checking replication status [33-9](#)

## cleaning up unused VPIM locations and contacts [33-17](#)

## client access to servers [33-25](#)

## configuring a smart host [33-10](#)

## configuring cross-server logon and transfers [33-13](#)

## configuring search spaces for [33-12](#)

## configuring SMTP access for cluster subscriber servers [33-11](#)

## creating a network-wide all voice mail users distribution list [33-16](#)

## cross-server logon and transfer overview [33-23](#)

## deployment decisions [33-4](#)

## identified user messaging between networked users [33-22](#)

## joining two servers to create a Digital Network [33-6](#)

## manually synchronizing locations [33-17](#)

## mapping users to systems [33-25](#)

## notable behavior [33-24](#)

## overview [33-1](#)

## prerequisites [33-2](#)

## removing a location from the network [33-18](#)

## replication suspended during bulk operations [33-25](#)

## replication with clusters [33-25](#)

## securing [33-13](#)

## setting up [33-2](#)

## setup task list [33-2](#)

## testing the setup [33-14](#)

## directory handlers

- creating [7-1](#)
- default [7-1](#)
- deleting [7-4](#)
- modifying [7-2](#)
- overview [4-2](#)
- System Directory Handler [7-1](#)

Disaster Recovery System [3-7](#)

dispatch messages [19-6](#)

Distribution Lists report [41-2](#)

DNS, resolving names with IP addresses [34-4](#)

## E

easy sign-in conversation [14-8](#)

Edit Disk Capacity Configuration page [19-17](#)

email

- configuring access in external message store [40-1](#)
- messages [19-2](#)

end of recording, configuring termination warning prompt [19-5](#)

enterprise parameters

- configuring for Cisco Unified Serviceability services [37-1](#)
- descriptions [37-2](#)
- for Cisco Unified Serviceability services [37-1](#)

Exchange 2003

- changing the calendar integration [35-16](#)
- changing user configurations for the calendar integration [35-17](#)
- creating a calendar integration [35-10](#)

Exchange 2007

- changing the calendar integration [35-8](#)
- changing user configurations for the calendar integration [35-8](#)
- creating a calendar integration [35-1](#)

Exchange contacts

- enabling importing from Exchange 2003 [35-10](#)
- enabling importing from Exchange 2007 [35-1](#)

extensions

- adding prepended digits [6-10](#)

- converting LDAP phone numbers into [43-4](#)

external message store, configuring access to emails in [40-1](#)

## F

fax

- about the Cisco Fax Server integration [32-1](#)
- changing the Cisco Unity Connection configuration [32-8](#)
- changing the user configuration [32-9](#)
- configuring Cisco Unity Connection [32-5](#)
- configuring single number for calls and faxes [32-9](#)
- configuring the Cisco Fax Server [32-2](#)
- configuring users [32-7](#)
- creating a Cisco Fax Server integration [32-1](#)
- requirements for the Cisco Fax Server integration [32-2](#)
- testing [32-7](#)

field definitions [2-2](#)

Firefox, configuring [1-1](#)

## G

G.711 A-Law codec

- selecting for calls [16-1, 29-9](#)
- selecting for recordings [16-2, 17-5, 19-4](#)

G.711 Mu-Law codec

- selecting for calls [16-1, 29-9](#)
- selecting for recordings [16-2, 17-5, 19-4](#)

G.729a codec

- selecting for calls [16-1, 29-9](#)
- selecting for recordings [16-2, 17-5, 19-4](#)

G726 codec, selecting for recordings [16-2, 17-5, 19-4](#)

global nicknames

- adding names to list [14-12](#)
- editing list [14-12](#)

Goodbye call handler [6-2](#)

Grammar Statistics tool, accessing [3-4](#)

## greetings

- call handlers [6-6](#)
- changing audio format for recording [17-5](#)
- recording by using Media Master [17-1](#)
- user settings in Cisco Unity Assistant [13-6](#)
- user settings in Connection conversation [13-6](#)

groupware email messages [19-2](#)

---

**H**hard disk, specifying maximum capacity [19-17](#)

## Help

- page and field [2-2](#)
- using [2-2](#)

## holidays

- designating [10-1](#)
- holiday schedule [10-1](#)

---

**I**

## identified user messaging

- and Digital Networking [33-22](#)
- overview [19-2](#)

## IMAP access

- accessing email messages from Connection by using [19-2](#)
- configuration procedures [20-4](#)
- configuration task list [20-3](#)
- Connection server configuration [20-5](#)
- security recommendations [20-3](#)
- SMTP message parameters [20-7](#)

## IMAP clients

- integrated messaging example [20-2](#)
- securing access to Cisco Unity Connection [25-1](#)
- security options [24-3](#)
- SMTP message handling [20-1](#)

Import Users tool, accessing [3-4](#)installing license files [44-2](#)integrated messaging, example [20-2](#)

## integration

- adding [29-2](#)
- adding phone system trunk [29-21](#)
- adding PIMG/TIMG units [29-15](#)
- adding port [29-17](#)
- adding port group [29-8](#)
- adding SIP certificate [29-24](#)
- adding SIP security profile [29-25](#)
- adding SIP server [29-13](#)
- adding TFTP server [29-12](#)
- AXL server, changing settings [29-7](#)
- AXL servers, adding [29-5](#)
- AXL servers, deleting [29-7](#)
- call loop detection, changing settings [29-4](#)
- changing AGC settings [29-17](#)
- changing Cisco Unified Communications Manager server settings [29-11](#)
- changing phone system trunk settings [29-21](#)
- changing PIMG/TIMG settings [29-16](#)
- changing port group advanced settings [29-16](#)
- changing port settings [29-18](#)
- changing SIP certificate [29-24](#), [29-25](#)
- changing SIP server settings [29-14](#)
- changing SIP settings [29-16](#)
- changing TFTP server settings [29-13](#)
- codec, changing preference settings [29-9](#)
- deleting [29-2](#)
- deleting Cisco Unified Communications Manager servers [29-11](#)
- deleting phone system trunk [29-21](#)
- deleting PIMG/TIMG units [29-15](#)
- deleting port [29-18](#)
- deleting SIP certificate [29-24](#)
- deleting SIP security profile [29-25](#)
- deleting SIP server [29-14](#)
- deleting TFTP server [29-12](#)
- MWI, disabling the use of the same port for turning on and off [29-3](#)
- MWI, synchronizing [29-4](#)
- MWIs, changing settings [29-10](#)

- phone system, changing settings [29-3](#)
- phone system trunk description [29-20](#)
- port certificate [29-20](#)
- port description [29-17](#)
- port group, changing settings [29-9](#)
- port group, deleting [29-9](#)
- port group description [29-7](#)
- root certificate for Connection [29-23](#)
- security for ports [29-22](#)
- users associated with phone system [29-3](#)
- viewing root certificate for Connection [29-22](#)

Internet Explorer, configuring [1-2](#)

interview handlers

- creating [8-1](#)
- deleting [8-3](#)
- modifying [8-2](#)
- overview [4-3](#)

## L

language

- changing system prompt language [14-6](#)
- language settings for call handlers [6-11](#)
- language settings for directory handlers [7-3](#)
- language settings for interview handlers [8-2](#)
- language settings for routing rules [9-3](#)
- message subject line format [19-13](#)

LDAP

- activating the Cisco DirSync service [43-3](#)
- adding configurations and synchronizing data [43-7](#)
- configuring authentication [43-5](#)
- converting LDAP phone numbers into Connection extensions [43-4](#)
- enabling synchronization [43-3](#)
- task list for configuring [43-2](#)

license files

- about using MAC addresses [44-1](#)
- about using multiple license files [44-2](#)
- Connection clusters [44-2](#)

- must be installed [44-2](#)

- obtaining and installing [44-2](#)

- parameters for Connection features [44-6](#)

- permanent, time-expiring, and demonstration [44-2](#)

- viewing reports [44-4](#)

live record

- about [19-4](#)

- configuring [19-18](#)

lockout policy [18-1](#)

logon policy [18-1](#)

## M

mailboxes, moving [21-4](#)

mailbox size quotas, setting systemwide and mailbox-store limits [22-1](#)

Mailbox Store report [41-4](#)

mailbox stores

- backing up [21-3](#)

- creating [21-4](#)

- deleting [21-5](#)

- disabling [21-7](#)

- maximum size [21-2](#)

- maximum size, changing [21-5](#)

- message handling when maximum size is exceeded [19-11](#)

- moving mailboxes [21-4](#)

- multiple [21-1](#)

Maximum Delay for TTS Access Before Timeout [19-9](#)

Media Master

- preventing users from saving messages [24-3](#)

- recording greetings and names [17-1](#)

MeetingPlace

- changing the calendar integration [35-23](#)

- changing user configurations for the calendar integration [35-24](#)

- creating a calendar integration [35-18](#)

MeetingPlace Express

- changing the calendar integration [35-30](#)



- changing user configurations for the calendar integration [35-32](#)
  - creating a calendar integration [35-25](#)
- message actions, configuring [19-13](#)
- message addressing
  - user settings in Cisco Unity Assistant [13-7](#)
  - user settings in Connection conversation [13-7](#)
- message attachment
  - adding [39-1](#)
  - changing [39-2](#)
  - deleting [39-2](#)
- message locator, phone view [31-1](#)
- message notification
  - setting up, SMS (SMPP) [23-2](#)
  - setting up, SMTP [23-1](#)
  - user settings in Cisco Unity Assistant [13-6](#)
  - user settings in Connection conversation [13-6](#)
- message playback
  - user settings in Cisco Unity Assistant [13-7](#)
  - user settings in Connection conversation [13-7](#)
- messages
  - actions, configuring [19-13](#)
  - dispatch messages [19-6](#)
  - groupware email messages [19-2](#)
  - how Connection handles messages that are interrupted by disconnected calls [19-10](#)
  - how Connection handles messages that cannot be delivered [19-9](#)
  - how Connection handles messages when mailbox quotas are exceeded [19-11](#)
  - how Connection handles messages when maximum mailbox store size is exceeded [19-11](#)
  - how Connection handles messages when system components are unavailable [19-9](#)
  - interview messages [19-3](#)
  - live record [19-4](#)
  - message delivery [19-9](#)
  - message storage [19-17](#)
  - migrating from Connection 1.x [3-5](#)
  - migrating from Connection 1.x using COBRAS (recommended) [3-2](#)
  - migrating from Unity [3-5](#)
  - migrating from Unity using COBRAS (recommended) [3-2](#)
  - notifications [19-3](#)
  - outside caller voice messages [19-1](#)
  - receipts [19-3](#)
  - security options for IMAP client access [24-3](#)
  - sensitivity [19-12](#)
  - subject line format [19-13](#)
  - system broadcast messages [19-2](#)
  - types of messages [19-1](#)
  - user to user voice messages [19-2](#)
  - VPIM [34-16](#)
- message security
  - call handlers [6-11](#)
  - option to disable saves in Media Master [24-3](#)
  - overview of options [24-1](#)
  - sensitivity options for users and unidentified callers [24-1](#)
- Message Traffic report [41-2](#)
- message waiting indicators, synchronizing for phone system [29-4](#)
- messaging overview [19-1](#)
- Migrate Messages utility, accessing [3-5](#)
- Migrate Users utility, accessing [3-6](#)
- migrating data and messages from Unity or Connection 1.x [3-2](#)
- modifying
  - call handlers [6-5](#)
  - call handler templates [6-2, 6-3](#)
  - call routing rules [9-2](#)
  - directory handlers [7-2](#)
  - interview handlers [8-2](#)
  - restriction tables [11-3](#)
  - schedules [10-2](#)
  - system distribution lists [27-3, 27-4](#)
- multiple mailbox stores [21-1](#)
- MWIs
  - changing settings [29-10](#)

disabling the use of the same port for turning on and off [29-3](#)  
 synchronizing for phone system [29-4](#)

## N

name resolution, VPIM [34-4](#)  
 names, recording by using Media Master [17-1](#)  
 notification  
     setting up, SMS (SMPP) [23-2](#)  
     setting up, SMTP [23-1](#)  
     user settings in Cisco Unity Assistant [13-6](#)  
     user settings in Connection conversation [13-6](#)

## O

obtaining license files [44-2](#)  
 one-key dialing  
     configuring [6-8](#)  
     overview [6-8](#)  
 Opening Greeting  
     call handler [6-1](#)  
     call routing rule [9-1](#)  
 Operator call handler [6-2](#)  
 Operator user [19-6](#)  
 Optional Conversation 1  
     changing message skipping behavior [14-10](#)  
     overview [13-3](#)  
 Outcall Billing Detail report [41-3](#)  
 Outcall Billing Summary report [41-3](#)  
 outside caller voice messages [19-1](#)

## P

page Help [2-2](#)  
 partitions  
     changing default [28-11](#)  
     creating [28-8](#)  
     default [28-2](#)

deleting [28-9](#)  
 finding objects in [28-11](#)  
 modifying [28-9](#)  
 overview [28-1](#)  
 password policy [18-1](#)  
 PCM codec, selecting for recordings [16-2, 17-5](#)  
 permanent license files, about [44-2](#)  
 personal contacts, user settings in Cisco Unity Assistant [13-8](#)  
 personal settings  
     user settings in Cisco Unity Assistant [13-7](#)  
     user settings in Connection conversation [13-7](#)  
 Phone Interface Failed Logon report [41-1](#)  
 phone language, changing [14-6](#)  
 phone system  
     adding AXL servers [29-5](#)  
     adding integration [29-2](#)  
     changing AXL server settings [29-7](#)  
     changing settings [29-3](#)  
     deleting AXL servers [29-7](#)  
     deleting integration [29-2](#)  
     disabling the use of the same port for turning on and off an MWI [29-3](#)  
     list of users associated with [29-3](#)  
     synchronizing MWIs [29-4](#)  
 phone system trunk  
     changing settings [29-21](#)  
     deleting [29-21](#)  
     description [29-20](#)  
 Phone View [29-4, 31-1](#)  
 PIMG unit  
     adding [29-15](#)  
     changing settings [29-16](#)  
     deleting [29-15](#)  
 PIN policy [18-1](#)  
 plugins  
     application [3-1](#)  
     installing [38-1](#)  
     overview [38-1](#)

Port Activity report [41-2](#)

port group

- adding [29-8](#)
- changing advanced settings [29-16](#)
- changing AGC settings [29-17](#)
- changing settings [29-9](#)
- deleting [29-9](#)
- description [29-7](#)

port memory, disabling [29-3](#)

ports

- adding [29-17](#)
- adding SIP certificate [29-24](#)
- adding SIP security profile [29-25](#)
- changing settings [29-18](#)
- changing SIP certificate [29-24, 29-25](#)
- deleting [29-18](#)
- deleting SIP certificate [29-24](#)
- deleting SIP security profile [29-25](#)
- description [29-17](#)
- port certificate for Connection [29-20](#)
- root certificate for Connection [29-23](#)
- security [29-22](#)
- viewing root certificate for Connection [29-22](#)

prepended digits for extensions [6-10](#)

prerequisites

- Digital Networking [33-2](#)
- VPIM Networking [34-2](#)

private lists

- and Digital Networking [33-24](#)
- user settings in Cisco Unity Assistant [13-7](#)
- user settings in Connection conversation [13-7](#)

prompts

- overview [13-2](#)
- what you can change [13-2](#)

## Q

quotas, message handling when exceeded [19-11](#)

## R

recordings

- changing the audio format (or codec) for [16-2, 17-5, 19-4](#)
- configuring termination warning prompt [19-5](#)
- greetings and names [17-1](#)
- selecting device [17-2](#)

relay settings for private and secure messages [20-5](#)

Remote Administration Tools [3-8](#)

replication

- Digital Networking, checking status of [33-9](#)
- overview [33-20](#)
- suspended during bulk operations [33-25](#)
- with clusters [33-25](#)

reports

- archiving data [41-5](#)
- Call Handler Traffic [41-3](#)
- configuration parameters [41-4](#)
- Dial Plan [41-4](#)
- Dial Search Scope [41-4](#)
- Distribution Lists [41-2](#)
- generating and viewing [41-5](#)
- licenses [44-4](#)
- Mailbox Store [41-4](#)
- Message Traffic [41-2](#)
- Outcall Billing Detail [41-3](#)
- Outcall Billing Summary [41-3](#)
- overview [41-1](#)
- Phone Interface Failed Logon [41-1](#)
- Port Activity [41-2](#)
- Subscriber Message Activity [41-2](#)
- System Configuration [41-3](#)
- Transfer Call Billing [41-3](#)
- Unused Voice Mail Accounts [41-3](#)
- User Lockout [41-3](#)
- Users [41-1](#)

restriction tables

- creating [11-1](#)

- default [11-1](#)
- Default Fax [11-1](#)
- Default Outdial [11-1](#)
- Default System Transfer [11-1](#)
- Default Transfer [11-1](#)
- deleting [11-3](#)
- modifying [11-3](#)
- overview [4-6](#)
- root certificate
  - saving as file [29-23](#)
  - viewing [29-22](#)
- Route From Next Call Routing Rule action [4-5](#)
- RSS Feeds [19-20](#)

## S

- schedules and holidays
  - All Hours [10-1](#)
  - creating schedules [10-2](#)
  - default [10-1](#)
  - deleting schedules [10-3](#)
  - designating holidays [10-1](#)
  - Holidays [10-1](#)
  - modifying schedules [10-2](#)
  - overview [4-8](#)
  - Voice Recognition Update [10-1](#)
  - Weekdays [10-1](#)
- search spaces
  - and call handlers [28-7](#)
  - and call routing rules [28-6](#)
  - and digital networking [28-7](#)
  - and directory handlers [28-7](#)
  - and interview handlers [28-7](#)
  - and system contacts [28-8](#)
  - and system distribution lists [28-6](#)
  - and user objects [28-5](#)
  - and VPIM locations [28-8](#)
  - changing default [28-11](#)
  - configuring for Digital Networking [33-12](#)
  - creating [28-10](#)
  - default [28-2](#)
  - deleting [28-10](#)
  - example configurations [28-3](#)
  - finding objects in [28-11](#)
  - modifying [28-10](#)
  - overview [28-2](#)
  - securing Cisco PCA and IMAP client access to Cisco Unity Connection [25-1](#)
  - security
    - adding SIP certificate [29-24](#)
    - adding SIP security profile [29-25](#)
    - changing SIP certificate [29-24, 29-25](#)
    - controlling access, distribution, and storage of voice messages [24-1](#)
    - deleting SIP certificate [29-24](#)
    - deleting SIP security profile [29-25](#)
    - description for ports [29-22](#)
    - IMAP client [24-3](#)
    - policies [18-1](#)
    - port certificate [29-20](#)
    - relay settings for private and secure messages [20-5](#)
    - root certificate for Connection [29-23](#)
    - user and unidentified caller messages [24-1](#)
    - viewing root certificate for Connection [29-22](#)
  - service parameters
    - configuring for Cisco Unified Serviceability services [36-1](#)
    - descriptions [36-2](#)
    - for Cisco Unified Serviceability services [36-1](#)
  - Session Initiation Protocol (SIP), changing settings [29-16](#)
  - session timeout setting, Cisco Unity Connection Administration [2-1](#)
  - setting up
    - SMS (SMPP) message notifications [23-2](#)
    - SMTP message notifications [23-1](#)
  - sign-in conversation [14-8](#)
  - simulating abbreviated extensions [6-10](#)
  - SIP
    - adding SIP certificate [29-24](#)

- adding SIP security profile [29-25](#)
- changing SIP certificate [29-24, 29-25](#)
- deleting SIP certificate [29-24](#)
- deleting SIP security profile [29-25](#)
- SIP server
  - adding [29-13](#)
  - changing settings [29-14](#)
  - deleting [29-14](#)
- smart host, configuring for Digital Networking [33-10](#)
- SMS (SMPP) message notifications, setting up [23-2](#)
- SMTP
  - message notifications, setting up [23-1](#)
  - messages, overview [20-1](#)
- SSL certificate, using to secure Cisco PCA and IMAP client access to Cisco Unity Connection [25-1](#)
- Subscriber Information Dump. See Connection User Data Dump.
- Subscriber Message Activity report [41-2](#)
- synchronizing MWIs for phone system [29-4](#)
- Synch Users Tool, accessing [3-4](#)
- System Configuration report [41-3](#)
- System Directory Handler [7-1](#)
- system distribution lists
  - adding alternate names [27-4](#)
  - adding and removing members [27-3](#)
  - and Digital Networking [33-23](#)
  - creating [27-2](#)
  - default lists [27-1](#)
  - modifying [27-3, 27-4](#)
  - overview [27-1](#)
- system prompts
  - changing language [14-6](#)
  - customizing [13-2](#)
- system transfers, setting up [12-1](#)

---

## T

- Task Management tool, accessing [3-7](#)
- termination warning prompt, configuring [19-5](#)

- TFTP server
  - adding [29-12](#)
  - changing settings [29-13](#)
  - deleting [29-12](#)
- time-expiring license files, about [44-2](#)
- timeouts in Cisco Unity Connection Administration [2-1](#)
- TIMG unit
  - adding [29-15](#)
  - changing settings [29-16](#)
  - deleting [29-15](#)
- tools, Custom Keypad Mapping [15-1](#)
- Transfer Call Billing report [41-3](#)
- trunk, phone system
  - adding [29-21](#)
  - changing settings [29-21](#)
  - deleting [29-21](#)

---

## U

- Undeliverable Messages distribution list [27-2](#)
- UndeliverableMessagesMailbox user [19-6](#)
- unidentified caller messages [19-1](#)
- Unity, migrating from [3-2](#)
- Unity Connection Messaging System user [19-6](#)
- Unused Voice Mail Accounts report [41-3](#)
- user accounts, creating [ii-xix](#)
- User Lockout report [41-3](#)
- users
  - list of users associated with phone system [29-3](#)
  - migrating from Connection 1.x [3-6](#)
  - migrating from Connection 1.x using COBRAS (recommended) [3-2](#)
  - migrating from Unity [3-6](#)
  - migrating from Unity using COBRAS (recommended) [3-2](#)
  - Operator [19-6](#)
  - UndeliverableMessagesMailbox [19-6](#)
  - Unity Connection Messaging System [19-6](#)
  - user speech recognition conversation [13-3](#)

- Users report [41-1](#)
- user to user voice messages [19-2](#)
- user workstations, setting up [ii-xix](#)
- utilities and tools
  - Bulk Administration Tool [3-2](#)
  - Bulk Edit [3-3](#)
  - Cisco Unified Serviceability [3-8](#)
  - Cisco Voice Technology Group Subscription Tool [3-7](#)
  - Connection Administration [3-2](#)
  - Connection Serviceability [3-6](#)
  - Disaster Recovery System [3-7](#)
  - Grammar Statistics [3-4](#)
  - Import Users [3-4](#)
  - Migrate Messages [3-5](#)
  - Migrate Users [3-6](#)
  - plug-ins [3-1](#)
  - RTMT [3-7](#)
  - Synch Users [3-4](#)
  - Task Management [3-7](#)

## V

- ViewMail for Microsoft Outlook, integrated messaging example [20-2](#)
- voice commands, using [13-3](#)
- voice messages
  - delivery [19-9](#)
  - dispatch messages [19-6](#)
  - interviews [19-3](#)
  - live record [19-4](#)
  - notifications [19-3](#)
  - outside caller [19-1](#)
  - receipts [19-3](#)
  - system broadcast [19-2](#)
  - user to user [19-2](#)
- voice messaging port
  - adding [29-17](#)
  - changing settings [29-18](#)

- deleting [29-18](#)
- voice recognition
  - allowing users to say their voice mail passwords [14-10](#)
  - Grammar Statistics tool [3-4](#)
- Voice Recognition Update schedule [10-1](#)
- VPIM contacts
  - after creating [34-10](#)
  - correcting CSV errors for Bulk Administration Tool [34-8](#)
  - creating [34-6](#)
  - creating by using Bulk Administration Tool [34-8](#)
  - creating by using CSV files [34-7](#)
  - creating with Bulk Administration Tool [34-7](#)
  - creating with Connection Administration [34-9](#)
  - customizing directory update settings [34-11](#)
  - deleting [34-14](#)
- VPIM locations
  - adding alternate names [34-13](#)
  - and Digital Networking [33-24](#)
  - creating [34-6](#)
  - customizing [34-6](#)
- VPIM Networking
  - adding alternate names for VPIM locations [34-13](#)
  - adding VPIM contacts with Connection Administration [34-9](#)
  - addresses [34-17](#)
  - addressing options [34-17](#)
  - after creating VPIM contacts [34-10](#)
  - audio formats [34-18](#)
  - configuring remote voice messaging system [34-14](#)
  - creating VPIM contacts [34-6](#)
  - creating VPIM contacts with Bulk Administration Tool [34-7, 34-8](#)
  - creating VPIM locations [34-6](#)
  - customizing VPIM contact directory update settings [34-11](#)
  - customizing VPIM locations [34-6](#)
  - deleting VPIM contacts [34-14](#)
  - design decisions [34-3](#)

- DNS [34-4](#)
- messages [34-16](#)
- messaging similarities and limitations [34-17](#)
- overview [34-1](#)
- prerequisites [34-2](#)
- removing a VPIM location [34-15](#)
- resolving names with IP addresses [34-4](#)
- sample message [34-16](#)
- setting up [34-1](#)
- setup procedures [34-3](#)
- using CSV files for creating VPIM contacts [34-7](#)
- verifying connectivity with remote voice messaging system [34-5](#)

---

## W

- Wallet Card Wizard [3-10](#)
- warning prompt for end of recording, configuring [19-5](#)
- Weekdays schedule [10-1](#)

