



Changing Your Connection Conversation Menu Style

You can hear either full or brief menus when you interact with Cisco Unity Connection by using the phone keypad. Full menus provide comprehensive instructions, and brief menus provide abbreviated versions of full menus.

When you interact with Connection by using voice commands, you hear full menus.

This section contains two procedures. Do the applicable procedure, depending on whether you are using the phone keypad or voice commands.

To Change Your Connection Conversation Menu Style by Using the Phone Keypad

- Step 1** Call and log on to Connection.
 - Step 2** At the Main menu, choose the options **Setup Options > Message Settings > Menu Style**.
 - Step 3** Follow the prompts to switch between full and brief menus.
-

To Change Your Connection Conversation Menu Style by Using Voice Commands

- Step 1** Call and log on to Connection.
- Step 2** When Connection asks, “What do you want to do,” say:
“**Setup Options.**” (Connection temporarily switches to the phone keypad.)
- Step 3** On the phone keypad, choose the options **Message Settings > Menu Style**.
- Step 4** Follow the prompts to switch between full and brief menus.



Tip To switch back to using voice commands, keep pressing * until you hear the “Voice Command Conversation” prompt.

