



A

AAR

- explained [17-1](#)

abbreviated dial

- described [43-25](#)

access log [4-3](#)

access privileges

- roles [4-2](#)

ad hoc conference

- drop conference settings [24-7](#)

- initiating [24-6](#)

- Join softkey [24-7](#)

- limitations [24-9](#)

- SIP phone restrictions [24-8](#)

- using cBarge softkey [24-7](#)

- using conference softkey [24-6](#)

administrator

tools

- BAT [47-1](#)

- CAR [47-2](#)

- Cisco CallManager Serviceability [47-1](#)

- more information [47-3](#)

- overview [47-1](#)

admission control [5-13, 8-1](#)

alternate routing

- video [44-8](#)

analog telephony protocols

- CAS [40-5](#)

- described [40-3](#)

- E&M signaling [40-4](#)

- ground-start signaling [40-4](#)

- loop-start signaling [40-4](#)

- announcements [23-4](#)

- announcements (table) [23-4](#)

- annunciator [23-1](#)

- announcements [23-4](#)

- announcements (table) [23-4](#)

- configuration checklist (table) [23-6](#)

- dependency records [23-5](#)

- more information [23-6](#)

- overview [23-1](#)

- planning configuration [23-2](#)

- system requirements and limitations [23-3](#)

- tones [23-4](#)

- troubleshooting [23-5](#)

- understanding [23-1](#)

- appliance [1-1](#)

application dial rules

- configuration design [19-1](#)

- configuration error checking [19-2](#)

application user

- associating devices [21-3](#)

- configuration checklist (table) [21-5](#)

- described [21-1, 21-2](#)

- more information [21-6](#)

audio quality [8-1](#)

automated alternate routing (AAR)

- dial prefix matrix example (table) [17-3](#)

- enable service parameter [17-3](#)

- example [17-2](#)

- explained [17-1](#)

- line/DN and AAR groups (table) [17-2](#)

autoregistration

- configuration checklist (table) [12-3](#)

- described [12-1](#)

more information [12-4](#)
 multiple protocol support [12-2](#)
 understanding [12-1](#)

B

balanced call processing
 explained [6-3](#)
 bandwidth
 allocation of [8-1](#)
 calculations for admission control [8-4](#)
 used by Cisco CallManager [5-7](#)
 used by codec types (table) [5-7](#)
 barge
 described [43-20](#)
 Basic Rate Interface (BRI) [40-6](#)
 BAT [47-1](#)
 Bulk Administration Tool (BAT) [47-1](#)
 buttons
 directories button [43-27](#)
 messages button [43-27](#)

C

call admission control [5-13](#)
 gatekeepers
 components [8-8](#)
 explained [8-6](#)
 in a distributed setting (figure) [8-7](#)
 locations
 explained [8-1](#)
 illustrated (figure) [8-2](#)
 more information [8-10, 9-22](#)
 overview [8-1](#)
 trunks [8-6](#)
 call completion, QSIG supplementary service, see Cisco Call Back
 call control [22-2](#)

call coverage
 call forwarding [17-10](#)
 described [17-10](#)
 hunting [17-10](#)
 maximum hunt timer [17-11](#)
 personal preferences [17-11](#)
 call detail records (CDRs)
 described [47-2](#)
 video [44-11](#)
 call diagnostics and voice quality metrics
 described [43-24](#)
 call display restrictions
 configuring in translation pattern [17-28](#)
 call diversion (forwarding), QSIG supplementary service [40-9](#)
 called party
 transformations [17-25](#)
 transformations settings [17-27](#)
 transformations settings (table) [17-27](#)
 caller identification
 restrictions [17-28](#)
 support for device control protocols (table) [17-33](#)
 support vs. device control protocols [17-32](#)
 types [17-28](#)
 call failure, avoiding [27-4](#)
 call forward
 described [17-10, 18-6, 43-20](#)
 in multiple voice-mail systems [29-5](#)
 multiple voice-mail systems examples [29-5](#)
 calling party
 presentation settings [17-28](#)
 restriction settings [17-28](#)
 transformations [17-25](#)
 transformations settings [17-25](#)
 transformations settings (table) [17-26, 17-29](#)
 calling search spaces
 dependency records [15-3](#)
 examples [15-2](#)
 explained [15-1](#)

- guidelines and tips [15-3](#)
 - list of topics [15-1](#)
 - more information [15-4](#)
 - search for phones [43-26](#)
- call park
 - described [43-21](#)
- call pickup
 - described [43-21](#)
- call pickup group
 - see features and services [34-1](#)
- call preservation
 - explained [11-4](#)
 - scenarios (table) [11-5](#)
- call processing
 - balanced load
 - explained [6-3](#)
 - by Cisco CallManager [2-2](#)
 - combined with redundancy (figure) [7-3](#)
- calls
 - making and receiving multiple per directory number [18-7](#)
 - on-hook call transfer [43-22](#)
 - video [44-2](#)
- call select
 - described [43-22](#)
- call transfer, QSIG supplementary service [40-10](#)
- call transfer using hookflash [29-6](#)
- call waiting
 - described [18-7](#)
- CAR
 - overview [47-2](#)
- Catalyst 4000
 - 4224 voice gateway switch [39-7](#)
 - access gateway module [39-7](#)
 - voice gateway modules [39-5](#)
- Catalyst 4224 Voice Gateway Switch [39-7](#)
- Catalyst 6000
 - Cisco Communication Media Module [39-7](#)
 - configuration illustrated (figure) [28-7](#)
 - described [28-10](#)
 - FXS analog interface module [39-6](#)
 - hookflash transfer [39-6](#)
 - T1/E1 line card [39-6](#)
 - voice gateway modules [39-5](#)
- Catalyst DSP
 - more information [28-10](#)
 - overview [28-1](#)
 - understanding [28-1](#)
- Catalyst MTP [28-2](#)
- Catalyst switches
 - 6000 family [28-10](#)
- CDR
 - described [47-2](#)
- CDR Analysis and Reporting (CAR) [47-2](#)
- centralized TFTP
 - master centralized TFTP [10-8](#)
 - overview [10-7](#)
- channel associated signaling (CAS) [39-1, 40-5](#)
- characters, special
 - configuring [17-15](#)
 - described (table) [17-16](#)
- Cisco Access Digital Trunk Gateways
 - DT-24+/DE-30+ [39-2](#)
- Cisco ATA 186
 - configuration checklist (table) [46-2](#)
 - connecting to Cisco CallManager [46-1](#)
 - more information [46-2](#)
- Cisco Call Back
 - described
- Cisco CallManager
 - additional documentation [1-2](#)
 - bandwidth usage [5-7](#)
 - becoming inactive [25-3, 27-5](#)
 - benefits [1-2](#)
 - call processing [2-2](#)
 - configuration, configuring [5-2](#)
 - configuring [5-2](#)
 - CTI redundancy [45-6](#)

- groups
 - configuring [5-3](#)
 - described [7-1](#)
 - illustrated (figure) [7-2](#)
- introduction [1-1](#)
- key features [1-2](#)
- more information [1-2](#)
- redundancy [7-1](#)
- server, configuring [5-1](#)
- supported voice codecs [5-7](#)
- voice mail connectivity [29-1](#)
- Cisco CallManager System Guide
 - conventions [xxv](#)
 - organization [xxiv](#)
 - related documentation [xxv](#)
- Cisco CallManager User Options [43-28](#)
- Cisco Communication Media Module (CMM) [39-7](#)
- Cisco Conference Bridge (WS-SVC-CMM) [24-3](#)
- Cisco DPA
 - illustrated (figure) [32-2](#)
 - integration overview [32-1](#)
 - more information [32-3](#)
- Cisco IAD2420 Integrated Access Device [39-4](#)
- Cisco IP Communicator
 - default phone button template [43-13](#)
 - described [43-8](#)
- Cisco IP Manager Assistant
 - softkey templates
 - described [43-15](#)
- Cisco IP Phone 7914 Expansion Module [43-4](#)
- Cisco IP Phones
 - 12 SP+, described [43-7](#)
 - 30 VIP, described [43-7](#)
 - 7905, described [43-5](#), [43-6](#)
 - 7910, described [43-5](#)
 - 7911, described [43-5](#)
 - 7912, described [43-4](#)
 - 7914, described [43-4](#)
 - 7920, described [43-4](#)
 - 7935, described [43-7](#)
 - 7936, described [43-6](#)
 - 7940, described [43-3](#)
 - 7941, described [43-3](#)
 - 7960, described [43-3](#)
 - 7961, described [43-3](#)
 - 7970, described [43-2](#)
 - 7971, described [43-2](#)
 - overview [43-1](#)
- Cisco IP Phone Services
 - configuration checklist (table) [35-3](#)
 - dependency records [35-3](#)
 - guidelines and tips [35-2](#)
 - more information [35-4](#)
 - overview [35-1](#)
 - understanding [35-1](#)
- Cisco IP SoftPhone [21-5](#)
- Cisco IP telephony
 - applications [2-2](#)
 - call processing [2-2](#)
 - clients [2-3](#)
 - components [2-1](#)
 - configuring system [3-1](#)
 - infrastructure [2-3](#)
 - more information [2-4](#)
 - network [2-3](#)
 - overview [2-1](#)
 - support [2-1](#)
- Cisco IP Video Phone
 - 7985, described [43-6](#)
- Cisco JTAPI
 - using user directory [21-1](#)
- Cisco Messaging Interface (CMI) [30-2](#)
- Cisco SIP endpoints
 - SIP profile [41-18](#)
- Cisco SIP IP Phones
 - models supported [43-7](#)
- Cisco TFTP service
 - alternate paths [10-8](#)

- configuration checklist (table) [10-9](#)
- list of topics [10-1](#)
- more information [10-10](#)
- overview [10-1](#)
- understanding [10-4](#)
- Cisco Unity
 - configuration checklist (table) [31-5](#)
 - connections with the phone system (figure) [31-2](#)
 - integrated mailbox configuration [31-4](#)
 - messaging integration
 - description [31-2](#)
 - overview [31-1](#)
 - more information [31-7](#)
 - system requirements [31-1](#)
- Cisco VG200 Voice Gateway [39-2](#)
- Cisco VG224 Analog Phone Gateway
 - configuring [39-4](#)
 - description [39-4](#)
- Cisco VG248 Analog Phone Gateway
 - configuring [39-2](#)
 - description [39-2](#)
 - gateway redundancy [39-14](#)
- closest-match routing [17-12](#)
- clusters
 - balanced call processing
 - explained [6-3](#)
 - communication between [6-2](#)
 - compared to groups [7-1](#)
 - described [6-1](#)
 - list of topics [6-1](#)
 - more information [6-4](#)
 - overview [6-1](#)
- CMI
 - redundancy
 - described [30-2](#)
 - illustrated (figure) [30-3](#)
- CMLocal date/time group [5-4](#)
- codecs
 - bandwidth used per call (table) [5-7](#)
 - G.711 [5-7](#)
 - G.723 [5-7](#)
 - G.729 [5-7](#)
 - GSM [5-7](#)
 - supported by Cisco CallManager [5-7](#)
 - video [44-2](#)
 - wideband [5-7](#)
- common phone profiles
 - described [43-19](#)
- communication
 - between clusters [6-2](#)
- communication protocols, gateway [39-9](#)
- compression of voice stream [28-3](#)
- Computer Telephony Integration (CTI) [45-1](#)
- conference
 - ad hoc
 - initiating [24-6](#)
 - limitations [24-9](#)
 - described [18-7](#)
 - meet me
 - limitations [24-9](#)
 - meet-me
 - initiating [24-9](#)
- conference bridge
 - ad hoc
 - described [24-6](#)
 - annunciator [24-4](#)
- Cisco IOS configuration settings (table) [24-4](#)
- configuration checklist (table) [24-11](#)
- dependency records [22-6, 24-9](#)
- meet-me
 - described [24-6](#)
- more information [24-11](#)
- overview [24-1](#)
- performance monitoring [24-10](#)
- troubleshooting [24-10](#)
- types in Cisco CallManager Administration [24-4](#)

conference devices

- Cisco Conference Bridge (WS-SVC-CMM), described [24-3](#)
- hardware
 - MTP WS-X6608 DSP service card [24-4](#)
- software, described [24-3](#)
- understanding [24-1](#)
- video, described [24-3](#)

conference list

- described [43-22](#)

conference routers

- described [24-2](#)

conferencing

- across an IP WAN [28-3](#)
- using Catalyst DSP [28-1](#)

configuration

- files for devices [11-2](#)
- settings
 - checklist (table) [5-16](#)
 - list of topics [5-1](#)

configuration checklist

- MGCP BRI [39-17](#)

connected party

- presentation settings [17-30](#)
- restriction settings [17-30](#)
- transformations settings (table) [17-31](#)

conventions [xxv](#)

counters

- video bridge [44-10](#)

CTI

- application failure [45-7](#)
- applications [45-1](#)
- configuration checklist (table) [45-8](#)
- controlled devices [45-3](#)
- CTIManager
 - described [45-2](#)
 - redundancy [45-7](#)
- dependency records [45-6](#)
- IP phones [45-3](#)

- list of topics [45-1](#)
- media termination points [45-2](#)
- more information [45-8](#)
- ports
 - described [43-8, 45-3](#)
- redundancy [7-4, 45-6](#)
- route points [45-3](#)
- super provider [45-5](#)
- user groups [45-5](#)
- user management [45-5](#)

D

date/time groups

- CMLocal [5-4](#)
- described [5-4](#)

DDI [17-13](#)

- configuring [17-18](#)
- explained (table) [17-18](#)

dependency records

- annunciator [23-5](#)
- calling search spaces [15-3](#)
- Cisco IP Phone Services [35-3](#)
- conference bridge [22-6, 24-9](#)
- CTI [45-6](#)
- directory numbers
 - described [18-8](#)
- gateways [39-13](#)
- MTP [27-6](#)
- partitions [15-3](#)
- phones
 - described [43-28](#)
- system-level settings [5-16](#)
- time periods [16-3](#)
- time schedules [16-3](#)
- transcoders [25-4](#)

device control protocols

- and caller identification support (table) [17-33](#)

device pools

- described [5-10, 11-3](#)
- search for phones [43-26](#)
- updating [5-11](#)

devices

- accessing TFTP server [10-6](#)
- associating to an application user [21-3](#)
- associating to an end user [21-4](#)
- associating with users [21-3](#)
- conference
 - Cisco Conference Bridge (WS-SVC-CMM) [24-3](#)
 - software [24-3](#)
 - understanding [24-1](#)
 - video [24-3](#)
- configuration files [11-2](#)
- CTI control [45-3](#)
- distributing for redundancy [7-3](#)
- firmware loads [11-2](#)
- identifying TFTP server [10-6](#)
- MTP
 - characteristics [27-4](#)
- support
 - list of topics [11-1](#)
 - more information [11-6](#)
- supported [11-1](#)
- transcoders
 - resetting [25-4](#)
- updating firmware loads [11-3](#)
- using Cisco TFTP [10-4](#)
- using DHCP [10-4](#)

DHCP

- alarms [13-4](#)
- and devices [10-4](#)
- DNS [13-2](#)
- migration [13-4](#)
- more information [13-4](#)
- server [13-1](#)
 - configuration process [13-2](#)
- TFTP [13-3](#)

dial plans

- accessing gateways [39-12](#)

dial rules

- more information [19-8](#)
- overview [19-1](#)

digital signal processor (DSP) [28-1](#)

digital telephony protocols

- BRI [40-6](#)
- described [40-5](#)
- E1 PRI [40-6](#)
- QSIG [40-6](#)
- T1 PRI [40-6](#)

digital trunk gateway

- DT-24+/DE-30+ [39-2](#)

digit analysis

- static
 - caveats [17-14](#)
 - configuration tip [17-13](#)
 - described [17-13](#)
 - example prior to static digit analysis [17-15](#)
 - explained [17-13](#)
 - IPMA example with static digit analysis [17-15](#)

directories button

- configuring [43-27](#)

directory

- access [20-3](#)
- access for Cisco IP telephony endpoints [20-5](#)
- configuration checklist (table) [20-6](#)
- extension mobility [21-4](#)
- LDAP [5-12](#)
- more information [20-7](#)
- overview [20-1](#)

directory lookup dial rules

- overview [19-3](#)

directory numbers

- active check box [18-5](#)
- call forward
 - busy trigger [18-6, 43-21](#)
 - no answer ring duration [18-6, 43-21](#)

- call forward information display [18-6, 43-21](#)
- characteristics [18-1](#)
- conference [18-7](#)
- configuration checklist (table) [18-9](#)
- dependency records
 - described [18-8](#)
- direct transfer [18-7](#)
- features [18-5](#)
 - call forward [18-6](#)
 - call waiting [18-7](#)
- find all directory numbers [18-8](#)
- join [18-7](#)
- making and receiving multiple calls [18-7](#)
- managing [18-5](#)
- more information [18-10](#)
- overview [18-1](#)
- search tips [18-8](#)
- shared line appearance [18-2](#)
- shared line appearance restrictions [18-4](#)
- transfer [18-7](#)
- update directory number of all devices sharing this line
 - check box [18-5](#)
- direct transfer
 - described [18-7, 43-22](#)
- discard digits instructions (DDI) [17-13](#)
 - configuring [17-18](#)
 - explained (table) [17-18](#)
- DNs
 - characteristics [18-1](#)
 - overview [18-1](#)
- document
 - conventions [xxv](#)
 - organization [xxiv](#)
- documentation
 - related [xxv](#)
- DPA 7630/7610
 - functionality [32-2](#)
 - illustrated (figure) [32-2](#)
 - purpose [32-2](#)

- understanding [32-1](#)
- using SMDI [32-2, 32-3](#)
- DSCP marking [44-8](#)

E

- E&M signaling
 - delay dial [40-4](#)
 - immediate start [40-4](#)
 - wink start [40-4](#)
- E1 CAS [40-5](#)
- E1 Primary Rate Interface (E1 PRI) [40-6](#)
- E1 Primary Rate Interface (PRI) [39-1](#)
- Effective Access Privileges For Overlapping User Groups
 - and Roles enterprise parameter [4-3](#)
- end user
 - associating devices [21-4](#)
 - configuration checklist (table) [21-5](#)
 - described [21-1, 21-2](#)
 - more information [21-6](#)
- enterprise parameters
 - described [5-15](#)
 - Effective Access Privileges For Overlapping User
 - Groups and Roles [4-3](#)
 - user groups [4-3](#)
- expansion module
 - Cisco IP Phone 7914 [43-4](#)
- extension mobility
 - described [36-1](#)
 - user device profile [21-4](#)
 - user directory [21-4](#)
- external route plan wizard
 - described [17-33](#)
 - generated route filters [17-34](#)
 - generated route groups [17-35](#)
 - generated route lists [17-35](#)
 - generated route patterns [17-36](#)

F

features

- call park [33-1](#)
- Cisco IP Manager Assistant [38-1](#)
- Cisco IP Phone Services [35-1](#)
- extension mobility
 - overview [36-1](#)
- music on hold (MOH) [26-1](#)
- phone features (table) [43-14](#)
- phone login
 - overview [36-1](#)

fields

- requiring route patterns (table) [17-17](#)

firmware loads

- described [11-2](#)
- updating [11-3](#)

Foreign Exchange Office (FXO) [39-1, 39-10, 40-3](#)Foreign Exchange Station (FXS) [39-1, 39-10, 40-3](#)FXO [39-1, 39-10, 40-3](#)FXS [39-1, 39-10, 40-3](#)

G
G.711 [5-7](#)G.723 [5-7](#)G.729 [5-7](#)

gatekeepers

- and call admission control (figure) [8-7](#)
- configuration checklist (table) [8-10](#)
- configuring [8-8](#)
- configuring in Cisco CallManager [8-9, 42-2](#)
- configuring on the router [8-8](#)
- described [8-6](#)

gateways

- Catalyst 4000 Access Gateway Module [39-7](#)
- Catalyst 4224 gateway [39-7](#)
- Catalyst 6000
 - configuration illustrated (figure) [28-7](#)

Catalyst 6000 FXS Analog Interface Module [39-6](#)Catalyst 6000 T1/E1 and Services Module [39-6](#)Cisco Communications Media Module [39-7](#)Cisco IOS H.323 devices [39-7](#)Cisco voice gateways [39-1](#)communication protocols (table) [39-9](#)configuration checklist (table) [39-16](#)dependency records [39-13](#)failover and fallback [39-13](#)H.323 devices list [39-7](#)models (table) [39-9](#)more information [39-18](#)overview [39-1](#)port types (table) [39-9](#)related to dial plans [39-12](#)

standalone

digital trunk [39-2](#)IAD2420 [39-4](#)VG200 voice [39-2](#)VG224 analog phone [39-4](#)VG248 analog phone [39-2](#)summary of voice gateways (table) [39-9](#)

trunk interfaces

table [39-9](#)

Global Directory

displaying with directories button [43-27](#)ground-start signaling [40-4](#)

groups, Cisco CallManager

compared to clusters [7-1](#)components of [7-1](#)configuring [5-3](#)illustrated (figure) [7-2](#)groups, date/time [5-4](#)GSM [5-7](#)

H

H.323

Cisco IOS gateways [39-7](#)

- clients [43-8](#)
 - gateways [39-7](#)
 - IOS gateway redundancy [39-14](#)
 - used in voice gateways [40-1](#)
 - video [44-4](#)
 - hookflash transfer [39-6](#)
 - hub-and-spoke topology [8-1](#)
 - hunting
 - described [17-10](#)
 - example [17-11](#)
 - maximum hunt timer [17-11](#)
 - personal preferences [17-11](#)
 - hunt lists
 - described [17-9](#)
 - hunt pilots
 - described [17-9](#)
 - wildcards [17-16](#)
-
- identification services
 - QSIG supplementary service, described [40-11](#)
 - immediate divert
 - described [43-23](#)
 - intercluster
 - communication [6-2](#)
 - voice mail [29-2](#)
 - internet
 - ecosystem [2-1](#)
 - introduction
 - to Cisco CallManager [1-1](#)
 - IP Phones, Cisco
 - 12 SP+ [43-7](#)
 - 30 VIP [43-7](#)
 - 7905 [43-5, 43-6](#)
 - 7910 [43-5](#)
 - 7911, described [43-5](#)
 - 7912, described [43-4](#)
 - 7914, described [43-4](#)
 - 7920, described [43-4](#)
 - 7935 [43-7](#)
 - 7936 [43-6](#)
 - 7940 [43-3](#)
 - 7941 [43-3](#)
 - 7960, described [43-3](#)
 - 7961, described [43-3](#)
 - 7970, described [43-2](#)
 - 7971, described [43-2](#)
 - 7985 [43-6](#)
 - features
 - abbreviated dial [43-25](#)
 - barge [43-20](#)
 - call diagnostics and voice quality metrics [43-24](#)
 - call forward [43-20](#)
 - call park [43-21](#)
 - call pickup [43-21](#)
 - call select [43-22](#)
 - conference list [43-22](#)
 - described [43-20](#)
 - direct transfer [43-22](#)
 - immediate divert [43-23](#)
 - join [43-23](#)
 - malicious call ID [43-23](#)
 - privacy [43-20](#)
 - quality report tool [43-23](#)
 - service URL [43-24](#)
 - speed dial [43-25](#)
 - overview [43-1](#)
 - supported models
 - described (table) [43-2](#)
 - listed [43-2](#)
 - IP Phone Services, Cisco
 - configuration checklist (table) [35-3](#)
 - guidelines and tips [35-2](#)
 - more information [35-4](#)
 - overview [35-1](#)
 - understanding [35-1](#)

IP SoftPhone, Cisco
 user directory [21-5](#)

IP telephony
 applications [2-2](#)
 call processing [2-2](#)
 clients [2-3](#)
 infrastructure [2-3](#)
 more information [2-4](#)
 network [2-3](#)
 overview [2-1](#)
 protocols
 more information [40-15](#)
 understanding [40-1](#)
 support [2-1](#)

J

join
 described [18-7, 43-23](#)

JTAPI
 using user directory [21-1](#)

L

LDAP
 described [5-12](#)
 directory
 more information [20-7](#)
 overview [20-1](#)

licensing
 alarms [14-3](#)
 migrating from 5.0(x) to 4.0(x) [14-3](#)
 more information [14-4](#)
 overview [14-1](#)
 splitting licenses [14-2](#)
 starting a license manager service [14-1](#)
 transferring licenses [14-4](#)

line groups
 described [17-8](#)
 load, firmware [11-2](#)
 load balancing
 distributing devices [7-3](#)
 explained [6-3](#)
 locations
 and call admission control (figure) [8-2](#)
 and regions [5-9](#)
 configuration checklist (table) [8-6, 9-11](#)
 described [8-1](#)
 interaction with regions [8-3](#)
 interaction with regions (figure) [8-4](#)
 used in admission control [8-1](#)
 video [44-8](#)
 loop-start signaling [40-4](#)

M

malicious call ID
 described [43-23](#)
 master centralized TFTP
 configuration tips [10-9](#)
 sending files to the master CTFTP server [10-8](#)
 maximum hunt timer [17-11](#)
 media control [22-2](#)
 Media Gateway Control Protocol (MGCP) [40-2](#)
 media resource group lists
 configuration checklist (table) [22-6](#)
 described [22-4](#)
 media resource groups
 configuration checklist (table) [22-6](#)
 described [22-3](#)
 media resource manager
 managing MTPs [27-2](#)
 using to manage transcoders [25-2](#)
 media resources
 call control [22-2](#)
 described [22-1](#)

- management [22-1](#)
 - media control [22-2](#)
 - media resource group lists [22-4](#)
 - media resource groups [22-3](#)
 - media termination point control [22-2](#)
 - more information [22-6](#)
 - music on hold control [22-3](#)
 - overview [22-1](#)
 - redundancy [7-4](#)
 - unicast bridge control [22-3](#)
 - media termination point (MTP) [27-1](#)
 - CTI [45-2](#)
 - media termination point control [22-2](#)
 - meet-me conference
 - limitations [24-9](#)
 - messages button [43-27](#)
 - message waiting
 - description [29-3](#)
 - indication [29-4](#)
 - messaging
 - Cisco Unity
 - integration description [31-2](#)
 - integration overview [31-1](#)
 - MGCP
 - described [40-2](#)
 - gateway redundancy [39-13](#)
 - gateways using [39-11](#)
 - MGCP BRI
 - configuring [39-17](#)
 - illustration of call flow [39-5](#)
 - MLPP
 - described [5-15](#)
 - modifying files [10-9](#)
 - MOH
 - described [26-1](#)
 - MOH control [22-3](#)
 - MTP
 - avoiding call failure/user alert [27-4](#)
 - Cisco CallManager becomes inactive [27-5](#)
 - configuration checklist (table) [27-7](#)
 - CTI [45-2](#)
 - dependency records [27-6](#)
 - device characteristics [27-4](#)
 - failover and fallback [27-5](#)
 - managing with media resource manager [27-2](#)
 - more information [27-7](#)
 - overview [27-1](#)
 - planning configuration [27-3](#)
 - resetting registered devices [27-6](#)
 - system requirements and limitations [27-5](#)
 - transcoding services [28-2](#)
 - types (table) [27-3](#)
 - understanding [27-1](#)
 - using transcoders [25-2](#)
 - WS-X6608 DSP service card [24-4](#)
 - multisite WAN
 - using centralized MTP transcoding (figure) [28-4](#)
 - music on hold (MOH)
 - described [26-1](#)
-
- ## N
- network
 - video [44-3](#)
-
- ## O
- on-hook call transfer [43-22](#)
 - organization [xxiv](#)
 - overview
 - of Cisco CallManager [1-1](#)
 - of dial rules [19-1](#)
 - of system configuration [3-1](#)

P

parameters

enterprise

described [5-15](#)

Effective Access Privileges For Overlapping User Groups and Roles [4-3](#)

service

described [5-15](#)

Maximum Phone FallBack Queue Depth [43-28](#)

Message Waiting Lamp Policy [29-4](#)

parameters, enterprise

user groups [4-3](#)

partitions

dependency records [15-3](#)

examples [15-2](#)

explained [15-1](#)

guidelines and tips [15-3](#)

list of topics [15-1](#)

more information [15-4](#)

name limitations [15-4](#)

path replacement

described [40-13](#)

performance monitoring counters

video [44-10](#)

personal preferences [17-11](#)

phone button templates

12 series, default template [43-12](#)

30 SP+, default template [43-12](#)

30 VIP, default template [43-12](#)

7902, default template [43-12](#)

7905 SCCP, default template [43-12](#)

7905 SIP, default template [43-12](#)

7910, default template [43-12](#)

7911 SCCP, default template [43-11](#)

7911 SIP, default template [43-12](#)

7912 SCCP, default template [43-11](#)

7912 SIP, default template [43-11](#)

7920, default template [43-11](#)

7940 SCCP, default template [43-11](#)

7940 SIP, default template [43-11](#)

7941 G-GE SCCP, default template [43-11](#)

7941 SCCP, default template [43-11](#)

7941 SIP, default template [43-11](#)

7960 SCCP, default template [43-11](#)

7960 SIP, default template [43-11](#)

7961 G-GE SCCP, default template [43-10](#)

7961 SCCP, default template [43-10](#)

7961 SIP, default template [43-10](#)

7970 SCCP, default template [43-10](#)

7970 SIP, default template [43-10](#)

7971 SCCP, default template [43-10](#)

7971 SIP, default template [43-10](#)

7985, default template [43-10](#)

analog phone, default template [43-13](#)

ATA 186, default template [43-13](#)

CN622, default template [43-13](#)

conference station 7935, default template [43-12](#)

conference station 7936, default template [43-12](#)

IP Communicator, default template [43-13](#)

IP-STE, default template [43-13](#)

ISDN BRI Phone, default template [43-13](#)

third-party SIP device, default template [43-13](#)

VGC phone, default template [43-12](#)

VGC Virtual, default template [43-12](#)

phone login

described [36-1](#)

phone NTP reference

configuring for SIP phones [5-4](#)

phones

administration tips [43-25](#)

associating with users [43-25](#)

button templates

default [43-9](#)

described [43-9](#)

guidelines [43-13](#)

listed by model (table) [43-10](#)

Cisco IP Phone 12 SP+ [43-7](#)

- Cisco IP Phone 30 VIP [43-7](#)
- Cisco IP Phone 7905 [43-5, 43-6](#)
- Cisco IP Phone 7910 [43-5](#)
- Cisco IP Phone 7911 [43-5](#)
- Cisco IP Phone 7912 [43-4](#)
- Cisco IP Phone 7914 [43-4](#)
- Cisco IP Phone 7920 [43-4](#)
- Cisco IP Phone 7935 [43-7](#)
- Cisco IP Phone 7936 [43-6](#)
- Cisco IP Phone 7940 [43-3](#)
- Cisco IP Phone 7941 [43-3](#)
- Cisco IP Phone 7960 [43-3](#)
- Cisco IP Phone 7961 [43-3](#)
- Cisco IP Phone 7970 [43-2](#)
- Cisco IP Phone 7971 [43-2](#)
- Cisco IP Phone Services [35-1](#)
- common phone profiles [43-19](#)
- dependency records
 - described [43-28](#)
- directories button [43-27](#)
- failover and fallback [43-29](#)
- features
 - abbreviated dial [43-25](#)
 - barge [43-20](#)
 - call diagnostics and voice quality metrics [43-24](#)
 - call park [43-21](#)
 - call pickup [43-21](#)
 - call select [43-22](#)
 - conference list [43-22](#)
 - described (table) [43-14](#)
 - descriptions [43-20](#)
 - direct transfer [43-22](#)
 - immediate divert [43-23](#)
 - join [43-23](#)
 - malicious call ID [43-23](#)
 - privacy [43-20](#)
 - quality report tool [43-23](#)
 - service URL [43-24](#)
 - speed dial [43-25](#)
 - find all phones [43-27](#)
 - messages button [43-27](#)
 - methods for adding [43-19](#)
 - more information [43-33](#)
 - on-hook call transfer [43-22](#)
 - overview [43-1](#)
 - SCCP configuration checklist (table) [43-29](#)
 - search by authentication string [43-26](#)
 - search by calling search space [43-26](#)
 - search by call pickup group [43-26](#)
 - search by description [43-26](#)
 - search by device name [43-26](#)
 - search by device pool [43-26](#)
 - search by device protocol [43-26](#)
 - search by device type [43-26](#)
 - search by directory number [43-26](#)
 - search by LSC status [43-26](#)
 - search by security profile [43-26](#)
 - search tips [43-25](#)
 - search within results [43-27](#)
 - SIP configuration checklist (table) [43-29](#)
 - softkey templates
 - add application [43-16](#)
 - configure softkey layout [43-16](#)
 - described [43-15](#)
 - supported models
 - described (table) [43-2](#)
 - listed [43-2](#)
- PLAR
 - for Cisco SIP phones [41-17](#)
- ports
 - configuring for SMDI [30-2](#)
- CTI
 - described [43-8](#)
- presentation settings
 - calling party [17-28](#)
 - connected party [17-30](#)
- preservation of calls
 - explained [11-4](#)

- scenarios (table) [11-5](#)
- privacy
 - described [43-20](#)
- private line automatic ringdown
 - for Cisco SIP phones [41-17](#)
 - SIP dial rules [19-7](#)
- privileges
 - roles [4-2](#)
- profiles
 - common phone [43-19](#)
- protocols
 - analog telephony [40-3](#)
 - H.323 [29-2, 40-1](#)
 - MGCP [40-2](#)
 - Session Initiation Protocol (SIP) [40-3](#)
 - Skinnny Client Control Protocol [39-3, 40-2](#)
 - Skinnny Client Control Protocol (SCCP) Gateway Protocol [39-13](#)
 - Skinnny Gateway Protocol [39-12](#)

Q

- QSIG [39-1, 39-10](#)
 - Annex M.1 [40-7](#)
 - basic call feature [40-8](#)
 - basic call setup [40-8](#)
 - call completion [40-8](#)
 - call diversion (rerouting) [40-9](#)
 - CallManager interface [40-14](#)
 - call transfer [40-10](#)
 - compatibility with older versions (ECMA) [40-10](#)
 - facility selection and reservation [40-11](#)
 - identification services [40-11](#)
 - message tunneling [40-7](#)
 - message waiting indication (MWI) service [40-13](#)
 - overview [40-6](#)
 - path replacement [40-13](#)
 - supplementary services
 - call diversion (forwarding) [40-9](#)

- Q signaling (QSIG) [39-1, 40-6](#)
- QSIG protocol
 - supplementary services
 - call completion (Cisco Call Back), described
 - call transfer [40-10](#)
 - identification [40-11](#)
 - path replacement [40-13](#)
- QSIG trunk interface [39-1](#)
- quality of sound [8-1](#)
- quality report tool
 - described [43-23](#)

R

- redundancy
 - and distributed call processing (figure) [7-3](#)
 - Cisco CallManager [45-6](#)
 - Cisco VG248 [39-14](#)
 - CMI
 - described [30-2](#)
 - illustrated (figure) [30-3](#)
 - CTI [45-6](#)
 - CTIManager [45-7](#)
 - IOS H.323 gateways [39-14](#)
 - list of topics [7-1](#)
 - MGCP gateway [39-13](#)
 - more information [7-4](#)
 - of CTI [7-4](#)
 - of media resources [7-4](#)
 - support for gateways [39-13](#)
 - types of [7-1](#)
 - with distributed call processing [7-3](#)
- regions
 - and call admission control [5-9](#)
 - and locations [5-9](#)
 - described [5-5](#)
 - example (figure) [5-9](#)
 - interaction with locations [8-3](#)
 - interaction with locations (figure) [8-4](#)

- used with admission control [8-3](#)
- used with admission control (figure) [8-4](#)
- video [44-7](#)
- related documentation [xxv](#)
- requirements
 - Cisco Unity [31-1](#)
- restriction settings
 - calling party [17-28](#)
 - connected party [17-30](#)
- roles
 - access privileges [4-2](#)
 - described [4-1, 4-2](#)
 - more information [4-4](#)
 - overview [4-1](#)
 - standard [4-4](#)
- route filters
 - associated with route lists (table) [17-34](#)
 - described [17-34](#)
- route groups
 - described [17-5](#)
 - generated [17-35](#)
 - related to dial plans [39-12](#)
- route lists
 - associated route filters (table) [17-34](#)
 - described [17-5](#)
 - generated [17-35](#)
 - types (table) [17-36](#)
 - types, example [17-5](#)
- route patterns
 - closest-match routing [17-12](#)
 - considerations for using [17-6](#)
 - explained [17-6](#)
 - fields in Cisco CallManager (table) [17-17](#)
 - generated with external route plan wizard [17-36](#)
 - usage [17-6](#)
 - using the @ wildcard character [17-12](#)
 - wildcards [17-16](#)
- route plans
 - and Cisco Analog Access Gateways (figure) [17-8](#)

- and Cisco Digital Access Gateways (figure) [17-7](#)

- external route plan wizard
 - generated route filters [17-34](#)
 - generated route groups [17-35](#)
 - generated route lists [17-35](#)
 - generated route patterns [17-36](#)
- list of topics [17-1](#)
- more information [17-37](#)
- overview [17-4](#)
- report [17-37](#)

- routers
 - conference
 - hardware [24-2](#)
- routing
 - automated alternate [17-1](#)
 - closest-match [17-12](#)
 - time-of-day [16-1](#)
 - dependency records [16-3](#)
 - for end users [16-2](#)
 - more information [16-3](#)
 - time periods [16-1](#)
 - time schedules [16-2](#)
 - understanding [16-1](#)

S

- SCCP auto-registration [12-2](#)
- search
 - by authentication string [43-26](#)
 - by calling search space [43-26](#)
 - by call pickup group [43-26](#)
 - by description [43-26](#)
 - by device name [43-26](#)
 - by device pool [43-26](#)
 - by device protocol [43-26](#)
 - by device type [43-26](#)
 - by directory number [18-8, 43-26](#)
 - by LSC status [43-26](#)
 - by security profile [43-26](#)

- for all directory numbers in the database [18-8](#)
- for all phones in the database [43-27](#)
- for directory numbers [18-8](#)
- for phones [43-25](#)
- within results [43-27](#)
- security profile
 - search for phones [43-26](#)
- server, Cisco CallManager
 - configuring [5-1](#)
- Serviceability
 - and video [44-10](#)
- service parameters
 - Automated Alternate Routing Enable [17-3](#)
 - described [5-15](#)
 - Maximum Phone FallBack Queue Depth [43-28](#)
 - Message Waiting Lamp Policy [29-4](#)
- service URL
 - described [43-24](#)
- Session Initiation Protocol (SIP)
 - understanding [41-1](#)
- settings
 - called party transformations
 - configuring [17-27](#)
 - explained (table) [17-27](#)
 - calling party transformations
 - explained (table) [17-26, 17-29](#)
 - configuring
 - checklist (table) [5-16](#)
 - described [5-1](#)
 - connected party transformations
 - explained (table) [17-31](#)
 - special characters [17-15](#)
- shared line appearance
 - active check box [18-5](#)
 - described [18-2](#)
 - restrictions [18-4](#)
 - update directory number of all devices sharing this line
 - check box [18-5](#)
- Simplified Message Desk Interface (SMDI) [29-2, 30-1](#)
- SIP
 - 3PCC [41-15](#)
 - ad hoc conference settings [24-8](#)
 - basic calls [41-6](#)
 - call identification services [41-9](#)
 - Cisco CallManager support for Cisco SIP endpoints [41-14](#)
 - Cisco IP Phones [43-7](#)
 - configuration checklist (table) [41-12](#)
 - description of Cisco CallManager and SIP [41-2](#)
 - diversion header [41-15](#)
 - DTMF Relay calls [41-6](#)
 - functions and features in Cisco CallManager [41-5](#)
 - join header [41-16](#)
 - more information [41-19](#)
 - networking [41-1](#)
 - protocol [40-3](#)
 - REFER [41-15](#)
 - remotecc [41-16](#)
 - remote party ID (RPID) header [41-15](#)
 - replaces and referred-by headers [41-15](#)
 - replaces header [41-16](#)
 - RFC3261 [41-15](#)
 - RFC3262 [41-15](#)
 - RFC3264 [41-15](#)
 - RFC3265 + dialog package [41-16](#)
 - RFC3265 + KPML package [41-16](#)
 - RFC3265 + presence package [41-16](#)
 - RFC3265 + RFC3842 MWI package [41-16](#)
 - RFC3311 [41-15](#)
 - RFC3514 [41-15](#)
 - RNDIS [41-11](#)
 - service parameters [41-3](#)
 - supplementary services [41-8](#)
 - understanding [41-1](#)
 - using MTP devices [41-3](#)
- SIP autoregistration [12-2](#)
- SIP dial rules
 - dial rule parameters [19-5](#)

- dial rule patterns [19-4](#)
- overview [19-4](#)
- PLAR [19-7](#)
- SIP endpoints
 - overview [41-13](#)
- SIP phone
 - default phone button template (advanced) [43-13](#)
 - default phone button template (basic) [43-13](#)
 - NTP reference [5-4](#)
 - PLAR [41-17](#)
- SIP profile
 - Cisco SIP endpoints [41-18](#)
 - SIP trunks [41-5](#)
- SIP standards
 - Cisco endpoints [41-14](#)
- SIP trunks
 - SIP profile [41-5](#)
- Skinnny Client Control Protocol [39-3, 40-2](#)
- Skinnny Client Control Protocol (SCCP) Gateway Protocol [39-13](#)
- Skinnny Gateway Protocol [39-12](#)
- SMDI
 - configuration checklist (table) [30-4](#)
 - integration requirements [30-1](#)
 - migration with DPA 7630/7610 [32-2, 32-3](#)
 - more information [30-5](#)
 - port configuration [30-2](#)
 - PSTN gateway interfaces [29-2](#)
 - voice mail integration [29-2, 30-1](#)
- softkey templates
 - call states described (table) [43-17](#)
 - layout (figure) [43-18](#)
 - operation [43-18](#)
- softphone [43-8](#)
- SoftPhone, Cisco IP [21-5](#)
- sound quality [8-1](#)
- special characters
 - configuring [17-15](#)
 - described (table) [17-16](#)
 - explained [17-16](#)
- speed dial
 - described [43-25](#)
- standard roles [4-4](#)
- standards
 - SIP [41-14](#)
- standard user groups [4-4](#)
- static digit analysis
 - caveats [17-14](#)
 - configuration tip [17-13](#)
 - described [17-13](#)
 - example prior to static digit analysis [17-15](#)
 - explained [17-13](#)
 - IPMA example with static digit analysis [17-15](#)
- supported devices [11-1](#)
- system configuration
 - for complete IP telephony system
 - overview [3-1](#)
 - overview checklist (table) [3-1](#)
 - more information [3-4](#)
 - overview [3-1](#)
- system-level configuration settings [5-1](#)

T

- T1 CAS [40-5](#)
- T1 Primary Rate Interface (PRI) [39-1](#)
- T1 Primary Rate Interface (T1 PRI) [40-6](#)
- templates, phone button
 - 12 series, default [43-12](#)
 - 30 SP+, default [43-12](#)
 - 30 VIP, default [43-12](#)
 - 7902, default [43-12](#)
 - 7905 SCCP, default [43-12](#)
 - 7905 SIP, default [43-12](#)
 - 7910, default [43-12](#)
 - 7911 SCCP, default [43-11](#)
 - 7911 SIP, default [43-12](#)
 - 7912 SCCP, default [43-11](#)

- 7912 SIP, default [43-11](#)
- 7920, default [43-11](#)
- 7940 SCCP, default [43-11](#)
- 7940 SIP, default [43-11](#)
- 7941 G-GE SCCP, default [43-11](#)
- 7941 SCCP, default [43-11](#)
- 7941 SIP, default [43-11](#)
- 7960 SCCP, default [43-11](#)
- 7960 SIP, default [43-11](#)
- 7961 G-GE SCCP, default [43-10](#)
- 7961 SCCP, default [43-10](#)
- 7961 SIP, default [43-10](#)
- 7970 SCCP, default [43-10](#)
- 7970 SIP, default [43-10](#)
- 7971 SCCP, default [43-10](#)
- 7971 SIP, default [43-10](#)
- 7985, default [43-10](#)
- analog phone, default [43-13](#)
- ATA 186, default [43-13](#)
- CN622, default [43-13](#)
- conference station 7935, default [43-12](#)
- conference station 7936, default [43-12](#)
- default [43-9](#)
- described [43-9](#)
- guidelines [43-13](#)
- IP Communicator, default [43-13](#)
- IP-STE, default [43-13](#)
- ISDN BRI phone, default [43-13](#)
- listed by model (table) [43-10](#)
- third-party SIP device, default [43-13](#)
- VGC phone, default [43-12](#)
- VGC Virtual, default [43-12](#)
- templates, softkey
 - add application [43-16](#)
 - configure softkey layout [43-16](#)
 - described [43-15](#)
 - layout (figure) [43-18](#)
 - operation [43-18](#)
- TFTP [10-8](#)
 - alternate paths [10-8](#)
 - centralized TFTP [10-7, 10-8, 10-9](#)
 - configuration checklist (table) [10-9](#)
 - configuration files [11-2](#)
 - configuring a backup or fallback server [10-7](#)
 - customizing files [10-9](#)
 - list of topics [10-1](#)
 - master centralized TFTP [10-8](#)
 - more information [10-10](#)
 - multiple cluster environment [10-7](#)
 - overview [10-1](#)
 - process overview for Cisco SIP IP phones [10-3](#)
 - process overview for SCCP devices [10-2](#)
 - server
 - accessing [10-6](#)
 - identifying [10-6](#)
 - understanding [10-4](#)
 - time-of-day routing [16-1](#)
 - dependency records [16-3](#)
 - for end users [16-2](#)
 - more information [16-3](#)
 - time periods [16-1](#)
 - time schedules [16-2](#)
 - understanding [16-1](#)
 - time periods
 - dependency records [16-3](#)
 - explained [16-1](#)
 - more information [16-3](#)
 - time schedules
 - dependency records [16-3](#)
 - explained [16-2](#)
 - more information [16-3](#)
 - time zones [5-4](#)
 - tones [23-4](#)
 - tools
 - administrator
 - BAT [47-1](#)
 - CAR [47-2](#)

- Cisco CallManager Serviceability [47-1](#)
 - more information [47-3](#)
 - overview [47-1](#)
 - transcoders
 - configuration checklist (table) [25-5](#)
 - dependency records [25-4](#)
 - failover and fallback [25-3](#)
 - managing with media resource manager [25-2](#)
 - more information [25-5](#)
 - overview [25-1](#)
 - performance monitoring [25-4](#)
 - resetting registered devices [25-4](#)
 - troubleshooting [25-4](#)
 - types in Cisco CallManager Administration [25-2](#)
 - understanding [25-1](#)
 - using as MTPs [25-2](#)
 - transcoding
 - centralized MTP and conferencing services (figure) [28-4](#)
 - IP-to-IP packet [28-3](#)
 - IP-to-IP packet across trunks [28-4](#)
 - IP-to-IP packet and voice compression [28-3](#)
 - using Catalyst DSP [28-1](#)
 - transfer
 - described [18-7](#)
 - on-hook [43-22](#)
 - transformations
 - called party [17-25](#)
 - calling party [17-25](#)
 - translation patterns
 - and called party transformations settings [17-27](#)
 - and calling party presentation and restriction settings [17-28](#)
 - and calling party presentation settings (table) [17-29](#)
 - and connected party presentation and restriction settings [17-30](#)
 - and connected party presentation settings (table) [17-31](#)
 - and route plan report [17-37](#)
 - use for failover [17-13](#)
 - Trivial File Transfer Protocol (TFTP) [10-1](#)
 - troubleshooting
 - annunciator [23-5](#)
 - trunk interfaces
 - BRI [40-6](#)
 - E1 CAS [40-5](#)
 - E1 PRI [39-1, 40-6](#)
 - FXO [39-1, 40-3](#)
 - FXS [39-1, 40-3](#)
 - QSIG [39-1, 40-6](#)
 - signaling
 - E&M [40-4](#)
 - ground start [40-4](#)
 - loop start [40-4](#)
 - T1 CAS [39-1, 40-5](#)
 - T1 PRI [39-1, 40-6](#)
 - trunks
 - associated route groups [42-6](#)
 - configuration [42-1](#)
 - configuration checklist (table) [8-10, 42-6](#)
 - configuring in Cisco CallManager [8-9, 42-2](#)
 - configuring on the router [8-8](#)
 - dependency records [42-6](#)
 - described [8-6](#)
 - gatekeeper controlled [42-2](#)
 - H.225 gatekeeper controlled [42-3](#)
 - intercluster gatekeeper controlled [42-3](#)
 - intercluster non-gatekeeper controlled [42-3](#)
 - more information [42-7](#)
 - non-gatekeeper controlled [42-2](#)
 - overview [42-1](#)
 - SIP [42-3](#)
-
- ## U
- unicast bridge control [22-3](#)
 - Unity, Cisco
 - configuration checklist (table) [31-5](#)
 - connections with the phone system (figure) [31-2](#)
 - integrated mailbox configuration [31-4](#)

- integration description [31-2](#)
- messaging integration [31-1](#)
- more information [31-7](#)
- system requirements [31-1](#)
- user
 - application
 - associating devices [21-3](#)
 - configuration checklist (table) [21-5](#)
 - described [21-1, 21-2](#)
 - more information [21-6](#)
 - configure phone features [43-28](#)
 - end
 - associating devices [21-4](#)
 - configuration checklist (table) [21-5](#)
 - described [21-1, 21-2](#)
 - more information [21-6](#)
- user alert, avoiding [27-4](#)
- user directory
 - extension mobility [21-4](#)
 - IP SoftPhone, Cisco [21-5](#)
- user groups
 - CTI [45-5](#)
 - described [4-1, 4-3](#)
 - enterprise parameters [4-3](#)
 - more information [4-4](#)
 - overview [4-1](#)
 - standard [4-4](#)
- user management
 - CTI [45-5](#)
- user options
 - Cisco CallManager User Options [43-28](#)
- call details records [44-11](#)
- calls [44-2](#)
- codecs [44-2](#)
- conference devices [24-3](#)
- configuration checklist (table) [44-12](#)
- DSCP marking [44-8](#)
- H.323 [44-4](#)
- locations [44-8](#)
- more information [44-13](#)
- network [44-3](#)
- other configuration [44-9](#)
- performance monitoring counters [44-10](#)
- phone configuration [44-8](#)
- regions [44-7](#)
- Skinny Client Control Protocol [44-6](#)
- Skinny Client Control Protocol bridging [44-6](#)
- understanding [44-1](#)
- video phones
 - Cisco IP Phone 7985 [43-6](#)
- voice codecs
 - bandwidth used per call (table) [5-7](#)
 - G.711 [5-7](#)
 - G.723 [5-7](#)
 - G.729 [5-7](#)
 - GSM [5-7](#)
 - supported by Cisco CallManager [5-7](#)
 - wideband [5-7](#)
- voice compression [28-3](#)
- voice gateways, see gateways
- voice mail
 - access [29-2](#)
 - gateway-based [29-2](#)
 - call forwarding
 - intercluster trunk, example [29-6](#)
 - intracluster trunk, examples [29-5](#)
 - call forwarding in multiple systems [29-5](#)
 - call transfer [29-6](#)
 - configuration
 - message waiting indication [29-4](#)

V

video

- alternate routing [44-8](#)
- and Serviceability [44-10](#)
- bandwidth management [44-7](#)
- bridge counters [44-10](#)

- message-waiting indication policy [29-4](#)
- more information [29-6](#)
- configuring messages button [43-27](#)
- connectivity
 - more information [29-6](#)
- connectivity to Cisco CallManager [29-1](#)
- gateway-based [29-2](#)
- interfaces [29-1](#)
 - intercluster [29-2](#)
 - PSTN gateway [29-2](#)
 - Skippy Protocol [29-1](#)
- message waiting configuration [29-3](#)
- pilot numbers [29-3](#)
- profiles [29-3](#)
- SMDI
 - configuration checklist (table) [30-4](#)
 - integration [30-1](#)
 - requirements for integration [30-1](#)
- voice messaging, see voice mail
- voice quality [8-1](#)

W

- wideband [5-7](#)
- wildcards
 - described (table) [17-16](#)
 - for hunt pilots [17-16](#)
 - for route patterns [17-16](#)
 - using @ in route patterns [17-12](#)