



A

AAR

explained [17-1](#)

abbreviated dial

described [43-25](#)

access log [4-3](#)

access privileges

roles [4-2](#)

ad hoc conference

drop conference settings [24-7](#)

initiating [24-6](#)

Join softkey [24-7](#)

limitations [24-9](#)

SIP phone restrictions [24-8](#)

using cBarge softkey [24-7](#)

using conference softkey [24-6](#)

administrator

tools

BAT [47-1](#)

CAR [47-2](#)

Cisco Unified CallManager Serviceability [47-1](#)

more information [47-3](#)

overview [47-1](#)

admission control [5-13, 8-1](#)

alternate routing

video [44-8](#)

analog telephony protocols

CAS [40-5](#)

described [40-3](#)

E&M signaling [40-4](#)

ground-start signaling [40-4](#)

loop-start signaling [40-4](#)

announcements [23-4](#)

announcements (table) [23-4](#)

annunciator [23-1](#)

announcements [23-4](#)

announcements (table) [23-4](#)

configuration checklist (table) [23-6](#)

dependency records [23-5](#)

more information [23-6](#)

overview [23-1](#)

planning configuration [23-2](#)

system requirements and limitations [23-3](#)

tones [23-4](#)

troubleshooting [23-5](#)

understanding [23-1](#)

appliance [1-1](#)

application dial rules

configuration design [19-1](#)

configuration error checking [19-2](#)

application user

associating devices [21-3](#)

configuration checklist (table) [21-5](#)

described [21-1, 21-2](#)

more information [21-6](#)

audio quality [8-1](#)

automated alternate routing (AAR)

dial prefix matrix example (table) [17-3](#)

enable service parameter [17-3](#)

example [17-2](#)

explained [17-1](#)

line/DN and AAR groups (table) [17-2](#)

autoregistration

configuration checklist (table) [12-3](#)

described [12-1](#)

more information [12-4](#)
 multiple protocol support [12-2](#)
 understanding [12-1](#)

B

balanced call processing
 explained [6-3](#)
 bandwidth
 allocation of [8-1](#)
 calculations for admission control [8-4](#)
 used by Cisco Unified CallManager [5-7](#)
 used by codec types (table) [5-8](#)
 barge
 described [43-20](#)
 Basic Rate Interface (BRI) [40-6](#)
 BAT [47-1](#)
 Bulk Administration Tool (BAT) [47-1](#)
 buttons
 directories button [43-28](#)
 messages button [43-27](#)

C

call admission control [5-13](#)
 gatekeepers
 components [8-8](#)
 explained [8-6](#)
 in a distributed setting (figure) [8-7](#)
 locations
 explained [8-2](#)
 illustrated (figure) [8-2](#)
 more information [8-10, 9-23](#)
 overview [8-1](#)
 trunks [8-6](#)
 call completion, QSIG supplementary service
 See Cisco Call Back
 call control [22-2](#)

call coverage
 call forwarding [17-10](#)
 described [17-10](#)
 hunting [17-10](#)
 maximum hunt timer [17-11](#)
 personal preferences [17-11](#)
 call detail records (CDRs)
 described [47-2](#)
 video [44-11](#)
 call diagnostics and voice quality metrics
 described [43-24](#)
 call display restrictions
 configuring in translation pattern [17-28](#)
 call diversion (forwarding), QSIG supplementary service [40-9](#)
 called party
 transformations [17-25](#)
 transformations settings [17-27](#)
 transformations settings (table) [17-27](#)
 caller identification
 restrictions [17-28](#)
 support for device control protocols (table) [17-33](#)
 support vs. device control protocols [17-32](#)
 types [17-28](#)
 call failure, avoiding [27-4](#)
 call forward
 described [17-10, 18-6, 43-20](#)
 in multiple voice-mail systems [29-5](#)
 multiple voice-mail systems examples [29-6](#)
 calling party
 presentation settings [17-28](#)
 restriction settings [17-28](#)
 transformations [17-25](#)
 transformations settings [17-25](#)
 transformations settings (table) [17-26, 17-29](#)
 calling search spaces
 dependency records [15-3](#)
 examples [15-2](#)
 explained [15-1](#)

- guidelines and tips [15-3](#)
 - list of topics [15-1](#)
 - more information [15-4](#)
 - search for phones [43-26](#)
- call park
 - described [43-21](#)
- call pickup
 - described [43-21](#)
- call pickup group
 - see features and services [34-1](#)
- call preservation
 - explained [11-4](#)
 - scenarios (table) [11-5](#)
- call processing
 - balanced load
 - explained [6-3](#)
 - by Cisco Unified CallManager [2-2](#)
 - combined with redundancy (figure) [7-3](#)
- calls
 - making and receiving multiple per directory number [18-7](#)
 - on-hook call transfer [43-23](#)
 - video [44-2](#)
- call select
 - described [43-22](#)
- call transfer, QSIG supplementary service [40-10](#)
- call transfer using hookflash [29-6](#)
- call waiting
 - described [18-7](#)
- CAR
 - overview [47-2](#)
- Catalyst 4000
 - 4224 voice gateway switch [39-7](#)
 - access gateway module [39-7](#)
 - voice gateway modules [39-5](#)
- Catalyst 4224 Voice Gateway Switch [39-7](#)
- Catalyst 6000
 - Cisco Communication Media Module [39-7](#)
 - configuration illustrated (figure) [28-7](#)
 - described [28-10](#)
 - FXS analog interface module [39-6](#)
 - hookflash transfer [39-6](#)
 - T1/E1 line card [39-6](#)
 - voice gateway modules [39-5](#)
- Catalyst DSP
 - more information [28-10](#)
 - overview [28-1](#)
 - understanding [28-1](#)
- Catalyst MTP [28-2](#)
- Catalyst switches
 - 6000 family [28-10](#)
- CDR
 - described [47-2](#)
- CDR Analysis and Reporting (CAR) [47-2](#)
- centralized TFTP
 - master centralized TFTP [10-8](#)
 - overview [10-7](#)
- channel associated signaling (CAS) [39-1, 40-5](#)
- characters, special
 - configuring [17-15](#)
 - described (table) [17-16](#)
- Cisco Access Digital Trunk Gateways
 - DT-24+/DE-30+ [39-2](#)
- Cisco ATA 186
 - configuration checklist (table) [46-2](#)
 - connecting to Cisco Unified CallManager [46-1](#)
 - more information [46-2](#)
- Cisco Call Back
 - described [40-8](#)
- Cisco Communication Media Module (CMM) [39-7](#)
- Cisco DPA
 - illustrated (figure) [32-2](#)
 - integration overview [32-1](#)
 - more information [32-3](#)
- Cisco IAD2420 Integrated Access Device [39-4](#)
- Cisco IP Communicator
 - default phone button template [43-13](#)
 - described [43-8](#)

- Cisco IP SoftPhone [21-5](#)
- Cisco Messaging Interface (CMI) [30-2](#)
- Cisco SIP endpoints
 - SIP profile [41-19](#)
- Cisco SIP IP Phones
 - default phone button template (advanced) [43-13](#)
 - default phone button template (basic) [43-13](#)
 - models supported [43-7](#)
- Cisco TFTP service
 - alternate paths [10-8](#)
 - configuration checklist (table) [10-9](#)
 - list of topics [10-1](#)
 - more information [10-10](#)
 - overview [10-1](#)
 - understanding [10-4](#)
- Cisco Unified CallManager
 - additional documentation [1-3](#)
 - bandwidth usage [5-7](#)
 - becoming inactive [25-3, 27-5](#)
 - benefits [1-2](#)
 - call processing [2-2](#)
 - configuration, configuring [5-2](#)
 - configuring [5-2](#)
 - CTI redundancy [45-6](#)
 - groups
 - configuring [5-3](#)
 - described [7-1](#)
 - illustrated (figure) [7-2](#)
 - introduction [1-1](#)
 - key features [1-2](#)
 - more information [1-3](#)
 - redundancy [7-1](#)
 - server, configuring [5-1](#)
 - supported voice codecs [5-7](#)
 - voice mail connectivity [29-1](#)
- Cisco Unified CallManager Assistant
 - softkey templates
 - described [43-15](#)
- Cisco Unified CallManager Conference Bridge (WS-SVC-CMM) [24-3](#)
- Cisco Unified CallManager JTAPI
 - using user directory [21-1](#)
- Cisco Unified CallManager System Guide
 - conventions [xxv](#)
 - organization [xxiv](#)
 - related documentation [xxv](#)
- Cisco Unified CallManager User Options [43-28](#)
- Cisco Unified Communications
 - applications [2-2](#)
 - call processing [2-2](#)
 - clients [2-3](#)
 - components [2-1](#)
 - configuring system [3-1](#)
 - infrastructure [2-3](#)
 - more information [2-4](#)
 - network [2-3](#)
 - overview [2-1](#)
 - support [2-1](#)
- Cisco Unified IP Phones
 - See also* phones
 - 12 SP+, described [43-7](#)
 - 30 VIP, described [43-7](#)
 - 7902, described [43-6](#)
 - 7905, described [43-5](#)
 - 7910, described [43-5](#)
 - 7911, described [43-5](#)
 - 7912, described [43-4](#)
 - 7914 Expansion Module, described [43-4](#)
 - 7920, described [43-4](#)
 - 7935, described [43-7](#)
 - 7940, described [43-3](#)
 - 7941, described [43-3](#)
 - 7960, described [43-3](#)
 - 7961, described [43-3](#)
 - 7970, described [43-2](#)
 - 7971, described [43-2](#)
 - 7985, described [43-6](#)

- Cisco Unified IP Conference Station 7936,
 - described [43-6](#)
- directories button [43-28](#)
- features
 - abbreviated dial [43-25](#)
 - barge [43-20](#)
 - call diagnostics and voice quality metrics [43-24](#)
 - call forward [43-20](#)
 - call park [43-21](#)
 - call pickup [43-21](#)
 - call select [43-22](#)
 - conference list [43-22](#)
 - described [43-20](#)
 - direct transfer [43-22](#)
 - immediate divert [43-23](#)
 - join [43-23](#)
 - malicious call ID [43-23](#)
 - privacy [43-20](#)
 - quality report tool [43-23](#)
 - service URL [43-25](#)
 - speed dial [43-25](#)
- messages button [43-27](#)
- overview [43-1](#)
- supported models
 - described (table) [43-2](#)
 - listed [43-2](#)
- Cisco Unified IP Phone Services
 - configuration checklist (table) [35-3](#)
 - dependency records [35-3](#)
 - guidelines and tips [35-2](#)
 - more information [35-4](#)
 - overview [35-1](#)
 - understanding [35-1](#)
- Cisco Unity
 - configuration checklist (table) [31-5](#)
 - connections with the phone system (figure) [31-2](#)
 - integrated mailbox configuration [31-4](#)
 - messaging integration [31-1, 31-2](#)
 - more information [31-7](#)
 - system requirements [31-1](#)
- Cisco VG200 Voice Gateway [39-2](#)
- Cisco VG224 Analog Phone Gateway
 - configuring [39-4](#)
 - description [39-4](#)
- Cisco VG248 Analog Phone Gateway
 - configuring [39-2](#)
 - description [39-2](#)
 - gateway redundancy [39-14](#)
- closest-match routing [17-12](#)
- clusters
 - balanced call processing
 - explained [6-3](#)
 - communication between [6-2](#)
 - compared to groups [7-1](#)
 - described [6-1](#)
 - list of topics [6-1](#)
 - more information [6-4](#)
 - overview [6-1](#)
- CMI
 - redundancy
 - described [30-2](#)
 - illustrated (figure) [30-3](#)
- CMLocal date/time group [5-4](#)
- codecs
 - bandwidth used per call (table) [5-8](#)
 - G.711 [5-7](#)
 - G.723 [5-7](#)
 - G.729 [5-7](#)
 - GSM [5-7](#)
 - supported by Cisco Unified CallManager [5-7](#)
 - video [44-2](#)
 - wideband [5-7](#)
- common phone profiles
 - described [43-19](#)
- communication
 - between clusters [6-2](#)
- communication protocols, gateway [39-9](#)
- compression of voice stream [28-3](#)

Computer Telephony Integration (CTI) [45-1](#)

conference

ad hoc

initiating [24-6](#)limitations [24-9](#)described [18-7](#)

meet me

limitations [24-9](#)

meet-me

initiating [24-9](#)

conference bridge

ad hoc

described [24-6](#)annunciator [24-4](#)Cisco IOS configuration settings (table) [24-4](#)configuration checklist (table) [24-11](#)dependency records [22-6, 24-9](#)

meet-me

described [24-6](#)more information [24-11](#)overview [24-1](#)performance monitoring [24-10](#)troubleshooting [24-10](#)types in Cisco Unified CallManager
Administration [24-4](#)

conference devices

Cisco Unified CallManager Conference Bridge
(WS-SVC-CMM), described [24-3](#)

hardware

MTP WS-X6608 DSP service card [24-4](#)software, described [24-3](#)understanding [24-1](#)video, described [24-3](#)

conference list

described [43-22](#)

conference routers

described [24-2](#)

conferencing

across an IP WAN [28-3](#)using Catalyst DSP [28-1](#)

configuration

files for devices [11-2](#)

settings

checklist (table) [5-16](#)list of topics [5-1](#)

configuration checklist

MGCP BRI [39-18](#)

connected party

presentation settings [17-30](#)restriction settings [17-30](#)transformations settings (table) [17-31](#)conventions [xxv](#)

counters

video bridge [44-11](#)

CTI

application failure [45-7](#)applications [45-1](#)configuration checklist (table) [45-8](#)controlled devices [45-3](#)

CTIManager

described [45-2](#)redundancy [45-7](#)dependency records [45-6](#)IP phones [45-3](#)list of topics [45-1](#)media termination points [45-2](#)more information [45-9](#)

ports

described [43-8, 45-3](#)redundancy [7-4, 45-6](#)route points [45-3](#)super provider [45-5](#)user groups [45-5](#)user management [45-5](#)

D

date/time groups

CMLocal [5-4](#)

described [5-4](#)

DDI [17-13](#)

configuring [17-18](#)

explained (table) [17-18](#)

dependency records

annunciator [23-5](#)

calling search spaces [15-3](#)

Cisco Unified IP Phone Services [35-3](#)

conference bridge [22-6, 24-9](#)

CTI [45-6](#)

directory numbers

described [18-8](#)

gateways [39-13](#)

MTP [27-6](#)

partitions [15-3](#)

phones

described [43-29](#)

system-level settings [5-16](#)

time periods [16-3](#)

time schedules [16-3](#)

transcoders [25-4](#)

device control protocols

and caller identification support (table) [17-33](#)

device pools

described [5-10, 11-3](#)

search for phones [43-26](#)

updating [5-11](#)

devices

accessing TFTP server [10-6](#)

associating to an application user [21-3](#)

associating to an end user [21-4](#)

associating with users [21-3](#)

conference

Cisco Unified CallManager Conference Bridge
(WS-SVC-CMM) [24-3](#)

software [24-3](#)

understanding [24-1](#)

video [24-3](#)

configuration files [11-2](#)

CTI control [45-3](#)

distributing for redundancy [7-3](#)

firmware loads [11-2](#)

identifying TFTP server [10-6](#)

MTP

characteristics [27-4](#)

support

list of topics [11-1](#)

more information [11-6](#)

supported [11-1](#)

transcoders

resetting [25-4](#)

updating firmware loads [11-3](#)

using Cisco TFTP [10-4](#)

using DHCP [10-4](#)

DHCP

alarms [13-4](#)

and devices [10-4](#)

DNS [13-2](#)

migration [13-4](#)

more information [13-4](#)

server [13-1](#)

configuration process [13-3](#)

TFTP [13-3](#)

dial plans

accessing gateways [39-12](#)

dial rules

more information [19-8](#)

overview [19-1](#)

digital signal processor (DSP) [28-1](#)

digital telephony protocols

BRI [40-6](#)

described [40-5](#)

E1 PRI [40-6](#)

QSIG [40-6](#)

- T1 PRI [40-6](#)
 - digital trunk gateway
 - DT-24+/DE-30+ [39-2](#)
 - digit analysis
 - static
 - caveats [17-14](#)
 - configuration tip [17-13](#)
 - described [17-13](#)
 - example prior to static digit analysis [17-15](#)
 - explained [17-13](#)
 - Unified CallManager Assistant example with static digit analysis [17-15](#)
 - directories button
 - configuring [43-28](#)
 - directory
 - access [20-3](#)
 - access for Cisco IP telephony endpoints [20-5](#)
 - configuration checklist (table) [20-6](#)
 - extension mobility [21-4](#)
 - LDAP [5-12](#)
 - more information [20-7](#)
 - overview [20-1](#)
 - directory lookup dial rules
 - overview [19-3](#)
 - directory numbers
 - active check box [18-5](#)
 - call forward
 - busy trigger [18-6, 43-21](#)
 - no answer ring duration [18-6, 43-21](#)
 - call forward information display [18-6, 43-21](#)
 - characteristics [18-1](#)
 - conference [18-7](#)
 - configuration checklist (table) [18-9](#)
 - dependency records
 - described [18-8](#)
 - direct transfer [18-7](#)
 - features [18-6](#)
 - call forward [18-6](#)
 - call waiting [18-7](#)
 - find all directory numbers [18-8](#)
 - join [18-7](#)
 - making and receiving multiple calls [18-7](#)
 - managing [18-5](#)
 - more information [18-10](#)
 - overview [18-1](#)
 - search tips [18-8](#)
 - shared line appearance [18-2](#)
 - shared line appearance restrictions [18-4](#)
 - transfer [18-7](#)
 - update directory number of all devices sharing this line check box [18-5](#)
 - direct transfer
 - described [18-7, 43-22](#)
 - discard digits instructions (DDI) [17-13](#)
 - configuring [17-18](#)
 - explained (table) [17-18](#)
 - DNs
 - characteristics [18-1](#)
 - overview [18-1](#)
 - document
 - conventions [xxv](#)
 - organization [xxiv](#)
 - documentation
 - related [xxv](#)
 - DPA 7630/7610
 - functionality [32-2](#)
 - illustrated (figure) [32-2](#)
 - purpose [32-2](#)
 - understanding [32-1](#)
 - using SMDI [32-2, 32-3](#)
 - DSCP marking [44-8](#)
-
- ## E
- E&M signaling
 - delay dial [40-4](#)
 - immediate start [40-4](#)
 - wink start [40-4](#)

- E1 CAS [40-5](#)
- E1 Primary Rate Interface (E1 PRI) [40-6](#)
- E1 Primary Rate Interface (PRI) [39-1](#)
- Effective Access Privileges For Overlapping User Groups and Roles enterprise parameter [4-3](#)
- end user
 - associating devices [21-4](#)
 - configuration checklist (table) [21-5](#)
 - described [21-1, 21-2](#)
 - more information [21-6](#)
- enterprise parameters
 - described [5-15](#)
 - Effective Access Privileges For Overlapping User Groups and Roles [4-3](#)
 - user groups [4-3](#)
- expansion module
 - Cisco Unified IP Phone 7914 [43-4](#)
- extension mobility
 - described [36-1](#)
 - user device profile [21-4](#)
 - user directory [21-4](#)
- external route plan wizard
 - described [17-33](#)
 - generated route filters [17-34](#)
 - generated route groups [17-35](#)
 - generated route lists [17-35](#)
 - generated route patterns [17-36](#)

F

- features
 - call park [33-1](#)
 - Cisco Unified CallManager Assistant [38-1](#)
 - Cisco Unified IP Phone Services
 - extension mobility
 - overview [36-1](#)
 - music on hold (MOH) [26-1](#)
 - phone features (table) [43-14](#)

- phone login
 - overview [36-1](#)
- fields
 - requiring route patterns (table) [17-17](#)
- firmware loads
 - described [11-2](#)
 - updating [11-3](#)
- Foreign Exchange Office (FXO) [39-1, 39-10, 40-3](#)
- Foreign Exchange Station (FXS) [39-1, 39-10, 40-3](#)
- FXO [39-1, 39-10, 40-3](#)
- FXS [39-1, 39-10, 40-3](#)

G

- G.711 [5-7](#)
- G.723 [5-7](#)
- G.729 [5-7](#)
- gatekeepers
 - and call admission control (figure) [8-7](#)
 - configuration checklist (table) [8-10](#)
 - configuring [8-8](#)
 - configuring in Cisco Unified CallManager [8-9, 42-2](#)
 - configuring on the router [8-8](#)
 - described [8-6](#)
- gateways
 - Catalyst 4000 Access Gateway Module [39-7](#)
 - Catalyst 4224 gateway [39-7](#)
 - Catalyst 6000
 - configuration illustrated (figure) [28-7](#)
 - Catalyst 6000 FXS Analog Interface Module [39-6](#)
 - Catalyst 6000 T1/E1 and Services Module [39-6](#)
 - Cisco Communications Media Module [39-7](#)
 - Cisco IOS H.323 devices [39-7](#)
 - Cisco voice gateways [39-1](#)
 - communication protocols (table) [39-9](#)
 - configuration checklist (table) [39-16](#)
 - dependency records [39-13](#)
 - failover and fallback [39-13](#)
 - H.323 devices list [39-7](#)

- models (table) [39-9](#)
- more information [39-18](#)
- overview [39-1](#)
- port types (table) [39-9](#)
- related to dial plans [39-12](#)
- standalone
 - digital trunk [39-2](#)
 - IAD2420 [39-4](#)
 - VG200 voice [39-2](#)
 - VG224 analog phone [39-4](#)
 - VG248 analog phone [39-2](#)
- summary of voice gateways (table) [39-9](#)
- trunk interfaces
 - table [39-9](#)
- Global Directory
 - displaying with directories button [43-28](#)
- ground-start signaling [40-4](#)
- groups, Cisco Unified CallManager
 - compared to clusters [7-1](#)
 - components of [7-1](#)
 - configuring [5-3](#)
 - illustrated (figure) [7-2](#)
- groups, date/time [5-4](#)
- GSM [5-7](#)

H

- H.323
 - Cisco IOS gateways [39-7](#)
 - clients [43-8](#)
 - gateways [39-7](#)
 - IOS gateway redundancy [39-14](#)
 - used in voice gateways [40-1](#)
 - video [44-4](#)
- hookflash transfer [39-6](#)
- hub-and-spoke topology [8-1](#)
- hunting
 - described [17-10](#)
 - example [17-11](#)

- maximum hunt timer [17-11](#)
- personal preferences [17-11](#)
- hunt lists
 - described [17-9](#)
- hunt pilots
 - described [17-9](#)
 - wildcards [17-16](#)

- identification services
 - QSIG supplementary service, described [40-11](#)
- immediate divert
 - described [43-23](#)
- intercluster
 - communication [6-2](#)
 - voice mail [29-2](#)
- internet
 - ecosystem [2-1](#)
- introduction
 - to Cisco Unified CallManager [1-1](#)
- IP Phones
 - See* Cisco Unified IP Phones
- IP Phone Services
 - See* Cisco Unified IP Phone Services
- IP SoftPhone, Cisco
 - user directory [21-5](#)
- IP telephony
 - protocols
 - more information [40-15](#)
 - understanding [40-1](#)

J

- join
 - described [18-7, 43-23](#)
- JTAPI
 - See* Cisco Unified CallManager JTAPI

L

LDAP

- described [5-12](#)
- directory
 - more information [20-7](#)
- overview [20-1](#)

licensing

- alarms [14-3](#)
- migrating from 5.0(x) to 4.0(x) [14-3](#)
- more information [14-4](#)
- overview [14-1](#)
- splitting licenses [14-2](#)
- starting a license manager service [14-1](#)
- transferring licenses [14-4](#)

line groups

- described [17-8](#)

load, firmware [11-2](#)

load balancing

- distributing devices [7-3](#)
- explained [6-3](#)

locations

- and call admission control (figure) [8-2](#)
- and regions [5-9](#)
- configuration checklist (table) [8-6, 9-12](#)
- described [8-2](#)
- interaction with regions [8-3](#)
- interaction with regions (figure) [8-4](#)
- used in admission control [8-1](#)
- video [44-8](#)

loop-start signaling [40-4](#)

M

malicious call ID

- described [43-23](#)

master centralized TFTP

- configuration tips [10-9](#)
- sending files to the master CTFTP server [10-8](#)

maximum hunt timer [17-11](#)

media control [22-2](#)

Media Gateway Control Protocol (MGCP) [40-2](#)

media resource group lists

- configuration checklist (table) [22-6](#)
- described [22-4](#)

media resource groups

- configuration checklist (table) [22-6](#)
- described [22-3](#)

media resource manager

- managing MTPs [27-2](#)
- using to manage transcoders [25-2](#)

media resources

- call control [22-2](#)
- described [22-1](#)
- management [22-1](#)
- media control [22-2](#)
- media resource group lists [22-4](#)
- media resource groups [22-3](#)
- media termination point control [22-2](#)
- more information [22-7](#)
- music on hold control [22-3](#)
- overview [22-1](#)
- redundancy [7-4](#)
- unicast bridge control [22-3](#)

media termination point (MTP) [27-1](#)

- CTI [45-2](#)

media termination point control [22-2](#)

meet-me conference

- limitations [24-9](#)

messages button [43-27](#)

message waiting

- description [29-4](#)
- indication [29-4](#)

messaging

Cisco Unity

- integration description [31-2](#)
- integration overview [31-1](#)

MGCP

- described [40-2](#)
- gateway redundancy [39-13](#)
- gateways using [39-11](#)

MGCP BRI

- configuring [39-18](#)
- illustration of call flow [39-5](#)

MLPP

- described [5-15](#)

modifying files [10-9](#)

MOH

- described [26-1](#)
- MOH control [22-3](#)

MTP

- avoiding call failure/user alert [27-4](#)
- Cisco Unified CallManager becomes inactive [27-5](#)
- configuration checklist (table) [27-7](#)
- CTI [45-2](#)
- dependency records [27-6](#)
- device characteristics [27-4](#)
- failover and fallback [27-5](#)
- managing with media resource manager [27-2](#)
- more information [27-7](#)
- overview [27-1](#)
- planning configuration [27-3](#)
- resetting registered devices [27-6](#)
- system requirements and limitations [27-5](#)
- transcoding services [28-2](#)
- types (table) [27-3](#)
- understanding [27-1](#)
- using transcoders [25-2](#)
- WS-X6608 DSP service card [24-4](#)

multisite WAN

- using centralized MTP transcoding (figure) [28-4](#)

music on hold (MOH)

- described [26-1](#)

N

network

- video [44-3](#)

O

on-hook call transfer [43-23](#)

organization [xxiv](#)

overview

- of Cisco Unified CallManager [1-1](#)
- of dial rules [19-1](#)
- of system configuration [3-1](#)

P

parameters

enterprise

- described [5-15](#)

Effective Access Privileges For Overlapping User Groups and Roles [4-3](#)

service

- described [5-15](#)

Maximum Phone FallBack Queue Depth [43-28](#)

Message Waiting Lamp Policy [29-5](#)

parameters, enterprise

- user groups [4-3](#)

partitions

- dependency records [15-3](#)
- examples [15-2](#)
- explained [15-1](#)
- guidelines and tips [15-3](#)
- list of topics [15-1](#)
- more information [15-4](#)
- name limitations [15-4](#)

path replacement

- described [40-13](#)

performance monitoring counters

- video [44-10](#)

- personal preferences [17-11](#)
- phone button templates
 - 12 series, default template [43-13](#)
 - 30 SP+, default template [43-12](#)
 - 30 VIP, default template [43-13](#)
 - 7902, default template [43-12](#)
 - 7905 SCCP, default template [43-12](#)
 - 7905 SIP, default template [43-12](#)
 - 7910, default template [43-12](#)
 - 7911 SCCP, default template [43-12](#)
 - 7911 SIP, default template [43-12](#)
 - 7912 SCCP, default template [43-12](#)
 - 7912 SIP, default template [43-12](#)
 - 7920, default template [43-11](#)
 - 7940 SCCP, default template [43-11](#)
 - 7940 SIP, default template [43-11](#)
 - 7941 G-GE SCCP, default template [43-11](#)
 - 7941 SCCP, default template [43-11](#)
 - 7941 SIP, default template [43-11](#)
 - 7960 SCCP, default template [43-11](#)
 - 7960 SIP, default template [43-11](#)
 - 7961 G-GE SCCP, default template [43-11](#)
 - 7961 SCCP, default template [43-11](#)
 - 7961 SIP, default template [43-11](#)
 - 7970 SCCP, default template [43-10](#)
 - 7970 SIP, default template [43-10](#)
 - 7971 SCCP, default template [43-10](#)
 - 7971 SIP, default template [43-10](#)
 - 7985, default template [43-10](#)
 - analog phone, default template [43-13](#)
 - ATA 186, default template [43-13](#)
 - Cisco IP Communicator, default template [43-13](#)
 - CN622, default template [43-13](#)
 - conference station 7935, default template [43-12](#)
 - conference station 7936, default template [43-12](#)
 - IP-STE, default template [43-13](#)
 - ISDN BRI Phone, default template [43-13](#)
 - third-party SIP device, default template [43-13](#)
 - VGC phone, default template [43-13](#)
 - VGC Virtual, default template [43-13](#)
- phone login
 - described [36-1](#)
- phone NTP reference
 - configuring for SIP phones [5-4](#)
- phones
 - See also* Cisco Unified IP Phones
 - administration tips [43-25](#)
 - associating with users [43-25](#)
 - button templates
 - default [43-10](#)
 - described [43-9](#)
 - guidelines [43-13](#)
 - listed by model (table) [43-10](#)
 - Cisco Unified IP Phone Services [35-1](#)
 - common phone profiles [43-19](#)
 - dependency records
 - described [43-29](#)
 - failover and fallback [43-29](#)
 - features
 - described (table) [43-14](#)
 - privacy [43-20](#)
 - find all phones [43-27](#)
 - methods for adding [43-19](#)
 - more information [43-33](#)
 - SCCP configuration checklist (table) [43-29](#)
 - search by authentication string [43-27](#)
 - search by calling search space [43-26](#)
 - search by call pickup group [43-26](#)
 - search by description [43-26](#)
 - search by device name [43-26](#)
 - search by device pool [43-26](#)
 - search by device protocol [43-27](#)
 - search by device type [43-26](#)
 - search by directory number [43-26](#)
 - search by LSC status [43-26](#)
 - search by security profile [43-27](#)
 - search tips [43-26](#)
 - search within results [43-27](#)

- SIP configuration checklist (table) [43-29](#)
- softkey templates
 - add application [43-16](#)
 - configure softkey layout [43-17](#)
 - described [43-15](#)
- PLAR
 - for Cisco SIP phones [41-18](#)
- ports
 - configuring for SMDI [30-2](#)
- CTI
 - described [43-8](#)
- presentation settings
 - calling party [17-28](#)
 - connected party [17-20](#)
- preservation of calls
 - explained [11-4](#)
 - scenarios (table) [11-5](#)
- privacy
 - described [43-20](#)
- private line automatic ringdown
 - for Cisco SIP phones [41-18](#)
 - SIP dial rules [19-7](#)
- privileges
 - roles [4-2](#)
- profiles
 - common phone [43-19](#)
- protocols
 - analog telephony [40-3](#)
 - H.323 [29-2, 40-1](#)
 - MGCP [40-2](#)
 - Session Initiation Protocol (SIP) [40-3](#)
 - Skinny Client Control Protocol [39-3, 40-2](#)
 - Skinny Client Control Protocol (SCCP) Gateway Protocol [39-14](#)
 - Skinny Gateway Protocol [39-12](#)

Q

QSIG

- Annex M.1 [40-7](#)
- basic call feature [40-8](#)
- basic call setup [40-8](#)
- call completion [40-8](#)
- call diversion (rerouting) [40-9](#)
- CallManager interface [40-15](#)
- call transfer [40-10](#)
- compatibility with older versions (ECMA) [40-10](#)
- facility selection and reservation [40-11](#)
- identification services [40-11](#)
- message tunneling [40-7](#)
- message waiting indication (MWI) service [40-13](#)
- overview [40-6](#)
- path replacement [40-13](#)
- supplementary services
 - call diversion (forwarding) [40-9](#)

Q signaling (QSIG) [39-1, 40-6](#)

QSIG protocol

- supplementary services
 - call completion (Cisco Call Back), described [40-8](#)
 - call transfer [40-10](#)
 - identification [40-11](#)
 - path replacement [40-13](#)

QSIG trunk interface [39-1](#)

quality of sound [8-1](#)

quality report tool

- described [43-23](#)

R

- redundancy
 - and distributed call processing (figure) [7-3](#)
 - Cisco Unified CallManager [45-6](#)
 - Cisco VG248 [39-14](#)
- CMI
 - described [30-2](#)

- illustrated (figure) [30-3](#)
- CTI [45-6](#)
- CTIManager [45-7](#)
- IOS H.323 gateways [39-14](#)
- list of topics [7-1](#)
- MGCP gateway [39-13](#)
- more information [7-4](#)
- of CTI [7-4](#)
- of media resources [7-4](#)
- support for gateways [39-13](#)
- types of [7-1](#)
- with distributed call processing [7-3](#)
- regions
 - and call admission control [5-9](#)
 - and locations [5-9](#)
 - described [5-5](#)
 - example (figure) [5-9](#)
 - interaction with locations [8-3](#)
 - interaction with locations (figure) [8-4](#)
 - used with admission control [8-3](#)
 - used with admission control (figure) [8-4](#)
 - video [44-8](#)
- related documentation [xxv](#)
- requirements
 - Cisco Unity [31-1](#)
- restriction settings
 - calling party [17-28](#)
 - connected party [17-30](#)
- roles
 - access privileges [4-2](#)
 - described [4-1, 4-2](#)
 - more information [4-4](#)
 - overview [4-1](#)
 - standard [4-4](#)
- route filters
 - associated with route lists (table) [17-34](#)
 - described [17-34](#)
- route groups
 - described [17-5](#)
 - generated [17-35](#)
 - related to dial plans [39-12](#)
- route lists
 - associated route filters (table) [17-34](#)
 - described [17-5](#)
 - generated [17-35](#)
 - types (table) [17-36](#)
 - types, example [17-5](#)
- route patterns
 - closest-match routing [17-12](#)
 - considerations for using [17-6](#)
 - explained [17-6](#)
 - fields in Cisco Unified CallManager (table) [17-17](#)
 - generated with external route plan wizard [17-36](#)
 - usage [17-6](#)
 - using the @ wildcard character [17-12](#)
 - wildcards [17-16](#)
- route plans
 - and Cisco Analog Access Gateways (figure) [17-8](#)
 - and Cisco Digital Access Gateways (figure) [17-7](#)
 - external route plan wizard
 - generated route filters [17-34](#)
 - generated route groups [17-35](#)
 - generated route lists [17-35](#)
 - generated route patterns [17-36](#)
 - list of topics [17-1](#)
 - more information [17-37](#)
 - overview [17-4](#)
 - report [17-37](#)
- routers
 - conference
 - hardware [24-2](#)
- routing
 - automated alternate [17-1](#)
 - closest-match [17-12](#)
 - time-of-day [16-1](#)
 - dependency records [16-3](#)
 - for end users [16-2](#)
 - more information [16-3](#)

time periods [16-1](#)
time schedules [16-2](#)
understanding [16-1](#)

S

SCCP auto-registration [12-2](#)

search

by authentication string [43-27](#)
by calling search space [43-26](#)
by call pickup group [43-26](#)
by description [43-26](#)
by device name [43-26](#)
by device pool [43-26](#)
by device protocol [43-27](#)
by device type [43-26](#)
by directory number [18-8, 43-26](#)
by LSC status [43-26](#)
by security profile [43-27](#)
for all directory numbers in the database [18-8](#)
for all phones in the database [43-27](#)
for directory numbers [18-8](#)
for phones [43-26](#)
within results [43-27](#)

security profile

search for phones [43-27](#)

server, Cisco Unified CallManager

configuring [5-1](#)

Serviceability

and video [44-10](#)

service parameters

Automated Alternate Routing Enable [17-3](#)
described [5-15](#)
Maximum Phone FallBack Queue Depth [43-28](#)
Message Waiting Lamp Policy [29-5](#)

service URL

described [43-25](#)

Session Initiation Protocol (SIP)

understanding [41-1](#)

settings

called party transformations

configuring [17-27](#)

explained (table) [17-27](#)

calling party transformations

explained (table) [17-26, 17-29](#)

configuring

checklist (table) [5-16](#)

described [5-1](#)

connected party transformations

explained (table) [17-31](#)

special characters [17-15](#)

shared line appearance

active check box [18-5](#)

described [18-2](#)

restrictions [18-4](#)

update directory number of all devices sharing this line
check box [18-5](#)

Simplified Message Desk Interface (SMDI) [29-2, 30-1](#)

SIP

3PCC [41-15](#)

ad hoc conference settings [24-8](#)

basic calls [41-6](#)

call identification services [41-9](#)

Cisco Unified CallManager support for Cisco SIP
endpoints [41-15](#)

configuration checklist (table) [41-13](#)

description of Cisco CallManager and SIP [41-2](#)

diversion header [41-16](#)

DTMF Relay calls [41-6](#)

functions and features in Cisco Unified
CallManager [41-5](#)

join header [41-16](#)

more information [41-20](#)

networking [41-1](#)

protocol [40-3](#)

REFER [41-16](#)

remotecc [41-17](#)

remote party ID (RPID) header [41-16](#)

replaces and referred-by headers [41-16](#)

- replaces header [41-16](#)
- RFC3261 [41-15](#)
- RFC3262 [41-15](#)
- RFC3264 [41-15](#)
- RFC3265 + dialog package [41-17](#)
- RFC3265 + KPML package [41-17](#)
- RFC3265 + presence package [41-17](#)
- RFC3265 + RFC3842 MWI package [41-17](#)
- RFC3311 [41-15](#)
- RFC3514 [41-16](#)
- RNDIS [41-12](#)
- service parameters [41-3](#)
- supplementary services [41-8](#)
- understanding [41-1](#)
- using MTP devices [41-3](#)
- SIP autoregistration [12-2](#)
- SIP dial rules
 - dial rule parameters [19-5](#)
 - dial rule patterns [19-4](#)
 - overview [19-4](#)
 - PLAR [19-7](#)
- SIP endpoints
 - overview [41-13](#)
- SIP phone
 - NTP reference [5-4](#)
 - PLAR [41-18](#)
- SIP phones
 - See* Cisco SIP IP Phones
- SIP profile
 - Cisco SIP endpoints [41-19](#)
 - SIP trunks [41-5](#)
- SIP standards
 - Cisco endpoints [41-15](#)
- SIP trunks
 - SIP profile [41-5](#)
- Skinny Client Control Protocol [39-3, 40-2](#)
- Skinny Client Control Protocol (SCCP) Gateway Protocol [39-14](#)
- Skinny Gateway Protocol [39-12](#)
- SMDI
 - configuration checklist (table) [30-4](#)
 - integration requirements [30-1](#)
 - migration with DPA 7630/7610 [32-2, 32-3](#)
 - more information [30-5](#)
 - port configuration [30-2](#)
 - PSTN gateway interfaces [29-2](#)
 - voice mail integration [29-2, 30-1](#)
- softkey templates
 - call states described (table) [43-17](#)
 - layout (figure) [43-18](#)
 - operation [43-18](#)
- softphone [43-8](#)
- SoftPhone, Cisco IP [21-5](#)
- sound quality [8-1](#)
- special characters
 - configuring [17-15](#)
 - described (table) [17-16](#)
 - explained [17-16](#)
- speed dial
 - described [43-25](#)
- standard roles [4-4](#)
- standards
 - SIP [41-15](#)
- standard user groups [4-4](#)
- static digit analysis
 - caveats [17-14](#)
 - configuration tip [17-13](#)
 - described [17-13](#)
 - example prior to static digit analysis [17-15](#)
 - explained [17-13](#)
 - Unified CallManager Assistant example with static digit analysis [17-15](#)
- supported devices [11-1](#)
- system configuration
 - for complete IP telephony system
 - overview [3-1](#)
 - overview checklist (table) [3-1](#)
 - more information [3-4](#)

overview [3-1](#)
 system-level configuration settings [5-1](#)

T

T1 CAS [40-5](#)

T1 Primary Rate Interface (PRI) [39-1](#)

T1 Primary Rate Interface (T1 PRI) [40-6](#)

templates, phone button

12 series, default [43-13](#)

30 SP+, default [43-12](#)

30 VIP, default [43-13](#)

7902, default [43-12](#)

7905 SCCP, default [43-12](#)

7905 SIP, default [43-12](#)

7910, default [43-12](#)

7911 SCCP, default [43-12](#)

7911 SIP, default [43-12](#)

7912 SCCP, default [43-12](#)

7912 SIP, default [43-12](#)

7920, default [43-11](#)

7940 SCCP, default [43-11](#)

7940 SIP, default [43-11](#)

7941 G-GE SCCP, default [43-11](#)

7941 SCCP, default [43-11](#)

7941 SIP, default [43-11](#)

7960 SCCP, default [43-11](#)

7960 SIP, default [43-11](#)

7961 G-GE SCCP, default [43-11](#)

7961 SCCP, default [43-11](#)

7961 SIP, default [43-11](#)

7970 SCCP, default [43-10](#)

7970 SIP, default [43-10](#)

7971 SCCP, default [43-10](#)

7971 SIP, default [43-10](#)

7985, default [43-10](#)

analog phone, default [43-13](#)

ATA 186, default [43-13](#)

Cisco IP Communicator, default [43-13](#)

CN622, default [43-13](#)

conference station 7935, default [43-12](#)

conference station 7936, default [43-12](#)

default [43-10](#)

described [43-9](#)

guidelines [43-13](#)

IP-STE, default [43-13](#)

ISDN BRI phone, default [43-13](#)

listed by model (table) [43-10](#)

third-party SIP device, default [43-13](#)

VGC phone, default [43-13](#)

VGC Virtual, default [43-13](#)

templates, softkey

add application [43-16](#)

configure softkey layout [43-17](#)

described [43-15](#)

layout (figure) [43-18](#)

operation [43-18](#)

TFTP [10-8](#)

alternate paths [10-8](#)

centralized TFTP [10-7, 10-8, 10-9](#)

configuration checklist (table) [10-9](#)

configuration files [11-2](#)

configuring a backup or fallback server [10-7](#)

customizing files [10-9](#)

list of topics [10-1](#)

master centralized TFTP [10-8](#)

more information [10-10](#)

multiple cluster environment [10-7](#)

overview [10-1](#)

process overview for Cisco SIP IP phones [10-3](#)

process overview for SCCP devices [10-2](#)

server

accessing [10-6](#)

identifying [10-6](#)

understanding [10-4](#)

time-of-day routing [16-1](#)

dependency records [16-3](#)

for end users [16-2](#)

- more information [16-3](#)
- time periods [16-1](#)
- time schedules [16-2](#)
- understanding [16-1](#)
- time periods
 - dependency records [16-3](#)
 - explained [16-1](#)
 - more information [16-3](#)
- time schedules
 - dependency records [16-3](#)
 - explained [16-2](#)
 - more information [16-3](#)
- time zones [5-4](#)
- tones [23-4](#)
- tools
 - administrator
 - BAT [47-1](#)
 - CAR [47-2](#)
 - Cisco Unified CallManager Serviceability [47-1](#)
 - more information [47-3](#)
 - overview [47-1](#)
- transcoders
 - configuration checklist (table) [25-5](#)
 - dependency records [25-4](#)
 - failover and fallback [25-3](#)
 - managing with media resource manager [25-2](#)
 - more information [25-5](#)
 - overview [25-1](#)
 - performance monitoring [25-4](#)
 - resetting registered devices [25-4](#)
 - troubleshooting [25-4](#)
 - types in Cisco Unified CallManager Administration [25-2](#)
 - understanding [25-1](#)
 - using as MTPs [25-2](#)
- transcoding
 - centralized MTP and conferencing services (figure) [28-4](#)
 - IP-to-IP packet [28-3](#)
 - IP-to-IP packet across trunks [28-4](#)
 - IP-to-IP packet and voice compression [28-3](#)
 - using Catalyst DSP [28-1](#)
- transfer
 - described [18-7](#)
 - on-hook [43-23](#)
- transformations
 - called party [17-25](#)
 - calling party [17-25](#)
- translation patterns
 - and called party transformations settings [17-27](#)
 - and calling party presentation and restriction settings [17-28](#)
 - and calling party presentation settings (table) [17-29](#)
 - and connected party presentation and restriction settings [17-30](#)
 - and connected party presentation settings (table) [17-31](#)
 - and route plan report [17-37](#)
 - use for failover [17-13](#)
- Trivial File Transfer Protocol (TFTP) [10-1](#)
- troubleshooting
 - annunciator [23-5](#)
- trunk interfaces
 - BRI [40-6](#)
 - E1 CAS [40-5](#)
 - E1 PRI [39-1, 40-6](#)
 - FXO [39-1, 40-3](#)
 - FXS [39-1, 40-3](#)
 - QSIG [39-1, 40-6](#)
- signaling
 - E&M [40-4](#)
 - ground start [40-4](#)
 - loop start [40-4](#)
 - T1 CAS [39-1, 40-5](#)
 - T1 PRI [39-1, 40-6](#)
- trunks
 - associated route groups [42-6](#)
 - configuration [42-1](#)
 - configuration checklist (table) [8-10, 42-6](#)

- configuring in Cisco Unified CallManager [8-9, 42-2](#)
- configuring on the router [8-8](#)
- dependency records [42-6](#)
- described [8-6](#)
- gatekeeper controlled [42-2](#)
- H.225 gatekeeper controlled [42-3](#)
- intercluster gatekeeper controlled [42-3](#)
- intercluster non-gatekeeper controlled [42-3](#)
- more information [42-7](#)
- non-gatekeeper controlled [42-2](#)
- overview [42-1](#)
- SIP [42-3](#)

U

- unicast bridge control [22-3](#)
- Unity, Cisco
 - See* Cisco Unity
- user
 - application
 - associating devices [21-3](#)
 - configuration checklist (table) [21-5](#)
 - described [21-1, 21-2](#)
 - more information [21-6](#)
 - configure phone features [43-28](#)
 - end
 - associating devices [21-4](#)
 - configuration checklist (table) [21-5](#)
 - described [21-1, 21-2](#)
 - more information [21-6](#)
- user alert, avoiding [27-4](#)
- user directory
 - extension mobility [21-4](#)
- user groups
 - CTI [45-5](#)
 - described [4-1, 4-3](#)
 - enterprise parameters [4-3](#)
 - more information [4-4](#)
 - overview [4-1](#)

- standard [4-4](#)
- user management
 - CTI [45-5](#)
- user options
 - Cisco Unified CallManager User Options [43-28](#)

V

- video
 - alternate routing [44-8](#)
 - and Serviceability [44-10](#)
 - bandwidth management [44-7](#)
 - bridge counters [44-11](#)
 - call details records [44-11](#)
 - calls [44-2](#)
 - codecs [44-2](#)
 - conference devices [24-3](#)
 - configuration checklist (table) [44-12](#)
 - DSCP marking [44-8](#)
 - H.323 [44-4](#)
 - locations [44-8](#)
 - more information [44-13](#)
 - network [44-3](#)
 - other configuration [44-9](#)
 - performance monitoring counters [44-10](#)
 - phone configuration [44-9](#)
 - regions [44-8](#)
 - Skinny Client Control Protocol [44-6](#)
 - Skinny Client Control Protocol bridging [44-6](#)
 - understanding [44-1](#)
- video phones
 - Cisco Unified IP Phone 7985 [43-6](#)
- voice codecs
 - bandwidth used per call (table) [5-8](#)
 - G.711 [5-7](#)
 - G.723 [5-7](#)
 - G.729 [5-7](#)
 - GSM [5-7](#)
 - supported by Cisco Unified CallManager [5-7](#)

- wideband [5-7](#)
- voice compression [28-3](#)
- voice gateways, see gateways
- voice mail
 - access [29-2](#)
 - gateway-based [29-2](#)
 - call forwarding
 - intercluster trunk, example [29-6](#)
 - intracluster trunk, examples [29-6](#)
 - call forwarding in multiple systems [29-5](#)
 - call transfer [29-6](#)
 - configuration
 - message waiting indication [29-4](#)
 - message-waiting indication policy [29-4](#)
 - more information [29-7](#)
 - configuring messages button [43-27](#)
 - connectivity
 - more information [29-7](#)
 - connectivity to Cisco Unified CallManager [29-1](#)
 - gateway-based [29-2](#)
 - interfaces [29-1](#)
 - intercluster [29-2](#)
 - PSTN gateway [29-2](#)
 - Skinnny Protocol [29-2](#)
 - message waiting configuration [29-4](#)
 - pilot numbers [29-3](#)
 - profiles [29-3](#)
 - SMDI
 - configuration checklist (table) [30-4](#)
 - integration [30-1](#)
 - requirements for integration [30-1](#)
- voice messaging, see voice mail
- voice quality [8-1](#)
 - for hunt pilots [17-16](#)
 - for route patterns [17-16](#)
 - using @ in route patterns [17-12](#)

W

- wideband [5-7](#)
- wildcards
 - described (table) [17-16](#)

