



A

AAR

- explained [7-1](#)

abbreviated dial

- described [11-26](#)

A Cisco DB Replicator service [19-7](#)

A Cisco DB service [19-7](#)

ac user

- associating with devices and pilot points [14-28](#)

- configuring [14-21](#)

administrators, CAR [24-5](#)

admission control [5-13](#)

Alarm configuration, described [16-1](#)

Alarms

- configuration checklist [20-3](#)

- configuration overview [20-2](#)

- configuring, procedure [16-1](#)

- definitions, described [20-2](#)

- described [20-1](#)

- destinations [16-3](#)

- destination settings [16-3](#)

- event levels [16-4](#)

- event level settings [16-4](#)

- Event Viewer [16-3](#)

- overview [20-1](#)

- SDI trace library [16-3](#)

- SDL trace library [16-3](#)

- Syslog [16-3](#)

- updating, procedure [16-1](#)

- viewing information

 - overview [20-2](#)

alerts

- emailing notification [23-61](#)

- enabling or disabling, by mail [26-8](#)

- notification for a counter [23-61](#)

- scheduling notification [23-61](#)

- thresholds [23-61](#)

Arabic locales

- phone support [39-1](#)

Attendant Console

- See* Cisco Unified CallManager Attendant Console

audio sources

- configuring [12-16](#)

- creating for MOH [12-9](#)

- default MOH sample [12-9](#)

- for MOH [12-8](#)

- managing for MOH [12-10](#)

- multicast [12-10](#)

- storing for MOH [12-9](#)

- unicast [12-10](#)

authenticate and show CAR pages [24-14](#)

Authentication [36-14](#)

authentication

- device [30-15](#)

- digest [30-15](#)

- interactions [30-5](#)

- overview [30-15](#)

- restrictions [30-5](#)

authorization [30-15](#)

- interactions [30-5](#)

- overview [30-15](#)

automated alternate routing (AAR)

- dial prefix matrix example (table) [7-3](#)

- enable service parameter [7-3](#)

- example [7-2](#)

explained [7-1](#)
 line/DN and AAR groups (table) [7-2](#)
 automatic
 database purge [25-14](#)
 report generation [26-6](#)
 AXL API [36-3](#)
 AXL Compliance [36-3](#)
 AXL Error Codes [36-3](#)
 AXL Schema Documentation [36-12](#)

B

backup
 service
 Cisco DRF Local [19-11](#)
 Cisco DRF Master [19-11](#)
 bandwidth
 used by Cisco Unified CallManager [5-7](#)
 used by codec types (table) [5-8](#)
 barge
 described [11-21](#)
 encryption restrictions with [30-11](#)
 base rate [26-2](#)
 bill
 department detail, report results [28-3](#)
 department summary, report results [28-2](#)
 individual detail, report results [28-3](#)
 individual summary, report results [28-2](#)
 buttons
 directories button [11-29](#)
 messages button [11-28](#)

C

C++ Example [36-6](#)
 call admission control [5-13](#)
 call coverage
 call forwarding [7-11](#)

 described [7-11](#)
 hunting [7-11](#)
 maximum hunt timer [7-12](#)
 personal preferences [7-12](#)
 call detail
 conference call detail, report results [28-21](#)
 call diagnostics and voice quality metrics
 described [11-26](#)
 call display restrictions
 configuring in translation pattern [7-29](#)
 called party
 transformations [7-26](#)
 transformations settings [7-28](#)
 transformations settings (table) [7-28](#)
 caller identification
 restrictions [7-29](#)
 support for device control protocols (table) [7-34](#)
 support vs. device control protocols [7-33](#)
 types [7-29](#)
 Call Flows [37-6](#)
 Desktop-based Client Application [37-6](#)
 WebDialer Browser-based Application [37-8](#)
 WebDialer Client-based Application [37-7](#)
 call forward
 described [7-11, 8-6, 11-21](#)
 calling party
 presentation settings [7-29](#)
 restriction settings [7-29](#)
 transformations [7-26](#)
 transformations settings [7-26](#)
 transformations settings (table) [7-27, 7-30](#)
 calling search spaces
 search for phones [11-27](#)
 call park
 described [11-23](#)
 example with MOH [12-5](#)
 call pickup
 described [11-23](#)
 call queuing [14-9](#)

- calls
 - making and receiving multiple per directory number [8-7](#)
 - on-hook call transfer [11-24](#)
- call select
 - described [11-23](#)
- call termination
 - CDR search by [27-4](#)
- call types
 - QoS report results by call types [28-11](#)
- call waiting
 - described [8-7](#)
- CAR
 - administrators, managers, users [24-5](#)
 - automatic database purge configuration [25-14](#)
 - automatic report generation/alert configuration [26-6](#)
 - call termination details, viewing [27-5](#)
 - CDR search
 - by call precedence levels [27-5](#)
 - configuration [27-1](#)
 - malicious calls [27-7](#)
 - overview [24-12](#)
 - CDR search by cause for call termination configuration [27-4](#)
 - CDR search by gateway configuration [27-3](#)
 - CDR search by user extension configuration [27-1](#)
 - checklist [24-15](#)
 - configuration, gateway [25-5](#)
 - described [24-2](#)
 - device reports
 - overview [24-10](#)
 - dial plan default values [25-4](#)
 - disabling automatic database purge [25-14](#)
 - event log report output parameters [25-16](#)
 - event log report status [25-15](#)
 - list of topics [24-1](#)
 - load CDR and CMR values [25-8](#)
 - manual database purge [25-12](#)
 - notification limits configuration [26-8](#)
 - QoS default values [26-5](#)
 - QoS values, defining [26-5](#)
 - rating engine configuration [26-1](#)
 - report configuration, described [26-1](#)
 - reports, results [28-1](#)
 - restoring database purge defaults [25-12](#)
 - restoring dial plan default values [25-4](#)
 - system configuration [24-6, 25-1](#)
 - system log screens, described [25-15](#)
 - system preferences parameters [25-6](#)
 - system reports
 - overview [24-8](#)
 - uninhibited loading of CDR values [25-8](#)
 - user reports [24-7](#)
- car_CDRSearchByCauseCodesReport [27-5](#)
- Catalyst 4000
 - 4224 voice gateway switch [10-7](#)
 - access gateway module [10-7](#)
 - voice gateway modules [10-5](#)
- Catalyst 4224 Voice Gateway Switch [10-7](#)
- Catalyst 6000
 - Cisco Communication Media Module [10-7](#)
 - FXS analog interface module [10-6](#)
 - hookflash transfer [10-6](#)
 - T1/E1 line card [10-6](#)
 - voice gateway modules [10-5](#)
- category
 - adding [18-17](#)
 - deleting [18-18](#)
 - renaming [18-17](#)
- category tabs [23-60](#)
 - sample rates [23-61](#)
- CDR
 - automatic database purge configuration [25-14](#)
 - disabling automatic database purge [25-14](#)
 - disabling loading [25-7](#)
 - dump table [28-25](#)
 - error, report results [28-17](#)
 - load schedule configuration [25-7](#)

- restoring the default load schedule [25-7](#)
- search [27-1](#)
- search by cause for call termination [27-4](#)
- search by gateway [27-3](#)
- search by user extension [27-1](#)
- search by user extension, report results [28-23](#)
- service
 - Cisco CAR Scheduler [19-5](#)
 - Cisco CAR Web Service [19-5](#)
 - Cisco CDR Agent [19-11](#)
 - Cisco SOAP - CDRonDemand Service [19-4](#)
- values
 - CDR load [25-8](#)
- CDR analysis and reporting
 - general information [24-6](#)
 - internationalization [24-14, 24-15](#)
- CDRs
 - understanding [24-1](#)
- CDR values
 - uninhibited loading [25-8](#)
- centralized TFTP
 - configuration tips [6-10](#)
 - master TFTP server [6-9](#)
 - overview [6-9](#)
 - secure clusters [6-10](#)
- Certificate Authority Proxy Function (CAPF)
 - CAPF service [31-5](#)
 - installing [30-12](#)
- certificates
 - external CAs [30-12](#)
 - types [30-12](#)
- Certificate Signing Requests (CSRs) [30-12](#)
- CFA Destination Override service parameter [8-6, 11-22](#)
- Changes in Release 5.0(2) [37-4](#)
- channel associated signaling (CAS) [10-1](#)
- characters, special
 - configuring [7-16](#)
 - described (table) [7-17](#)
- Cisco Access Digital Trunk Gateways
 - DT-24+/DE-30+ [10-2](#)
- Cisco AMC Service [19-10](#)
- Cisco Analog Access
 - perfmon object and counters [23-3](#)
- Cisco Analyzer service [19-4](#)
- Cisco Annunciator Device
 - perfmon object and counters [23-4](#)
- Cisco AXL Web Service [19-5](#)
- Cisco Bulk Provisioning Service [19-5](#)
- Cisco CallManager
 - perfmon object and counters [23-4](#)
- Cisco CallManager Admin service [19-9](#)
- Cisco CallManager Attendant Console
 - perfmon object and counters [23-11](#)
- Cisco CallManager Attendant Console Server
 - service [19-3](#)
 - service parameters [14-32](#)
 - understanding [14-10](#)
- Cisco CallManager Cisco IP Phone Services [19-3](#)
- Cisco CallManager Personal Directory service [19-9](#)
- Cisco CallManager Serviceability service [19-9](#)
- Cisco CallManager System Performance
 - perfmon object and counters [23-12](#)
- Cisco CAR Scheduler service [19-5](#)
- Cisco CAR Web Service [19-5](#)
- Cisco CDP Agent service [19-8](#)
- Cisco CDP service [19-9](#)
- Cisco CDR Agent service [19-11](#)
- Cisco Certificate Authority Proxy Function (CAPF)
 - service [19-6](#)
- Cisco Certificate Expiry Monitor service [19-8](#)
- Cisco Communication Media Module (CMM) [10-7](#)
- Cisco CTIManager
 - perfmon object and counters [23-15](#)
- Cisco CTL Provider service [19-6](#)
- Cisco Database Layer Monitor service [19-8](#)
- Cisco DB Replicator service [19-7](#)
- Cisco DB service [19-7](#)
- Cisco DHCP Monitor service [19-4](#)

- Cisco Dual-Mode Mobility perfmon object and counters [23-16](#)
- Cisco Electronic Notification service [19-8](#)
- Cisco Extended Functions service [19-3](#)
- Cisco Extension Mobility
 - perfmon object and counters [23-17](#)
- Cisco Extension Mobility Application [19-10](#)
- Cisco Gatekeeper
 - perfmon object and counters [23-17](#)
- Cisco H.323
 - perfmon object and counters [23-18](#)
- Cisco Hunt Lists
 - perfmon object and counters [23-19](#)
- Cisco HW Conference Bridge Device
 - perfmon object and counters [23-20](#)
- Cisco IAD2420 Integrated Access Device [10-4](#)
- Cisco IP Communicator
 - default phone button template [11-14](#)
 - described [11-9](#)
- Cisco IP Manager Assistant
 - perfmon object and counters [23-20](#)
- Cisco IP Phone services
 - report results [28-9](#)
- Cisco IP Voice Media Streaming App service [19-3](#)
- Cisco License Manager service [19-8](#)
- Cisco Lines
 - perfmon object and counters [23-21](#)
- Cisco Locations
 - perfmon object and counters [23-21](#)
- Cisco Log Partition Monitoring Tool service [19-9](#)
- Cisco Media Streaming Application
 - perfmon object and counters [23-22](#)
- Cisco Messaging Interface
 - perfmon object and counters [23-25](#)
- Cisco Messaging Interface service [19-3](#)
- Cisco MGCP FXO Device
 - perfmon object and counters [23-25](#)
- Cisco MGCP FXS Device
 - perfmon object and counters [23-26](#)
- Cisco MGCP Gateways
 - perfmon object and counters [23-26](#)
 - Cisco MGCP Gateways [23-27](#)
- Cisco MGCP PRI Device
 - perfmon object and counters [23-27](#)
- Cisco MGCP T1CAS Device
 - perfmon object and counters [23-27](#)
- Cisco MOH Device
 - perfmon object and counters [23-28](#)
- Cisco MTP Device
 - perfmon object and counters [23-29](#)
- Cisco Phones
 - perfmon object and counters [23-29](#)
- Cisco Presence Feature
 - perfmon object and counters [23-30](#)
- Cisco QSIG Features
 - perfmon object and counters [23-30](#)
- Cisco RIS Data Collector service [19-9](#)
- Cisco RTMT Reporter Servlet [19-10](#)
- Cisco Serviceability Reporter service [19-5](#)
- Cisco SIP
 - perfmon object and counters [23-30](#)
- Cisco SIP IP Phones
 - default phone button template (advanced) [11-14](#)
 - default phone button template (basic) [11-14](#)
 - models supported [11-8](#)
 - third-party SIP device differences [4-1](#)
- Cisco SIP Stack
 - perfmon object and counters [23-31](#)
- Cisco SOAP - CDRonDemand Service [19-4](#)
- Cisco SOAP-Log-Collection APIs [19-10](#)
- Cisco SOAP Performance Monitoring APIs service [19-10](#)
- Cisco SW Conf Bridge Device
 - perfmon object and counters [23-39](#)
- Cisco Syslog Agent service [19-8](#)
- Cisco TelePresence
 - described [11-9](#)
- Cisco TFTP Server
 - perfmon object and counters [23-40](#)

- Cisco TFTP service [19-3](#)
 - alternate Cisco file servers [6-8](#)
 - configuration checklist (table) [6-11](#)
 - list of topics [6-1](#)
 - more information [6-11](#)
 - overview [6-1](#)
 - understanding [6-4](#)
- Cisco Tomcat Connector
 - perfmon object and counters [23-43](#)
- Cisco Tomcat service [19-7](#)
- Cisco Tomcat Stats Servlet [19-10](#)
- Cisco Trace Collection Service [19-9](#)
- Cisco Trace Collection Servlet [19-9](#)
- Cisco Transcode Device
 - perfmon object and counters [23-47](#)
- Cisco Unified CallManager
 - bandwidth usage [5-7](#)
 - configuration, configuring [5-2](#)
 - configuring [5-2](#)
 - groups
 - configuring [5-3](#)
 - MOH servers [12-7](#)
 - server, configuring [5-1](#)
 - service
 - Cisco Analyzer [19-4](#)
 - Cisco CallManager [19-2](#)
 - Cisco CallManager Admin [19-9](#)
 - Cisco CallManager Attendant Console Server [19-3](#)
 - Cisco CallManager Personal Directory [19-9](#)
 - Cisco CallManager Serviceability [19-9](#)
 - Cisco CDP [19-9](#)
 - Cisco CTIManager [19-3](#)
 - Cisco DHCP Monitor Service [19-4](#)
 - Cisco Extended Functions [19-3](#)
 - Cisco Extension Mobility Application [19-10](#)
 - Cisco IP Voice Media Streaming App [19-3](#)
 - Cisco Log Partition Monitoring Tool [19-9](#)
 - Cisco Messaging Interface [19-3](#)
 - Cisco TFTP [19-3](#)
 - Cisco Tomcat Stats Servlet [19-10](#)
 - Cisco Trace Collection Service [19-9](#)
 - Cisco Trace Collection Servlet [19-9](#)
 - supported voice codecs [5-7](#)
 - Cisco Unified CallManager Assistant
 - softkey templates
 - described [11-16](#)
 - Cisco Unified CallManager Attendant Console
 - associating devices and pilot points with ac user [14-28](#)
 - client configuration settings (table) [14-37](#)
 - configuration checklist [14-17](#)
 - configuring [14-16](#)
 - configuring attendant settings [14-37](#)
 - configuring held icon timers [14-39](#)
 - CorporateDirectory.txt file
 - creating and uploading [14-33](#)
 - deleting [14-34](#)
 - dependency records [14-40](#)
 - directory [14-9](#)
 - Enabling Super Provider [14-22](#)
 - Firewall Support [14-12](#)
 - hunt groups
 - configuration settings (table) [14-30](#)
 - deleting members [14-32](#)
 - understanding [14-2](#)
 - viewing members [14-32](#)
 - installation and activation [14-16](#)
 - installing [14-35](#)
 - interactions [14-14](#)
 - overview [14-1](#)
 - pilot points
 - configuration settings [14-25](#)
 - configuring [14-24](#)
 - deleting [14-27](#)
 - finding [14-23](#)
 - resetting [14-28](#)
 - understanding [14-2](#)
 - redundancy [14-11](#)
 - restrictions [14-15](#)

- starting after installing Windows XP SP2 [14-36](#)
- system requirements [14-12](#)
- users
 - configuration settings [14-20](#)
 - configuring [14-18](#)
 - configuring the ac user [14-21](#)
 - deleting [14-21](#)
 - finding [14-19](#)
 - understanding [14-2](#)
- Cisco Unified CallManager System Guide
 - conventions [xxv](#)
 - organization [xxiv](#)
 - related documentation [xxv](#)
- Cisco Unified CallManager User Options [11-29](#)
- Cisco Unified IP Phones
 - See also phones*
 - 12 SP+, described [11-7](#)
 - 30 VIP, described [11-8](#)
 - 7902, described [11-6](#)
 - 7905, described [11-6](#)
 - 7906, described [11-5](#)
 - 7910, described [11-5](#)
 - 7911, described [11-5](#)
 - 7912, described [11-4](#)
 - 7914 Expansion Module, described [11-4](#)
 - 7920, described [11-4](#)
 - 7935, described [11-7](#)
 - 7940, described [11-3](#)
 - 7941, described [11-3](#)
 - 7960, described [11-3](#)
 - 7961, described [11-3](#)
 - 7970, described [11-2](#)
 - 7971, described [11-2](#)
 - 7985, described [11-6](#)
 - Cisco Unified IP Conference Station 7936,
 - described [11-7](#)
 - configuration tips for phone security profiles [32-1](#)
 - deleting CTL file [31-16](#)
 - directories button [11-29](#)
 - encrypted configuration file [33-1](#)
 - features
 - abbreviated dial [11-26](#)
 - barge [11-21](#)
 - call diagnostics and voice quality metrics [11-26](#)
 - call forward [11-21](#)
 - call park [11-23](#)
 - call pickup [11-23](#)
 - call select [11-23](#)
 - conference list [11-24](#)
 - described [11-21](#)
 - direct transfer [11-24](#)
 - immediate divert [11-24](#)
 - join [11-24](#)
 - malicious call ID [11-25](#)
 - privacy [11-21](#)
 - quality report tool [11-25](#)
 - service URL [11-26](#)
 - speed dial [11-26](#)
 - messages button [11-28](#)
 - overview [11-1](#)
 - security icons [30-5](#)
 - restrictions [30-9](#)
 - supported models
 - described (table) [11-2](#)
 - listed [11-2](#)
- Cisco Unified Personal Communicator
 - described [11-9](#)
- Cisco VG200 Voice Gateway [10-2](#)
- Cisco VG224 Analog Phone Gateway
 - configuring [10-4](#)
 - description [10-4](#)
- Cisco VG248 Analog Phone Gateway
 - configuring [10-2](#)
 - description [10-2](#)
 - gateway redundancy [10-18](#)
- Cisco Video Conference Bridge
 - perfmon object and counters [23-47](#)
- Cisco WebDialer

- perfmon object and counters [23-48](#)
- Cisco WSM Connector
 - perfmon object and counters [23-48](#)
- CLI
 - starting services [15-6](#)
 - stopping services [15-6](#)
- closest-match routing [7-12](#)
- CMLocal date/time group [5-4](#)
- CMR dump table [28-25](#)
- CMR values, CDR load [25-8](#)
- codecs
 - bandwidth used per call (table) [5-8](#)
 - G.711 [5-7](#)
 - G.723 [5-7](#)
 - G.729 [5-7](#)
 - GSM [5-7](#)
 - supported by Cisco Unified CallManager [5-7](#)
 - wideband [5-7](#)
- common phone profiles
 - described [11-20](#)
- conference
 - described [8-7](#)
- conference bridge utilization, report results [28-22](#)
- conference call detail, report results [28-21](#)
- conference list
 - described [11-24](#)
- configuration
 - settings
 - checklist (table) [5-17](#)
 - list of topics [5-1](#)
- configuration checklist
 - CAR [24-15](#)
 - MGCP BRI [10-21](#)
- configuration file
 - encryption [30-19](#)
- configuration profile
 - adding [18-5](#)
 - deleting [18-6](#)
 - restoring [18-6](#)
- using default [18-5](#)
- configuring [27-5, 27-7](#)
- connected party
 - presentation settings [7-31](#)
 - restriction settings [7-31](#)
 - transformations settings (table) [7-32](#)
- Control Center
 - described [19-12](#)
 - feature services [19-12](#)
 - network services [19-12](#)
 - starting services [15-4](#)
 - starting services, described [19-12](#)
 - stopping services [15-4](#)
 - stopping services, described [19-12](#)
 - viewing service status, described [19-12](#)
 - viewing status [15-4](#)
- conventions [xxv](#)
- CorporateDirectory.txt file
 - creating and uploading [14-33](#)
 - deleting [14-34](#)
- counters
 - adding [23-61](#)
 - alert notification [23-61](#)
 - chart [23-61](#)
 - perfmon, described [23-1](#)
 - properties [23-61](#)
 - zooming [23-61](#)
- CTI
 - Cisco CTIManager
 - perfmon object and counters [23-15](#)
 - Cisco CTIManager service [19-3](#)
 - finding CTI devices [18-10](#)
 - monitoring CTI applications [18-14](#)
 - monitoring CTI devices [18-14](#)
 - monitoring CTI lines [18-15](#)
 - ports
 - described [11-8](#)
 - service
 - Cisco IP Manager Assistant Service [19-4](#)

- Cisco WebDialer Web Service [19-4](#)
- viewing CTIManager information [18-14](#)
- CTL client
 - CAPF service [31-5](#)
 - clusterwide security mode
 - updating [31-12](#)
 - configuration checklist (table) [31-3](#)
 - configuration settings (table) [31-13](#)
 - configuration tips [31-2](#)
 - configuring [31-8](#)
 - TLS ports [31-5](#)
 - CTL Provider service [31-4](#)
 - deleting CTL file on phone [31-16](#)
 - installing [30-12, 31-6](#)
 - migrating [31-7](#)
 - overview [31-2](#)
 - security mode
 - verifying [31-15](#)
 - security token password
 - changing [31-16](#)
 - setting the Smart Card service [31-15](#)
 - uninstalling [31-18](#)
 - upgrading [31-7](#)
 - verifying [31-18](#)
 - version
 - determining [31-17](#)
- CTL file
 - deleting entry [31-12](#)
 - deleting on phone [31-16](#)
 - updating [31-10](#)
- CTL Provider
 - activating service [31-4](#)
- CUPS license
 - configuring [3-1](#)
- customizing, reports for automatic generation [26-7](#)
- customizing reports for automatic generation [24-11](#)

D

- daily charges, notification limits configuration [26-8](#)
- daily reports
 - scheduling [25-9](#)
- database
 - automatic purge configuration [25-14](#)
 - disabling automatic purge [25-14](#)
 - restoring purge defaults [25-12](#)
 - scalability [12-7](#)
 - service
 - A Cisco DB [19-7](#)
 - A Cisco DB Replicator [19-7](#)
 - Cisco AXL Web Service [19-5](#)
 - Cisco Bulk Provisioning Service [19-5](#)
 - Cisco Database Layer Monitor [19-8](#)
- Database Change Notification Client
 - perfmon object and counters [23-49](#)
- Database Change Notification Server
 - perfmon object and counters [23-50](#)
- Database Change Notification Subscription
 - perfmon object and counters [23-50](#)
- Database Local DSN
 - perfmon object and counters [23-50](#)
- Data Encryption [36-14](#)
- date/time groups
 - CMLocal [5-4](#)
 - described [5-4](#)
- DB User Host Information Counters
 - perfmon object and counters [23-51](#)
- DDI [7-13](#)
 - configuring [7-19](#)
 - explained (table) [7-19](#)
- definitions
 - alarms [20-2](#)
- department bill detail, report results [28-3](#)
- department bill summary, report results [28-2](#)
- dependency records
 - Cisco Unified CallManager Attendant Console [14-40](#)

- directory numbers
 - described [8-9](#)
- gateways [10-16](#)
- phones
 - described [11-30](#)
- system-level settings [5-16](#)
- detail
 - department bill, report results [28-3](#)
 - gateway, report results [28-18](#)
 - individual bill, report results [28-3](#)
 - QoS, report results [28-9](#)
- device authentication [30-15](#)
 - configuration settings (table)
 - for SCCP phone [32-4](#)
 - for SIP phones [32-6](#)
 - configuring for phones [32-3](#)
- device control protocols
 - and caller identification support (table) [7-34](#)
- device pools
 - described [5-10](#)
 - search for phones [11-27](#)
 - updating [5-11](#)
- device reports, CAR [24-10](#)
- devices
 - accessing TFTP server [6-6](#)
 - identifying TFTP server [6-6](#)
 - using Cisco TFTP [6-4](#)
 - using DHCP [6-4](#)
- DHCP
 - and devices [6-4](#)
- dial plan, configuration [25-2](#)
- dial plans
 - accessing gateways [10-16](#)
- digest authentication [30-15](#)
 - configuration settings (table)
 - for SIP phones [32-6](#)
 - configuring for phones [32-3](#)
 - enabling for SIP third-party phones [4-2](#)
- digital trunk gateway
 - DT-24+/DE-30+ [10-2](#)
- digit analysis
 - static
 - caveats [7-15](#)
 - configuration tip [7-14](#)
 - described [7-14](#)
 - example prior to static digit analysis [7-15](#)
 - explained [7-14](#)
 - Unified CallManager Assistant example with static digit analysis [7-16](#)
- directories button
 - configuring [11-29](#)
- directory
 - access [9-3](#)
 - access for Cisco IP telephony endpoints [9-5](#)
 - Cisco DirSync service [19-7](#)
 - Cisco Unified CallManager Attendant Console, understanding [14-9](#)
 - configuration checklist (table) [9-6](#)
 - LDAP [5-12](#)
 - more information [9-7](#)
 - overview [9-1](#)
- directory numbers
 - active check box [8-5](#)
 - call forward
 - busy trigger [8-6, 11-22](#)
 - no answer ring duration [8-6, 11-22](#)
 - call forward information display [8-6, 11-22](#)
 - characteristics [8-1](#)
 - conference [8-7](#)
 - configuration checklist (table) [8-10](#)
 - dependency records
 - described [8-9](#)
 - direct transfer [8-8](#)
 - features [8-5](#)
 - call forward [8-6](#)
 - call waiting [8-7](#)
 - find all directory numbers [8-9](#)
 - join [8-8](#)

- making and receiving multiple calls [8-7](#)
- managing [8-5](#)
- more information [8-11](#)
- overview [8-1](#)
- search tips [8-8](#)
- shared line appearance [8-2](#)
- shared line appearance restrictions [8-4](#)
- transfer [8-7](#)
- update directory number of all devices sharing this line
 - check box [8-5](#)
- direct transfer
 - described [8-8, 11-24](#)
- disabling
 - alerts by mail [26-8](#)
 - automatic CAR and CDR database purge [25-14](#)
 - automatic database purge [25-14](#)
 - CDR loading [25-7](#)
- discard digits instructions (DDI) [7-13](#)
 - configuring [7-19](#)
 - explained (table) [7-19](#)
- divert to voice messaging
 - phone support [38-1](#)
 - phone user [38-1](#)
- DNs
 - characteristics [8-1](#)
 - overview [8-1](#)
- document
 - conventions [xxv](#)
 - organization [xxiv](#)
- documentation
 - related [xxv](#)
- dump table, CDR and CMR [28-25](#)
- duration [26-2](#)

E

- E1 Primary Rate Interface (PRI) [10-1](#)
- enabling
 - alerts by mail [26-8](#)

- reports for automatic generation [26-7](#)
- enabling reports for automatic generation [24-11](#)
- encrypted configuration file
 - configuration checklist (table) [33-5](#)
 - configuration settings (table)
 - for manual key [33-7](#)
 - configuration tips [33-4](#)
 - configuring manual key distribution [33-6](#)
 - disabling [33-9](#)
 - enabling [33-6](#)
 - entering symmetric key [33-7](#)
 - manual key configuration checklist (table) [33-7](#)
 - manual key distribution [33-2](#)
 - phone support [33-4](#)
 - symmetric key encryption with public key [33-3](#)
 - understanding [33-1](#)
 - using symmetric key encryption w/public key [33-8](#)
 - verifying [33-8](#)
- encryption
 - configuration settings (table)
 - for SCCP phone [32-4](#)
 - for SIP phone security profiles [32-6](#)
 - configuring for phones [32-3](#)
 - configuring with barge [30-11](#)
 - installing [30-12](#)
 - interactions [30-5](#)
 - overview [30-19](#)
 - restrictions [30-5, 30-6](#)
 - with authentication [30-7](#)
 - with barge [30-7](#)
 - with media resources [30-8](#)
 - with packet capturing [30-9](#)
 - with phone and trunk devices [30-8](#)
 - with security icons [30-9](#)
- signaling
 - configuring for phones [32-3](#)
- endCallSoap [37-11](#)
- enterprise parameters
 - described [5-15](#)

Enterprise Replication DBSpace Monitors

perfmon object and counters [23-51](#)

Enterprise Replication Perfmon Counters

perfmon object and counters [23-51](#)

error

CDR report, results [28-17](#)

etoken

changing password [31-16](#)event levels for alarms [16-4](#)

event log

generating [25-15](#)event log, generating [24-6](#)

event log report

output [25-16](#)status [25-15](#)Example AXL Requests [36-5](#)Example XML Structure [36-13](#)

expansion module

Cisco Unified IP Phone 7914 [11-4](#)

extension

CDR search by [27-1](#)CDR search by, report results [28-23](#)

external route plan wizard

described [7-34](#)generated route filters [7-35](#)generated route groups [7-36](#)generated route lists [7-36](#)generated route patterns [7-37](#)

F

features

immediate divert [13-1](#)phone features (table) [11-15](#)

feature services

activating [15-1, 19-1](#)configuration checklist (table) [19-13](#)deactivating [15-1](#)described [19-1](#)multiserver recommendations (table) [15-2](#)starting [15-4, 19-1](#)stopping [15-4, 19-1](#)viewing status [15-4, 19-1](#)

fields

requiring route patterns (table) [7-18](#)file authentication [30-15](#)configuring for phones [32-3](#)

fixed audio source

configuration settings (table) [12-23](#)configuring [12-21, 12-22](#)deleting [12-22](#)Foreign Exchange Office (FXO) [10-1](#)Foreign Exchange Station (FXS) [10-1](#)FXO [10-1](#)FXS [10-1](#)

G

G.711 [5-7](#)G.723 [5-7](#)G.729 [5-7](#)

gateway

CDR search by [27-3](#)configuration for CAR [25-5](#)QoS report results by gateway [28-11](#)gateway detail, report results [28-18](#)

gateways

Catalyst 4000 Access Gateway Module [10-7](#)Catalyst 4224 gateway [10-7](#)Catalyst 6000 FXS Analog Interface Module [10-6](#)Catalyst 6000 T1/E1 and Services Module [10-6](#)Cisco Communications Media Module [10-7](#)Cisco IOS H.323 devices [10-7](#)Cisco voice gateways [10-1](#)configuration checklist (table) [10-20](#)dependency records [10-16](#)failover and fallback [10-17](#)H.323 devices list [10-7](#)

- models (table) [10-9](#)
- more information [10-22](#)
- overview [10-1](#)
- port types (table) [10-9](#)
- related to dial plans [10-16](#)
- signaling protocols (table) [10-9](#)
- standalone
 - digital trunk [10-2](#)
 - IAD2420 [10-4](#)
 - VG200 voice [10-2](#)
 - VG224 analog phone [10-4](#)
 - VG248 analog phone [10-2](#)
- summary of voice gateways (table) [10-9](#)
- trunk interfaces
 - table [10-9](#)
- gateway summary, report results [28-19](#)
- gateway utilization, report results [28-21](#)
- generating
 - event log [25-15](#)
- getProfileSoap [37-13](#)
- Global Directory
 - displaying with directories button [11-29](#)
- groups, Cisco Unified CallManager
 - configuring [5-3](#)
- groups, date/time [5-4](#)
- GSM [5-7](#)

H

H.323

- Cisco IOS gateways [10-7](#)
- clients [11-8](#)
- gateways [10-7](#)
- IOS gateway redundancy [10-17](#)
- held icon timers, configuring [14-39](#)
- hookflash transfer [10-6](#)
- Host Resources Agent service [19-8](#)
- HTML over HTTP Interfaces [37-15](#)
- hunt groups

- broadcast, understanding [14-8](#)
 - circular, understanding [14-6](#)
 - configuration settings (table) [14-30](#)
 - configuring [14-29](#)
 - deleting members [14-32](#)
 - linked, understanding [14-5](#)
 - understanding [14-2](#)
 - viewing members [14-32](#)
- described [7-11](#)
 - example [7-11](#)
 - maximum hunt timer [7-12](#)
 - personal preferences [7-12](#)
- described [7-10](#)
- described [7-10](#)
 - wildcards [7-16](#)

- image authentication [30-15](#)
- immediate divert
 - configuration checklist (table) [13-9](#)
 - described [11-24](#)
 - installing and activating [13-9](#)
 - interactions [13-6](#)
 - more information [13-11](#)
 - overview [13-1](#)
 - restrictions [13-8](#)
 - setting service parameters [13-10](#)
 - system requirements [13-2](#)
 - using [13-4](#)
- individual bill detail, report results [28-3](#)
- individual bill summary, report results [28-2](#)
- Install Changes [37-6](#)
- Integration Considerations [36-14](#)
- integrity
 - overview [30-15](#)

Interfaces [37-9](#)
 internationalization for CDR analysis and reporting [24-14](#)
 Introduction [36-1](#)
 IP
 perfmon object and counters [23-51](#)
 IP Phones
 See Cisco Unified IP Phones
 IPSec [30-12](#)
 isClusterUserSoap [37-14](#)

J

Java Example [36-10](#)
 JavaScript sample [37-19](#)
 join
 described [8-8, 11-24](#)

L

LDAP
 described [5-12](#)
 directory
 more information [9-7](#)
 overview [9-1](#)
 license capabilities assignment
 adding for multiple users [3-3](#)
 adding for one user [3-2](#)
 configuration settings (table) [3-4](#)
 configuring [3-1](#)
 finding [3-1](#)
 updating for multiple users [3-3](#)
 updating for one user [3-2](#)
 line groups
 described [7-9](#)
 load
 CDR schedule configuration [25-7](#)
 disabling CDR [25-7](#)
 restoring the default CDR schedule [25-7](#)

locations
 and regions [5-9](#)
 logon page [24-14](#)
 Log Partition Monitoring
 service [19-9](#)
 logs
 perfmon [23-62](#)

M

mail server parameters [25-2](#)
 makeCall [37-15](#)
 makeCallProxy [37-15](#)
 makeCallSoap [37-9](#)
 malicious call ID
 described [11-25](#)
 managers, CAR [24-5](#)
 manual database purge, configuration [25-12](#)
 master TFTP server
 sending files to the master TFTP server [6-9](#)
 maximum hunt timer [7-12](#)
 media encryption (*See also* encryption)
 overview [30-19](#)
 media information [28-25](#)
 Memory
 perfmon object and counters [23-52](#)
 messages button [11-28](#)
 MGCP
 gateway redundancy [10-17](#)
 MGCP BRI
 configuring [10-21](#)
 illustration of call flow [10-5](#)
 MIB2 Agent service [19-8](#)
 MLPP
 described [5-15](#)
 mode
 mixed [30-9](#)
 nonsecure [30-9](#)
 modifying files [6-10](#)

MOH

audio files

- deleting [12-30](#)
- displaying [12-28](#)
- managing [12-28](#)
- uploading [12-29](#)

audio sources [12-16](#)

- configuration settings (table) [12-19](#)
- configuring [12-18](#)
- deleting [12-19](#)
- explained [12-8](#)
- finding [12-17](#)

call park example [12-5](#)characteristics [12-3](#)configuration checklist (table) [12-14](#)configuring [12-23](#)creating audio sources [12-9](#)database scalability [12-7](#)default MOH sample [12-9](#)definitions [12-2](#)described [12-1](#)failover and fallback [12-13](#)

features

- database requirements [12-7](#)
- database scalability [12-7](#)
- manageability [12-7](#)
- MOH servers [12-5](#)
- server manageability [12-6](#)
- server redundancy [12-6](#)
- server scalability [12-6](#)

fixed audio source [12-21](#)

- configuration settings (table) [12-23](#)
- configuring [12-22](#)
- deleting [12-22](#)

functionality [12-4](#)list of topics [12-1](#)managing audio sources [12-10](#)

monitoring performance

- overview (table) [12-15](#)

service states [12-16](#)requirements and limits [12-12](#)server configuration settings (table) [12-26](#)

servers

- characteristics [12-5](#)
- configuring [12-24](#)
- database requirements [12-7](#)
- explained [12-8](#)
- finding [12-23](#)
- manageability [12-6](#)
- perfmon counters [12-15](#)
- redundancy [12-6](#)
- resetting [12-25](#)
- scalability [12-6](#)

storing audio sources [12-9](#)supported features [12-5](#)transfer hold example [12-5](#)understanding [12-1](#)user hold example [12-5](#)

monitoring

- CTI applications [18-14](#)
- CTI devices [18-10, 18-14](#)
- CTI lines [18-15](#)
- gateways [18-10](#)
- H.323 devices [18-10](#)
- hunt list [18-10](#)
- media resources [18-10](#)
- performance [23-61](#)
- phones [18-10](#)
- predefined objects [18-7](#)
- services [18-7](#)
- SIP trunk [18-10](#)
- voice-mail devices [18-10](#)

monthly reports

- scheduling [25-11](#)

multicast

- audio sources for MOH [12-10](#)
- configuration checklist (table) [12-12](#)
- explained [12-10](#)

Multiple Cluster Applications [37-19](#)

Multiple Clusters [37-3](#)

music on hold (MOH)

- audio sources [12-8](#)
- call park example [12-5](#)
- characteristics [12-3](#)
- configuration checklist (table) [12-14](#)
- creating audio sources [12-9](#)
- default MOH sample [12-9](#)
- definitions [12-2](#)
- described [12-1](#)
- failover and fallback [12-13](#)
- functionality [12-4](#)
- list of topics [12-1](#)
- managing audio sources [12-10](#)
- monitoring performance
 - overview (table) [12-15](#)
 - service states [12-16](#)
- requirements and limits [12-12](#)
- servers
 - characteristics [12-5](#)
 - database requirements [12-7](#)
 - explained [12-8](#)
 - manageability [12-6](#)
 - perfmon counters [12-15](#)
 - redundancy [12-6](#)
 - scalability [12-6](#)
- storing audio sources [12-9](#)
- supported features [12-5](#)
- transfer hold example [12-5](#)
- understanding [12-1](#)
- user hold example [12-5](#)

N

Network Agent Adaptor service [19-8](#)

Network Interface

- perfmon object and counters [23-54](#)

network services

Control Center [19-7](#)

- described [19-7](#)
- starting [15-4, 19-7](#)
- stopping [15-4, 19-7](#)
- viewing status [15-4, 19-7](#)

New and Changed Information [36-2](#)

notification limits [26-8](#)

NT Event Viewer [16-3](#)

Number of Replicates

- perfmon object and counters [23-55](#)

O

object

- perfmon, described [23-1](#)

object and counters

- Database Change Notification Client [23-49](#)

on-hook call transfer [11-24](#)

organization [xxiv](#)

Overview [37-2](#)

overview

- automatic report generation [26-6](#)
- error and event logs [24-6](#)

P

parameters

- enterprise
 - described [5-15](#)
- factoring time of day for rating [26-3](#)
- factoring voice quality for rating [26-4](#)
- mail server configuration [25-2](#)
- service
 - described [5-16](#)
 - Maximum Phone FallBack Queue Depth [11-30](#)
 - setting the base rate and duration for rating [26-2](#)
 - system configuration [25-1](#)

Partition

- perfmon object and counters [23-55](#)
- Partition Support [37-6](#)
- perfmon
 - counters
 - adding [23-61](#)
 - category tabs, described [23-60](#)
 - chart [23-61](#)
 - properties [23-61](#)
 - sample rates [23-61](#)
 - zooming [23-61](#)
 - logs [23-62](#)
 - object and counters
 - Cisco Analog Access [23-3](#)
 - Cisco Annunciator Device [23-4](#)
 - Cisco CallManager [23-4](#)
 - Cisco CallManager Attendant Console [23-11](#)
 - Cisco CallManager System Performance [23-12](#)
 - Cisco CTIManager [23-15](#)
 - Cisco Dual-Mode Mobility [23-16](#)
 - Cisco Extension Mobility [23-17](#)
 - Cisco Gatekeeper [23-17](#)
 - Cisco H.323 [23-18](#)
 - Cisco Hunt Lists [23-19](#)
 - Cisco HW Conference Bridge Device [23-20](#)
 - Cisco IP Manager Assistant [23-20](#)
 - Cisco Lines [23-21](#)
 - Cisco Locations [23-21](#)
 - Cisco Media Streaming Application [23-22](#)
 - Cisco Messaging Interface [23-25](#)
 - Cisco MGCP FXO Device [23-25](#)
 - Cisco MGCP FXS Device [23-26](#)
 - Cisco MGCP Gateways [23-26](#)
 - Cisco MGCP PRI Device [23-27](#)
 - Cisco MGCP T1CAS Device [23-27](#)
 - Cisco MOH Device [23-28](#)
 - Cisco MTP Device [23-29](#)
 - Cisco Phones [23-29](#)
 - Cisco Presence Feature [23-30](#)
 - Cisco QSIG Feature [23-30](#)
 - Cisco SIP [23-30](#)
 - Cisco SIP Stack [23-31](#)
 - Cisco SW Conf Bridge Device [23-39](#)
 - Cisco TFTP Server [23-40](#)
 - Cisco Tomcat Connector [23-43](#)
 - Cisco Transcode Device [23-47](#)
 - Cisco Video Conference Bridge [23-47](#)
 - Cisco WebDialer [23-48](#)
 - Cisco WSM Connector [23-48](#)
 - Database Change Notification Server [23-50](#)
 - Database Change Notification Subscription [23-50](#)
 - Database Local DSN [23-50](#)
 - DB User Host Information [23-51](#)
 - described [23-1](#)
 - Enterprise Replication [23-51](#)
 - Enterprise Replication DBSpace Monitors [23-51](#)
 - IP [23-51](#)
 - Memory [23-52](#)
 - Network Interface [23-54](#)
 - Partition [23-55](#)
 - Process [23-56](#)
 - Processor [23-57](#)
 - System [23-58](#)
 - TCP [23-58](#)
 - Thread [23-59](#)
 - Tomcat JVM [23-45](#)
 - Tomcat Web Application [23-46](#)
- perfmon counters
 - counter descriptions (table) [12-16](#)
 - using to view MOH servers [12-15](#)
- performance monitoring
 - category tabs, described [23-60](#)
 - counters
 - adding [23-61](#)
 - chart [23-61](#)
 - properties [23-61](#)
 - zooming [23-61](#)
 - Number of Replicates [23-55](#)
 - object and counters

- Cisco Analog Access [23-3](#)
- Cisco Annunciator Device [23-4](#)
- Cisco CallManager [23-4](#)
- Cisco CallManager Attendant Console [23-11](#)
- Cisco CallManager System Performance [23-12](#)
- Cisco CTIManager [23-15](#)
- Cisco Dual-Mode Mobility [23-16](#)
- Cisco Extension Mobility [23-17](#)
- Cisco Gatekeeper [23-17](#)
- Cisco H.323 [23-18](#)
- Cisco Hunt Lists [23-19](#)
- Cisco HW Conference Bridge Device [23-20](#)
- Cisco IP Manager Assistant [23-20](#)
- Cisco Lines [23-21](#)
- Cisco Locations [23-21](#)
- Cisco Media Streaming Application [23-22](#)
- Cisco Messaging Interface [23-25](#)
- Cisco MGCP FXO Device [23-25](#)
- Cisco MGCP FXS Device [23-26](#)
- Cisco MGCP Gateways [23-26](#)
- Cisco MGCP PRI Device [23-27](#)
- Cisco MGCP T1CAS Device [23-27](#)
- Cisco MOH Device [23-28](#)
- Cisco MTP Device [23-29](#)
- Cisco Phones [23-29](#)
- Cisco Presence Feature [23-30](#)
- Cisco QSIG Feature [23-30](#)
- Cisco SIP [23-30](#)
- Cisco SIP Stack [23-31](#)
- Cisco SW Conf Bridge Device [23-39](#)
- Cisco TFTP Server [23-40](#)
- Cisco Tomcat Connector [23-43](#)
- Cisco Transcode Device [23-47](#)
- Cisco Video Conference Bridge [23-47](#)
- Cisco WebDialer [23-48](#)
- Cisco WSM Connector [23-48](#)
- Database Change Notification Server [23-50](#)
- Database Change Notification Subscription [23-50](#)
- Database Local DSN [23-50](#)
- DB User Host Information [23-51](#)
- described [23-1](#)
- Enterprise Replication [23-51](#)
- Enterprise Replication DBSpace Monitors [23-51](#)
- IP [23-51](#)
- Memory [23-52](#)
- Network Interface [23-54](#)
- Number of Replicates [23-55](#)
- Partition [23-55](#)
- Process [23-56](#)
- Processor [23-57](#)
- System [23-58](#)
- TCP [23-58](#)
- Thread [23-59](#)
- Tomcat JVM [23-45](#)
- Tomcat Web Application [23-46](#)
- sample rates [23-61](#)
- service
 - Cisco AMC Service [19-10](#)
 - Cisco CallManager Cisco IP Phone Services [19-3](#)
 - Cisco CallManager Serviceability RTMT [19-10](#)
 - Cisco CCM SNMP Service [19-6](#)
 - Cisco Extended Functions [19-3](#)
 - Cisco RIS Data Collector [19-9](#)
 - Cisco RTMT Reporter Servlet [19-10](#)
 - Cisco Serviceability Reporter [19-5](#)
- personal preferences [7-12](#)
- phone button templates
 - 12 series, default template [11-14](#)
 - 30 SP+, default template [11-13](#)
 - 30 VIP, default template [11-13](#)
 - 7902, default template [11-13](#)
 - 7905 SCCP, default template [11-13](#)
 - 7905 SIP, default template [11-13](#)
 - 7906 SCCP, default template [11-13](#)
 - 7906 SIP, default template [11-13](#)
 - 7910, default template [11-13](#)
 - 7911 SCCP, default template [11-12](#)
 - 7911 SIP, default template [11-13](#)

- 7912 SCCP, default template [11-12](#)
- 7912 SIP, default template [11-12](#)
- 7920, default template [11-12](#)
- 7940 SCCP, default template [11-12](#)
- 7940 SIP, default template [11-12](#)
- 7941 G-GE SCCP, default template [11-12](#)
- 7941 SCCP, default template [11-12](#)
- 7941 SIP, default template [11-12](#)
- 7960 SCCP, default template [11-12](#)
- 7960 SIP, default template [11-12](#)
- 7961 G-GE SCCP, default template [11-11](#)
- 7961 SCCP, default template [11-11](#)
- 7961 SIP, default template [11-11](#)
- 7970 SCCP, default template [11-11](#)
- 7970 SIP, default template [11-11](#)
- 7971 SCCP, default template [11-11](#)
- 7971 SIP, default template [11-11](#)
- 7985, default template [11-11](#)
- analog phone, default template [11-14](#)
- ATA 186, default template [11-14](#)
- Cisco IP Communicator, default template [11-14](#)
- Cisco TelePresence, default template [11-14](#)
- CN622, default template [11-14](#)
- conference station 7935, default template [11-13](#)
- conference station 7936, default template [11-13](#)
- IP-STE, default template [11-14](#)
- ISDN BRI Phone, default template [11-14](#)
- third-party SIP device, default template [11-14](#)
- VGC phone, default template [11-14](#)
- VGC Virtual, default template [11-14](#)
- phone NTP reference
 - configuring for SIP phones [5-4](#)
- phones
 - See also* Cisco Unified IP Phones
 - administration tips [11-27](#)
 - associating with users [11-27](#)
 - button templates
 - default [11-10](#)
 - described [11-10](#)
 - guidelines [11-14](#)
 - listed by model (table) [11-11](#)
 - common phone profiles [11-20](#)
 - dependency records
 - described [11-30](#)
 - failover and fallback [11-30](#)
 - features
 - described (table) [11-15](#)
 - privacy [11-21](#)
 - find all phones [11-28](#)
 - methods for adding [11-20](#)
 - more information [11-35](#)
 - SCCP configuration checklist (table) [11-31](#)
 - search by authentication string [11-28](#)
 - search by calling search space [11-27](#)
 - search by call pickup group [11-28](#)
 - search by description [11-27](#)
 - search by device name [11-27](#)
 - search by device pool [11-27](#)
 - search by device protocol [11-28](#)
 - search by device type [11-28](#)
 - search by directory number [11-27](#)
 - search by LSC status [11-28](#)
 - search by security profile [11-28](#)
 - search tips [11-27](#)
 - search within results [11-28](#)
 - SIP configuration checklist (table) [11-31](#)
 - softkey templates
 - add application [11-17](#)
 - configure softkey layout [11-18](#)
 - described [11-16](#)
- pilot points
 - associating with the ac user [14-28](#)
 - configuration settings [14-25](#)
 - configuring [14-24](#)
 - deleting [14-27](#)
 - finding [14-23](#)
 - resetting [14-28](#)
 - understanding [14-2](#)

platform services

- Cisco CDP Agent [19-8](#)
- Cisco Certificate Expiry Monitor Service [19-8](#)
- Cisco DB [19-7](#)
- Cisco Electronic Notification [19-8](#)
- Cisco License Manager [19-8](#)
- Cisco Syslog Agent [19-8](#)
- Cisco Tomcat [19-7](#)
- Host Resources Agent [19-8](#)
- MIB2 Agent [19-8](#)
- Network Agent Adaptor [19-8](#)
- SNMP Master Agent [19-8](#)

polling intervals

- sample rate [23-61](#)

polling rate [18-13](#)

port

- CTL Provider [31-5](#)
- Ethernet phone [31-5](#)
- SIP secure [31-5](#)

ports

- CTI
- described [11-8](#)

predefined objects

- monitoring [18-7](#)

preferences

- system configuration [25-6](#)

presentation settings

- calling party [7-29](#)
- connected party [7-31](#)

privacy

- described [11-21](#)

Process

- perfmon object and counters [23-56](#)

Processor

- perfmon object and counters [23-57](#)

profiles

- common phone [11-20](#)

protocols

- Skinn Client Control Protocol [10-3](#)

Skinn Client Control Protocol (SCCP) Gateway Protocol [10-17](#)Skinn Gateway Protocol [10-16](#)

purge

- automatic database configuration [25-14](#)
- disabling automatic database [25-14](#)
- restoring database defaults [25-12](#)

Q

QoS

- default values [26-5](#)
- defining values [26-5](#)
- notification limits configuration [26-8](#)

QoS by call types, report results [28-11](#)QoS by gateway, report results [28-11](#)QoS detail, report results [28-9](#)QoS summary, report results [28-11](#)Q signaling (QSIG) [10-1](#)QSIG trunk interface [10-1](#)

quality report tool

- described [11-25](#)

R
rating engine, configuration [26-1](#)

rating parameters

- factoring time of day [26-3](#)
- factoring voice quality [26-4](#)
- setting the base rate and duration [26-2](#)

Real-Time Monitoring Tool

alerts

- notification for a counter [23-61](#)

category

- adding [18-17](#)
- deleting [18-18](#)
- renaming [18-17](#)

category tabs, described [23-60](#)

configuration profile

- adding [18-5](#)
- deleting [18-6](#)
- restoring [18-6](#)
- using default [18-5](#)
- counters
 - adding [23-61](#)
 - alert notification [23-61](#)
 - chart [23-61](#)
 - monitor [23-61](#)
- e-mail notification, configuring [18-4](#)
- finding
 - CTI applications [18-14](#)
 - CTI devices [18-14](#)
 - CTI lines [18-15](#)
 - devices [18-10](#)
- installing [18-1](#)
- list of topics [22-1](#)
- loading [18-3](#)
- logging and report generation
 - call log [22-9](#)
 - device log [22-13](#)
 - server log [22-7](#)
 - service log [22-11](#)
- monitoring
 - call processing [18-7](#)
 - CTIManager [18-7](#)
 - devices [18-7](#)
 - predefined objects [18-7](#)
 - server [18-7](#)
 - services [18-7](#)
 - summary [18-7](#)
- monitoring predefined objects [18-7](#)
- monitoring summary [18-7](#)
- overview [22-1](#)
- polling interval [23-61](#)
- polling rate, configuring [18-13](#)
- sample rate [23-61](#)
- service
 - Cisco AMC Service [19-10](#)
 - Cisco CallManager Serviceability RTMT [19-10](#)
 - Cisco RTMT Reporter Servlet [19-10](#)
 - Cisco Syslog Agent [19-8](#)
- uninstalling [18-2](#)
- using [18-3](#)
- viewing
 - CTIManager information [18-14](#)
 - device properties [18-12](#)
 - phone information [18-12](#)
- view tab
 - summary [22-6](#)
- window components [22-3](#)
- zooming a counter [23-61](#)
- Redirector Servlet [37-2](#)
- redundancy
 - Cisco Unified CallManager Attendant Console [14-11](#)
 - Cisco VG248 [10-18](#)
 - IOS H.323 gateways [10-17](#)
 - MGCP gateway [10-17](#)
 - MOH servers [12-6](#)
 - support for gateways [10-17](#)
- regions
 - adding [2-3](#)
 - and call admission control [5-9](#)
 - and locations [5-9](#)
 - configuration settings (table) [2-5](#)
 - configuring [2-1](#)
 - deleting [2-7](#)
 - described [5-5](#)
 - example (figure) [5-9](#)
 - finding [2-1](#)
- related documentation [xxv](#)
- report
 - CDR search [27-1](#)
 - CDR search by cause for call termination [27-4](#)
 - CDR search by gateway [27-3](#)
 - CDR search by user extension [27-1](#)
- report configuration, CAR [26-1](#)
- report results

- CDR error [28-17](#)
- CDR search by user extension [28-23](#)
- Cisco IP Phone services [28-9](#)
- conference bridge utilization [28-22](#)
- conference call detail [28-21](#)
- department bill, detail [28-3](#)
- department bill, summary [28-2](#)
- gateway detail [28-18](#)
- gateway summary [28-19](#)
- gateway utilization [28-21](#)
- individual bill, detail [28-3](#)
- individual bill, summary [28-2](#)
- QoS by gateway [28-11](#)
- QoS detail [28-9](#)
- QoS report by call types [28-11](#)
- QoS summary [28-11](#)
- route group utilization [28-21](#)
- route list utilization [28-21](#)
- route pattern utilization [28-21](#)
- system overview [28-16](#)
- top N by charge [28-4](#)
- top N by duration [28-4](#)
- top N by number of calls [28-5](#)
- traffic summary [28-12](#)
- traffic summary by extensions [28-12](#)
- voice mail utilization [28-23](#)
- Reports
 - CAR report results [28-1](#)
- reports
 - automatic generation configuration [26-6](#)
 - automatic report generation/alert [26-6](#)
 - customizing for automatic generation [24-11, 26-7](#)
 - enabling for automatic generation [24-11, 26-7](#)
 - overview [24-15](#)
 - perfmon logs [23-62](#)
 - scheduling daily [25-9](#)
 - scheduling monthly [25-11](#)
 - scheduling weekly [25-10](#)
 - system overview results [28-16](#)
 - user, CAR [24-7](#)
- restore
 - service
 - Cisco DRF Local [19-11](#)
 - Cisco DRF Master [19-11](#)
- restoring
 - CAR database purge defaults [25-12](#)
 - default CDR load schedule [25-7](#)
- restriction settings
 - calling party [7-29](#)
 - connected party [7-31](#)
- Results [37-10](#)
- route
 - group utilization, report results [28-21](#)
 - list utilization, report results [28-21](#)
 - pattern utilization, report results [28-21](#)
- route filters
 - associated with route lists (table) [7-35](#)
 - described [7-35](#)
- route groups
 - described [7-5](#)
 - generated [7-36](#)
 - related to dial plans [10-16](#)
- route lists
 - associated route filters (table) [7-35](#)
 - described [7-5](#)
 - generated [7-36](#)
 - types (table) [7-37](#)
 - types, example [7-5](#)
- route patterns
 - closest-match routing [7-12](#)
 - considerations for using [7-6](#)
 - explained [7-6](#)
 - fields in Cisco Unified CallManager (table) [7-18](#)
 - generated with external route plan wizard [7-37](#)
 - usage [7-6](#)
 - using the @ wildcard character [7-13](#)
 - wildcards [7-16](#)
- route plans

- and Cisco Analog Access Gateways (figure) [7-9](#)
- and Cisco Digital Access Gateways (figure) [7-8](#)
- external route plan wizard
 - generated route filters [7-35](#)
 - generated route groups [7-36](#)
 - generated route lists [7-36](#)
 - generated route patterns [7-37](#)
- list of topics [7-1](#)
- more information [7-38](#)
- overview [7-4](#)
- report [7-38](#)
- routing
 - automated alternate [7-1](#)
 - closest-match [7-12](#)

S

- sample rate [23-61](#)
- schedule
 - CDR load configuration [25-7](#)
 - restoring the default CDR load [25-7](#)
- scheduling
 - daily reports [25-9](#)
 - monthly reports [25-11](#)
 - weekly reports [25-10](#)
- search
 - by authentication string [11-28](#)
 - by calling search space [11-27](#)
 - by call pickup group [11-28](#)
 - by description [11-27](#)
 - by device name [11-27](#)
 - by device pool [11-27](#)
 - by device protocol [11-28](#)
 - by device type [11-28](#)
 - by directory number [8-8, 11-27](#)
 - by LSC status [11-28](#)
 - by security profile [11-28](#)
 - CDR by cause for call termination [27-4](#)
 - CDR by gateway [27-3](#)
 - CDR by user extension [27-1](#)
 - CDR by user extension, report results [28-23](#)
 - CDRs [27-1](#)
 - for all directory numbers in the database [8-9](#)
 - for all phones in the database [11-28](#)
 - for directory numbers [8-8](#)
 - for phones [11-27](#)
 - within results [11-28](#)
- secure sockets layer (SSL)
 - installing [30-12](#)
- security
 - authentication overview [30-15](#)
 - authorization overview [30-15](#)
 - best practices [30-10](#)
 - certificate types [30-12](#)
 - configuration checklist for authentication and encryption (table) [30-22](#)
 - CTL client overview [31-2](#)
 - encryption overview [30-19](#)
 - external CAs [30-12](#)
 - features list [30-4](#)
 - features list (table) [30-5](#)
 - installing [30-12](#)
 - interactions [30-5](#)
 - rebooting the cluster [30-10](#)
 - rebooting the server [30-10](#)
 - resetting devices [30-10](#)
 - restarting Cisco Unified CallManager service [30-10](#)
 - restrictions [30-5, 30-6](#)
 - service
 - Cisco Certificate Authority Proxy Function (CAPF) [19-6](#)
 - Cisco CTL Provider [19-6](#)
 - system requirements [30-4](#)
 - terminology (table) [30-2](#)
 - tokens [31-2, 31-6, 31-8, 31-10, 31-16](#)
 - using barge with encryption [30-11](#)
 - where to find more information [30-25](#)
- security mode

- clusterwide
 - configuring [31-12](#)
 - verifying [31-15](#)
- restrictions
 - cluster and device modes [30-9](#)
- security profile
 - applying to phones [32-9](#)
 - configuration settings (table)
 - for SCCP phone [32-4](#)
 - for SIP phones [32-6](#)
 - configuration tips for phones [32-1](#)
 - configuring for phones [32-3](#)
 - deleting for phones [32-10](#)
 - finding for phones [32-2](#)
 - finding phones that use [32-11](#)
 - overview for phones [32-1](#)
 - search for phones [11-28](#)
- server, Cisco Unified CallManager
 - configuring [5-1](#)
- server, mail parameters [25-2](#)
- service
 - A Cisco DB [19-7](#)
 - A Cisco DB Replicator [19-7](#)
 - Cisco AMC Service [19-10](#)
 - Cisco Analyzer [19-4](#)
 - Cisco AXL Web Service [19-5](#)
 - Cisco Bulk Provisioning Service [19-5](#)
 - Cisco CallManager [19-2](#)
 - Cisco CallManager Admin [19-9](#)
 - Cisco CallManager Attendant Console Server [19-3](#)
 - Cisco CallManager Cisco IP Phone Services [19-3](#)
 - Cisco CallManager Personal Directory [19-9](#)
 - Cisco CallManager Serviceability [19-9](#)
 - Cisco CallManager Serviceability RTMT [19-10](#)
 - Cisco CAR Scheduler [19-5](#)
 - Cisco CAR Web Service [19-5](#)
 - Cisco CCM SNMP Service [19-6](#)
 - Cisco CDP [19-9](#)
 - Cisco CDP Agent [19-8](#)
 - Cisco CDR Agent [19-11](#)
 - Cisco Certificate Authority Proxy Function (CAPF) [19-6](#)
 - Cisco Certificate Expiry Monitor [19-8](#)
 - Cisco CTIManager [19-3](#)
 - Cisco CTL Provider [19-6](#)
 - Cisco Database Layer Monitor [19-8](#)
 - Cisco DHCP Monitor Service [19-4](#)
 - Cisco DirSync [19-7](#)
 - Cisco DRF Local [19-11](#)
 - Cisco DRF Master [19-11](#)
 - Cisco Electronic Notification [19-8](#)
 - Cisco Extended Functions [19-3](#)
 - Cisco Extension Mobility Application [19-10](#)
 - Cisco IP Manager Assistant [19-4](#)
 - Cisco IP Voice Media Streaming App [19-3](#)
 - Cisco License Manager [19-8](#)
 - Cisco Log Partition Monitoring Tool [19-9](#)
 - Cisco Messaging Interface [19-3](#)
 - Cisco RIS Data Collector [19-9](#)
 - Cisco RTMT Reporter Servlet [19-10](#)
 - Cisco Serviceability Reporter [19-5](#)
 - Cisco SOAP - CDRonDemand Service [19-4](#)
 - Cisco SOAP-Log Collection APIs [19-10](#)
 - Cisco SOAP Performance Monitoring APIs [19-10](#)
 - Cisco Syslog Agent [19-8](#)
 - Cisco TFTP [19-3](#)
 - Cisco Tomcat [19-7](#)
 - Cisco Tomcat Stats Servlet [19-10](#)
 - Cisco Trace Collection Service [19-9](#)
 - Cisco Trace Collection Servlet [19-9](#)
 - Cisco WebDialer Web Service [19-4](#)
 - configuration checklist (table) [19-13](#)
 - Control Center, described [19-12](#)
 - feature services [19-1](#)
 - Host Resources Agent [19-8](#)
 - MIB2 Agent [19-8](#)
 - Native Agent Adaptor [19-8](#)
 - network services [19-7](#)

- SNMP Master Agent [19-8](#)
- starting services, described [19-12](#)
- stopping services, described [19-12](#)
- viewing service status, described [19-12](#)
- service activation
 - activating [15-1](#)
 - deactivating [15-1](#)
 - multiserver recommendations (table) [15-2](#)
- service parameter
 - CFA Destination Override [8-6, 11-22](#)
- service parameters
 - Automated Alternate Routing Enable [7-3](#)
 - described [5-16](#)
 - Maximum Phone FallBack Queue Depth [11-30](#)
- services
 - activating [15-1](#)
 - deactivating [15-1](#)
 - monitoring [18-7](#)
 - starting [15-4](#)
 - stopping [15-4](#)
 - viewing status [15-4](#)
- service URL
 - described [11-26](#)
- settings
 - called party transformations
 - configuring [7-28](#)
 - explained (table) [7-28](#)
 - calling party transformations
 - explained (table) [7-27, 7-30](#)
 - configuring
 - checklist (table) [5-17](#)
 - described [5-1](#)
 - connected party transformations
 - explained (table) [7-32](#)
 - special characters [7-16](#)
- shared line appearance
 - active check box [8-5](#)
 - described [8-2](#)
 - restrictions [8-4](#)
 - update directory number of all devices sharing this line
 - check box [8-5](#)
- signaling authentication
 - overview [30-15](#)
- signaling encryption
 - overview [30-19](#)
- signaling protocols, gateway [10-9](#)
- Simple Network Management Protocol
 - service
 - Cisco CCM SNMP Service [19-6](#)
 - Cisco CDP Agent [19-8](#)
 - Host Resources Agent [19-8](#)
 - MIB2 Agent [19-8](#)
 - Network Agent Adaptor [19-8](#)
 - SNMP Master Agent [19-8](#)
- SIP
 - configuration differences [4-1](#)
 - configuring third-party devices [4-1](#)
 - third-party SIP phone configuration checklist
 - (table) [4-4](#)
 - third-party SIP phones and TFTP [4-2](#)
- SIP phone
 - NTP reference [5-4](#)
- SIP phones
 - enabling digest authentication
 - third-party phones [4-2](#)
 - See Cisco SIP IP Phones
- Site Administrator Security Token (SAST) [31-2](#)
- Skinny Client Control Protocol [10-3](#)
- Skinny Client Control Protocol (SCCP) Gateway Protocol [10-17](#)
- Skinny Gateway Protocol [10-16](#)
- SNMP
 - service
 - Cisco CCM SNMP Service [19-6](#)
 - Cisco CDP [19-9](#)
 - Cisco CDP Agent [19-8](#)
 - Host Resources Agent [19-8](#)
 - MIB2 Agent [19-8](#)
 - Network Agent Adaptor [19-8](#)

- SNMP Master Agent [19-8](#)
- SNMP Master Agent service [19-8](#)
- SOAP
 - service
 - Cisco SOAP - CDRonDemand Service [19-4](#)
 - Cisco SOAP-Log Collection APIs [19-10](#)
 - Cisco SOAP Performance Monitoring APIs [19-10](#)
- SOAP over HTTP Interface [37-9](#)
- softkey templates
 - call states described (table) [11-18](#)
 - layout (figure) [11-19](#)
 - operation [11-19](#)
- softphone [11-9](#)
- special characters
 - configuring [7-16](#)
 - described (table) [7-17](#)
 - explained [7-16](#)
- speed dial
 - described [11-26](#)
- static digit analysis
 - caveats [7-15](#)
 - configuration tip [7-14](#)
 - described [7-14](#)
 - example prior to static digit analysis [7-15](#)
 - explained [7-14](#)
 - Unified CallManager Assistant example with static digit analysis [7-16](#)
- summary
 - department bill, report results [28-2](#)
 - gateway, report results [28-19](#)
 - individual bill, report results [28-2](#)
 - QoS, report results [28-11](#)
 - traffic, report results [28-12](#)
 - traffic by extensions, report results [28-12](#)
- System
 - perfmon object and counters [23-58](#)
- system, CAR [24-6](#)
- system-level configuration settings [5-1](#)
- system log screens

- CAR [25-15](#)
- system overview, report results [28-16](#)
- system parameters, configuration [25-1](#)
- system preferences
 - configuration [25-6](#)
- system preferences parameters for CAR [25-6](#)
- system reports, CAR [24-8](#)

T

- T1 Primary Rate Interface (PRI) [10-1](#)
- table, CDR and CMR dump [28-25](#)
- Target Audience for this Chapter [36-2](#)
- TCP
 - perfmon object and counters [23-58](#)
- templates, phone button
 - 12 series, default [11-14](#)
 - 30 SP+, default [11-13](#)
 - 30 VIP, default [11-13](#)
 - 7902, default [11-13](#)
 - 7905 SCCP, default [11-13](#)
 - 7905 SIP, default [11-13](#)
 - 7906 SCCP, default [11-13](#)
 - 7906 SIP, default [11-13](#)
 - 7910, default [11-13](#)
 - 7911 SCCP, default [11-12](#)
 - 7911 SIP, default [11-13](#)
 - 7912 SCCP, default [11-12](#)
 - 7912 SIP, default [11-12](#)
 - 7920, default [11-12](#)
 - 7940 SCCP, default [11-12](#)
 - 7940 SIP, default [11-12](#)
 - 7941 G-GE SCCP, default [11-12](#)
 - 7941 SCCP, default [11-12](#)
 - 7941 SIP, default [11-12](#)
 - 7960 SCCP, default [11-12](#)
 - 7960 SIP, default [11-12](#)
 - 7961 G-GE SCCP, default [11-11](#)
 - 7961 SCCP, default [11-11](#)

- 7961 SIP, default [11-11](#)
- 7970 SCCP, default [11-11](#)
- 7970 SIP, default [11-11](#)
- 7971 SCCP, default [11-11](#)
- 7971 SIP, default [11-11](#)
- 7985, default [11-11](#)
- analog phone, default [11-14](#)
- ATA 186, default [11-14](#)
- Cisco IP Communicator, default [11-14](#)
- Cisco TelePresence, default [11-14](#)
- CN622, default [11-14](#)
- conference station 7935, default [11-13](#)
- conference station 7936, default [11-13](#)
- default [11-10](#)
- described [11-10](#)
- guidelines [11-14](#)
- IP-STE, default [11-14](#)
- ISDN BRI phone, default [11-14](#)
- listed by model (table) [11-11](#)
- third-party SIP device, default [11-14](#)
- VGC phone, default [11-14](#)
- VGC Virtual, default [11-14](#)
- templates, softkey
 - add application [11-17](#)
 - configure softkey layout [11-18](#)
 - described [11-16](#)
 - layout (figure) [11-19](#)
 - operation [11-19](#)
- TFTP [6-9](#)
 - alternate Cisco file server fields [6-8](#)
 - alternate Cisco file servers [6-8](#)
 - centralized TFTP [6-9, 6-10](#)
 - configuration checklist (table) [6-11](#)
 - configuration tips
 - alternate Cisco file server fields [6-10](#)
 - configuring a redundant or load-sharing TFTP server [6-8](#)
 - customizing files [6-10](#)
 - list of topics [6-1](#)
 - master TFTP server [6-9](#)
 - more information [6-11](#)
 - multiple cluster environment [6-9](#)
 - overview [6-1](#)
 - process overview for Cisco SIP IP phones [6-2](#)
 - process overview for SCCP devices [6-2](#)
 - server
 - accessing [6-6](#)
 - identifying [6-6](#)
 - third-party SIP phones [4-2](#)
 - understanding [6-4](#)
- TFTP services [31-2](#)
- Thread
 - perfmon object and counters [23-59](#)
- Throttling Requests [36-12](#)
- time of day [26-3](#)
- time zones [5-4](#)
- TLS Proxy server [31-2](#)
- Tomcat JVM
 - perfmon object and counters [23-45](#)
- Tomcat Web Application
 - perfmon object and counters [23-46](#)
- top N
 - by charge, report results [28-4](#)
 - by duration, report results [28-4](#)
 - by number of calls, report results [28-5](#)
- top N by charge, report results [28-4](#)
- top N by duration, report results [28-4](#)
- top N by number of calls, report results [28-5](#)
- Trace
 - configuration
 - described [21-2](#)
 - configuration and collection checklist [21-4](#)
 - list of topics [21-1](#)
 - overview [21-1](#)
 - trace and log central
 - described [21-3](#)
 - troubleshooting trace setting
 - described [21-2](#)

traffic summary, report results [28-12](#)
 traffic summary by extensions, report results [28-12](#)
 transfer
 described [8-7](#)
 on-hook [11-24](#)
 transfer hold, example with MOH [12-5](#)
 transformations
 called party [7-26](#)
 calling party [7-26](#)
 translation patterns
 and called party transformations settings [7-28](#)
 and calling party presentation and restriction settings [7-29](#)
 and calling party presentation settings (table) [7-30](#)
 and connected party presentation and restriction settings [7-31](#)
 and connected party presentation settings (table) [7-32](#)
 and route plan report [7-38](#)
 use for failover [7-14](#)
 transport layer security (TLS) [30-12](#)
 port [31-5](#)
 transport security
 and real-time protocol (RTP) [30-12](#)
 and secure real-time protocol (SRTP) [30-12](#)
 configuration settings (table)
 for SCCP phone [32-4](#)
 for SIP phone [32-6](#)
 configuring for SIP phones [32-3](#)
 IPSec [30-12](#)
 TLS [30-12](#)
 Trivial File Transfer Protocol (TFTP) [6-1](#)
 troubleshooting
 deleting CTL file on phone [31-16](#)
 Troubleshooting Trace Setting
 configuration [17-1](#)
 trunk interfaces
 E1 PRI [10-1](#)
 FXO [10-1](#)
 FXS [10-1](#)

QSIG [10-1](#)
 T1 CAS [10-1](#)
 T1 PRI [10-1](#)

U

unicast
 audio sources for MOH [12-10](#)
 explained [12-10](#)
 uninhibited loading of CDR values [25-8](#)
 user
 configure phone features [11-29](#)
 user hold, example with MOH [12-5](#)
 user options
 Cisco Unified CallManager User Options [11-29](#)
 user reports, CAR [24-7](#)
 users
 Cisco Unified CallManager Attendant Console
 configuring [14-18](#)
 understanding [14-2](#)
 users, CAR [24-5](#)
 using [25-12](#)
 utilization
 conference bridge, report results [28-22](#)
 gateway, report results [28-21](#)
 route group, report results [28-21](#)
 route list, report results [28-21](#)
 voice mail, report results [28-23](#)

V

video phones
 Cisco Unified IP Phone 7985 [11-6](#)
 voice codecs
 bandwidth used per call (table) [5-8](#)
 G.711 [5-7](#)
 G.723 [5-7](#)
 G.729 [5-7](#)

- GSM [5-7](#)
 - supported by Cisco Unified CallManager [5-7](#)
 - wideband [5-7](#)
- voice gateways
 - See* gateways
- voice mail
 - configuring messages button [11-28](#)
- voice mail utilization, report results [28-23](#)
- voice quality [26-4](#)

W

- WebDialer
 - Servlet [37-2](#)
 - Single Cluster Applications [37-19](#)
 - SIP Support [37-6](#)
 - Support for Enhancements in CTI and JTAPI [37-4](#)
 - Using the Redirector Servlet [37-3](#)
 - WSDL [37-16](#)
- weekly reports
 - scheduling [25-10](#)
- wideband [5-7](#)
- wildcards
 - described (table) [7-17](#)
 - for hunt pilots [7-16](#)
 - for route patterns [7-16](#)
 - using @ in route patterns [7-13](#)

Z

- zooming a counter [23-61](#)

