



A

A Cisco DB service [2-7](#)

Alarms

configuration checklist [3-3](#)

configuration overview [3-2](#)

definitions

described [3-2](#)

described [3-1](#)

overview [3-1](#)

viewing information

overview [3-2](#)

alerts

action configuration (table) [7-5](#)

customization (table) [7-3](#)

emailing notification [6-66](#)

logs, described [7-6](#)

notification for a counter [6-66](#)

preconfigured [7-2](#)

scheduling notification [6-66](#)

thresholds [6-66](#)

B

backup

service

Cisco DRF Local [2-11](#)

Cisco DRF Master [2-6](#)

C

category tabs [6-65](#)

sample rates [6-65](#)

CDR

service

Cisco CAR Scheduler [2-4](#)

Cisco CAR Web Service [2-4](#)

Cisco CDR Agent [2-11](#)

Cisco AMC Service [2-9](#)

Cisco Analog Access

perfmon object and counters [6-3](#)

Cisco Analyzer service [2-3](#)

Cisco Annunciator Device

perfmon object and counters [6-4](#)

Cisco AXL Web Service [2-5](#)

Cisco Bulk Provisioning Service [2-5](#)

Cisco CallManager

perfmon object and counters [6-4](#)

Cisco CallManager Admin service [2-8](#)

Cisco CallManager Attendant Console

perfmon object and counters [6-12](#)

Cisco CallManager Attendant Console Server service [2-3](#)

Cisco CallManager Personal Directory service [2-9](#)

Cisco CallManager Serviceability service [2-9](#)

Cisco CallManager System Performance

perfmon object and counters [6-13](#)

Cisco CAR Scheduler service [2-4](#)

Cisco CAR Web Service [2-4](#)

Cisco CDP Agent service [2-8](#)

Cisco CDP service [2-9](#)

Cisco CDR Agent service [2-11](#)

Cisco Certificate Authority Proxy Function (CAPF)
service [2-6](#)

Cisco Certificate Expiry Monitor service [2-8](#)

Cisco CTIManager

perfmon object and counters [6-16](#)

- Cisco CTL Provider service [2-6](#)
- Cisco Database Layer Monitor service [2-8](#)
- Cisco DB service [2-7](#)
- Cisco DHCP Monitor service [2-4](#)
- Cisco Dual-Mode Mobility perfmon object and counters [6-17](#)
- Cisco Electronic Notification service [2-8](#)
- Cisco Extended Functions service [2-3](#)
- Cisco Extension Mobility
 - perfmon object and counters [6-18](#)
- Cisco Extension Mobility Application [2-10](#)
- Cisco Gatekeeper
 - perfmon object and counters [6-19](#)
- Cisco H.323
 - perfmon object and counters [6-19](#)
- Cisco Hunt Lists
 - perfmon object and counters [6-20](#)
- Cisco HW Conference Bridge Device
 - perfmon object and counters [6-21](#)
- Cisco IP Manager Assistant
 - perfmon object and counters [6-22](#)
- Cisco IP Voice Media Streaming App service [2-3](#)
- Cisco License Manager service [2-8](#)
- Cisco Lines
 - perfmon object and counters [6-22](#)
- Cisco Locations
 - perfmon object and counters [6-23](#)
- Cisco Log Partition Monitoring Tool service [2-9](#)
- Cisco Media Streaming Application
 - perfmon object and counters [6-24](#)
- Cisco Messaging Interface
 - perfmon object and counters [6-27](#)
- Cisco Messaging Interface service [2-3](#)
- Cisco MGCP FXO Device
 - perfmon object and counters [6-28](#)
- Cisco MGCP FXS Device
 - perfmon object and counters [6-28](#)
- Cisco MGCP Gateways
 - perfmon object and counters [6-29](#)
- Cisco MGCP Gateways [6-29](#)
- Cisco MGCP PRI Device
 - perfmon object and counters [6-29](#)
- Cisco MGCP T1CAS Device
 - perfmon object and counters [6-30](#)
- Cisco MOH Device
 - perfmon object and counters [6-31](#)
- Cisco MTP Device
 - perfmon object and counters [6-32](#)
- Cisco Phones
 - perfmon object and counters [6-33](#)
- Cisco Presence Feature
 - perfmon object and counters [6-33](#)
- Cisco QSIG Features
 - perfmon object and counters [6-34](#)
- Cisco RIS Data Collector service [2-9](#)
- Cisco RTMT Reporter Servlet [2-10](#)
- Cisco Serviceability Reporter service [2-5](#)
- Cisco SIP
 - perfmon object and counters [6-34](#)
- Cisco SIP Stack
 - perfmon object and counters [6-35](#)
- Cisco SOAP-Log-Collection APIs [2-10](#)
- Cisco SOAP Performance Monitoring APIs service [2-10](#)
- Cisco SW Conf Bridge Device
 - perfmon object and counters [6-43](#)
- Cisco Syslog Agent service [2-8](#)
- Cisco TFTP Server
 - perfmon object and counters [6-44](#)
- Cisco TFTP service [2-2](#)
- Cisco Tomcat Connector
 - perfmon object and counters [6-48](#)
- Cisco Tomcat service [2-7](#)
- Cisco Tomcat Stats Servlet [2-10](#)
- Cisco Trace Collection Service [2-9](#)
- Cisco Trace Collection Servlet [2-9](#)
- Cisco Transcode Device
 - perfmon object and counters [6-52](#)
- Cisco Unified CallManager

- service
 - Cisco Analyzer [2-3](#)
 - Cisco CallManager [2-2](#)
 - Cisco CallManager Admin [2-8](#)
 - Cisco CallManager Attendant Console Server [2-3](#)
 - Cisco CallManager Personal Directory [2-9](#)
 - Cisco CallManager Serviceability [2-9](#)
 - Cisco CDP [2-9](#)
 - Cisco CTIManager [2-3](#)
 - Cisco DHCP Monitor Service [2-4](#)
 - Cisco Extended Functions [2-3](#)
 - Cisco Extension Mobility Application [2-10](#)
 - Cisco IP Voice Media Streaming App [2-3](#)
 - Cisco Log Partition Monitoring Tool [2-9](#)
 - Cisco Messaging Interface [2-3](#)
 - Cisco TFTP [2-2](#)
 - Cisco Tomcat Stats Servlet [2-10](#)
 - Cisco Trace Collection Service [2-9](#)
 - Cisco Trace Collection Servlet [2-9](#)
- Cisco Unified CallManager Cisco IP Phone Services [2-3](#)
- Cisco Video Conference Bridge
 - perfmon object and counters [6-52](#)
- Cisco WebDialer
 - perfmon object and counters [6-53](#)
- Cisco WSM Connector
 - perfmon object and counters [6-54](#)
- Control Center
 - described [2-11](#)
 - feature services [2-11](#)
 - network services [2-11](#)
 - starting services, described [2-11](#)
 - stopping services, described [2-11](#)
 - viewing service status, described [2-11](#)
- conventions [xi](#)
- counters
 - adding [6-66](#)
 - alert notification [6-66](#)
 - chart [6-66](#)
 - perfmon, described [6-1](#)

- properties [6-66](#)
- zooming [6-66](#)

CTI

- Cisco CTIManager
 - perfmon object and counters [6-16](#)
- Cisco CTIManager service [2-3](#)
- service
 - Cisco Unified CallManager Assistant Service [2-4](#)
 - Cisco WebDialer Web Service [2-4](#)

D

- database
 - service
 - A Cisco DB [2-7](#)
 - Cisco AXL Web Service [2-5](#)
 - Cisco Bulk Provisioning Service [2-5](#)
 - Cisco Database Layer Monitor [2-8](#)
- Database Change Notification Client
 - perfmon object and counters [6-54](#)
- Database Change Notification Server
 - perfmon object and counters [6-55](#)
- Database Change Notification Subscription
 - perfmon object and counters [6-55](#)
- Database Layer Monitor
 - perfmon object and counters [6-55](#)
- Database Local DSN
 - perfmon object and counters [6-56](#)
- DB User Host Information Counters
 - perfmon object and counters [6-56](#)
- definitions
 - alarms [3-2](#)
- directory
 - Cisco DirSync service [2-6](#)
- document
 - audience [x](#)
 - conventions [xi](#)
 - organization [x](#)
 - purpose [ix](#)

documentation

related [xi](#)

E

e [2-3](#)

Enterprise Replication DBSpace Monitors

perfmon object and counters [6-56](#)

Enterprise Replication Perfmon Counters

perfmon object and counters [6-56](#)

F

feature services

activating [2-1](#)

configuration checklist (table) [2-12](#)

described [2-1](#)

starting [2-1](#)

stopping [2-1](#)

viewing status [2-1](#)

H

Host Resources Agent service [2-7](#)

I

informs

Cisco Unified CallManager parameters (table) [11-5](#)

SNMP [11-4](#)

IP

perfmon object and counters [6-57](#)

L

Log Partition Monitoring

described [8-1](#)

service [2-9](#)

logs

alerts [7-6](#)

perfmon [6-67](#)

M

Management Information Base

CISCO-CCM-MIB [11-8](#)

Cisco-CDP-MIB [11-6](#)

CISCO-SYSLOG-MIB [11-7](#)

HOST-RESOURCES MIB [11-7](#)

HP MIB [11-8](#)

IBM MIB [11-8](#)

MIB-II [11-7](#)

SYSAPPL-MIB [11-7](#)

Management Information Base (MIB) [11-6](#)

Memory

perfmon object and counters [6-58](#)

MIB

CISCO-CCM-MIB [11-8](#)

Cisco-CDP-MIB [11-6](#)

CISCO-SYSLOG-MIB [11-7](#)

described [11-6](#)

HOST-RESOURCES MIB [11-7](#)

HP MIB [11-8](#)

IBM MIB [11-8](#)

MIB-II [11-7](#)

SYSAPPL-MIB [11-7](#)

MIB2 Agent service [2-7](#)

monitoring

performance [6-66](#)

N

Network Agent Adaptor service [2-7](#)

Network Interface

perfmon object and counters [6-59](#)

network services

- Control Center [2-7](#)
- described [2-7](#)
- starting [2-7](#)
- stopping [2-7](#)
- viewing status [2-7](#)
- Number of Replicates
 - perfmon object and counters [6-60](#)

O

- o [6-63](#)
- object
 - perfmon, described [6-1](#)
- object and counters
 - Database Change Notification Client [6-54](#)
- organization [x](#)
- overview
 - browser support [1-3](#)
 - remote serviceability [1-2](#)
 - serviceability [1-1](#)

P

- Partition
 - perfmon object and counters [6-60](#)
- perfmon
 - counters
 - adding [6-66](#)
 - category tabs, described [6-65](#)
 - chart [6-66](#)
 - properties [6-66](#)
 - sample rates [6-65](#)
 - zooming [6-66](#)
 - logs [6-67](#)
 - object and counters
 - Cisco Analog Access [6-3](#)
 - Cisco Annunciator Device [6-4](#)
 - Cisco CallManager [6-4](#)

- Cisco CallManager Attendant Console [6-12](#)
- Cisco CallManager System Performance [6-13](#)
- Cisco CTIManager [6-16](#)
- Cisco Dual-Mode Mobility [6-17](#)
- Cisco Extension Mobility [6-18](#)
- Cisco Gatekeeper [6-19](#)
- Cisco H.323 [6-19](#)
- Cisco Hunt Lists [6-20](#)
- Cisco HW Conference Bridge Device [6-21](#)
- Cisco IP Manager Assistant [6-22](#)
- Cisco Lines [6-22](#)
- Cisco Locations [6-23](#)
- Cisco Media Streaming Application [6-24](#)
- Cisco Messaging Interface [6-27](#)
- Cisco MGCP FXO Device [6-28](#)
- Cisco MGCP FXS Device [6-28](#)
- Cisco MGCP Gateways [6-29](#)
- Cisco MGCP PRI Device [6-29](#)
- Cisco MGCP T1CAS Device [6-30](#)
- Cisco MOH Device [6-31](#)
- Cisco MTP Device [6-32](#)
- Cisco Phones [6-33](#)
- Cisco Presence Feature [6-33](#)
- Cisco QSIG Feature [6-34](#)
- Cisco SIP [6-34](#)
- Cisco SIP Stack [6-35](#)
- Cisco SW Conf Bridge Device [6-43](#)
- Cisco TFTP Server [6-44](#)
- Cisco Tomcat Connector [6-48](#)
- Cisco Transcode Device [6-52](#)
- Cisco Video Conference Bridge [6-52](#)
- Cisco WebDialer [6-53](#)
- Cisco WSM Connector [6-54](#)
- Database Change Notification Server [6-55](#)
- Database Change Notification Subscription [6-55](#)
- Database Layer Monitor [6-55](#)
- Database Local DSN [6-56](#)
- DB User Host Information [6-56](#)
- described [6-1](#)

- Enterprise Replication [6-56](#)
- Enterprise Replication DBSpace Monitors [6-56](#)
- IP [6-57](#)
- Memory [6-58](#)
- Network Interface [6-59](#)
- Partition [6-60](#)
- Process [6-61](#)
- Processor [6-62](#)
- System [6-63](#)
- TCP [6-63](#)
- Thread [6-64](#)
- Tomcat JVM [6-50](#)
- Tomcat Web Application [6-51](#)
- performance monitoring
 - category tabs, described [6-65](#)
 - counters
 - adding [6-66](#)
 - chart [6-66](#)
 - properties [6-66](#)
 - zooming [6-66](#)
- Number of Replicates [6-60](#)
- object and counters
 - Cisco Analog Access [6-3](#)
 - Cisco Annunciator Device [6-4](#)
 - Cisco CallManager [6-4](#)
 - Cisco CallManager Attendant Console [6-12](#)
 - Cisco CallManager System Performance [6-13](#)
 - Cisco CTIManager [6-16](#)
 - Cisco Dual-Mode Mobility [6-17](#)
 - Cisco Extension Mobility [6-18](#)
 - Cisco Gatekeeper [6-19](#)
 - Cisco H.323 [6-19](#)
 - Cisco Hunt Lists [6-20](#)
 - Cisco HW Conference Bridge Device [6-21](#)
 - Cisco IP Manager Assistant [6-22](#)
 - Cisco Lines [6-22](#)
 - Cisco Locations [6-23](#)
 - Cisco Media Streaming Application [6-24](#)
 - Cisco Messaging Interface [6-27](#)
 - Cisco MGCP FXO Device [6-28](#)
 - Cisco MGCP FXS Device [6-28](#)
 - Cisco MGCP Gateways [6-29](#)
 - Cisco MGCP PRI Device [6-29](#)
 - Cisco MGCP T1CAS Device [6-30](#)
 - Cisco MOH Device [6-31](#)
 - Cisco MTP Device [6-32](#)
 - Cisco Phones [6-33](#)
 - Cisco Presence Feature [6-33](#)
 - Cisco QSIG Feature [6-34](#)
 - Cisco SIP [6-34](#)
 - Cisco SIP Stack [6-35](#)
 - Cisco SW Conf Bridge Device [6-43](#)
 - Cisco TFTP Server [6-44](#)
 - Cisco Tomcat Connector [6-48](#)
 - Cisco Transcode Device [6-52](#)
 - Cisco Video Conference Bridge [6-52](#)
 - Cisco WebDialer [6-53](#)
 - Cisco WSM Connector [6-54](#)
 - Database Change Notification Server [6-55](#)
 - Database Change Notification Subscription [6-55](#)
 - Database Layer Monitor [6-55](#)
 - Database Local DSN [6-56](#)
 - DB User Host Information [6-56](#)
 - described [6-1](#)
 - Enterprise Replication [6-56](#)
 - Enterprise Replication DBSpace Monitors [6-56](#)
 - IP [6-57](#)
 - Memory [6-58](#)
 - Network Interface [6-59](#)
 - Number of Replicates [6-60](#)
 - Partition [6-60](#)
 - Process [6-61](#)
 - Processor [6-62](#)
 - System [6-63](#)
 - Thread [6-64](#)
 - Tomcat JVM [6-50](#)
 - Tomcat Web Application [6-51](#)
 - sample rates [6-65](#)

- service
 - Cisco AMC Service [2-9](#)
 - Cisco CCM SNMP Service [2-5](#)
 - Cisco Extended Functions [2-3](#)
 - Cisco RIS Data Collector [2-9](#)
 - Cisco RTMT Reporter Servlet [2-10](#)
 - Cisco Serviceability Reporter [2-5](#)
 - Cisco Unified CallManager Cisco IP Phone Services [2-3](#)
 - Cisco Unified CallManager Serviceability RTMT [2-10](#)
- platform services
 - Cisco CDP Agent [2-8](#)
 - Cisco Certificate Expiry Monitor Service [2-8](#)
 - Cisco DB [2-7](#)
 - Cisco Electronic Notification [2-8](#)
 - Cisco License Manager [2-8](#)
 - Cisco Syslog Agent [2-8](#)
 - Cisco Tomcat [2-7](#)
 - Host Resources Agent [2-7](#)
 - MIB2 Agent [2-7](#)
 - Network Agent Adaptor [2-7](#)
 - SNMP Master Agent [2-7](#)
- polling intervals
 - sample rate [6-65](#)
- Process
 - perfmon object and counters [6-61](#)
- Processor
 - perfmon object and counters [6-62](#)
- alert summary report [10-13](#)
- call activities report [10-9](#)
- category tabs, described [6-65](#)
- counters
 - adding [6-66](#)
 - alert notification [6-66](#)
 - chart [6-66](#)
 - monitor [6-66](#)
- device statistics report [10-2](#)
- list of topics [5-1](#)
- logging and report generation
 - call log [5-8](#)
 - device log [5-12](#)
 - server log [5-7](#)
 - service log [5-10](#)
- overview [5-1](#)
- performance protection report [10-15](#)
- polling interval [6-65](#)
- sample rate [6-65](#)
- server statistics report [10-5](#)
- service
 - Cisco AMC Service [2-9](#)
 - Cisco RTMT Reporter Servlet [2-10](#)
 - Cisco Syslog Agent [2-8](#)
 - Cisco Unified CallManager Serviceability RTMT [2-10](#)
- serviceability reports archive [10-2](#)
- service statistics report [10-7](#)
- view tab
 - summary [5-5](#)
- window components [5-3](#)
- zooming a counter [6-66](#)
- related documentation [xi](#)
- remote serviceability [1-2](#)
- reporting tools [1-2](#)
- reports
 - perfmon logs [6-67](#)
- restore
 - service

R

Real-Time Monitoring Tool

- alerts
 - action configuration (table) [7-5](#)
 - customization (table) [7-3](#)
 - logs, described [7-6](#)
 - notification for a counter [6-66](#)
 - preconfigured [7-2](#)

Cisco DRF Local [2-11](#)
 Cisco DRF Master [2-6](#)

S

sample rate [6-65](#)

security

service

Cisco Certificate Authority Proxy Function (CAPF) [2-6](#)

Cisco CTL Provider [2-6](#)

service

A Cisco DB [2-7](#)

Cisco AMC Service [2-9](#)

Cisco Analyzer [2-3](#)

Cisco AXL Web Service [2-5](#)

Cisco Bulk Provisioning Service [2-5](#)

Cisco CallManager [2-2](#)

Cisco CallManager Admin [2-8](#)

Cisco CallManager Attendant Console Server [2-3](#)

Cisco CallManager Personal Directory [2-9](#)

Cisco CallManager Serviceability [2-9](#)

Cisco CAR Scheduler [2-4](#)

Cisco CAR Web Service [2-4](#)

Cisco CCM SNMP Service [2-5](#)

Cisco CDP [2-9](#)

Cisco CDP Agent [2-8](#)

Cisco CDR Agent [2-11](#)

Cisco Certificate Authority Proxy Function (CAPF) [2-6](#)

Cisco Certificate Expiry Monitor [2-8](#)

Cisco CTIManager [2-3](#)

Cisco CTL Provider [2-6](#)

Cisco Database Layer Monitor [2-8](#)

Cisco DHCP Monitor Service [2-4](#)

Cisco DirSync [2-6](#)

Cisco DRF Local [2-11](#)

Cisco DRF Master [2-6](#)

Cisco Electronic Notification [2-8](#)

Cisco Extended Functions [2-3](#)

Cisco Extension Mobility Application [2-10](#)

Cisco IP Voice Media Streaming App [2-3](#)

Cisco License Manager [2-8](#)

Cisco Log Partition Monitoring Tool [2-9](#)

Cisco Messaging Interface [2-3](#)

Cisco RIS Data Collector [2-9](#)

Cisco RTMT Reporter Servlet [2-10](#)

Cisco Serviceability Reporter [2-5](#)

Cisco SOAP-Log Collection APIs [2-10](#)

Cisco SOAP Performance Monitoring APIs [2-10](#)

Cisco Syslog Agent [2-8](#)

Cisco TFTP [2-2](#)

Cisco Tomcat [2-7](#)

Cisco Tomcat Stats Servlet [2-10](#)

Cisco Trace Collection Service [2-9](#)

Cisco Trace Collection Servlet [2-9](#)

Cisco Unified CallManager Assistant [2-4](#)

Cisco Unified CallManager Cisco IP Phone Services [2-3](#)

Cisco Unified CallManager Serviceability RTMT [2-10](#)

Cisco WebDialer Web Service [2-4](#)

configuration checklist (table) [2-12](#)

Control Center, described [2-11](#)

feature services [2-1](#)

Host Resources Agent [2-7](#)

MIB2 Agent [2-7](#)

Native Agent Adaptor [2-7](#)

network services [2-7](#)

SNMP Master Agent [2-7](#)

starting services, described [2-11](#)

stopping services, described [2-11](#)

viewing service status, described [2-11](#)

serviceability

browser support [1-3](#)

introduction [1-1](#)

overview [1-1](#)

remote [1-2](#)

reporting tools [1-2](#)

Serviceability Reports Archive

- described [10-1](#)
- service parameters [10-2](#)
- Simple Network Management Protocol
 - basics [11-2](#)
 - community strings, described [11-4](#)
 - configuration checklist (table) [11-9](#)
 - described [11-1](#)
 - inform parameters (table) [11-5](#)
 - informs [11-4](#)
 - MIB [11-6](#)
 - service
 - Cisco CCM SNMP Service [2-5](#)
 - Cisco CDP Agent [2-8](#)
 - Host Resources Agent [2-7](#)
 - MIB2 Agent [2-7](#)
 - Network Agent Adaptor [2-7](#)
 - SNMP Master Agent [2-7](#)
 - SNMPv1 [11-3](#)
 - SNMPv2c [11-3](#)
 - SNMPv3 [11-3](#)
 - trace configuration [11-9](#)
 - traps [11-4](#)
 - troubleshooting [11-10](#)
 - users, described [11-4](#)
- SNMP
 - basics [11-2](#)
 - community strings, described [11-4](#)
 - configuration checklist (table) [11-9](#)
 - described [11-1](#)
 - inform parameters (table) [11-5](#)
 - informs [11-4](#)
 - MIB [11-6](#)
 - remote monitoring with [11-1](#)
 - service
 - Cisco CCM SNMP Service [2-5](#)
 - Cisco CDP [2-9](#)
 - Cisco CDP Agent [2-8](#)
 - Host Resources Agent [2-7](#)
 - MIB2 Agent [2-7](#)

- Network Agent Adaptor [2-7](#)
- SNMP Master Agent [2-7](#)
- SNMPv1 [11-3](#)
- SNMPv2c [11-3](#)
- SNMPv3 [11-3](#)
- trace configuration [11-9](#)
- trap parameters (table) [11-5](#)
- traps [11-4](#)
- troubleshooting [11-10](#)
- users, described [11-4](#)
- SNMP Master Agent service [2-7](#)
- SOAP
 - service
 - Cisco SOAP-Log Collection APIs [2-10](#)
 - Cisco SOAP Performance Monitoring APIs [2-10](#)
- System
 - perfmon object and counters [6-63](#)

T

- TCP
 - perfmon object and counters [6-63](#)
- Thread
 - perfmon object and counters [6-64](#)
- Tomcat JVM
 - perfmon object and counters [6-50](#)
- Tomcat Web Application
 - perfmon object and counters [6-51](#)
- Trace
 - configuration
 - described [4-2](#)
 - configuration and collection checklist [4-4](#)
 - list of topics [4-1](#)
 - overview [4-1](#)
 - trace and log central
 - described [4-3](#)
 - troubleshooting trace setting
 - described [4-2](#)
- traps

trap configuration parameters (table) [11-5](#)
traps, SNMP [11-4](#)

Z

zooming a counter [6-66](#)